

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
(L)513CUF/EA()		UNIT, ALTITUDE ALERTING	SMITHS
*0728 KTD/1		INDICATOR, PERCENT TACHOMETER	SMITHS
*727MV/BU()		INDICATOR, MILLIVOLTMETER TEMPERATURE	SMITHS
*762MV/BM/31/810		INDICATOR, MILLIVOLTMETER TEMPERATURE	SMITHS
*762MV/BU()		INDICATOR, MILLIVOLTMETER TEMPERATURE	SMITHS
*1301 KTS/FA()		INDICATOR, TURN & SLIP	SMITHS
*762MV-BU()-900		INDICATOR, MILLIVOLTMETER TEMPERATURE	SMITHS
001815	ELP-362D	BATTERY, NON-RESTRICTIVE	BENTHOS
006-5236-01	RS 841A	SENSOR, RADAR	BENDIX
006-5237-01	IN 842A	INDICATOR, COLOR RADAR	BENDIX
01-003-1/01-004-1	35 & 36	INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
01-0770285	70285	STROBE LIGHT ASSEMBLY	WHELEN
01-0770905-01	7090501	LED ANTI COLLISION LIGHT ASSEMBLY	WHELEN
01-0770946-()	70946 SERIES	LED ANTI COLLISION LIGHT ASSEMBLY	WHELEN
01-0770946-01		LED ANTI COLLISION LIGHT ASSEMBLY	WHELEN
01-0790102-00		STROBE, WINGTIP LIGHT	WHELEN
01-0790104-00		STROBE, TAIL LIGHT	WHELEN
01-200-10()	01-200-10()	ALTIMETER, ENCODING	SMITHS
01-200-10()	01-200-10()	ALTIMETER, ENCODING	SMITHS
01-200-10X	01-200-10X	ALTIMETER, ENCODING	SMITHS
01-200-10X		INDICATOR, ALTIMETER	SMITHS
014-901-001		UNIT, TANK	GULL
014-901-008		UNIT, TANK	GULL
014-901-010		UNIT, TANK	GULL
014-901-012		UNIT, TANK	GULL
014-901-016		UNIT, TANK	GULL
014-901-017		UNIT, TANK	GULL
0204KID-0()		INDICATOR, FUEL QUANTITY	SMITHS
0205KID-0()		INDICATOR, FUEL QUANTITY	SMITHS
0206KID0()		INDICATOR, FUEL QUANTITY	SMITHS
020-901-001		UNIT, TANK	GULL
020-904-002		UNIT, TANK	GULL
024054-000	257CH-9	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
024055-000	427CK-1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
024147-000	539CH1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
024904-000	43BO34LB03	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
027-003-()		UNIT, TANK	GULL
027-003-000		TRANSMITTER, QUANTITY - FUEL	GULL
027-003-001		TRANSMITTER, QUANTITY - FUEL	GULL
027-003-002		TRANSMITTER, QUANTITY - FUEL	GULL
027-003-003		TRANSMITTER, QUANTITY - FUEL	GULL
027-003-004		TRANSMITTER, QUANTITY - FUEL	GULL
027-003-005		TRANSMITTER, FUEL QUANTITY	GULL
028-025-001		TRANSMITTER, FUEL QUANTITY	GULL
028-025-001		UNIT, FUEL QUANTITY TANK	GULL
02XX-KSB/()		DETECTOR, STALL	SMITHS
03-017393-()-()		UNIT, FIRE DETECTOR	FENWAL
04-1504-1429	ACL-1000	POWER SUPPLY, STROBE - ANTI-COLLISION	FLIGHT COMPONENTS AG
050-03011-XXXX	CNI5000	PACKAGE, INTEGRATED RADIO MOUNTING	HONEYWELL
05-01-100()	RSS-147	TRANSMITTER, EMERGENCY LOCATOR	DEFT
060-00015-XXXX	KG102A	GYRO, DIRECTIONAL	HONEYWELL
060-0013-XXXX	KSG105	GYRO, SLAVED DIRECTIONAL	HONEYWELL
064-01051-XXXX	KY97A	TRANSCEIVER, COMMUNICATIONS	HONEYWELL
064-01076-0101	KTR909B	TRANSCEIVER, UHF COMMUNICATIONS	HONEYWELL
064-1023-XXXX	KTR908	TRANSCEIVER, VHF COMM	HONEYWELL
065-000178-XXXX	KS270C	SYSTEM, SERVO	HONEYWELL
065-000179-XXXX	KS271C	SERVO	HONEYWELL
065-00178-XXXX	KS 270C	SYSTEM, SERVO	HONEYWELL
065-00180-XXXX	KS272C	SERVO, TRIM	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
065-00183-XXXX	KC225	COMPUTER, FLIGHT	HONEYWELL
065-0027-XX	KS270	SERVO, PITCH	HONEYWELL
065-0028-XX	KS271	SERVO, ROLL	HONEYWELL
065-0029-XX	KS272	SERVO, TRIM	HONEYWELL
065-0040-XX	KS273	SERVO	HONEYWELL
065-0053-XXXX	KAS297A	SELECTOR / ALERTER, ALTITUDE	HONEYWELL
065-0059-XX	KS270A	SERVO, PITCH	HONEYWELL
065-0060-XX	KS271A	SERVOS, AUTOPILOT	HONEYWELL
065-0061-XX	KS272A	SERVOS, AUTOPILOT	HONEYWELL
065-0082-XX	KDC481	COMPUTER, AIR DATA	HONEYWELL
066-00011-0000	KG102	GYRO, DIRECTIONAL	HONEYWELL
066-01066-XXXX	KDM706/706A	EQUIPMENT, DISTANCE MEASURING	HONEYWELL
066-01069-XXXX	KDI/574	INDICATOR, DME	HONEYWELL
066-01127-XXXX	TRA-67A	TRANSPONDER, MODE-S	HONEYWELL
066-01146-0101	CAS66A	SYSTEM, TCAS I	HONEYWELL
066-01152-0101	KTA810	SYSTEM, MULTI-HAZARD AWARENESS	HONEYWELL
066-01171-XXXX	IVA-81D	INDICATOR, VERTICAL SPEED	HONEYWELL
066-01175-XXXX	KMH820	SYSTEM, MULTI-HAZARD AWARENESS	HONEYWELL
066-01177-0101	KTA910	UNIT, TCAS I	HONEYWELL
066-01178-2101	KMH920	UNIT, MULTI-HAZARD AWARENESS	HONEYWELL
066-01507-XXXX	FFS-578A	UNIT, MODE S CONTROL	HONEYWELL
066-03029-XXXX	KI525	INDICATOR, PICTORIAL NAVIGATION	HONEYWELL
066-03046-XXXX	KI525A	INDICATOR, PICTORIAL NAVIGATION	HONEYWELL
066-03062-()	KEA346	ALTIMETER, SERVOED ENCODING	KING
066-03114-0000, 0001	IN 812A	INDICATOR, RADAR	BENDIX
066-04035-XXXX	KDM540	DISPLAY, MULTI-FUNCTION	HONEYWELL
066-1022-00	KDF8000	ADF	KING
066-1022-01	KDF8000	ADF	KING
066-1052-()	KN61	DME, REMOTE	KING
066-1069-01	KDI572	INDICATOR, DME	KING
066-1069-02	KDI573	INDICATOR, DME	KING
066-1069-03	KDI573	INDICATOR, DME	KING
066-1069-04	KDI574	INDICATOR, DME	KING
066-1070-01	KN63	EQUIPMENT, DISTANCE MEASURING	KING
066-1070-02	KN63	EQUIPMENT, DISTANCE MEASURING	KING
066-1078-XXXX	KNR634/634A	RECEIVER, VHF NAVIGATION	HONEYWELL
066-3031-()	KNI415	INDICATOR, NAVIGATION	HONEYWELL
066-3034-XXXX	KI202/206/207	INDICATOR, NAVIGATION	HONEYWELL
066-3044-()	KNI416	INDICATOR, NAVIGATION	HONEYWELL
066-3077-XX	KAV485	INDICATOR, ALTITUDE / VERTICAL SPEED	HONEYWELL
066-3079-XX	KAI487	INDICATOR, MACH AIRSPEED	HONEYWELL
066-3080-XX	KST488	INDICATOR, SPEED / TEMPERATURE	HONEYWELL
066-3132-XX	KAS489	SELECTOR, REMOTE ALTITUDE	HONEYWELL
066-3132-XX	KAS489	SELECTOR, REMOTE ALTITUDE	HONEYWELL
066-402X-XXXX	SG464/465	GENERATOR, SYMBOL	BENDIX
066-4035-XXXX	KMD540	SYSTEM, MULTI-FUNCTION DISPLAY	HONEYWELL
066-50000-XXXX	TPA-81A	TCAS PROCESSOR	HONEYWELL
066-50001-XXXX	IVA-81A	INDICATOR, VERTICAL SPEED	HONEYWELL
066-50002-0501	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-0601	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-0701	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-0801	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-0901	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-1001	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-8101	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-8102	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-8103	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-8104	IVA-81B	RESOLUTION ADVISORY/VERTICAL SPEED	HONEYWELL
066-50002-XXXX	IVA-81B	INDICATOR, VERTICAL SPEED	HONEYWELL
066-50003-XXXX	ITA-81A	DISPLAY, TCAS TRAFFIC - DEDICATED	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
066-5001-XXXX	TID66A	DISPLAY, TRAFFIC INDICATOR	HONEYWELL
066-50024-XXXX	FPD500	PANEL, FLAT, DISPLAY	HONEYWELL
069-01032-XXXX	KX155A	NAV / COMM, VHF	HONEYWELL
069-01033-XXXX	KX165A	NAV / COMM, VHF	HONEYWELL
071-00017-XXXX	KA57	ADAPTER, AUTOPILOT	HONEYWELL
071-00112-XXXX	KCM805	MODULE, CONFIGURATION	HONEYWELL
071-01052-XXXX	KMT112	TRANSMITTER, MAGNETIC AZIMUTH	HONEYWELL
071-01053-XXXX	KA51()	ACCESSORY, SLAVING	HONEYWELL
071-01055-XXXX	KA52	ADAPTER, AUTOPILOT	HONEYWELL
071-01242-XXXX	KA51B	ACCESSORY, SLAVING	HONEYWELL
071-01477-XXXX	CTA-81A	CONTROL UNIT, TRANSPONDER/TCAS_____	HONEYWELL
071-01480-XXXX	CTA-81B	CONTROL UNIT, TRANSPONDER/TCAS_____	HONEYWELL
071-01492-XXXX	CTA-81B	CONTROL UNIT, TRANSPONDER/TCAS_____	HONEYWELL
071-01503-XXXX	CTA-81A	CONTROL UNIT, TRANSPONDER/TCAS_____	HONEYWELL
071-01507-XXXX	KFS578A	UNIT, MODE S CONTROL	HONEYWELL
071-01508-XXXX	KA90	ADAPTER, HSI	HONEYWELL
071-01519-0101	ART2000	ANTENNA/RECEIVER/TRANSMITTER	HONEYWELL
071-01542-()	CD671C	UNIT, MODE S TCAS CONTROL	HONEYWELL
071-01542-XXXX	CD671C	UNIT, MODE S / TCAS CONTROL	HONEYWELL
071-01550-0101	ART2100	ANTENNA/RECEIVER/TRANSMITTER	HONEYWELL
071-01568-()	CP66B	UNIT, TCAS CONTROL	HONEYWELL
071-01578-0000	CP500	PANEL, DISPLAY	HONEYWELL
071-01599-0100	KA815	ANTENNA, DIRECTIONAL	HONEYWELL
071-05026-0000	KTS152	TEST SET	HONEYWELL
071-05027-0000	KTS153	TEST SET	HONEYWELL
071-1041-01	KA39	CONVERTER, VOLTAGE	HONEYWELL
071-1215-XXXX	KFS598	UNITS, VHF COMM CONTROL	HONEYWELL
071-1216-XXXX	KFS564	UNIT, NAV CONTROL	HONEYWELL
071-1282-XXXX	KFS598A	UNITS, VHF COMM CONTROL	HONEYWELL
071-1283-XXXX	KFS564A	UNIT, NAV CONTROL	HONEYWELL
071-2006-()	KA37	PANEL, AUDIO SWITCH	KING
071-50001-XXXX	ANT-81A	ANTENNA, DIRECTIONAL - ARRAY	HONEYWELL
0832-1-8048		INDICATOR, FUEL CONTENTS	AMETEK
0832-I-804B		INDICATOR, FUEL QUANTITY	AMETEK
084SMG1		GENERATOR, MOTOR	SMITHS
09007-0117		INDICATOR, SUCTION GAUGE	AEROSONIC
09-205-101		INDICATOR, POWERED FLIGHT CONTROL	SMITHS
095001	VR-1010-24-1A	REGULATOR, DC VOLTAGE	PHOENIX AEROSPACE INC.
095002	DH-1030-24-65-CS	INVERTER, STATIC - SOLID STATE	PHOENIX AEROSPACE
095032	DH-1030-24-600-CS	INVERTER, STATIC - SOLID STATE	PHOENIX AEROSPACE
097768-0100	1014A	TRANSPONDER	HONEYWELL
097768-0101	1014A	TRANSPONDER	HONEYWELL
097768-0201	1014B	TRANSPONDER	HONEYWELL
099-3025-00X		CONTROL, FLIGHT DIRECTOR	COLLINS
1.1023BV		SWITCH, PRESSURE	JAEGER
1.1078FH		SWITCH, THERMAL	JAEGER
1.11041-12		TRANSMITTER, CONTENTS	JAEGER
1.1106ZB		TRANSMITTER, PRESSURE	JAEGER
1.1223-03		INDICATOR, FUEL QUANTITY	JAEGER
1.1306AA		INDICATOR, FUEL QUANTITY - DUAL	JAEGER
100/300	100/300	INDICATOR, HORIZON REFERENCE	JET/AIM
100-0034-()	RCA40()-()	INDICATOR, TACHOMETER	KELLY
100-0034-27	30-Y-1000	INDICATOR, TACHOMETER	KELLY
100-0034-28	30-Y-1001	INDICATOR, TACHOMETER	KELLY
100-0043-()	RCA40()-()	INDICATOR, TACHOMETER	KELLY
100-0049-()	RCA41()-()	INDICATOR, TACHOMETER	KELLY
100-0051-()	RCA40()-()	INDICATOR, TACHOMETER	KELLY
10-0055-()		LIGHT, EMERGENCY EXIT	GRIMES
10-0067-()		LIGHT, EMERGENCY EXIT	GRIMES
10013-0000-02		INDICATOR, FUEL QUANTITY PRIMARY	SIMMONDS PRECISION

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
10014-0000-02		INDICATOR, FUEL QUANTITY REPEATER	SIMMONDS PRECISION
10-0341-()		LIGHT, CLOSET	GRIMES
10035-11424		INDICATOR, PRESSURE ALTIMETER	AEROSONIC
10035-81996		INDICATOR, ALTIMETER	AEROSONIC
10035-81996		INDICATOR, ALTIMETER	AEROSONIC
10-0359-()		LIGHT, FLIGHT DECK DOME	GRIMES
100-361096-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
100-364295-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
100-365360-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
100-418-098-109		INDICATOR, N1 % RPM	MARCONI
100-418-098-110		INDICATOR, N2 % RPM	MARCONI
100-418-098-119		INDICATOR, N1 % RPM	MARCONI
100-418-098-120		INDICATOR, N2 % RPM	MARCONI
100-418101-107		ITT INDICATOR	MARCONI
100-418101-115		ITT INDICATOR	MARCONI
100-418101-120		ITT INDICATOR	MARCONI
100-418107-100		INDICATOR, FUEL FLOW	MARCONI
100-418107-104		INDICATOR, FUEL FLOW	MARCONI
100-478286-100		INDICATOR, FUEL FLOW	MARCONI
100-478286-102		INDICATOR, FUEL FLOW	MARCONI
100-478286-105		INDICATOR, FUEL FLOW	MARCONI
10048-0000-01		INDICATOR, FUEL QUANTITY PRIMARY	SIMMONDS PRECISION
10049-0000-01		INDICATOR, FUEL QUANTITY REPEATER	SIMMONDS PRECISION
10049-0000-01		INDICATOR, FUEL QUANTITY REPEATER	SIMMONDS PRECISION
100-5657-()		INDICATOR, PERCENT TACHOMETER	AERO-MACH
100-5658-()		INDICATOR, PROP TACHOMETER	AERO-MACH
100-5805-01		INDICATOR, EXHAUST GAS TEMPERATURE	AERO-MACH
10060		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10061		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10062		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10062-1-X	AN5730-()	TRANSMITTER, MAGNESYN - COMPASS	BENDIX
10063	10063	SWITCHES, ALTITUDE	MEGGITT AVIONICS
10066-0000-01		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
1008()-01	1008()-01	SWITCHES, COMPRESSION RATIO LIMIT	KOLLSMAN
10091-01		INDICATOR, FUEL QUANTITY PRIMARY	SIMMONDS PRECISION
101-00165/168/169	1811G/H	TEST SET, PITOT-STATIC	BARFIELD
101-00267		HARNESSE, ADAPTER	BARFIELD
101-00420	2548H	TEST SET, FUEL QUANTITY	BARFIELD
101-00540	8000	TESTER, AC FUEL QUANTITY SYSTEM	BARFIELD
101-0055X	2312G SERIES	TEST, SET, TURBINE TEMPERATURE INDICATING	BARFIELD
101-00901	TT-1000A	TEST SET, DIGITAL TURBINE TEMPERATURE	BARFIELD
101-00930	TT1200A	TEST SET, TURBINE TEMPERATURE	BARFIELD
101-01180	DPS400	TEST SET, PITOT-STATIC	BARFIELD
101-01400	AC-2K	TEST SET, FUEL QUANTITY - DIGITAL	BARFIELD
101-01401	AC-2K	TEST SET, DIGITAL FUEL QUANTITY	BARFIELD
10-1081-()		SERVICE BULLETIN	GRIMES
1011()	1011()	SWITCHES, AIRSPEED AND PRESSURE	MEGGITT AVIONICS
10112		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10113		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10115-01		INDICATOR, FUEL QUANTITY PRIMARY	SIMMONDS PRECISION
10116		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10116-01		INDICATOR, FUEL QUANTITY REPEATER	SIMMONDS PRECISION
10120		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
10121		SWITCH, OVERSPEED	NEGRETTE & ZAMBRA LTD
10124		SWITCH, ALTITUDE	NEGRETTE & ZAMBRA LTD
10125		SWITCH, DIFFERENTIAL ALTITUDE	NEGRETTE & ZAMBRA LTD
10129		SWITCH, AIRSPEED AND PRESSURE	NEGRETTE & ZAMBRA LTD
101-341687-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-361143-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-361143-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
101-361161-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364086-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364086-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364092-25		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364170-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364170-17		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364170-21		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-17		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364210-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364304-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364326-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364328-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-15		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-17		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-21		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-23		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-25		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364572-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364578-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364580-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-15		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364582-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364584-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364668-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364672-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364672-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364674-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364712-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364715-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364715-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364739-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364782-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
101-364851-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364851-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364851-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-15		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-17		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-19		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-364948-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
101-365739-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1013-XX-XXXX	UNS-1M	SYSTEM, NAVIGATION MANAGEMENT	UNIVERSAL AVIONICS
10-1418-()		UNIT, PASSENGER SERVICE	GRIMES
101420		INDICATOR, ALTIMETER - ENCODING	AEROSONIC
101435		INDICATOR, ALTIMETER - ENCODING	AEROSONIC
101450		INDICATOR, ALTIMETER - ENCODING	AEROSONIC
101450-11952		ALTIMETER, ALTITUDE REPORTING ("HG)	AEROSONIC
101450-11953		ALTIMETER, ALTITUDE REPORTING (MB)	AEROSONIC
10147		SWITCH, OVERSPEED	NEGRETTI & ZAMBRA LTD
10159		SWITCH, AIRSPEED	NEGRETTI & ZAMBRA LTD
101617		INDICATOR, PRESSURE REPORTING ALTIMETER	AEROSONIC
101627		INDICATOR, PRESSURE REPORTING ALTIMETER	AEROSONIC
10-162810-()		INDICATOR, TACHOMETER	BENDIX
10-162950-()		INDICATOR, TACHOMETER	BENDIX
101635		INDICATOR, PRESSURE REPORTING ALTIMETER	AEROSONIC
10164		SWITCH, AIRSPEED	NEGRETTI & ZAMBRA LTD
10167N01W00		INDICATOR, TORQUE	AMETEK
10167N02W00		INDICATOR, TORQUE	AMETEK
10168N01T00		INDICATOR, INTERTURBINE TEMPERATURE	AMETEK
10169N01R00		INDICATOR, PROP RPM	AMETEK
10170		SWITCH, AIRSPEED	NEGRETTI & ZAMBRA LTD
10170N01R00		INDICATOR, NH% RPM	AMETEK
10171N01F01		INDICATOR, FUEL FLOW	AMETEK
10171N03F02		INDICATOR, FUEL FLOW	AMETEK
10174N01W01		INDICATOR, TORQUE	AMETEK
10174N02W01		INDICATOR, TORQUE	AMETEK
10174N03W02		INDICATOR, TORQUE	AMETEK
10174N04W02		INDICATOR, TORQUE	AMETEK
10175N01T00		INDICATOR, INTERTURBINE TEMPERATURE	AMETEK
10176N01R00		INDICATOR, NL% RPM	AMETEK
10176N02R00		INDICATOR, NL% RPM	AMETEK
10177N01R00		INDICATOR, NH% RPM	AMETEK
10178N01T01		INDICATOR, STATIC/FLEX AIR TEMPERATURE	AMETEK
10178N02T01		INDICATOR, STATIC/FLEX AIR TEMPERATURE	AMETEK
1017XX SERIES	1017XX SERIES	INDICATOR, ALTIMETER	AEROSONIC
1017-XX-XXX	UNS-1C	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
10181		SWITCH, AIRSPEED AND PRESSURE	NEGRETTI & ZAMBRA LTD
102-0003-01	RCA25A-1	INDICATOR, ELECTRIC ATTITUDE GYROSCOPE	KELLY
102-0032	RCA23-1	INDICATOR, ATTITUDE GYROSCOPE	KELLY
102-0041-()	RCA22-()	INDICATOR, HORIZON GYROSCOPE	KELLY
102-0041-01	RCA22-2	INDICATOR, HORIZON GYROSCOPE	KELLY
102-0045-01	RCA26BK-1	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0045-02	RCA26BK-1	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0047-01	RCA26CM-1	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0047-02	RCA26CM-3	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0047-03	RCA26CM-5	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0050-01, 02	RCA26BK-8	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0051-01, 02	RCA26BK-2	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0051-04	RCA26BK-20	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0052-01, 02	RCA26C-5	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0053-01, 02	RCA26AK-1	INDICATOR, ATTITUDE - GYROSCOPE	KELLY

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
102-0053-03, 04	RCA26AK-6	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0054-01, 02	RCA26BK-3	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0054-03	RCA26BK-12	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0054-04	RCA26BK-12	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0055-01, 02	RCA26BK-4	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0057-01, 02	RCA26BK-6	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0057-02	RCA26BK-16	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0059-01	RCA26BK-7	INDICATOR, ELECTRIC ATTITUDE GYROSCOPE	KELLY
102-0059-01	RCA26BK-7	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0060-01, 02	RCA26BK-9	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0060-15, 16	RCA26BK-36	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0061-01, 02	RCA26AK-2	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0064-01, 02	RCA26AK-4	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0065-01, 02	RCA26BK-10	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0066-01, 02	RCA26AK-3	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0067-02	RCA26CM-4	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0070-01	RCA26CM-2	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0070-02	RCA26CM-6	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0072-01, 02	RCA26C-7	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0076-01	RCA26C-8	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0076-02	RCA26C-9	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0077-01	RCA26BK-18	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
102-0079-01	RCA26BK-21	INDICATOR, ATTITUDE - GYROSCOPE	KELLY
10201-1		SWITCH, STALL DETECTION	NEGRETTE & ZAMBRA LTD
10-2050		INDICATOR, TURBINE INTERSTAGE TEMP	SIMTEK INC.
102200-()		INDICATOR, ALTIMETER - ENCODING	AEROSONIC
102220-11886		INDICATOR, ALTIMETER	AEROSONIC
10224-()		TRANSDUCER, HYDRAULIC PRESSURE	NEGRETTE & ZAMBRA LTD
10224-()		TRANSDUCER, HYDRAULIC PRESSURE	NEGRETTE & ZAMBRA LTD
102319	B-11	INDICATOR, THERMOCOUPLE THERMOMETER	AMETEK
102459	E-12	INDICATOR, TACHOMETER	AMETEK
10250	10250	SWITCHES, ALTITUDE	MEGGITT AVIONICS
10252		SYSTEM, PHOTOCELL	CHADWICH-HELMUTH
102550	IND-A5-UH1	INDICATOR, ATTITUDE - REMOTE	ASTRONAUTICS
102594	E-12	GENERATOR, TACHOMETER	AMETEK
10270	10270	ADAPTER, TACH RADIO	CHADWICH-HELMUTH
10275-001-()		INDICATOR, TURN & BANK	SIGMA-TEK
103/104	103/104	INDICATOR, AIRSPEED	BADIN
103-0012-01	RCA11D-5	INDICATOR, DIRECTIONAL GYROSCOPE	KELLY
1030-1		CONTROL, AUDIO	AVTECH
10322-A	AN5773-1	GAUGE, TRIPLE ENGINE	AUTO-LITE
10359	10359	SWITCHES, ALTITUDE	MEGGITT AVIONICS
103AM		INDICATOR, SENSITIVE ALTIMETER	SMITHS
1040-1		CONTROL, AUDIO	AVTECH
104-052C		CONDITIONER, SIGNAL - MODULATED CARRIER	COX
1041PG/SB		TRANSMITTER, PRESSURE	SMITHS
10420-11968E		INDICATOR, ALTIMETER	AEROSONIC
10450-()	AAU-27/A	INDICATOR, COUNTER DRUM POINTER	AEROSONIC
10450-11900		INDICATOR, ALTIMETER	AEROSONIC
104AMA/JA/()		INDICATOR, MACH AIRSPEED	SMITHS
105290	E-12	GENERATOR, TACHOMETER	AMETEK
1053-13-01	1053-13-01	INDICATOR, DUAL TACHOMETER	KOLLSMAN
10541N03R02		INDICATOR, RPM	AMETEK
10541N06R02		INDICATOR, RPM	AMETEK
10542N02W01		INDICATOR, TORQUE	AMETEK
1054PG		TRANSMITTER, PRESSURE	SMITHS
105C/110B	105C/110B	INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
106-()-()		INDICATOR, FUEL	BOSTON
106785B100		MOTOR, DIRECT CURRENT	GENERAL CONTROLS
106788B107		VALVE, GATE	GENERAL CONTROLS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
106-BO-()		INDICATOR, FUEL	BOSTON
1081-()		UNIT, SERVO ELECTRIC	MID-CONTINENT
1081-()		ACTUATOR	MID-CONTINENT
108305	E-12	INDICATOR, TACHOMETER	AMETEK
108525	AB-5785-1	TRANSMITTER, POSITION	AMETEK
1092310	RESCU406AF	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
109-360013-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-360013-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-360013-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-360013-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-361016-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-361016-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-364054-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-364081-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
109-364083-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1098()	1098()	UNITS, FUEL QUANTITY TANK	HONEYWELL
10B	10B	TRANSCIEVER, CHF COMMUNICATION	DYNAIR
1100, 1200 SERIES	1100, 1200 SERIES	SUB-ASSEMBLY, GYRO ROTOR	JET/AIM
11000-12	11000-12	BREAKS, SINGLE DISC	GOODYEAR
110077	G-5	INDICATOR, UNIVERSAL THERMOMETER	AMETEK
110507	B-11	INDICATOR, THERMOCOUPLE THERMOMETER	AMETEK
110612	G-5	INDICATOR, DUAL UNIVERSAL THERMOMETER	AMETEK
110AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
111-150		INDICATOR, OIL	BOSTON
111302-5		INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
111303-4	113540	INDICATOR, ATTITUDE DIRECTOR	ASTRONAUTICS
1114-XX-XXX	UNS-1MSP	SYSTEM, NAVIGATION MANAGEMENT	UNIVERSAL AVIONICS
11160X	AN-5780-()	INDICATOR, TAIL/NOSE WHEEL POSITION	AMETEK
11162-XX-XXXX	UNS-1K+	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
1-117-()		TRANSDUCER, VIBRATION METER	BELL & HOWELL
111AM/PC/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
1121	1121	SYSTEM, FUEL QUANTITY MEASURING	SIMMONDS PRECISION
112-364021-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
112-364021-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
112-364032-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1130-()	1130-()	INDICATOR, ALTIMETER SETTING	KOLLSMAN
113540	111303-4	INDICATOR, ATTITUDE DIRECTOR	ASTRONAUTICS
114.005		INDICATOR, TEMPERATURE	KRATOS
114.054		INDICATOR, DC AMMETER	KRATOS
114.056()		INDICATOR, AC AMMETER	KRATOS
114.058		INDICATOR, FUEL TEMPERATURE	KRATOS
114.059		INDICATOR, DUCT TEMPERATURE	KRATOS
114.060		INDICATOR, DISCHARGER VALVE POSITION	KRATOS
114.062		INDICATOR, BATTERY AMMETER AC	KRATOS
114.065		INDICATOR, SPOILER POSITION	KRATOS
114.158		INDICATOR, SPOILER POSITION	KRATOS
114001-2	2578470	CLUTCH-RESISTOR	HONEYWELL
114-364068-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364068-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364068-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364086-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364093-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364101-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
114-364140-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1145-0015/00035		TRANSMITTER, WATER QUANTITY	ROYLYN
1145-0019		SWITCH, LOW LEVEL MAGNA WARNING	ROYLYN
114AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
115.015		INDICATOR, TEMPERATURE	KRATOS
115.024		INDICATOR, CABIN TEMPERATURE	KRATOS
115.026		INDICATOR, HYDRAULIC PRESSURE	KRATOS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
115.033		INDICATOR, DC VOLTMETER	KRATOS
115.034		INDICATOR, AC VOLTMETER	KRATOS
115.035		INDICATOR, FREQUENCY	KRATOS
115.079		INDICATOR, CABIN TEMPERATURE	ROGERSON AIRCRAFT CORP.
115.083		INDICATOR, TEMPERATURE - EGT	KRATOS
115.084		INDICATOR, RPM	KRATOS
115.085		INDICATOR, DC AMMETER	KRATOS
115.086-()		INDICATOR, AC FREQUENCY & TRANSMITTER	KRATOS
115.087		INDICATOR, AC VOLTMETER	KRATOS
115.089		INDICATOR, AC AMMETER	KRATOS
115.221		INDICATOR, HYDRAULIC QUANTITY	KRATOS
115.250		INDICATOR, AC VOLTMETER	KRATOS
1151324-1	RESCU406	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
1152794-1	RESCU406	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
1152890-1	RESCU406	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
1152892-1	RESCU406	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
1153046-1	RESCU406	TRANSMITTER, EMERGENCY LOCATOR	HONEYWELL
1-157-0001/2		METER, VIBRATION	BELL & HOWELL
115AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
117181		INDICATOR, HSI	ASTRONAUTICS
117-364059-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
117800	125780	INDICATOR, REMOTE ATTITUDE	ASTRONAUTICS
118-364014-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
118-364017-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
118-364059-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
118-364059-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1190-XXX-XXXX	UNS-1B	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
1192-X0-XXXXXX	UNS-1D	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
11XX KSD/BU/1		SWITCH, ALTITUDE	SMITHS
120-()		INDICATOR, ALTIMETER	AEROSONIC
120-()		INDICATOR, ALTIMETER PRESSURE	AEROSONIC
1201 KSD/BU/1		SWITCH, ALTITUDE	SMITHS
120AM/PC/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
120AM/PC/M/1		INDICATOR, SENSITIVE ALTIMETER	SMITHS
120AM/PC/M/OH		INDICATOR, SENSITIVE ALTIMETER	SMITHS
12-1100-()		INDICATOR, AMMETER	KELLY
121672-01	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
121672-01	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
121672-01-15	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
121672-01-16	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
121672-01-17	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
121AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
12-2000-()		INDICATOR, VOLT / AMMETER	KELLY
12-2004-()		INDICATOR, VOLT / AMMETER	KELLY
1221L1		TRANSDUCER, AIRSPEED	ROSEMOUNT
1221P()		TRANSDUCER, AIRSPEED	ROSEMOUNT
1229-()-()		INDICATOR, BATTERY TEMPERATURE	AVTECH
1234129		UNIT, MOTOR ASSEMBLY	MID-CONTINENT
124.013		INDICATOR, DUAL TEMPERATURE	KRATOS
124.014-()		INDICATOR, DUAL TEMPERATURE AND	KRATOS
124.01X		INDICATOR, TEMP / PRESSURE	KRATOS
124.039		INDICATOR, AMMETER - DC (DUAL)	KRATOS
124.039-3		INDICATOR, AMMETER - DC (DUAL)	KRATOS
124.040		VOLTMETER, AC / DC	KRATOS
124.041	212-070-116-007	INDICATOR, DUAL TEMPERATURE AND	KRATOS
124.041-1	212-075-036-101	INDICATOR, DUAL TEMPERATURE AND	KRATOS
124.041-3		INDICATOR, DUAL TEMPERATURE AND	KRATOS
124.043		INDICATOR, DUAL	KRATOS
124.044-()		INDICATOR, FUEL PRESSURE	KRATOS
124.045		INDICATOR, TEMP/PRESSURE - XMSN OIL	KRATOS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
124.04X		INDICATOR, TEMP / PRESSURE	KRATOS
124.067		INDICATOR, TEMPERATURE	KRATOS
124.067-2		INDICATOR, INTER TURBINE TEMPERATURE	KRATOS
124.1012-()		INDICATOR, TRANSMISSION TEMP / PRESSURE	KRATOS
124.1013		INDICATOR, ENGINE OIL TEMPERATURE AND	KRATOS
124.1013-()		INDICATOR, ENGINE OIL TEMPERATURE AND	KRATOS
124.1014-()		INDICATOR, LOADMETER/FUEL PRESS - DUAL	KRATOS
124.1130-2		INDICATOR, VOLTMETER	KRATOS
124.115		INDICATOR, TEMP/PRESSURE - OIL	KRATOS
124.115-1		INDICATOR, TEMP/PRESSURE - OIL	KRATOS
124.115-3		INDICATOR, TEMP/PRESSURE - OIL	KRATOS
124.115-5		INDICATOR, TEMP/PRESSURE - OIL	KRATOS
124.1214-()		INDICATOR, TEMPERATURE - EGT	KRATOS
124.181-1		INDICATOR, BREAK PRESSURE	KRATOS
124.183		INDICATOR, OUTSIDE AIR TEMPERATURE	KRATOS
124.244-102		INDICATOR, VOLTS AC/DC - DUAL	KRATOS
124.251		INDICATOR, OIL TEMP / PRESSURE	KRATOS
124.273()		INDICATOR, HYDRAULIC TEMP / PRESSURE	KRATOS
124.306-()		INDICATOR, TOTALIZING FUEL QUANTITY	KRATOS
124.324-5		INDICATOR, TEMPERATURE - EGT	KRATOS
124.412		INDICATOR, TEMPERATURE	KRATOS
124.439		INDICATOR, PRESSURE - TRANSMISSION OIL	KRATOS
124.440		INDICATOR, FUEL QUANTITY	KRATOS
124.441		INDICATOR, ENGINE OIL TEMPERATURE AND	KRATOS
124.442-2		INDICATOR, TEMPERATURE - TOT	KRATOS
124.443		INDICATOR, AMPS - DC	KRATOS
124.444-()		INDICATOR, TEMPERATURE - TOT	KRATOS
124.480-1		INDICATOR, TEMPERATURE - ITT	KRATOS
124.480-3		INDICATOR, TEMPERATURE - ITT	KRATOS
124.545		INDICATOR, DUAL FUEL QUANTITY	KRATOS
124.546		INDICATOR, HYDRAULIC OIL TEMPERATURE AND	KRATOS
124.549		INDICATOR, TRANSMISSION OIL TEMPERATURE	KRATOS
124.550		INDICATOR, ENGINE OIL TEMPERATURE AND	KRATOS
124.551()		INDICATOR, TEMPERATURE - ITT	KRATOS
124.551-()		CONDITIONER, SIGNAL	KRATOS
124.593-()		INDICATOR, FLAP POSITION	KRATOS
124.620-()		INDICATOR, TURBINE GAS TEMPERATURE	KRATOS
124.621-()		INDICATOR, TURBINE GAS TEMPERATURE	KRATOS
124.643-()		INDICATOR, TORQUE	KRATOS
124.676		INDICATOR, HYDRAULIC OIL TEMPERATURE AND	KRATOS
124.677-1		INDICATOR, ENGINE OIL TEMPERATURE AND	KRATOS
124.678		INDICATOR, TRANSMISSION OIL TEMP /	KRATOS
124.679		INDICATOR, GEAR BOX OIL TEMPERATURE AND	KRATOS
124.832		INDICATOR, AC VOLTMETER	KRATOS
124.833	10-60757-23	INDICATOR, DC VOLTMETER	KRATOS
124.834		INDICATOR, DC AMMETER	KRATOS
124.835		INDICATOR, FREQUENCY METER	KRATOS
124.836		INDICATOR, WATTMETER	KRATOS
124.837		INDICATOR, AC AMMETER	KRATOS
124.837		INDICATOR, AC AMMETER	KRATOS
124.838		INDICATOR, TEMPERATURE	KRATOS
124.924		INDICATOR, TEMP / PRESSURE	KRATOS
124.933A		INDICATOR, DUAL	KRATOS
124.934A		INDICATOR, DUAL	KRATOS
124.935		INDICATOR, TEMP / PRESSURE	KRATOS
124.935A		INDICATOR, DUAL	KRATOS
124.972		INDICATOR, TEMP / PRESSURE	KRATOS
124.972A		INDICATOR, DUAL	KRATOS
124.984		INDICATOR, TEMPERATURE	KRATOS
1240-1		CONTROL, AUDIO	AVTECH

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1240X		INDICATOR, ATTITUDE GYRO	BENDIX
12411	ATD-AC-7	CONTROLLER, ALTITUDE	KOLLSMAN
124623-01	7000E	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
124623-01(-)	7000E	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
124623-01-09	7000E	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
124623-01-10	7000E	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
124623-01-12	7000E	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
125/126	125/126	INDICATOR, MIXTURE CONTROL	ALCOR
125/126/135	125/126/135	INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
1250-1		PANEL, AUDIO CONTROL	AVTECH
1250-1(C)		PANEL, AUDIO CONTROL	AVTECH
1251-1		PANEL, AUDIO CONTROL	AVTECH
1251-1(C)		PANEL, AUDIO CONTROL	AVTECH
125780	117800	INDICATOR, REMOTE ATTITUDE	ASTRONAUTICS
125781		INDICATOR, REMOTE ATTITUDE	ASTRONAUTICS
125810-5		INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
12585	ATD-AC-7	CONTROLLER, ALTITUDE	KOLLSMAN
126.306-7		INDICATOR, DUAL FUEL QUANTITY	KRATOS
126PN01Y07		INDICATOR, INTEGRATING TORQUEMETER	ECE
1286-1A		UNIT, COMMUNICATION CONTROL	AVTECH
1286-20		UNIT, COMMUNICATION CONTROL	AVTECH
1286-31	1286-31	ASSY PCB	AVTECH
1286-4		PANEL, CONTROL - AUDIO	AVTECH
1286-80	1286-80	ASSY TRANSFORMER	AVTECH
1286-9		UNIT, COMMUNICATION CONTROL	AVTECH
128848	G-5	INDICATOR, MULTI-FUNCTION TEMPERATURE	AMETEK
129222		INDICATOR, HORIZONTAL SITUATION	ASTRONAUTICS
129-364037-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364041-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364041-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364043-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364043-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364045-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364045-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364066(-)		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364066-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364066-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364079-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364081-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364091-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364100-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364100-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364106(-)		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364106-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
129-364106-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1296-5-0193	1296-5-0193	INDICATOR, AIRSPEED	KOLLSMAN
12B201-1		INDICATOR, AMMETER	KELLY
12B201-11		INDICATOR, AMMETER	KELLY
12B201-3		INDICATOR, AMMETER	KELLY
12B201-5		INDICATOR, AMMETER	KELLY
12B201-7		INDICATOR, AMMETER	KELLY
12B201-9		INDICATOR, AMMETER	KELLY
1301-0001		INDICATOR, ALTIMETER	AEROSONIC
1301-1001		INDICATOR, ALTIMETER	AEROSONIC
1301-1002		INDICATOR, ALTIMETER	AEROSONIC
1301-2001		INDICATOR, ALTIMETER	AEROSONIC
130333B	H-14	AUTOPILOT, ADAPTIVE	BEECHCRAFT
130-364048-5		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364048-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364076-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
130-364078(-)		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-11		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-13		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-3		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364078-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364090-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364125(-)		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364125-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364125-7		BOARD, PRINTED CIRCUIT	BEECHCRAFT
130-364125-9		BOARD, PRINTED CIRCUIT	BEECHCRAFT
1311-5(-)-B		TRANSMITTER, AUTOSYN FUEL LEVEL	BENDIX
132702	1123-6	INDICATOR, TEMPERATURE	AMETEK
132875	1123-2	INDICATOR, TEMPERATURE	AMETEK
132876	1123-3	INDICATOR, TEMPERATURE	AMETEK
132B	132B	INDICATOR, COMPASS	KOLLSMAN
1340-1		CONTROL, AUDIO	AVTECH
1349-(-)-()	1349-(-)-()	ALTIMETER, SENSITIVE	KOLLSMAN
134CK-(-)-033	134CK-(-)-033	ALTIMETER, SENSITIVE	KOLLSMAN
135-()		INDICATOR, ALTIMETER PRESSURE	AEROSONIC
1353--A		TRANSMITTER, AUTOSYN LIQUID LEVEL	BENDIX
1354--A		TRANSMITTER, AUTOSYN LIQUID LEVEL	BENDIX
1355-A		TRANSMITTER, AUTOSYN LIQUID LEVEL	BENDIX
135640	1123-4	INDICATOR, TEMPERATURE	AMETEK
135641	1123-5	INDICATOR, TEMPERATURE	AMETEK
1356-5833()		ACCUMULATOR, HYDRAULIC	PARKER-HANNIFIN
1356--A		TRANSMITTER, AUTOSYN LIQUID LEVEL	BENDIX
135M-10B	135M-10B	STROBEX BLADE TRACKER	CHADWICK-HELMUTH
135M-9	135M-9	STROBEX BLADE TRACKER	CHADWICK-HELMUTH
136/145/146	136/145/146	INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
13710		UNIT, SYNCHRO MASTER TEST	KOLLSMAN
1372-1-()		DETECTOR, RPM LIMIT	AVTECH
1372-1-5		DETECTOR, RPM LIMIT	AVTECH
137660	1123-7	INDICATOR, TEMPERATURE	AMETEK
137661	1123-8	INDICATOR, TEMPERATURE	AMETEK
138474-01-01	7650A	GYROSCOPE, RATE SWITCHING	SMITHS
138AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
1394(B)		INDICATOR, TURN & SLIP	MID-CONTINENT
1394T100()	Z SERIES	COORDINATOR, TURN	ELECTRIC GYRO CORP.
1396-2	1396	RPM SENSOR	AVTECH
1396-3		INDICATOR, RPM SENSOR	AVTECH
13CT-0113-A		TRANSFORMER, CONTROL SURFACE POSITION	ASTRO INSTRUMENT CORP.
13TX-0114-A		TRANSMITTER, CONTROL SURFACE POSITION	ASTRO INSTRUMENT CORP.
140100-01-01	4005T	INDICATOR, ATTITUDE	SMITHS
140540-01-01	7650C	GYROSCOPE, RATE SWITCHING	SMITHS
140AM/PC/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
14104	410	CONTROLLER, ALTITUDE	KOLLSMAN
141400-01-01	4005AB	INDICATOR, ATTITUDE	SMITHS
1416KMB/1		SWITCH, MACH AIRSPEED	SMITHS
1426-1AE-A1	C-14	INDICATOR, AIRSPEED (40-300 MPH)	BENDIX
1426-1Z-A1	C-14	INDICATOR, AIRSPEED (40-300 MPH)	BENDIX
1426-2J-A1	B-8	INDICATOR, AIRSPEED (20-200 MPH)	BENDIX
1426-37()A6	F-3	INDICATOR, AIRSPEED (50-700 MPH)	BENDIX
1426-37()-A6	F-2	INDICATOR, AIRSPEED (50-700 MPH)	BENDIX
142640-01-01	4005AC	INDICATOR, ATTITUDE	SMITHS
143-17037-()		ASSEMBLY, MASTER CAUTION	MASTER SPECIALTIES
1432-22B-A-A1	F-1	INDICATOR, AIRSPEED (50-700 MPH)	BENDIX
1432-22D-B-A1	F-1A	INDICATOR, AIRSPEED (45-700 MPH)	BENDIX
143224	1123-9	INDICATOR, TEMPERATURE	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
143422	1123-10	INDICATOR, TEMPERATURE	AMETEK
1441-07		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AERO-MACH
1450PG		TRANSMITTER, PRESSURE	SMITHS
1457M20		ACTUATOR, ROLL TRMI	HONEYWELL
145974-01-03	9000C	GYRO, VERTICAL DISPLACEMENT	LEAR SIEGLER
145AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
14602-()-()		INDICATOR, ATTITUDE	BENDIX
14602-1R-A2		INDICATOR, ATTITUDE GYRO	BENDIX
14605-()-()		INDICATOR, ATTITUDE GYRO	BENDIX
14605-1P-A1	J-8	INDICATOR, ATTITUDE GYRO	BENDIX
14608-()-B1		INDICATOR, ATTITUDE GYRO	BENDIX
14608-1AP-B1		INDICATOR, GYRO HORIZON	BENDIX
14609-1X-X1		INDICATOR, ATTITUDE GYRO	BENDIX
14613-()-()		INDICATOR, ATTITUDE GYRO	BENDIX
1467M21		ACTUATOR, PITCH TRIM	HONEYWELL
146AM/PC, PC/1		INDICATOR, SENSITIVE ALTIMETER	SMITHS
1470-8-20	AN5745-L3	ACCELEROMETER	KOLLSMAN
147B13		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B13A		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B21A4		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B30		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B30A		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31A		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31A3		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31A4		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31B		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B31C		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B7		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B7A		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147B8		THERMOMETERS, HERMETICALLY SEALED	LEWIS
147D2		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
149150-01-01	4058AC/A	INDICATOR, ATTITUDE DIRECTOR	SMITHS
149150-01-02	4058AC/D	INDICATOR, ATTITUDE DIRECTOR	SMITHS
149155-01-01	4058AC/B	INDICATOR, ATTITUDE DIRECTOR	SMITHS
149155-01-02	4058AC/E	INDICATOR, ATTITUDE DIRECTOR	SMITHS
149190-01-02	4145F	INDICATOR, ATTITUDE	SMITHS
149B()		INDICATOR, TEMPERATURE	LEWIS
149E()		INDICATOR, TEMPERATURE	LEWIS
14X0-1	1400 SERIES	CONTROL, AUDIO	AVTECH
15035-01102		INDICATOR, ALTIMETER, 2 INCH	AEROSONIC
1505-1		DIMMER, D.C LAMP	AVTECH
1505-21-1		DIMMER, VDC LAMP	AVTECH
15080-1109		INDICATOR, ALTIMETER, PRESSURE	AEROSONIC
15082-7	15082-7	SWITCH, PRESSURE	HYDRA-ELECTRIC
1509-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-10		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-11		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-15		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-3		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-7		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1509-1-9		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
150L		INDICATOR, FUEL	BOSTON
1510-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1510-1-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1511-4-C		PUMP, AIR - MOTOR DRIVEN (DRY)	BENDIX
1514-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
151826	151826	SCHEMATIC, WIRING	HORIZON
151CH1		AIRCRAFT BATTERY	SAFT
151CH2		AIRCRAFT BATTERY	SAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1529-1		BATTERY TEMPERATURE MONITOR	AVTECH
152B()		INDICATOR, TEMPERATURE - ITT	LEWIS
152B204		INDICATOR, TEMPERATURE	LEWIS
152B206		INDICATOR, TEMPERATURE	LEWIS
152B208B		INDICATOR, TEMPERATURE	LEWIS
152B208D		INDICATOR, TEMPERATURE	LEWIS
152B208E		INDICATOR, TEMPERATURE	LEWIS
152B208F		INDICATOR, TEMPERATURE	LEWIS
152B208F		INDICATOR, TEMPERATURE	LEWIS
152B210		INDICATOR, TEMPERATURE	LEWIS
152BL2D		INDICATOR, TEMPERATURE - ITT	LEWIS
152BL702		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL702A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL702C		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL702D		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL702E		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL703		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL704		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL706		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL708		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL708A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL708B		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL708H		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL709		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL709A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL722		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL80()		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801B		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801C		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801D		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL801E		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL802A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL802B		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL802C		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL802D		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL803		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL803A		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL803B		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152BL803C		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152C208L		INDICATOR, TEMPERATURE - ITT	LEWIS
152C304		INDICATOR, TEMPERATURE	LEWIS
152C305		INDICATOR, TEMPERATURE - TURBINE OUTLET	LEWIS
152C42		INDICATOR, TEMPERATURE	LEWIS
152HL2W		INDICATOR, TEMPERATURE	LEWIS
152HL2W3		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
152HL3W		INDICATOR, TEMPERATURE	LEWIS
152LU47		INDICATOR, VIBRATION	LEWIS
1532-3-A		VALVE, DE-ICER DISTRIBUTING	BENDIX
153LA30()		INDICATOR, AMMETER	LEWIS
153LCA8		INDICATOR, AMPS	LEWIS
153LV28		INDICATOR, DC VOLTMETER	LEWIS
153LV30		INDICATOR, DC VOLTMETER	LEWIS
154019-()	8121-M3()	INDICATOR, 3" COUNTER POINTER	HORIZON
154114-()	8122-A3()	INDICATOR, 3" DRUM POINTER	HORIZON
154195	211S	ASSEMBLY, SELECTOR	HORIZON
154290	211	ASSEMBLY, SELECTOR	HORIZON
154909	8047/()	INDICATOR, 2" COUNTER-POINTER ALTIMETER	HORIZON
154BS101-1	AMPS-2000	SYSTEM, MODULAR POWER	ACME ELECTRIC CORP.

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
154BS101-2	AMPS-2000	SYSTEM, MODULAR POWER	ACME ELECTRIC CORP.
155010-()-()	8142B-()-()	INDICATOR, 3" DRUM POINTER	HORIZON
155020-()-()	8141B-()-()	INDICATOR, 3" COUNTER POINTER	HORIZON
15527-1()		CONTROL, BAROMETER ALTITUDE	BENDIX
15527-1X		CONTROL, BAROMETER ALTITUDE	BENDIX
155456-()	8502C-()	INDICATOR, AIRSPEED	HORIZON
155456-6	8502-S20LW	INDICATOR - AIRSPEED	HORIZON
155750-()	8503-()	INDICATOR, 3" TRI-POINTER ALTIMETER	HORIZON
156	156	UNIT, CONTROL	SIGMA-TEK
15625		ENCODER, TRIP AND DATE	LORAL
15653-()A		SERVO, SURFACE	BENDIX
1568-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1568-1-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
1568-1-4		REMOTE ELECTRONICS UNIT	AVTECH
1568-1-5		REMOTE ELECTRONICS UNIT	AVTECH
157	157	INDICATOR, AIRSPEED	KOLLSMAN
1571262-5109		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
15780X	1122-3/4	INDICATOR, THERMOCOUPLE TEMPERATURE	AMETEK
15790-()		INDICATOR, SERVOED ALTIMETER	KOLLSMAN
15826-1-A		GYRO, RATE - SWITCHING	BENDIX
15831-()-()		GYRO, RATE - THREE AXIS	BENDIX
15900-()	720	INDICATOR, CABIN ALTITUDE, RATE, PRESSURE	KOLLSMAN
15900-903/904	720	INDICATOR, CABIN ALTITUDE, RATE, PRESSURE	KOLLSMAN
15901		INDICATOR, ATTITUDE GYRO	BENDIX
159787-01-01()	7901C	PLATFORM, TWIN GYRO	SMITHS
15RNA/EA/1		INDICATOR, GROUND SPEED AND DRIFT	SMITHS
15X0-1	1500 SERIES	CONTROL, AUDIO	AVTECH
16007-()	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
16007-20/220		INDICATOR, ENCODING ALTIMETER	KOLLSMAN
16007-231 THUR 236	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
16007-3()	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
16007-313/314	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
1606-1	1606-1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
16070-1()		COUPLER, MACH TRIM	BENDIX
16-1010-()	PS-801()	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
162AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
162B2	G-10	THERMOMETERS, ELECTRICAL RESISTANCE	LEWIS
162B2D		THERMOMETERS, ELECTRICAL RESISTANCE	LEWIS
162B3		THERMOMETERS, ELECTRICAL RESISTANCE	LEWIS
162B3A	G-10	THERMOMETERS, ELECTRICAL RESISTANCE	LEWIS
162B4		THERMOMETERS, ELECTRICAL RESISTANCE	LEWIS
162BL50()		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL602		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL701		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL701A		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL702		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL703		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704A		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704C		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704D		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704F		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704H		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704K		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704L		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL704N		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL801		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL802		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL802A		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL803		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
162BL803A		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162BL90()		THERMOMETER, ELECTRICAL RESISTANCE	LEWIS
162CD2		INDICATOR, DUAL TEMPERATURE ELECTRICAL	LEWIS
1634-()-()-()		INDICATOR, RATE OF CLIMB	BENDIX
1634-1A()-B1		INDICATOR, RATE OF CLIMB	BENDIX
1634-2AC-C1-1		INDICATOR, RATE OF CLIMB	BENDIX
1634-4()-D1-1		INDICATOR, RATE OF CLIMB	BENDIX
1634-6A()-C6-1		INDICATOR, RATE OF CLIMB	BENDIX
1634-6AA-E6-1		INDICATOR, RATE OF CLIMB	BENDIX
1634--A1		INDICATOR, RATE OF CLIMB	BENDIX
163B()		INDICATOR, MULTIFUNCTION RESISTANCE TEMP	LEWIS
163B103()		INDICATOR, TEMPERATURE	LEWIS
163B137		INDICATOR, TEMPERATURE	LEWIS
163B202()		INDICATOR, ELECTRICAL RESISTANCE	LEWIS
163BL5()		INDICATOR, ELECTRICAL RESISTANCE	LEWIS
163BL501		INDICATOR, TEMPERATURE	LEWIS
1-64	1-64	SYSTEMS, COMMAND AND AUTOMATIC TRIM	CENTURY
1643-6()-B6-()		INDICATOR, RATE OF CLIMB	BENDIX
1649-1A()-A1-1		INDICATOR, RATE OF CLIMB	BENDIX
1650-6AN-A6-2		INDICATOR, RATE OF CLIMB	BENDIX
1652-6A()-B6-1		INDICATOR, RATE OF CLIMB	BENDIX
1653,1654,1659,1662		INDICATOR, RATE OF CLIMB	BENDIX
1653-6AB-()6-1		INDICATOR, RATE OF CLIMB	BENDIX
1656-1	1656-1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
1656-6	1656-6	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
1659-6AB-A6-1		INDICATOR, RATE OF CLIMB	BENDIX
1662-6AB-A6-1		INDICATOR, RATE OF CLIMB	BENDIX
1662-6AB-D6-1		INDICATOR, RATE OF CLIMB	BENDIX
1662-6AB-E6-4		INDICATOR, RATE OF CLIMB	BENDIX
16800-1A-1A1	C-5B	INDICATOR, DIRECTIONAL GYRO	BENDIX
1680-4U-A2		INDICATOR, RATE OF CLIMB	BENDIX
1680-4-U-A2		INDICATOR, RATE OF CLIMB	BENDIX
169	169	MODULES, CLUSTER	SIGMA-TEK
16906-2C,-1()		PANEL, CONTROL	BENDIX
16928-1A		PANEL, CONTROL	BENDIX
16935-1A		PANEL, CONTROL	BENDIX
16X0-1	1600 SERIES	CONTROL, AUDIO	AVTECH
1704-1001-()	2390-()	DETECTOR, RPM LIMIT WARNING	SEACO
17110		SWITCH, AIRSPEED AND PRESSURE	NEGRETTI & ZAMBRA LTD.
1719649-5XX	AP-4001	PEDESTAL, ANTENNA	HONEYWELL
1719672-50X	AP-3001	PEDESTAL, ANTENNA	HONEYWELL
1719694-507	AP-5001	PEDESTAL, ANTENNA	HONEYWELL
1719694-508	AP-5001	PEDESTAL, ANTENNA	HONEYWELL
1719694-5XX	WA-800	PEDESTAL, ANTENNA	HONEYWELL
1719726-()	RT-5001	TRANSMITTER, RECEIVER	HONEYWELL
1719726-()	RT-5001	TRANSMITTER, RECEIVER	HONEYWELL
1719726-()	RT-5001	RECEIVER-TRANSMITTER	HONEYWELL
1719726-505	RT-4001	RECEIVER-TRANSMITTER	HONEYWELL
1719726-50X	RT-4001	TRANSMITTER, RECEIVER	HONEYWELL
171BS101-1	AMPS-500	POWER SUPPLY, MODULAR	ACME-UTAH RESEARCH &
171BS101-M	AMPS-500	POWER SUPPLY, MODULAR	ACME-UTAH RESEARCH &
17265-()A		GYROSCOPE, DIRECTIONAL DISPLACEMENT	BENDIX
1727()		INDICATOR, VARIOUS	JAEGER
172B2	MJ-4	INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
172B3		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
17300 / 17400		EXTINGUISHER, 86 CUBIC INCH AIRCRAFT FIRE	AMERICAN STANDARD
173-13227-000		ASSEMBLY, PANEL BOARD	MASTER SPECIALTIES
17317		ASSEMBLY, CALIBRATING JIG	KOLLSMAN
173966	1122-209	INDICATOR, RESISTANCE THERMOMETER	AMETEK
176391	1122-9L	INDICATOR, THERMOCOUPLE TEMPERATURE	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
17650	17650	TEST SET, HIGH VOLTAGE	DAYTON & GRANGER
17680-01	GNS-XLS	MODULE, CONFIGURATION	HONEYWELL
1775132		CONTROLLER, COMPASS	HONEYWELL
1775143	PS-143	SUPPLY, LATITUDE POWER	HONEYWELL
1775405		CONTROLLER, DUAL COMPASS	HONEYWELL
1776167-()		GYRO, DIRECTIONAL	HONEYWELL
1776167-1	DG-211	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
1776167-2	DG-212	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
1776167-3	DG-213	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
1776365-(X)	HZ-4	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL
1776366-()	R-4	INDICATOR, PICTORIAL DEVIATION	HONEYWELL
1777211-()	R-1	INDICATOR, PICTORIAL DEVIATION - LIGHTED	HONEYWELL
1777213	C-6	INDICATOR, GYROSYN COMPASS	HONEYWELL
1777214	C-6A	INDICATOR, GYROSYN COMPASS	HONEYWELL
1777215	C-6B	INDICATOR, GYROSYN COMPASS - LIGHTED	HONEYWELL
1778686	C-6D	INDICATOR, GYROSYN COMPASS	HONEYWELL
1778686-655	C-6D	INDICATOR, GYROSYN COMPASS	HONEYWELL
177CK-()-()	177CK-()-()	ALTIMETER, SENSITIVE	KOLLSMAN
177M-()		BALANCER, VIBREX	CHADWICH-HELMUTH
177M-6	177M-6	BALANCER	CHADWICK-HELMUTH
177M-6()		BALANCER, VIBREX	CHADWICH-HELMUTH
177M-7A		BALANCER, VIBREX	CHADWICH-HELMUTH
177P-()-()	177P-()-()	ALTIMETERS, SENSITIVE	KOLLSMAN
1780076		CONTROLLER, DUAL COMPASS	HONEYWELL
1780958		CONTROLLER, COMPASS	HONEYWELL
1781216		CONTROLLER, FLIGHT	HONEYWELL
1781218		COMPUTER, FLIGHT CONTROL	HONEYWELL
1782356		GYRO, VERTICAL	HONEYWELL
1782483		CALIBRATOR, GAIN	HONEYWELL
1782874-XXX	SP-40	SYSTEM, AUTOMATIC FLIGHT CONTROL	HONEYWELL
1782993	C-6F	INDICATOR, GYROSYN COMPASS	HONEYWELL
1783180-()	C-()	SYSTEM, COMPASS RACK	HONEYWELL
1783662-()	R-4	INDICATOR, PICTORIAL DEVIATION	HONEYWELL
1783755	C-6H	INDICATOR, GYROSYN COMPASS	HONEYWELL
1783867-()	C-()	AMPLIFIER, SERVO	HONEYWELL
1783867-()		AMPLIFIER, SERVO	HONEYWELL
1783993-()	MHR-4	INDICATOR, GYROSYN COMPASS	HONEYWELL
1784389	C-6J	INDICATOR, GYROSYN COMPASS	HONEYWELL
1784460	C-6E	INDICATOR, GYROSYN COMPASS	HONEYWELL
1784460-()	C-6E	INDICATOR, GYROSYN COMPASS	HONEYWELL
1784775-(X)	HZ-6	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL
1784775-44	HZ-6	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
17960-0101-XXXX	GNS-XLS	UNIT, DISPLAY CONTROL	HONEYWELL
17960-0102-XXXX	GNS-XLS	UNIT, DISPLAY CONTROL	HONEYWELL
17960-0203-XXXX	GNS-XLS	UNIT, DISPLAY CONTROL	HONEYWELL
17AT()	17AT()	INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
17B	17B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
17MXXX-()	F800	RECORDER, DIGITAL FLIGHT	L3 COMMUNICATIONS
17TES0010	PAU	UNIT, PORTABLE ANALYSIS	L3 COMMUNICATIONS
17TES0020	PPU	UNIT, PORTABLE PRINTER	L3 COMMUNICATIONS
17TES0031	GS2	STATION, GROUND	L3 COMMUNICATIONS
17TES0040	DRU	UNIT, DATA RETRIEVAL	L3 COMMUNICATIONS
17TES0043	PI	INTERFACE, PORTABLE	L3 COMMUNICATIONS
17TES0050	ACS/5S	SYSTEM, AIRCRAFT STIMULATOR	L3 COMMUNICATIONS
17TES0051		CABLE, PI AUDIO READOUT	L3 COMMUNICATIONS
17TES0052		CABLE, PI AUX READOUT	L3 COMMUNICATION
17TES0053		MODULE, PI MEMORY CARD	L3 COMMUNICATIONS
17TES0431	TAC	CABLE, TAPE ADAPTER	L3 COMMUNICATIONS
18013B-()	550	INDICATOR, VERTICAL SPEED	KOLLSMAN
18013B-100/300 SERIE	550	INDICATOR, VERTICAL SPEED	KOLLSMAN

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1801BX.CJ.CH		INDICATOR, FUEL QUANTITY	JAEGER
1801CH		INDICATOR, SINGLE ELECTRICAL	JEAGER
18-1000-()		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
18-1000-1		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
18-1102	MS28020-()	INDICATOR, PRESSURE - OIL (0-100 PSI)	COURTER
1811FER	1811FER	TEST SET, PITOT STATIC SYSTEM	BARFIELD
18-1258-()		INDICATOR, POSITION - FLAPS	COURTER
18-1299-()		INDICATOR, POSITION - FLAPS	COURTER
18-1299-4, -4-2		INDICATOR, POSITION - FLAPS	COURTER
1812SMG()		GENERATORS, MOTOR	SMITHS
18-1505		INDICATOR, FLAP POSITION	COURTER
18152-()	422	MODULE, STATIC DEFECT CORRECTION	KOLLSMAN
18-1814		TRANSMITTER, TORQUE	COURTER
1818-1-A		INDICATOR, COMPASS - STANDBY	BENDIX
18-1838-15		INDICATOR, DUAL TORQUE	COURTER
18-1838-15,17		INDICATOR, DUAL TORQUE	COURTER
18-1838-17		INDICATOR, DUAL TORQUE	COURTER
1818-3-A		INDICATOR, COMPASS - STANDBY	BENDIX
18-1842-7		TRANSMITTER, TORQUE PRESSURE	COURTER
1818-4-A		INDICATOR, COMPASS - STANDBY	BENDIX
18-1851		INDICATOR, FLAP POSITION	COURTER
1818-5-A		INDICATOR, COMPASS - STANDBY	BENDIX
18-1874		INDICATOR, BEARING HEADING	COURTER
181PG/()/()		TRANSMITTER, PRESSURE	SMITHS
18204-12	880	TESTER, ENCODING ALTIMETER	KOLLSMAN
18-2100-()		INDICATOR, PRESSURE - OIL	COURTER
18210-1		COMPUTER, AIR DATA	KOLLSMAN
18-2101-2		INDICATOR, HYDRUALIC OIL QUANTITY	COURTER
18-2104		INDICATOR, VARIABLE RELUCTANCE	COURTER
18-2105		INDICATOR, VARIABLE RELUCTANCE	COURTER
1821BS		TRANSMITTER, CONTENTS - FUEL	JAEGER
1821BS		UNIT, CONTENTS GAUGE TANK	JEAGER
18220-()		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
18220-()		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
18295B-()	513	INDICATOR, SAT/TAS	KOLLSMAN
1835-1		CHALLENGER AUDIO CONTROL SYSTEM	AVTECH
18352-()	513	INDICATOR, SAT/TAS	KOLLSMAN
18385		COMPUTER, AIR DATA - TEST SET-UP	KOLLSMAN
1841-3-A		INDICATOR, COMPASS - STANDBY	BENDIX
1845X-4-03	1845X-4-03	ALTIMETER, PRESSURE	KOLLSMAN
1845X-4-03	1845X-4-03	ALTIMETER, SENSITIVE	KOLLSMAN
1845X-4-03		ALTIMETERS, SENSITIVE	KOLLSMAN
185.102-()		INDICATOR, TRIPLE	KRATOS
1850-1RB		AUDIO, W/D AV	AVTECH
1851-1RB		AUDIO, W/D AV	AVTECH
18513	877	TESTER, ALTITUDE MODULE	KOLLSMAN
18515	877	TESTER, AIRSPEED/MACH MODULE	KOLLSMAN
18520	877	TESTER, HOLD CLUTCH	KOLLSMAN
1852-1		PANEL, AUDIO CONTROL	AVTECH
1852-1		AUDIO, W/D AV	AVTECH
1853-1		PANEL, AUDIO CONTROL	AVTECH
1853-1		AUDIO, W/D AV	AVTECH
1866-1		PANEL, AUDIO CONTROL	AVTECH
18711-B()	525	INDICATOR, SERVO PNEUMATIC ALTIMETER	KOLLSMAN
18719-1B_		AMPLIFIER-COMPUTER, YAW	BENDIX
1872		TRANSMITTER, CONTENTS	JAEGER
1872AA		TRANSMITTER, CONTENTS	JAEGER
18749-1A		COUPLER, YAW DAMPER	BENDIX
1877AB	310	TRANSMITTER, QUANTITY - FUEL CONTENTS	JAEGER
1878745	18942-1A	COUPLER, COMPASS	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1880		TRANSMITTER, CONTENTS	JAEGER
18B332-()		GAGE, ENGINE	KELLY
18C452-1		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
18C454-()		INDICATOR, DUAL ENGINE GAUGE	KELLY
18-I-305	18-I-305	INDICATOR, AIRSPEED	KOLLSMAN
18P200-()		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
1913FT		INDICATOR, PRESSURE - SINGLE POWER	JAEGER
1914FA		SWITCH, PRESSURE - RELATIVE	JAEGER
1914KA		SWITCH, PRESSURE - RELATIVE	JAEGER
1919-1()-A1		INDICATOR, PRESSURE - MANIFOLD	BENDIX
192	192	ANALYZER, SPECTRUM	CHADWICH-HELMUTH
192	192	ANALYZER, SPECTRUM	CHADWICH-HELMUTH
19-20-290	129-380002-1	INDICATOR, FLAP POS	PENN KEYSTONE
1925-1()-A1		INDICATOR, PRESSURE - MANIFOLD	BENDIX
1925756-()		INDICATOR, ATTITUDE DIRECTOR	BENDIX
1925757-()		INDICATOR, HORIZONTAL SITUATION	BENDIX
1929-8()-A1		INDICATOR, PRESSURE - MANIFOLD	BENDIX
192A	192A	ANALYZER, SPECTRUM	CHADWICH-HELMUTH
192A	192A	ANALYZER, SPECTRUM	CHADWICH-HELMUTH
1936BA		TRANSMITTER, POSITION	JAEGER
195-1SN112	AN5773-2	UNITS, ENGINE GAGE	EDISON
195-1TN112	AN5773T2	UNITS, ENGINE GAGE	EDISON
1956()	1956()	METER, ZONE IDENTIFICATION	DECCA
1957ED		INDICATOR, ELECTRIC - DUAL	JAEGER
195-7SN112	AN5773-2	UNITS, ENGINE GAGE	EDISON
195-7SN122	AN5773-1A	UNITS, ENGINE GAGE	EDISON
1964391-1		GYRO, DIRECTIONAL DISPLACEMENT	BENDIX
196BS101-1	AMPS-2000A	SYSTEM, MODULAR POWER	ACME ELECTRIC CORP.
1977-1		LAMP DIMMER	AVTECH
1977-1		LAMP DIMMER	AVTECH
1978191-1		INDICATOR, 3-INCH ATTITUDE	BENDIX
1982AA		BULB, THERMOMETER RESISTANCE	JEAGER
19E()-()-A		ASSEMBLY, AIR EJECTOR	BENDIX
1B495		DETECTOR, MAGNETIC FLUX	SIGMA-TEK
1C709	1C709	AMPLIFIER, ELECTRONIC PITCH TRIM	SIGMA-TEK
1C709	1C709	AMPLIFIER, ELECTRONIC PITCH TRIM	SIGMA-TEK
1C714		AMPLIFIER, DUAL CHANNEL GYRO SLAVING	SIGMA-TEK
1C714		AMPLIFIER, DUAL CHANNEL GYRO SLAVING	SIGMA-TEK
1C722		AMPLIFIER, DUAL CHANNEL GYRO SLAVING	SIGMA-TEK
1C727-()	1C727-()	HOLD, ELECTRONIC ALTITUDE	SIGMA-TEK
1C727-()		HOLD, ELECTRONIC ALTITUDE	CENTURY
1C753-()		DAMPER, YAW	CENTURY
1C771		PROGRAMMER, MODE	CENTURY
1C774		ANNUNCIATOR, MODE	CENTURY
1D496-()	CENTURY IV	DIRECTOR, FLIGHT	CENTURY
1D747	1D747	HOLD, ELECTRONIC ALTITUDE	SIGMA-TEK
1D747		HOLD, ELECTRONIC ALTITUDE	CENTURY
1D747		HOLD, ELECTRONIC ALTITUDE	CENTURY
1D755		AMPLIFIER, GYRO SLAVING WITH BOOTSTAP	SIGMA-TEK
1D755		AMPLIFIER, GYRO SLAVING WITH BOOTSTRAP	SIGMA-TEK
1D757-()	CENTURY 41	COMPUTER, FLIGHT	CENTURY
1U028 SERIES		GAUGE, FUEL PRESSURE / FLOW	SIGMA-TEK
1U028-002-15S		INDICATOR, PRESSURE - MANIFOLD (DUAL)	SIGMA-TEK
1U149()	5000	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149()	5000	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-()-()	5000E	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001 / - 010SP	5000	INDICATOR, ATTITUDE GYRO ASSEMBLY	SIGMA-TEK
1U149-001 / - 010SP	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001 / -010	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001-1	5000B-5	INDICATOR, ATTITUDE GYRO	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1U149-001-2	5000B-25	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001-3	5000B-28	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001-5	5000B-35	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-001-6	5000B-41	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-002	5000F-5	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-002-1	5000F-7	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-002-2	5000F-10	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-002-3	5000F-11	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-002-6	5000F-17	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-005	5000B-11	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010	5000E-13	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-1	5000B-37	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-2	5000B-39	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-4	5000B-54	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-5	5000B-64	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-6	5000B-66	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-010-7	5000B-70	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-011	5000B-27	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-011 THRU -020	5000B-()/5000E-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-012	5000B-40	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-012-1	5000B-47	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-012-2	5000B-52	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-012-4	5000B-55	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-013-1	5000B-45	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-013-3	5000B-53	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-014-12	5000B-73	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-014-13	5000B-74	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-014-5	5000B-58	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-015-11	5000B-72	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-015-15	5000B-75	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-015-9	5000B-67	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-016-7	5000B-62	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-016-8	5000B-63	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-017-10	5000B-68	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-019-19	5000B-76	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-021 THRU -030	5000M-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-021-1	5000M	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-021-9	5000M-16	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-022-2	5000M-5	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-023-3	5000M-6	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-024-4	5000M-7	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-025-5	5000M-8	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-026-6	5000M-9	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-027-7	5000M-14	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U149-028-8	5000M-15	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U202	1U202	INDICATOR, AIRSPEED	SIGMA-TEK
1U202-()	1U202-()	INDICATOR, AIRSPEED	SIGMA-TEK
1U248-001-()	5000L	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U262-()-()	4000B	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
1U262-()-()	4000B	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
1U262-()-()	4000C	INDICATOR, DIRECTIONAL GYRO WITH	SIGMA-TEK
1U262-001-37	4000B-26	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-39	4000B-30	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-50	4000B-35	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-52	4000B-37	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-54	4000B-39	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-57	4000B-42	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-58	4000B-43	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-60	4000B-44	DIRECTIONAL GYRO	SIGMA-TEK
1U262-001-61	4000B-45	DIRECTIONAL GYRO	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1U262-002-12	4000B-11	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-42	4000B-31	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-44	4000B-33	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-51	4000B-36	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-53	4000B-38	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-55	4000B-40	DIRECTIONAL GYRO	SIGMA-TEK
1U262-002-67	4000B-46	DIRECTIONAL GYRO	SIGMA-TEK
1U262-003-14	4000C	INDICATOR, DIRECTIONAL GYRO WITH	SIGMA-TEK
1U262-005-()	4000D	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
1U262-007-23	4000HR	DIRECTIONAL GYRO	SIGMA-TEK
1U262-007-33	4000HR-1	DIRECTIONAL GYRO	SIGMA-TEK
1U262-007-40	4000HR-2	DIRECTIONAL GYRO	SIGMA-TEK
1U262-009-31	4000C-3	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
1U262-010-41	4000HR-3	DIRECTIONAL GYRO	SIGMA-TEK
1U262-010-59	4000HR-5	DIRECTIONAL GYRO	SIGMA-TEK
1U262-010-62	4000HR-6	DIRECTIONAL GYRO	SIGMA-TEK
1U262-010-63	4000HR-7	DIRECTIONAL GYRO	SIGMA-TEK
1U262-011-1	4000B-23	DIRECTIONAL GYRO	SIGMA-TEK
1U262-011-14	4000B-34	DIRECTIONAL GYRO	SIGMA-TEK
1U262-011-15	4000B-41	DIRECTIONAL GYRO	SIGMA-TEK
1U262-011-8	4000B-28	DIRECTIONAL GYRO	SIGMA-TEK
1U262-012-2	4000B-24	DIRECTIONAL GYRO	SIGMA-TEK
1U262-013-3	4000B-25	DIRECTIONAL GYRO	SIGMA-TEK
1U262-017-7	4000B-27	DIRECTIONAL GYRO	SIGMA-TEK
1U262-019-9	4000B-32	DIRECTIONAL GYRO	SIGMA-TEK
1U262-031-1	4000H	DIRECTIONAL GYRO	SIGMA-TEK
1U262-032-2	4000H	DIRECTIONAL GYRO	SIGMA-TEK
1U262-032-2	4000H-1	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
1U262-033-13	4000H-12	DIRECTIONAL GYRO	SIGMA-TEK
1U262-033-3	4000H-2	DIRECTIONAL GYRO	SIGMA-TEK
1U262-033-5	4000H-4	DIRECTIONAL GYRO	SIGMA-TEK
1U262-034-4	4000H-3	DIRECTIONAL GYRO	SIGMA-TEK
1U262-034-6	4000H-5	DIRECTIONAL GYRO	SIGMA-TEK
1U262-035-7	4000H-6	DIRECTIONAL GYRO	SIGMA-TEK
1U262-036-8	4000H-7	DIRECTIONAL GYRO	SIGMA-TEK
1U262-037-9	4000H-8	DIRECTIONAL GYRO	SIGMA-TEK
1U262-038-10	4000H-9	DIRECTIONAL GYRO	SIGMA-TEK
1U262-039-11	4000H-10	DIRECTIONAL GYRO	SIGMA-TEK
1U262-040-12	4000H-11	DIRECTIONAL GYRO	SIGMA-TEK
1U295-()-()		INDICATOR, SLAVED DIRECTIONAL GYRO	SIGMA-TEK
1U367	1U367	INDICATOR, HORIZON GYRO	SIGMA-TEK
1U367-()-()		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-00X-X	1U367	INDICATOR, ATTITUDE DIRECTOR	SIGMA-TEK
1U367-101 THRU -110		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-101-1		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-102-2		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-102-9		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-103-3		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-104-4		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-105-5		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-105-6		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-106-7		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-107-8		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-1XX-()		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-201-1		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-202-2		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-203-3		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-204-17	52D267N	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-204-4	52D267M	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-205-5		INDICATOR, ATTITUDE GYRO	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
1U367-206-6		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-207-13		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-207-15		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-207-16		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-207-7		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-207-8		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-208-9		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-209-10		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-210-11		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-210-12		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-211-1	52D266-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-212-2	52D266-1M	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-213-3	52D267-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-214-4	52D267-1M	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-221-1	G-549A	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-221-3	G-549B	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-222-2	G-549A	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-222-4	G-549B	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-231-1		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-232-2		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-232-4		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-233-3		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-233-6		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-234-5		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1U367-302-2		GYRO, ATTITUDE	SIGMA-TEK
1U378-()-()	1U378	GAUGE, ENGINE	SIGMA-TEK
1U407-001-()		INDICATOR, FLIGHT DIRECTOR	SIGMA-TEK
1U445		INDICATOR, HORIZONTAL SITUATION	SIGMA-TEK
1U457-001		PANEL, ADF DUAL CONTROL	SIGMA-TEK
1U471-()		PANEL, AUDIO SELECTOR	SIGMA-TEK
1V285-()	5000	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V285-991		ASSEMBLY, GYRO ROTOR	SIGMA-TEK
1V304-()	1V304-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V304-()	1V304-()_	INDICATOR, AIRSPEED	SIGMA-TEK
1V340-()	1V340-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V347-()	1V347-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V347-()	1V347-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V347-003/002/001	1V347-003/002/001	INDICATOR, AIRSPEED	SIGMA-TEK
1V352-991		ASSEMBLY, GYRO ROTOR	SIGMA-TEK
1V374-()-()		INDICATOR, ATTITUDE DIRECTIONAL	SIGMA-TEK
1V374-001()		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V374-001/-010		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V439-()	1V439-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V439-()	1V439-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V446-()		INDICATOR, ATTITUDE GYRO CASE SUB-ASS'Y	SIGMA-TEK
1V446-()-()		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V446-021 THRU -030		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V446-041/-050		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V446-051 THRU -060		INDICATOR, ATTITUDE GYRO	SIGMA-TEK
1V474-()	1V474-()	INDICATOR, AIRSPEED	SIGMA-TEK
1V474-006/005/004	1V474-006/005/004	INDICATOR, AIRSPEED	SIGMA-TEK
200 SERIES	200 SERIES	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
2000	2000	VIBREX	CHADWICH-HELMUTH
2000()-37-()-4-A()	A-4	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
20000		INDICATORS, MAGNESYN	BENDIX
20000---A()		INDICATOR, SINGLE MAGNESYN	BENDIX
20000---A()		INDICATOR, SINGLE MAGNESYN	BENDIX
20001		INDICATORS, MAGNESYN	BENDIX
20001---()1		INDICATOR, SINGLE MAGNESYN	BENDIX
20002		INDICATORS, MAGNESYN	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
20002-37C-17-A1	A-4A	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
20002---A1		INDICATOR, SINGLE MAGNESYN	BENDIX
20003		INDICATORS, MAGNESYN	BENDIX
20003---A()		INDICATOR, SINGLE MAGNESYN	BENDIX
200059	PC-125	INVERTER, 125 VA STATIC	FLITE-TRONICS
200060	PC-125	INVERTER, STATIC	FLITE-TRONICS
200-08336-0020	IN182A	INDICATOR, RADAR	BENDIX
200-08336-0020	IN812A	INDICATOR, RADAR	BENDIX
200-10	200-10	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-10	200-10	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200102	PC-250	INVERTER, STATIC	FLITE-TRONICS
200102	PC-250	INVERTER, 250 VA STATIC	FLITE-TRONICS
200-10BL	200-10BL	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-10BL	200-10BL	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-11	200-11	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-11	200-11	INDICATOR, DIRECTIONAL GYRO	JET/AIM
20015		INDICATOR, AIRSPEED 0-180 KNOTS	AEROSONIC
20015-11187		INDICATOR, AIRSPEED	AEROSONIC
20016		INDICATOR, AIRSPEED 0-180 KNOTS	AEROSONIC
20016-11232		INDICATOR, AIRSPEED	AEROSONIC
20018		INDICATOR, AIRSPEED 0-180 KNOTS	AEROSONIC
20018-11292		INDICATOR, AIRSPEED	AEROSONIC
20018-21152		INDICATOR, AIRSPEED	AEROSONIC
20020-11190		INDICATOR, AIRSPEED	AEROSONIC
20020-11212		INDICATOR, AIRSPEED	AEROSONIC
20020-11293		INDICATOR, AIRSPEED	AEROSONIC
20020-11327		INDICATOR, AIRSPEED	AEROSONIC
20022-0000-010X		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
20022-0000-010X		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
20027	PC-450	INVERTER, 450 VA STATIC	FLITE-TRONICS
200-3	200-3	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
2003B	2003B	INDICATOR, ATTITUDE	HORIZON
200-5	200-5	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-6	200-6	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-6	52D54	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-6	52D54	INDICATOR, DIRECTIONAL GYRO	MITCHELL
20087(A)		REGULATOR, VOLTAGE	OECO CORPORATION
200-914-001		INDICATOR, FUEL QUANTITY	GULL
200-914-002		INDICATOR, FUEL QUANTITY	GULL
200-9C	200-9C	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-9C	200-9C	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-9C2	200-9C2	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-9C3	200-9C3	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-9M	200-9M	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-9M	200-9M	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200-9M3	200-9M3	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200-9M3	200-9M3	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200DC	200DC	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200E	200E	INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200E	200E	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200E	200-E	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200H	200H	INDICATOR, DIRECTIONAL GYRO	JET/AIM
200H		INDICATOR, DIRECTIONAL GYRO	CASTLEBERRY
200XX-0000-0101		UNITS, FUEL QUANTITY TANK	SIMMONDS PRECISION
20100		INDICATORS, MAGNESYN	BENDIX
20100---A()		INDICATOR, SINGLE MAGNESYN	BENDIX
20126-01248		INDICATOR, AIRSPEED	AEROSONIC
20130-()		INDICATOR, AIRSPEED	AEROSONIC
20130-()		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC
20130-01162		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
20130-11236		INDICATOR, AIRSPEED - MAXIMUM ALLOWABLE	AEROSONIC
20130-11288		INDICATOR, AIRSPEED	AEROSONIC
20130-11294		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC
20130-11358		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC
201530-11373		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC
201RNA/EA/1		INDICATOR, GROUND SPEED AND DRIFT	SMITHS
20240-1148		INDICATOR, AIRSPEED & MACH NUMBER	AEROSONIC
20240-118X		INDICATOR, PITOT-STATIC AIRSPEED	AEROSONIC
20300		INDICATORS, MAGNESYN	BENDIX
203-021-003		INDICATOR, FUEL QUANTITY	GULL
203-021-003		INDICATOR, FUEL QUANTITY	GULL
203-022-003		INDICATOR, ENGINE OIL TEMP/OIL PRES.	GULL
203-022-005		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-005		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-007		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-008		INDICATOR, TRANSMISSION OIL TEMP /	GULL
203-022-009		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-013		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-014		INDICATOR, TRANSMISSION OIL TEMP /	GULL
203-022-014		INDICATOR, TRANSMISSION OIL TEMP /	GULL
203-022-016		INDICATOR, TRANSMISSION OIL TEMP /	GULL
203-022-017		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-022-017		INDICATOR, ENGINE OIL TEMP / PRESSURE	GULL
203-023-003		INDICATOR, PRESSURE - HYDRAULIC	GULL
204	204	INTERPHONE, 3 STATION AMPLIFIER	DB SYSTEMS, INC.
204-060-006		INDICATOR, PTIT	GULL
2041234-3401 THRU 15	RNA-34A	RECEIVER, VHF NAVIGATION	BENDIX
2041234-3417 THRU 25	RNA-34A	RECEIVER, VHF NAVIGATION	BENDIX
204-1A		INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
20-4300-8765-1L		INDICATOR, ATTITUDE	MID-CONTINENT
2045-02-1	2045-02-1	INDICATOR, ENGINE PRESSURE RATIO	SMITHS
2045-05-1	2045-05-1	INDICATOR, ENGINE PRESSURE RATIO	SMITHS
2045-06-1	2045-06-1	INDICATOR, ENGINE PRESSURE RATIO	SMITHS
2045-08-1	2045-08-1	INDICATOR, ENGINE PRESSURE RATIO	SMITHS
2050-01-1		INDICATOR, SERVOED ALTIMETER	SMITHS
2050-04-01		INDICATOR, SERVOED ALTIMETER	SMITHS
2050-10-01		INDICATOR, SERVOED ALTIMETER	SMITHS
205-074-001-1		DETECTOR, RPM LIMIT WARNING	SEACO
205-1A		INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
20545-()	540	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
206-07()-()-()		INDICATOR, TURBINE OUTLET TEMPERATURE	SOLOY CONVERSIONS LTD
206-075-187-003		INDICATOR, ENGINE OIL TEMP / PRESSURE	SOLOY CONVERSIONS LTD
2061-()	2061-()	INDICATOR, FLAP POSITION	HAROWE SYSTEMS INC.
2061-11,12,13,14		INDICATOR, FLAP POSITION	SMITHS
206-1A		INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
2067210-()	RTA-41A	TRANSCEIVER, SERIES 2 VHF	BENDIX
2067593-()	RNA-26C	RECEIVER, VHF NAVIGATION	BENDIX
2067635-()	INA-51A	INDICATOR, ALTITUDE - RADIO	BENDIX
207	207	AMPLIFIER, PASSENGER SPEAKER	DB SYSTEMS, INC.
2070-03-1		INDICATOR, VERTICAL SPEED	SMITHS
2070-04-1		INDICATOR, VERTICAL SPEED	SMITHS
2070-05-1		INDICATOR, VERTICAL SPEED	SMITHS
2070135-5101	INA-51D	INDICATOR, ALTITUDE - RADIO	BENDIX
2070945-0701	RTA-43	SYSTEM, VHF COMMUNICATIONS	HONEYWELL
2070945-4301	RTA-43A	VHF TRANSCEIVER	BENDIX
209-075-326-1		DETECTOR, RPM LIMIT WARNING	SEACO
209-075-365-001	9000C	GYRO, VERTICAL DISPLACEMENT	SMITHS
2094-0004		INDICATOR, WATER QUANTITY	ROYLYN
2100-()-()	FA2100	RECORDER, FLIGHT DATA	L3 COMMUNICATIONS
21000		INDICATORS, MAGNESYN	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
21000-()-4-A1		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
21000-4()-()-A()		INDICATORS, MAGNESYN OIL PRESSURE	BENDIX
21001		INDICATORS, MAGNESYN	BENDIX
2100-1010-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-1020-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-1025-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-1026-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-102X-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-1XXX-()	FA2100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
2100-2042-()	FA2100	RECORDER, FLIGHT DATA	L3 COMMUNICATIONS
2100-2044-()	FA2100	RECORDER, FLIGHT DATA	L3 COMMUNICATIONS
21002-37A-16-A1	A-5	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
2100-3XXX-()	FA2100	RECORDER, COCKPIT VOICE AND DATA	L3 COMMUNICATIONS
21004		INDICATORS, MAGNESYN	BENDIX
2100-4042-()	FA2100	RECORDER, FLIGHT DATA	L3 COMMUNICATIONS
2100-4045-()	FA2100	RECORDER, FLIGHT DATA	L3 COMMUNICATIONS
21005		INDICATORS, MAGNESYN	BENDIX
21005-()-19-A()		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
21005-24()-19-A()		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
2100752-()	EA5172-()	INDICATOR, AIRSPEED	SIGMA-TEK
2100753-()	EA5173-()	INDICATOR, AIRSPEED	SIGMA-TEK
2101-01-1		INDICATOR, FUEL QUANTITY	SMITHS
2101-01-2		INDICATOR, FUEL QUANTITY	SMITHS
210-1A		INDICATOR, EXHAUST GAS TEMPERATURE	ALCOR
2105-()-()	2105	INDICATOR, RADIO MAGNETIC	AERONETICS
2105-2105L		INDICATOR, RADIO MAGNETIC	AERONETICS
2107-2107L		INDICATOR, RADIO MAGNETIC	AERONETICS
2108-2108L		INDICATOR, RADIO MAGNETIC	AERONETICS
2109-2109L		INDICATOR, RADIO MAGNETIC	AERONETICS
21100		INDICATORS, MAGNESYN	BENDIX
21100-A()		INDICATORS, DUAL CONCENTRIC MAGNESYN	BENDIX
21140-1120		INDICATOR, AIRSPEED	AEROSONIC
21140-1134-1, -2		INDICATOR, AIRSPEED	AEROSONIC
21140-1134-2		INDICATOR, AIRSPEED	AEROSONIC
21140-1150		INDICATOR, AIRSPEED 50-400 KNOTS	AEROSONIC
2116-XX-XXXX	UNS-1L	SYSTEM, SUPER FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
211C227-1		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-2		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-3		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-4		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-5		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-7		SWITCH, PRESSURE - HYDRAULIC	EATON
211C227-8		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-1		SWITCH, PRESSURE GAGE HYDRAULIC	EATON
211C228-1		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-2		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-2		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-4		SWITCH, PRESSURE GAGE HYDRAULIC	EATON
211C228-4		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-5		SWITCH, PRESSURE GAGE HYDRAULIC	EATON
211C228-5		SWITCH, PRESSURE - HYDRAULIC	EATON
211C228-7		SWITCH, PRESSURE GAGE HYDRAULIC	EATON
211C228-7		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-1		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-10		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-2		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-3		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-6		SWITCH, PRESSURE - HYDRAULIC	EATON
211C229-7		SWITCH, PRESSURE - HYDRAULIC	EATON
211C50		SWITCH, PRESSURE	EATON

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
212	212	SYSTEMS, DC INDICATOR	BARFIELD
21200		INDICATORS, MAGNESYN	BENDIX
21200--A()		INDICATORS, DUAL CONCENTRIC MAGNESYN	BENDIX
21200---A()		INDICATORS, DUAL CONCENTRIC MAGNESYN	BENDIX
21201		INDICATORS, MAGNESYN	BENDIX
212C50		SWITCH, PRESSURE	EATON
2138-50000-103/104		ASSEMBLY, DROOP COMPENSATOR AMPLIFIER	NORDEN
213C50		SWITCH, PRESSURE	EATON
2146-5		SYSTEM, AC WARNING	AUTRONICS
2146-5		SYSTEM, A/C WARNING	AUTRONICS
214C40-3-206		SWITCH, ALTITUDE LOW PRESSURE	EATON
214C50		SWITCH, PRESSURE	EATON
21663-()		INDICATOR, MAZ ALLOWABLE AIRSPEED	KOLLSMAN
21663-()		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
217-()A		INDICATOR, OIL PRESSURE	EDISON
217-03221		INDICATOR, TORQUE PRESSURE	EDISON
217-03221		INDICATOR, TORQUE PRESSURE	EDISON
217-12241		INDICATOR, TORQUE PRESSURE	EDISON
217A-()A		INDICATOR, OIL PRESSURE	EDISON
217A-100A		INDICATOR, OIL PRESSURE	EDISON
217A-100K-D7		INDICATOR, OIL PRESSURE	EDISON
217A-65K-D1		INDICATOR, FUEL PRESSURE	EDISON
218-()		TRANSMITTER, OIL PRESSURE	EDISON
21843	111	INDICATOR, RATE OF CLIMB	BADIN
21844	11	INDICATOR, RATE OF CLIMB	BADIN
21856	801	INDICATOR, RATE OF CLIMB	BADIN
21857	2501	INDICATOR, RATE OF CLIMB	BADIN
218C50		SWITCH, PRESSURE	EATON
218C50-3		SWITCH, PRESSURE	EATON
218C50-3		SWITCH, PRESSURE	EATON
21B17-()-()		REGULATOR, VOLTAGE - AC	BENDIX
21B29-()-()		REGULATOR, VOLTAGE - AC	BENDIX
22000-1-A1		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
22001-2-()-()		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
22001-2-()1-()		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
22003-2-()A		TRANSMITTERS, MAGNESYN OIL PRESSURE	BENDIX
22005-()-A1-()		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
22007-30-A1-2		TRANSMITTERS, FUEL AND OIL PRESSURE	BENDIX
2200X		TRANSMITTER, MAGNESYN (LINEAR)	BENDIX
2203B	2203B	CONTROL, ALTITUDE	SMITHS
22050-08-1		INDICATOR, SERVOED ALTIMETER	SMITHS
2210()-()-A5-()	D-4	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
2210X		TRANSMITTER, MAGNESYN (LINEAR)	BENDIX
22-111-02		INDICATOR, TORQUEMETER	SIGMA-TEK
2215	2215	CONTROLLER, CABIN PRESSURE	KOLLSMAN
2215B	2215B	CONTROLLER, CABIN PRESSURE	KOLLSMAN
22-162-()		INDICATOR, LIQUIDOMETER QUANTITY	SIGMA-TEK
22-164-()		INDICATOR, LIQUIDOMETER QUANTITY	SIGMA-TEK
2217D-()	2217D-()	AMPLIFIER, CABIN PRESSURE	KOLLSMAN
2217D-()	2217D-()	AMPLIFIER, CABIN PRESSURE CONTROL	KOLLSMAN
22200		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
222-001-071-105		CARTRIDGE, DIRECTIONAL SPRING	HONEYWELL
222-001-072-10X		SPRING, LONGITUDINAL FEEL	HONEYWELL
222-001-763-101		ASSEMBLY, DIRECTIONAL ACTUATOR	HONEYWELL
222-00336-0000	KUTIL90	TESTER, PC	HONEYWELL
222-00336-0020	KUTIL90A	TESTER, PC	HONEYWELL
222-00336-0040	KUTIL90B	TESTER, PC	HONEYWELL
222-00336-0060	KLN900	LOADER, MEMORY	HONEYWELL
222-00336-0060	KLN900	SYSTEM, GPS NAVIGATION	KING
222-00366-0002	KPA900	CONFIGURATION, SOFTWARE	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
222-00421-0001	KRA405B	TESTER, PC	HONEYWELL
222-00421-0001	KRA405B	ALTIMETER, RADAR	KING
222-005-001		INDICATOR, ACTUATOR POSITION	HONEYWELL
22201		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
22-201-()		INDICATOR, RATE OF CLIMB	SIGMA-TEK
22-202-01A	G991	INDICATOR, VERTICAL SPEED	SIGMA-TEK
222-075-133-101		PANEL, TRIM CONTROL	HONEYWELL
22-258-01-()		INDICATOR, DUAL TACHOMETER	SIGMA-TEK
2226,7-()-()		INDICATOR, TACHOMETER	BENDIX
22-260-042		INDICATOR, PRESSURE - MANIFOLD (DUAL)	SIGMA-TEK
22-279-010-1-A		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-010-A		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-02		INDICATOR, TURBINE TACHOMETER	SIGMA-TEK
22-279-03		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-03-1		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-03-3		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-03-4		INDICATOR, PROPELLER TACHOMETER	SIGMA-TEK
22-279-05-()		INDICATOR, PERCENT TACHOMETER	SIGMA-TEK
22-280 SERIES		INDICATOR, DUAL TACHOMETER	SIGMA-TEK
22-280-902-()		INDICATOR, TURBINE TACHOMETER	SIGMA-TEK
22-284-020		INDICATOR, DUAL TACHOMETER	SIGMA-TEK
22-285-03-()		INDICATOR, DUAL TACHOMETER	SIGMA-TEK
22-285-03-()		INDICATOR, TACHOMETER	SIGMA-TEK
22-290-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-292-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-293-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-294-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-295-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-296-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-297-()		INDICATOR, TEMPERATURE	SIGMA-TEK
22-298-()		INDICATOR, TEMPERATURE	SIGMA-TEK
222X-11-B		INDICATOR, TACHOMETER	BENDIX
22300		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
22300-()-()-()		TRANSMITTER, MAGNESYN OIL PRESSURE	BENDIX
22-304-()		INDICATOR, THERMOCOUPLES	SIGMA-TEK
22-374-()	374	INDICATOR, ALTIMETER	SIGMA-TEK
22-375-()	375	INDICATOR, ALTIMETER	SIGMA-TEK
2240-()		SHAFT, SOLENOID ROTATING	MID-CONTINENT
2245-1		CONTROL, DIMMER - LIGHTS	AUTRONICS
2245-5		DIMMER	AUTRONICS
22-468-03-()		INDICATOR, FUEL PRESSURE/FLOW	SIGMA-TEK
2260-1204		DETECTOR, RPM LIMIT WARNING	SEACO
22-607-021		INDICATOR, FUEL FLOW	SIGMA-TEK
22-607-026		INDICATOR, FUEL FLOW	SIGMA-TEK
22-695-0100		INDICATOR, AIRSPEED	SIGMA-TEK
22-695-090-()		INDICATOR, AIRSPEED	SIGMA-TEK
22-696-02		INDICATOR, AIRSPEED	SIGMA-TEK
22-697-06-()		INDICATOR, AIRSPEED	SIGMA-TEK
22702-()	519	INDICATOR, ALTIMETER ENCODING	KOLLSMAN
22702-500 SERIES	519	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
22719-()	550	INDICATOR, VERTICAL SPEED	KOLLSMAN
22719-()	550	INDICATOR, VERTICAL SPEED	KOLLSMAN
22722-()	540	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
22749-1 thru 10		COMPUTER, AIR DATA	KOLLSMAN
22-803-()		GAUGE, TRIPLE ENGINE	SIGMA-TEK
22-804-020-()		GAGE, ENGINE	SIGMA-TEK
22-804-023-()		UNIT, ENGINE GAUGE	SIGMA-TEK
22-804-023-1,2		INDICATOR, ENGINE - TRIPLE	AMETEK
22-868/869 SERIES		GAUGE, FUEL PRESSURE / FLOW	SIGMA-TEK
229-0192-00	332D-6A	GYRO, VERTICAL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
229-0236-00	332G-2	INDICATOR, RATE GYRO	COLLINS
229-0236-00	332G-2	GYRO, RATE	COLLINS
229-0236-00	332G-2	GYRO, RATE	COLLINS
229-0236-000	332G-2	GYRO, YAW RATE	COLLINS
229-0316-040	319RGS/3	GYRO, MINIATURE RATE	COLLINS
229-0316-040	319RGS/3	GYRO, MINIATURE RATE	LEAR SEIGLER
229-0316-040	319RGS/3	GYRO, MINIATURE RATE	SMITHS
229-0324-001	NAC-80	ACCELEROMETER, VERTICAL	COLLINS
229-0324-010	NAC-80	ACCELEROMETER, VERTICAL	COLLINS
229-0324-010	NAC-80	ACCELEROMETER, VERTICAL	COLLINS
229-0324-020	LAC-80	ACCELEROMETER, LATERAL/LONGITUDINAL	COLLINS
229-2054-010	334T-2	SERVO, AUTOTHROTTLE	COLLINS
229-9015-010	590A-6	CONTROL, ALTITUDE	COLLINS
229-9015-010	590A-6	CONTROL, ALTITUDE	COLLINS
229-9015-010	590A-6	CONTROLLER, ALTITUDE	COLLINS
22-991-()		INDICATOR, RATE OF CLIMB	SIGMA-TEK
22-995-()		INDICATOR, TEMPERATURE	SIGMA-TEK
2300-07-1		INDICATOR, FUEL QUANTITY	SMITHS
2300X		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
230-1		CONTROL, POWER SUPPLY DIMMER	PACIFIC SYSTEMS CORP.
23048-001	23048-001	STARTER-GENERATOR, DC	LEAR SIEGLER
23070-()		INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
23080-()	422	MODULE, STATIC DEFECT CORRECTION	KOLLSMAN
2310X		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
23175	23175	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
23176	23176	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
23180	23180	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
23186	23186	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
23-2100		TEMPERATURE, PROBE	KELLY
23396	23396	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
23-477-()		INDICATOR, TURN & BANK	SIGMA-TEK
23-501-001-4	5000B-30	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-01/-09	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-010	5000F-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-010/-021	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-010/-021	5000B/F	INDICATOR, ATTITUDE GYRO ILLUSTRATION	SIGMA-TEK
23-501-010-3	5000B-49	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-013	5000B-3	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-014	5000F-2	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-015	5000F-3	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-016	5000B-10	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-016-1	5000B-33	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-016-2	5000B-34	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-017	5000F-6	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-017-1	5000F-9	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-017-2	5000F-14	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-018	5000B-12	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-018-1	5000B-13	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-018-2	5000B-22	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-019	5000F-8	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-019-1	5000F-12	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-02	5000D	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-02 THRU -09		INDICATOR, ATTITUDE GYRO ILLUSTRATION	SIGMA-TEK
23-501-020	5000F-13	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-021	5000B-31	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-03	5000B	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-03-1	5000B-8	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-031/-040	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-03-10	5000B-21	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-031-1	5000B-38	INDICATOR, ATTITUDE GYRO	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
23-501-03-12	5000B-24	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-03-13	5000B-26	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-03-2	5000B-15	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-032-2	5000B-43	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-032-3	5000B-50	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-033-3	5000B-46	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-034-4	5000B-51	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-035-5	5000M-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-036-6	5000M-2	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-037-7	5000M-3	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-039-9	5000M-10	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-040-10	5000M-11	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-041/-050	5000()-()	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-041-1	5000B-60	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-04-2	5000E-8	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-042-2	5000B-61	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-043-3	5000M-12	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-044-4	5000M-13	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-05-2	5000E-9	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06	5000B-4	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-1	5000B-2	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-14	5000B-29	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-15	5000B-32	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-16	5000B-36	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-17	5000B-42	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-18	5000B-44	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-19	5000B-48	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-2	5000B-7	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-20	5000B-57	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-21	5000B-65	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-22	5000B-69	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-23	5000B-71	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-3	5000B-9	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-4	5000B-14	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-6	5000B-17	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-7	5000B-18	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-8	5000B-19	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-06-9	5000B-20	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-07	5000B-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-08	5000D-1	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
23-501-09	5000F	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
2376-()	2376-()	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
2376-5	2376-5	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
2390-2	2390-2	DETECTOR, RPM LIMIT WARNING	SATURN
23929-519, 532	24929-519, 532	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
23932-()	570	INDICATOR, PNEUMATIC ALTIMETER	KOLLSMAN
23932-901, 902	23932-901, 902	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
23932-903, 904	23932-903, 904	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
23932-929, 930	23932-929, 930	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
23989-()	540	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
23989-500	540	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
2400X		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
24030-()	24030-()	INDICATOR, MAX ALLOWABLE AIRSPEED MACH	KOLLSMAN
240A0901		INVERTER	ELECTRONICS RESEARCH
241.030	VF28()	VALVE, FLOAT	INTER-TECHNIQUE
24100		INDICATORS, MAGNESYN	BENDIX
24100-37B-20-A6	A-7	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
24100-9E-13-A1		INDICATOR, MAGNESYN POSITION SINGLE	BENDIX
24100---A()		INDICATOR, SINGLE MAGNESYN	BENDIX
24200		INDICATORS, MAGNESYN	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
24200---A()		INDICATORS, DUAL CONCENTRIC MAGNESYN	BENDIX
24201		INDICATORS, MAGNESYN	BENDIX
24201---A()		INDICATORS, DUAL CONCENTRIC MAGNESYN	BENDIX
2426-100		INDICATOR, FUEL PRESSURE (100PSI)	AMCAN INSTRUMENTS
2426-200		INDICATOR, OIL PRESSURE (200PSI)	AMCAN INSTRUMENTS
24500-37A-1-()1	A-8	TRANSMITTERS, PRESSURE TORQUEMETER	BENDIX
24606		INDICATOR, DIGITAL FUEL FLOW	ALCOR
24660-()	513	INDICATOR, TAS/SAT/TAT	KOLLSMAN
24660-001	513	INDICATOR, TAS/SAT	KOLLSMAN
24660-500	513	INDICATOR, TAS/SAT/TAT	KOLLSMAN
24660-540	513	INDICATOR, TAS/SAT	KOLLSMAN
24680-500	513	INDICATOR, TAS/SAT	KOLLSMAN
24680-540	513	INDICATOR, TAS/SAT/TAT	KOLLSMAN
24779-()	530	INDICATOR, AIRSPEED	KOLLSMAN
248541	1862-2W	INDICATOR, RUDDER POSITION	AMETEK
24929-()	570	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
24929-()	570	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
24929-531, 532	24929-531, 532	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
249-300		PANEL ASSEMBLY, MASTER CAUTION	MASTER SPECIALTIES
2500099-1	ZDSDH8TL5/1/L438	SYNCHROS, TANDEM	HONEYWELL
25005-()	571	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
25020-0179		INDICATOR, AIRSPEED, 2 INCH	AEROSONIC
2503148-2		INDICATOR, ACTUATOR POSITION	HONEYWELL
25040-1	830-()	INDICATOR, DIRECTIONAL GYRO	BADIN
2504481-1	ZDSDSH8TL5/5/L353	SYNCHROS, TANDEM	HONEYWELL
2504604-1	ZGGH8TL1/1/L420	SYNCHROS, TANDEM	HONEYWELL
250VA115/26VAC400 HZ	SPC-10(PW)	INVERTER, STATIC	KGS ELECTRONICS
250VA115/26VAC400 HZ	SPC-10(PW)	INVERTER, STATIC	KGS ELECTRONICS
25100-()	540	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
25201-A15B-4-1-A1		INDICATOR, MULTI-PURPOSE	BENDIX
253683	1824-22LW	INDICATOR, OIL PRESSURE	AMETEK
253685	1122-213LW	INDICATOR, FUEL AIR TEMPERATURE	AMETEK
253686	1122-214LW	INDICATOR, FREE AIR TEMPERATURE	AMETEK
253687	1122-212LW	INDICATOR, CABIN AIR TEMPERATURE	AMETEK
253862	1824-21LW	INDICATOR, OIL TEMPERATURE	AMETEK
25410038	7000	CONTROL DISPLAY UNIT	ADVANCED NAVIGATION INC
2544-FA		SIMULATOR, TANK UNIT	BARFIELD
2548GA/H	2548GA/H	TEST SET, FUEL QUANTITY	BARFIELD
2548-H	2548-H	TEST SET, FUEL QUANTITY SYSTEM	BARFIELD
254BK-6-086	254BK-6-086	GAGE, CABIN DIFFERENTIAL PRESSURE	KOLLSMAN
254BK-8-045	254BK-8-045	INDICATOR, CABIN PRESSURE	KOLLSMAN
254BK-8-046	254BK-8-046	INDICATOR, SUPERCHARGER AIRFLOW	KOLLSMAN
25510A122A8A2		INDICATOR, PRESSURE - OIL	BENDIX
25510-B25B-8-A3		INDICATOR, SYNCHRO	BENDIX
25514-B25A-3-A3		INDICATOR, FUEL FLOW	BENDIX
25514-B25A-3-A3		INDICATOR, FUEL FLOW	BENDIX
25516-C96A-14-A3		INDICATOR, SYNCHRO	BENDIX
2553919		SWITCH DIFFERENTIAL PRESSURE	HONEYWELL
2562-()-03-12		INDICATOR, VOLT / AMMETER	BRION-LEROUX
25683-0-1	850-()	INDICATOR, GYRO HORIZON	BADIN
25683-1-1	851-()	INDICATOR, GYRO HORIZON	BADIN
2579-116-1		VOLTMETER, DC	BRION-LEROUX
25850-730	575	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
2585302		GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2585302-1	DG-224	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2585421	C-2G	CONTROLLER, COMPASS	HONEYWELL
2585703	C-()	AMPLIFIER, SLAVING	HONEYWELL
2585703		AMPLIFIER, SLAVING	HONEYWELL
2585703-2	C-()	AMPLIFIER, SLAVING	HONEYWELL
2585703-2		AMPLIFIER, SLAVING	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
2585802-1	SP-50	PANEL, CONTROL	HONEYWELL
2586137		GYRO, VERTICAL DISPLACEMENT - REMOTE	HONEYWELL
2586137-()	VG-203()	GYRO, VERTICAL DISPLACEMENT - REMOTE	HONEYWELL
2586220		SENSOR, POSITION	HONEYWELL
2586257-1	C-12	COMPENSATOR, FLUX DETECTOR	HONEYWELL
2586257-1	CS-313	COMPENSATOR, REMOTE	HONEYWELL
2586257-1	CS-313	COMPENSATOR, REMOTE	HONEYWELL
2586257-1	CS-313	COMPENSATOR, REMOTE	HONEYWELL
2586257-1		COMPENSATOR, REMOTE MAGNETIC	HONEYWELL
2586261-()	C-12	CONTROLLER, COMPASS - DIGITAL	HONEYWELL
2586333-1	C-12	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2586333-1, 2, 3	C-12	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2586333-2, 3	C-12	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2586384-()		AMPLIFIER, POWER SUPPLY	HONEYWELL
2587193-1	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-143	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-2	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-21	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-22	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-23	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-24	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-25	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-25	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-26	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-3	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-33	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-36	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-4	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-41	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-42	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-43	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-44	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-45	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-46	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-47	C-14A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587193-5	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-6	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587193-7	C-14	SYSTEM, GYROSYN COMPASS	HONEYWELL
2587317	C-6L	INDICATOR, GYROSYN COMPASS	HONEYWELL
2587317-()	C-6L	INDICATOR, GYROSYN COMPASS	HONEYWELL
2587329		CONTROLLER, FLIGHT	HONEYWELL
2587335-()	311/313	GYRO, VERTICAL DISPLACEMENT - REMOTE	HONEYWELL
2587335-11	VG-311	GYRO, VERTICAL DISPLACEMENT - REMOTE	HONEYWELL
2587335-11	VG-311	GYRO, VERTICAL DISPLACEMENT - REMOTE	HONEYWELL
2587349		COUPLER, ENGAGE	HONEYWELL
2587451-()	DG-312	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587566-1	DG-206	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2587567-()	CI-600	INDICATOR, GYROSYN COMPASS	HONEYWELL
2587794	FX-150	VALVE, FLUX	HONEYWELL
2587794	FX-150	VALVE, FLUX	HONEYWELL
2587794	FX-150	VALVE, FLUX	HONEYWELL
2587794		VALVE, FLUX	HONEYWELL
2587909-9XX	HZ-6B	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL
2588260-9XX	HZ-6()	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
2588282-()	C-6M	INDICATOR, GYROSYN COMPASS	HONEYWELL
2588302-()	DG-23()	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-1	DG-233	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-10	DG-236	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-2	DG-241	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-3	DG-242	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-3	DG-242	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-4	DG-206A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-4	DG-206A	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-5	DG-234	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-5	DG-234	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-5	DG-234	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-5	DG-234	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-6	DG-235	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-7	DG-243	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588302-8	DG-244	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2588369-()	AD-200	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2588423	C-()	SYSTEM, COMPASS RACK	HONEYWELL
2588767-90()	RD-100	INDICATOR, RADIO DIRECTION	HONEYWELL
2588838		SENSOR, POSITION	HONEYWELL
2589167	C-()	AMPLIFIER, SERVO	HONEYWELL
2589174-1	C-()	AMPLIFIER, SLAVING	HONEYWELL
258919-902		VALVE, INDEXED AND PRECALIBRATED FLUX	HONEYWELL
2589210-()		RACK, COMPASS SYSTEM	HONEYWELL
2589210-90()	C-()	SYSTEM, COMPASS RACK	HONEYWELL
2589226-1		AMPLIFIER, POWER SUPPLY	HONEYWELL
2589419-901		VALVE, FLUX	HONEYWELL
2589419-901		VALVE, INDEXED FLUX	HONEYWELL
2589420-901		COMPENSATOR, FLUX DETECTOR	HONEYWELL
2589931	C-()	SUPPLY, POWER	HONEYWELL
2591201-903		COUPLER, COMPASS	HONEYWELL
2591201-922	CL-201	COUPLER, COMPASS	HONEYWELL
2591201-922	CL-201	COUPLER, COMPASS	HONEYWELL
2591201-922	CL-201	COUPLER, COMPASS	HONEYWELL
2591411-044	AR-44	INDICATOR, ATTITUDE REFERENCE	HONEYWELL
2591411-144	HZ-144	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2591411-244	HZ-244	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2591411-245/902	HZ-245	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2591411-264	HZ-264	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2591411-265	HZ-256	INDICATOR, ATTITUDE	HONEYWELL
259-1411-265	HZ-265	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2591411-444	HZ-444	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL
259-1411-444/9XX	HZ-444	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
2592789-902		AMPLIFIER, ELECTRONIC CONTROL	HONEYWELL
2592920-()	RD-44()	INDICATOR, RADIO DEVIATION	HONEYWELL
2592920-044	RD-44	INDICATOR, RADIO DEVIATION	HONEYWELL
2592920-44	RD-44	INDICATOR, RADIO DEVIATION	HONEYWELL
2592920-444	RD-444	INDICATOR, RADIO DEVIATION	HONEYWELL
2592920-901	RD-44	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
2592934-1	CN-1251/ASN-89(V)	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2593379-()	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-()	DRC-1	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-001	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-001	DRC-1	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-002	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-002	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
25933791	CS-412	COMPENSATOR, DUAL	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593379-1	CS-412	COMPENSATOR, DUAL REMOTE	HONEYWELL
2593604-200	ZC-200	COMPUTER / CONTROLLER, FLIGHT DIRECTOR	HONEYWELL
2593691-901	VG-401	REFERENCE, ATTITUDE	HONEYWELL
2593996-333	TARSYN	REFERENCE, THREE-AXIS	HONEYWELL
2593996-333,444,555	TARSYN	SENSOR, THREE AXIS REFERENCE	HONEYWELL
2593996-333/444	TARSYN-333/444	SENSOR, THREE AXIS REFERENCE	HONEYWELL
2594484	FX-220	DETECTOR, FLUX - MAGNETIC	HONEYWELL
2594484	FX-220	VALVE FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVE, FLUX	HONEYWELL
2594484	FX-220	VALVES, FLUX	HONEYWELL
2594732		MONITOR, COMPARATOR	HONEYWELL
2594732-200	CM-200	MONITOR, COMPARATOR	HONEYWELL
2594732-200	CM-200	MONITOR, COMPARATOR	HONEYWELL
2594732-200	CM-200	MONITOR, COMPARATOR	HONEYWELL
2594732-600	CM-600	MONITOR, COMPARATOR	HONEYWELL
2594732-600	CM-600	MONITOR, COMPARATOR	HONEYWELL
2594732-X00	CM-200 / 600	MONITOR, COMPARATOR	HONEYWELL
2594732-X00	CM-200 / 600	MONITOR, COMPARATOR	HONEYWELL
2594733-200	CM-200	MONITOR, COMPARATOR	HONEYWELL
2594733-200	FA-200	AMPLIFIER, FLAG	HONEYWELL
2594733-200	FA-200	AMPLIFIER, FLAG	HONEYWELL
2594775-200	AC-200	CONTROL, ALTITUDE	HONEYWELL
2594775-200	AC-200	CONTROL, ALTITUDE	HONEYWELL
2594775-200	AC-200	CONTROL, ALTITUDE	HONEYWELL
2594860-901	DG-207	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2594860-911	DG-207J	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
2597483-1		TRANSDUCERS, POSITION	HONEYWELL
26002806-201		ANTENNA, GPS	HONEYWELL
260582	1862-3LW	INDICATOR, ELEVATOR POSITION	AMETEK
260637	1122-48LW	INDICATOR, TURBINE GAS TEMPERATURE	AMETEK
260638	1824-27LW	INDICATOR, FUEL TEMPERATURE	AMETEK
2624F/G	2624F/G	TEST SET, FUEL QUANTITY	BARFIELD
26325-()	575	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
2643-GA	2643-GA	TEST SET, FUEL GAGING	BARFIELD
2643-GA	2643-GA	TEST SET, FUEL GAGING	BARFIELD
2643-GA	2643-GA	TEST SET, FUEL GAGING	BARFIELD
2643-GA	2643-GA	TEST SET, FUEL GAGING	BARFIELD
26447-()		INDICATOR, ENCODING ALTIMETER	KOLLSMAN
26465-()	575	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
26-66306-1		INDICATOR, PERCENT RPM	SWEARINGEN
26700-412	532	INDICATOR, MAX ALLOWABLE AIRSPEED -	KOLLSMAN
267-901-()		INDICATOR, FUEL QUANTITY	GULL
267-907-003		INDICATOR, FUEL QUANTITY	GULL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
267-917-003		INDICATOR, FUEL FLOW	GULL
267-942-002		INDICATOR, RPM - %	GULL
26980-()	520	INDICATOR, ALTIMETER - METRIC	KOLLSMAN
26B221		INDICATOR, PITCH TRIM	KELLY
26B224-()		INDICATOR, FLAP POSITION	KELLY
26B225-()		INDICATOR, TRIM - PITCH	KELLY
26T100-()		INDICATOR, FLAP	KELLY
26T101		INDICATOR, TRIM - ELEVATOR/RUDDER	KELLY
270-0055-000	590D-1	COMPUTER, CENTRAL AIR DATA	COLLINS
270-0055-010	590D-1	COMPUTER, CENTRAL AIR DATA	COLLINS
270-0055-010	590D-1	COMPUTER, AIR DATA	COLLINS
270-0213-000	590D-2	COMPUTER, CENTRAL AIR DATA	COLLINS
270-0213-010	590D-2	COMPUTER, CENTRAL AIR DATA	COLLINS
270-0489-010	HAS-751	SENSOR, HELICOPTER AIRSPEED	COLLINS
270-0859-010	590A-6A	CONTROL, ALTITUDE	COLLINS
270-0859-010	590A-6A	CONTROL, ALTITUDE	COLLINS
270-0930-010	YRS-65	SENSOR, YAW RATE	COLLINS
270-0930-010	YRS-65	SENSOR, YAW RATE	COLLINS
270-1306-010	CMA-764	RECEIVER, VLF/OMEGA	COLLINS
270-1306-020	VLF-ANT	COUPLER, ANTENNA	COLLINS
270-1306-060	CMA-764	RECEIVER, VLF/OMEGA	COLLINS
270-1306-070	CMA-764-1	RECEIVER, VLF/OMEGA/GPS	COLLINS
270-1306-080	GPS-ANT	ANTENNA, GPS	COLLINS
270-1306-110	CMA-764-2	RECEIVER, VLF/OMEGA/GPS	COLLINS
270-1306-120	GPS-ANT	ANTENNA, GPS	COLLINS
270-1721-010		SUPPLY, POWER	COLLINS
270-2196-010	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-010	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-010	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-010	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-010	590D-1	SENSOR, AIRSPEED	COLLINS
270-2196-0X0	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-0XX	590B-2	SENSOR, AIRSPEED	COLLINS
270-2196-0XX	590B-2	SENSOR, AIRSPEED	COLLINS
270-2424-()	329T-1	INDICATOR, TURN & SLIP	COLLINS
270-2425-010	331P-1	INDICATOR, DIRECTIONAL GYRO - ELECTRIC	COLLINS
270-2425-010	331P-1	INDICATOR, DIRECTIONAL GYRO	COLLINS
270-2425-020	331P-1V	INDICATOR, DIRECTIONAL GYRO - VACUUM DRIVE	COLLINS
270-2425-020	331P-1V	INDICATOR, DIRECTIONAL GYRO	COLLINS
270-2425-030	323A-5	DETECTOR, FLUX	COLLINS
270-2425-030	323A-5	DETECTOR, FLUX	COLLINS
270-2425-040	327C-3	INDICATOR, SLAVING	COLLINS
270-2425-040	327C-3	INDICATOR, SLAVING	COLLINS
270-2426-0X0	329A-4V	INDICATOR, HORIZON REFERENCE	COLLINS
270-2436-()	613L-3	UNIT, CONTROL	COLLINS
270-2578-040	DCU-2000	UNIT, DATA CONCENTRATOR	COLLINS
270A()	270A()	ASSEMBLY, CIRCUIT BOARD	E.M.P. ELECTRONICS
271-00141		INDICATOR, OIL PRESSURE	EDISON
2723043-003	SA226 SERIES	AMPLIFIER, NOSE GEAR STEERING	FAIRCHILD
273-()		UNITS, ENGINE GAGE	EDISON
273-7SN112	MS28043-2	UNITS, ENGINE GAGE	EDISON
27419	9011	INDICATOR, RATE OF CLIMB	BADIN
2763K73P002	716700-102	COUNTER, PRECISION INTERNAL PINION	AMETEK
27-66009-1		INDICATOR, OIL TEMP.	SWEARINGEN
27-66108-3		INDICATOR, TORQUE PRESSURE	SWEARINGEN
276PG/()		TRANSMITTER, PRESSURE	SMITHS
27703-()	519	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
27774		INDICATOR, ENCODING ALTIMETER	KOLLSMAN
27-82186-()	SA227 SERIES	INDICATOR, LANDING GEAR POSITION	FAIRCHILD
27943-()		SYSTEMN, CABIN DISPLAY	KOLLSMAN

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
27C370		INDICATOR, TORQUE	KELLY
2800(4245-4)		COORDINATOR, TURN	MID-CONTINENT
2800(4275-4)		COORDINATOR, TURN	MID-CONTINENT
2800-20		INDICATOR, BANK AND TURN	MID-CONTINENT
2800-4530N1()		INDICATOR, TURN & SLIP	MID-CONTINENT
2800-6845N1L		INDICATOR, BANK AND TURN	MID-CONTINENT
28007-()	518	INDICATOR, ALTIMETER ENCODING	KOLLSMAN
28007-()	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
28007-201 THRU 231	518	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
28260-()	930	CONTROLLER, TIME TO DESTINATION DISPLAY	KOLLSMAN
28690	880	TESTER, SAT/TAS COMPUTER	KOLLSMAN
28702-()	519	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
28704-()	519	INDICATOR, ENCODING ALTIMETER	KOLLSMAN
28847-()	TYPE 80	INDICATOR, AIRSPEED	BADIN
290-02240		INDICATOR, OIL PRESSURE	EDISON
29007-()	519	INDICATOR, ENCODING ALTIMETER - RADIO	KOLLSMAN
29007-()	521	INDICATOR, ENCODING ALTIMETER - RADIO	KOLLSMAN
29020-()	29020-()	INDICATOR, ALTIMETER - ENCODING	KOLLSMAN
29-2006-()		INDICATOR, TEMPERATURE - CYLINDER HEAD	KELLY
29-209		INDICATOR, TEMPERATURE - CARB AIR	KELLY
29400-()	995	CONVERTER, RADIO ALTIMETER	KOLLSMAN
29568	BTM503-501	MONITOR, BATTERY TEMPERATURE	MARATHON
29568	BTM503-501	MONITOR, BATTERY TEMPERATURE	MARATHON
29711-()	29711-()	INDICATOR, ALTIMETER - SERVOED ENCODING	KOLLSMAN
298CKX-(-)-01	298CKX-(-)-01	INDICATOR, PRESSURE - MANIFOLD	KOLLSMAN
2CM5()		GENERATOR, TACHOMETER	AMETEK
2CM5ABW		GENERATOR, TACHOMETER	AMETEK
2CM5ABW		GENERATOR, TACHOMETER	AMETEK
2CM5ACE		GENERATOR, TACHOMETER	AMETEK
2CM5ACE		GENERATOR, TACHOMETER	AMETEK
2CM5ACZ		GENERATOR, TACHOMETER	AMETEK
2CM5ACZ		GENERATOR, TACHOMETER	AMETEK
2CM5ADR		GENERATOR, TACHOMETER	AMETEK
2CM5ADR		GENERATOR, TACHOMETER	AMETEK
2CM5AEN		GENERATOR, TACHOMETER	AMETEK
2CM5AEN		GENERATOR, TACHOMETER	AMETEK
2CM5BAL		GENERATOR, TACHOMETER	AMETEK
2CM5BAL		GENERATOR, TACHOMETER	AMETEK
2CM5BAM		GENERATOR, TACHOMETER	AMETEK
2CM5BAM		GENERATOR, TACHOMETER	AMETEK
2CM7()		GENERATOR, TACHOMETER	AMETEK
2CM7AAA		GENERATOR, TACHOMETER	AMETEK
2CM7AAA		GENERATOR, TACHOMETER	AMETEK
2CM7AAN		GENERATOR, TACHOMETER	AMETEK
2CM7AAN		GENERATOR, TACHOMETER	AMETEK
2CM9()	CM-9	GENERATOR, TACHOMETER	AMETEK
2CM9AAA1		GENERATOR, TACHOMETER	AMETEK
2CM9AAA1		GENERATOR, TACHOMETER	AMETEK
2CM9AAA2		GENERATOR, TACHOMETER	AMETEK
2CM9AAA2		GENERATOR, TACHOMETER	AMETEK
2CM9AAAC		GENERATOR, TACHOMETER	AMETEK
2CM9AAAC		GENERATOR, TACHOMETER	AMETEK
2CM9AAB		GENERATOR, TACHOMETER	AMETEK
2CM9AAB		GENERATOR, TACHOMETER	AMETEK
2CM9AAC1		GENERATOR, TACHOMETER	AMETEK
2CM9AAC1		GENERATOR, TACHOMETER	AMETEK
2CM9AAC2		GENERATOR, TACHOMETER	AMETEK
2CM9AAC2		GENERATOR, TACHOMETER	AMETEK
2CM9AAC6		GENERATOR, TACHOMETER	AMETEK
2CM9AAC6		GENERATOR, TACHOMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
2CM9AAF2		GENERATOR, TACHOMETER	AMETEK
2CM9AAF2		GENERATOR, TACHOMETER	AMETEK
2SJ1A1	G-1	PILOT, AUTOMATIC	AMETEK
3001-01-1XX		INDICATOR, ACCELEROMETER	AMETEK
3001-01-1XX		INDICATOR, ACCELEROMETER	MAGNATEK
300-11B	300-11B	INDICATOR, ATTITUDE DIRECTOR GYRO	JET/AIM
300-14L()	300-14L()	INDICATOR, HORIZON REFERENCE	JET/AIM
300-3()	300-3()	INDICATOR, HORIZON REFERENCE	EMBRAER
30-0515-()		LIGHT, STROBE	GRIMES
30-0516-()		LIGHT, TAIL POSITION	GRIMES
300-7/9	300-7/9	INDICATOR, FLIGHT DIRECTOR HORIZON	JET/AIM
300-7DC()	300-7DC	HORIZON, DIRECTOR	JET/AIM
30-0837-()		LIGHT, STROBE ANTI-COLLISION	GRIMES
30-0849-()		LIGHT, STROBE ANTI-COLLISION	GRIMES
30095-()	570	INDICATOR, PNEUMATIC ALTIMETER	KOLLSMAN
30-1033-()		LIGHT, FLASHTUBE ANTI-COLLISION	GRIMES
30-1136-()		LIGHT, STROBE	GRIMES
30-1172-()		LIGHT, FLASHTUBE POSTION	GRIMES
30-1329-()		LIGHT, FLASHTUBE POSTION	GRIMES
30-1329-()		FLASHTUBE, AIRCRAFT NAVIGATIONAL LIGHT-	MIDLAND ROSS
30-1401-()		LIGHT, STROBE ANTI-COLLISION	GRIMES
30-1401-13		LIGHT, STROBE ANTI-COLLISION	GRIMES
30-1401-3		LIGHT, STROBE ANTI-COLLISION	GRIMES
30-1579-1		LIGHT, ANTI-COLLISION - STROBE	GRIMES
30-1809-1		LIGHT, FLASHTUBE ANTI-COLLISION	GRIMES
30-2272-()		LIGHT, STROBE	GRIMES
30230-1174		INDICATOR, VERTICAL SPEED	AEROSONIC
30230-1174		INDICATOR, VERTICAL SPEED	AEROSONIC
30-231-9		DETECTOR, SMOKE	PYROTECTOR
30-231R-7B		DETECTOR, SMOKE	PYROTECTOR
30260-0122		INDICATOR, VERTICAL VELOCITY	AEROSONIC
30260-1117		INDICATOR, VERTICAL VELOCITY	AEROSONIC
30260-1166		INDICATOR, VERTICAL SPEED	AEROSONIC
30260-1166		INDICATOR, VERTICAL SPEED	AEROSONIC
30260-1166		INDICATOR, VERTICAL SPEED	AEROSONIC
303-006-003		INDICATOR, DUAL TORQUE	GULL
303-006-006		INDICATOR, DUAL TORQUE	GULL
303-006-006		INDICATOR, DUAL TORQUE	GULL
30-303A	30-303A	AMPLIFIER, CONTROL	PROTECTOR
30-303A()		AMPLIFIER, CONTROL	PYROTECTOR
30-326()-()		AMPLIFIER, CONTROL	PYROTECTOR
30-3935		ASSEMBLY, INVERTER	MID-CONTINENT
304565		SENSOR, RATE - DUAL	BENDIX
304A0000-1	PS-304-1	INVERTER, STATIC	E.M.P. ELECTRONICS
305 SERIES	305 SERIES	INDICATOR, ATTITUDE GYRO	JET/AIM
30510-()	422	COMPUTER, SDC MODULE-TAS/SAT	KOLLSMAN
30542-103	999	PANEL, CABIN DISPLAY	KOLLSMAN
305520-()		COMPENSATOR, ITT	GARRETT
3057-165-2		INDICATOR, TEMPERATURE	LABEM
3057-3-131		INDICATOR, TORQUE	LABEM
3057-3-131		INDICATOR, TORQUE	LABEM
3057-3-135		INDICATOR, TORQUEMETER	LABEM
3057-3-136-()		INDICATOR, TORQUEMETER	LABEM
30680-()	575	INDICATOR, COMBINED SPEED	KOLLSMAN
30980-()	630	COMPUTER, SAT/TAS	KOLLSMAN
30980-126		COMPUTER, SAT/TAS	KOLLSMAN
30-9918		ASSEMBLY, CAPACITANCE SYSTEM	MID-CONTINENT
310-007-003		INDICATOR, DUAL TORQUE	GULL
31004-()		SWITCH, WARNING - MACH AIRSPEED	BENDIX
31006-()		SWITCH, MACH AIRSPEED WARNING	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
31007-()		SWITCH, MACH AIRSPEED WARNING	BENDIX
3105()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3106()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
31060-1114		INDICATOR, VERTICAL SPEED - CABIN	AEROSONIC
3107()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
31100()		INDICATOR, DIRECTIONAL GYRO	AERITALIA
31101		INDICATOR, DIRECTIONAL GYRO	AERITALIA
3112-A		UNIT, VACUUM WARNING	BENDIX
3115()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3116()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3117()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3117L-B2-1A	3117L-B2-1A	INDICATOR, RADIO MAGNETIC	AERONETICS
31230-1120		INDICATOR, VERTICAL SPEED	AEROSONIC
31230-1127		INDICATOR, VERTICAL SPEED	AEROSONIC
3123-3A-120		SWITCH, WARNING - FUEL PRESSURE	BENDIX
3125()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3126()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3127()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3129-1-A	C-2 & C-3	SWITCH, PRESSURE	BENDIX
3130		CATALOGUE, MISC. PARTS	JAEGER
31-304-()		INVERTER, POWER SUPPLY	SIGMA-TEK
31-304-900		GYRO, POWER SUPPLY	AMETEK
3135()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3135-6-C		SWITCH, WARNING - PRESSURE	BENDIX
3136()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3137()	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
3137LBXXX		INDICATOR, RADIO MAGNETIC	GATES LEARJET CORP.
31426-001	877	TESTER, TRANSDUCER	KOLLSMAN
318-()		TRANSMITTER, FUEL PRESSURE	EDISON
318-01X30		TRANSMITTER, PRESSURE	EDISON
3180-2	3180-2	INDICATOR, ARTIFICIAL HORIZON GYRO	BARFIELD
318-0XX10		TRANSMITTER, PRESSURE	EDISON
318-0XX50		TRANSMITTER, PRESSURE	EDISON
318-0XX50		TRANSMITTER, PRESSURE	EDISON
318-100		TRANSMITTER, OIL PRESSURE	EDISON
318-100()		TRANSMITTER, OIL PRESSURE	EDISON
318-50/50C		TRANSMITTER, PRESSURE	EDISON
318-60		TRANSMITTER, OIL PRESSURE	EDISON
32-001		INDICATOR, TURN CO-ORDINATOR GYRO	ASTRONAUTICS
32-003		ASSEMBLY, GIMBLE AND WHEEL	ASTRONAUTICS
32005-005	32005-005	GENERATOR, TACHOMETER	SMITHS
32005-007	32005-007	GENERATOR, TACHOMETER	SMITHS
320297-01-01	B1200-90001	TRANSDUCER, ALTITUDE	SMITHS
3252010-1101	AAU-31/A	ALTIMETER, COUNTER DRUM POINTER	BENDIX
3252013-()		ALTIMETER, ENCODING	BENDIX
32622-6		INDICATOR, FLOW TRANSDUCER	AEROSONIC
32638-001	880	TEST SET, SAT/TAS GENERATOR - DC ANALOG	KOLLSMAN
3265011-0101		INDICATOR, FUEL FLOW	BENDIX
3265011-0101		INDICATOR, FUEL FLOW	BENDIX
32760-()	530	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
32815-200/300	575	INDICATOR, MAX ALLOWABLE AIRSPEED -	KOLLSMAN
33050-()	420	TRANSDUCER, AIRSPEED	KOLLSMAN
33075-()	575	INDICATOR, MAX ALLOWABLE AIRSPEED -	KOLLSMAN
332-00120		INDICATOR, TORQUE PRESSURE	EDISON
33349		INDICATORS, TEMPERATURE	EDISON
33350		INDICATORS, TEMPERATURE	EDISON
3337L-B-X-X-X	3337	INDICATOR, RADIO MAGNETIC	AERONETICS
33480-011	999	CONTROLLER, CABIN DISPLAY CONVERTER	KOLLSMAN
34000	AN5773-1A	UNITS, ENGINE GAUGE	EDISON
34000-()	999	CONVERTER, CABIN DISPLAY DIGITAL	KOLLSMAN

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
34107-C1AG-13-1A3		INDICATOR, TACHOMETER	BENDIX
34108-C1AF-13-1A3		INDICATOR, TACHOMETER	BENDIX
3419-5A-A1	B-4, B-6	ACCELEROMETERS	BENDIX
34200	AN5773-2	UNITS, ENGINE GAUGE	EDISON
34200 / 34400	AN5773T2	UNITS, ENGINE GAGE	EDISON
34401-30-A22-1		TRANSMITTER, TORQUE	BENDIX
34670-()	550	INDICATOR, VERTICAL SPEED	KOLLSMAN
34670-()	550	INDICATOR, VERTICAL SPEED	KOLLSMAN
34870-0000	A-33A	ANTENNA	HONEYWELL
34970		INDICATORS, TEMPERATURE	EDISON
35000-()		UNIT, FIRE CONTROL	FENWAL
35020-1174		INDICATOR, CABIN CLIMB	AEROSONIC
35020-1174		INDICATOR, VERTICAL VELOCITY	AEROSONIC
35060-1122		INDICATOR, VERTICAL VELOCITY	AEROSONIC
35060-1175		INDICATOR, VERTICAL VELOCITY	AEROSONIC
35140-()	G-113()	GYRO, ATTITUDE	ARC
35160-1110		INDICATOR, VERTICAL VELOCITY	AEROSONIC
35180-0000	A-29C	ANTENNA	HONEYWELL
35250-()	575	INDICATOR, MAX ALLOWABLE AIRSPEED -	KOLLSMAN
35303-()		FITTINGS, WIRE END	FENWELL
35405-200/300	35405-200/300	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
35405-400/500	35405-400/500	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
35450-()		CONTROLLER, TIME TO DESTINATION DISPLAY	KOLLSMAN
35500	AN5773-2	UNITS, ENGINE GAGE	EDISON
3567401-1501		TRANSMITTER, PRESSURE (0-50 PSI)	BENDIX
3567401-3001		TRANSMITTER, PRESSURE (0-100 PSI)	BENDIX
3567401-4002		TRANSMITTER, PRESSURE	BENDIX
3567401-8801		TRANSMITTER, PRESSURE	BENDIX
3567411-()		TRANSMITTER, PRESSURE	BENDIX
3567643-4801		TRANSMITTER, PRESSURE	BENDIX
3567707-0202	7707-2-C5-1	TRANSMITTER, PRESSURE	BENDIX
3567707-0203	7707-2-D5-1	TRANSMITTER, PRESSURE	BENDIX
3567707-0701	7707-7-A5-1	TRANSMITTER, PRESSURE (0-100 PSI)	BENDIX
3567707-3001	7707-30-D5-1	TRANSMITTER, PRESSURE	BENDIX
3567707-3002	7707-30-D5-2	TRANSMITTER, PRESSURE	BENDIX
3567707-3004	7707-30-A23-1	TRANSMITTER, PRESSURE	BENDIX
3567707-3005	7707-30-B8-2	TRANSMITTER, PRESSURE	BENDIX
3567707-9801	7707-111-A25-1	TRANSMITTER, PRESSURE	BENDIX
3567707-9901	7707-99-A5-1	TRANSMITTER, PRESSURE	BENDIX
3567742-()		TRANSMITTER, SYNCHRO PRESSURE	BENDIX
3567742-()		TRANSMITTER, SYNCHRO PRESSURE	BENDIX
3567749-4001		TRANSMITTER, PRESSURE	BENDIX
3567758-()		TRANSMITTER, PRESSURE	BENDIX
3571212-()		INDICATOR, TORQUE	BENDIX
3571251-()		INDICATOR, MEASURED GAS TEMP.	BENDIX
3571251-()		INDICATOR, TURBINE OUTLET TEMPERATURE	BENDIX
3571251-()		INDICATOR, TORQUE	BENDIX
3571251-()		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3571251-9115		INDICATOR, INTER TURBINE TEMP.	BENDIX
3571251-9131		INDICATOR, INTER TURBINE TEMP.	BENDIX
3571251-9131		INDICATOR, INTER TURBINE TEMP.	BENDIX
3571251-9210		INDICATOR, FUEL PRESSURE	BENDIX
3571260-()		INDICATOR, TACHOMETER	BENDIX
3571260-7001		INDICATOR, TACHOMETER	BENDIX
3571260-8001		INDICATOR, % GAS PRODUCER TACHOMETER	BENDIX
3571260-8002		INDICATOR, % GAS PRODUCER TACHOMETER	BENDIX
3571260-8003		INDICATOR, % GAS PRODUCER TACHOMETER	BENDIX
3571261-3101		INDICATOR, TACHOMETER	BENDIX
3571261-5101		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3571262-()		INDICATOR, ELECTRICAL TACHOMATER	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
3571262-5101		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3571262-5108		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3571262-5109		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3571281-()		INDICATOR, TACHOMETER	BENDIX
3571281-8103,4		INDICATOR, TACHOMETER	BENDIX
3571281-8104		INDICATOR, TACHOMETER	BENDIX
3571320 SERIES	3571320 SERIES	INDICATOR, SYNCHRO	BENDIX
3571320-0010		INDICATOR, DUAL % TORQUE	BENDIX
3571370-0001		INDICATOR, DUAL TACHOMETER	BENDIX
3571371-()		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571371-6001		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571371-6002		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571371-9001		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571371-9002		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571371-9004		INDICATOR, TRIPLE TACHOMETER	BENDIX
3571810-()		INDICATORS	BENDIX
3571810-0003		INDICATOR, SYNCHRO	BENDIX
3571810-0007		INDICATOR, PRESSURE - OIL	BENDIX
3571810-2001,2002		INDICATOR, SYNCHRO	BENDIX
3571810-8001		INDICATOR, SYNCHRO	BENDIX
3581320-2001		INDICATOR, FUEL QUANTITY	BENDIX
3581470-()-()		INDICATOR, TURVINE DUAL TACHOMETER	BENDIX
35900-()	575	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
36	36	INDICATOR, ALTIMETER	JAEGER
36001		INDICATOR, DUAL RADIO AND MAGNETIC	BENDIX
36001		INDICATOR, DUAL RADIO MAGNETIC	BENDIX
36001-()		INDICATOR, RADIO MAGNETIC	BENDIX
36002-()		INDICATOR, RADIO MAGNETIC	BENDIX
36050-0000	IN-41A	INDICATOR, COURSE	HONEYWELL
361-()-001	GTF-1,2	TESTER, CAPACITANCE FUEL SYSTEM - FIELD	GULL
361-()-001	GTF-1,2	TESTER, CAPACITANCE FUEL SYSTEM - FIELD	GULL
3610()-1()-1()-A()		INDICATOR, RADIO MAGNETIC	BENDIX
36100		INDICATOR, GYROSCOPIC HORIZON	AERITALIA
36101		INDICATOR, GYROSCOPIC HORIZON	AERITALIA
36101		INDICATOR, DUAL RADIO AND MAGNETIC	BENDIX
36101-()		INDICATOR, RADIO MAGNETIC	BENDIX
36102		INDICATOR, RADIO MAGNETIC	BENDIX
36102-()		INDICATOR, RADIO MAGNETIC	BENDIX
36104-()		INDICATOR, RADIO MAGNETIC	BENDIX
36105		INDICATOR, DUAL RADIO AND MAGNETIC	BENDIX
36105		INDICATOR, RADIO MAGNETIC	BENDIX
36105-()		INDICATOR, RADIO MAGNETIC	BENDIX
36105-1()-()-C()		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36106		INDICATOR, DUAL RADIO AND MAGNETIC	BENDIX
36106		INDICATOR, RADIO MAGNETIC	BENDIX
36106-()		INDICATOR, RADIO MAGNETIC	BENDIX
36109-()		INDICATOR, RADIO MAGNETIC	BENDIX
36115-001	880	TEST SET, SAT/TAS INDICATOR	KOLLSMAN
36116-1		CABLE, TESTER - SAT/TAS INDICATOR	KOLLSMAN
36118-1W-19-A3		INDICATOR, CONTINENTAL COMPASS RADIO	BENDIX
36135-()		INDICATOR, RADIO MAGNETIC	AERONETICS
36135-()		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
3614278-()	CP-113()	PANELS, RADAR CONTROL	TELEPHONICS
36148-()		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36148-1AJ25A()		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36150-1L-11-A1		INDICATOR, RADIO MAGNETIC	BENDIX
36154-1AG25A()		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36154-1AH25()1		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36154-1AJ33B1		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX
36155-1AJ25A1		INDICATOR, RADIO MAGNETIC COMPASS	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
36194-X15/X19	36194-X15/X19	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
370		PRESSURE GAUGE, DIGITAL	SETRA
37070-()		COMPUTER, SAT/TAS/TAT	KOLLSMAN
371-007-001		TRANSMITTER, PRESSURE (5000 PSI)	GULL
371-007-001		TRANSMITTER, PRESSURE (5000 PSI)	GULL
371-007-002		TRANSMITTER, PRESSURE (200 PSI)	GULL
371-007-002		TRANSMITTER, PRESSURE (200 PSI)	GULL
371-007-003		TRANSMITTER, PRESSURE (150 PSI)	GULL
371-007-004		TRANSMITTER, PRESSURE (150 PSI)	GULL
37118-001		TEST SET, ALTITUDE CAPSULE	KOLLSMAN
3713246-50X	DI-3001	INDICATOR, DIGITAL	HONEYWELL
3713407-508	WA-800	PEDESTAL, ANTENNA	HONEYWELL
3713407-50X	PRIMUS-90 WXD	PEDESTAL, ANTENNA	HONEYWELL
3713527-501	MI-585201	INDICATOR, DIGITAL	HONEYWELL
3713527-502	MI-585201-1	INDICATOR, DIGITAL	HONEYWELL
3713527-507	DI-5001	INDICATOR, DIGITAL	HONEYWELL
3713527-508	DI-5001	INDICATOR, DIGITAL	HONEYWELL
3713527-509	MI-585201-2	INDICATOR, DIGITAL	HONEYWELL
3713527-50X	DI-3003	INDICATOR, DIGITAL	HONEYWELL
3713527-510	MI-585201-3	INDICATOR, DIGITAL	HONEYWELL
3713700-50X	DI-2006	INDICATOR, DIGITAL	HONEYWELL
3713717-50X	AP-3001	PEDESTAL, ANTENNA	HONEYWELL
3713725-50X	DI-3004	INDICATOR, DIGITAL - DUAL-FUNCTION	HONEYWELL
3713741-501	KB-3001	KEYBOARD, PILOT ENTRY	HONEYWELL
3713756-50X	WEATHERSCOUT	SYSTEM, DIGITAL WEATHER RADAR	HONEYWELL
3713756-50X		ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
3713756-50X		ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
3713757-50X	WEATHERSCOUT	SYSTEM, DIGITAL WEATHER RADAR	HONEYWELL
3713757-50X		ASSEMBLY, RADAR SYSTEM INDICATOR	HONEYWELL
3713847-50X	DI-9001	INDICATOR, DIGITAL	HONEYWELL
3713878-501	RT-3001	RECEIVER-TRANSMITTER	HONEYWELL
3713878-502	RT-3002	TRANSMITTER, RECEIVER	HONEYWELL
3714518-5XX	WEATHERSCOUT	SYSTEM, DIGITAL WEATHER RADAR	HONEYWELL
3714518-5XX		ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
3714518-5XX		ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
3714752-()	DI-4002	ASSEMBLY, DIGITAL INDICATOR	HONEYWELL
3714752-501	DI-2007	INDICATOR, DIGITAL	HONEYWELL
3714752-502	DI-2007	INDICATOR, DIGITAL	HONEYWELL
3714752-503	DI-2008	INDICATOR, DIGITAL	HONEYWELL
3714752-504	DI-2008	INDICATOR, DIGITAL	HONEYWELL
3714752-509	DI-2007	INDICATOR, DIGITAL	HONEYWELL
3714752-510	DI-2007	INDICATOR, DIGITAL	HONEYWELL
3714925-501	RTA-1003	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
3714925-502	RTA-1003	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
3715703-501	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715703-502	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715703-503	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715703-504	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715703-505	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715703-506	WI-800	INDICATOR, DIGITAL	HONEYWELL
3715752-501	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-501	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-502	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-502	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-503	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-503	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-504	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-504	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-505	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-505	WR-800	RECEIVER-TRANSMITTER	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
3715752-506	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-506	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-507	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-507	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-508	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-508	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-509	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3715752-509	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
3716302-501	DI-5001	INDICATOR, DIGITAL	HONEYWELL
3716302-502	DI-5001	INDICATOR, DIGITAL	HONEYWELL
371K-()-()	371K-()-()	ALTIMETER, SENSITIVE	KOLLSMAN
371P-()-01	371P-()-01	ALTIMETERS, SENSITIVE	KOLLSMAN
371P-4-01	371P-4-01	ALTIMETER, PRESSURE	KOLLSMAN
371P-4-01	371P-4-01	ALTIMETER, PRESSURE	KOLLSMAN
371P-4-01	371P-4-01	ALTIMETER, SENSITIVE	KOLLSMAN
371P-4-01	371P-4-01	ALTIMETERS, SENSITIVE	KOLLSMAN
37230-()		INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
3743333-()		INDICATOR, TRIPLE TACHOMETER	BENDIX
37500-()		INDICATOR, ALTIMETER	BADIN
37500-0841		INDICATOR, ALTIMETER	BADIN
377-4	377-4	TESTER, PITOT AND STATIC SYSTEM	CASTLEBERRY
37804-()	585	INDICATOR, FUEL FLOW	KOLLSMAN
381057-()__		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381057-06007		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381058-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381065-009		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381078-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381079-02777		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381093-02909		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381094-()		ASSEMBLY, TANK UNIT	SIMMONDS PRECISION
381094-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
381096-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
38210-()		INDICATOR, RATE OF CLIMB	BADIN
38222		INDICATOR, ELECTRICAL DIRECTIONAL GYRO	BADIN
383000-()		ASSEMBLY, INDICATOR	SIMMONDS PRECISION
383030-02434		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
383093-019		INDICATOR, REPEATER FUEL QUANTITY	SIMMONDS PRECISION
383093-019		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
38399-()		INDICATOR, AIRSPEED	BADIN
38399-()-()		INDICATOR, AIRSPEED	BADIN
384124-023		ASSEMBLY, CONTROL UNIT	SIMMONDS PRECISION
384178-()		ASSEMBLIES, SELECTOR SWITCH	SIMMONDS PRECISION
384178-()		ASSEMBLIES, SELECTOR SWITCH	SIMMONDS PRECISION
384178-()		ASSEMBLIES, SELECTOR SWITCH	SIMMONDS PRECISION
384178-056		SWITCH, SELECTOR - FUEL QUANTITY	SIMMONDS PRECISION
384178-091		SWITCH, SELECTOR - FUEL QUANTITY	SIMMONDS PRECISION
384178-103		SWITCH, SELECTOR - FUEL QUANTITY	SIMMONDS PRECISION
384178-111		SWITCH, SELECTOR - FUEL QUANTITY	SIMMONDS PRECISION
38451-004		BATTERY, NI-CAD	MARATHON
389-()		INDICATOR, TRANSMITTER TEST	EDISON
38E59-()A		VALVE, REGULATING & RELIEF	BENDIX
39007-090 SERIES	521	INDICATOR, ENCODING ALTIMETER - RADIO	KOLLSMAN
3906-1M-A1		INDICATOR, TURN & BANK GYRO	BENDIX
3906-1M-A1		INDICATOR, ELECTRIC TURN AND BANK	BENDIX
391001-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391002-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391002-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391002-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391002-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391012-01001		TRANSMITTER, LIQUID QUANTITY ENGINE OIL	BF GOODRICH

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
391012-01001		TRANSMITTER, LIQUID QUANTITY ENGINE OIL	BF GOODRICH
391019-001		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391020-001		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391030-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391031-02342		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391036-03159		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391036-03200		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391037-03160		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391037-03201		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-197		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-199		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-200		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391046-366		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391056-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391057-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391057-155		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391057-297		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391061-0323X		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391063-002		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391065-009		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391065-010		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391065-011		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391067-04679		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391087-()		ASSEMBLY, LIQUID QUANTITY TRANSMITTER	SIMMONDS PRECISION
391087-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
391088-()		TRANSMITTER, LIQUID QUANTITY	SIMMONDS PRECISION
391093-()		TRANSMITTER, FUEL QUANTITY	SIMMONDS PRECISION
3911213-()		INDICATOR, TEMPERATURE - ITT	BENDIX
3911213-9003		INDICATOR, INTER-TURBINE TEMPERATURE	BENDIX
3911213-9008		INDICATOR, TEMPERATURE - ITT	BENDIX
39270-0000	IN-41D	INDICATOR, COURSE	HONEYWELL
3929-1AG-()-1		INDICATOR, TURN & SLIP	BENDIX
393000-()		ASSEMBLY, INDICATOR	SIMMONDS PRECISION
393000-0X961		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393002-007		TECHNICAL INFORMATION - FUEL QUANTITY	SIMMONDS PRECISION
393002-009		INDICATOR, FUEL FLOW	SIMMONDS PRECISION
393002-009		TECHNICAL INFORMATION - FUEL FLOW	SIMMONDS PRECISION
393003-07206		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-01156		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-01491		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01539		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01685		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01699		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01827		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01862		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-01884		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-01884		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393004-01970		ASSEMBLIES, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
393004-051		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-036		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-037		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-037		INDICATOR, FUEL QUANTITY (RED LITES)	SIMMONDS PRECISION

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
393008-040		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-040		INDICATOR, FUEL QUANTITY (WHITE LITES)	SIMMONDS PRECISION
393008-042		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-042		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-046		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-047		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-047		INDICATOR, FUEL QUANTITY (WHITE LITES)	SIMMONDS PRECISION
393008-053		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-056		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-056		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-064		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-074		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-074		INDICATOR, FUEL QUANTITY (LONG RANGE)	SIMMONDS PRECISION
393008-077		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-078		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008082		INDICATOR, FUEL QUANTITY (RED LITES)	SIMMONDS PRECISION
393008-082		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393008-53		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393020-003		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
393020-012		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
393020-01789		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
393026-001		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-002		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-003		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-01837		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-01838		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-01840		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-01841		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-01880		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03235		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03236		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03334		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03335		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03508		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-03569		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-036		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-037		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-040		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-042		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-044		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-047		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-048		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-052		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-054		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-065		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-073		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393026-074		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393029-01412		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393029-01412		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393084-()		INDICATOR, LIQUID QUANTITY	SIMMONDS PRECISION
393084-04408,596		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
393085-43708		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393085-43708		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
393086-()		INDICATOR, QUANTITY - FUEL	SIMMONDS PRECISION
393086-01236	10-60520-5	INDICATOR, QUANTITY - FUEL	SIMMONDS PRECISION
3932		INDICATOR, TURN & SLIP GYRO	BENDIX
3932-1AG-()-1		INDICATOR, TURN & SLIP	BENDIX
3932241-()		INDICATOR, TOTALIZING DUAL FUEL QUANTITY	BENDIX
39380-()	631	UNIT, AIR DATA	KOLLSMAN
3940233-()		INDICATOR, TURBINE TACHOMETER	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
3940233-()		INDICATOR, TURBINE TACHOMETER	BENDIX
3940233-9003		INDICATOR, GAS PRODUCER TACHOMETER	BENDIX
3941231-()		INDICATOR, PROP RPM	BENDIX
3941233-()		INDICATOR, PROP RPM	BENDIX
3942333-()		INDICATOR, DUAL TACHOMETER	BENDIX
3942333-9001		INDICATOR, DUAL TACHOMETER	BENDIX
3942333-9002		INDICATOR, DUAL TACHOMETER	BENDIX
3942333-9003		INDICATOR, DUAL TACHOMETER	BENDIX
3943333-9001		INDICATOR, TRIPLE TACHOMETER	BENDIX
3943333-9002		INDICATOR, TRIPLE TACHOMETER	BENDIX
395	71010135001	VIBRATOR, ELECTRO-MECHANICAL	SENSONICS
39563-001	18-S104	BATTERY, STORAGE - NICAD	MARATHON
396-()		INDICATOR, TORQUE PRESSURE	EDISON
39600-()		INDICATOR, ENCODING ALTIMETER	BADIN
39676-1		TEST SET, DC ALTIMETER	KOLLSMAN
398()-()-01	398()-()-01	INDICATOR, DIRECTION	KOLLSMAN
39800-111/112	39800-111/112	INDICATOR, FAN SPEED	KOLLSMAN
39800-121/122	39800-121/122	INDICATOR, FAN SPEED	KOLLSMAN
39939-C2701	39939-C2701	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
39948-()	39948-B2233, 6	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
39948-E290()	39948-E290()	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
39951-213		INDICATOR, TACHOMETER - N/ROTOR	THALES
39A152-()	A152()	UNITS, CONTROL	LORAL
3B	3B	SYSTEM, ALTIMETER ALTITUDE ALERTING	SMITHS
3D1472-11		TIMER, DE-ICER	B.F.GOODRICH
3D1472-11 TIMER		SYSTEM, PNEU MATIC DE-ICING	B.F.GOODRICH
3E1150-3		TIMER, PROP. DE-ICING SYSTEM	B.F.GOODRICH
3E1150-3 TIMER		SYSTEM, ELECTRICAL PROPELLER DE-ICING	B.F.GOODRICH
3E2205-4		TIMER, DE-ICER	B.F.GOODRICH
3E2205-4 TIMER		SYSTEM, ELECTROTHERMAL PROPELLER DE-	B.F.GOODRICH
3E2205-4 TIMER		SYSTEM, ELECTROTHERMAL PROPELLER DE-	B.F.GOODRICH
3LO-453	3LO-453	SWITCH, INERTIA	INERTIA SWITCH INC.
3LO-453	3LO-453	SWITCH, INERTIA	INERTIA SWITCH INC.
400/800	400/800	SYSTEMS, SLAVED GYRO/RMI	JET/AIM
400/800	400/800	SYSTEMS, SLAVED DIRECTIONAL GYRO/RMI	JET/AIM
4000(AF)	4000(AF)	TRANSMITTER, EMERGENCY LOCATOR	POINTER SENTRY
4000(AP)	4000(AP)	TRANSMITTER, EMERGENCY LOCATOR	POINTER SENTRY
40000	40000	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
40000	40000	INDICATOR, PNEUMATIC ENCODING ALTIMETER	KOLLSMAN
4000-10	4000-10	TRANSMITTER, EMERGENCY LOCATOR	POINTER SENTRY
4000-10, -11	4000-10, -11	TRANSMITTER, EMERGENCY LOCATOR	POINTER SENTRY
4000172-()	IN-831A	INDICATOR, SITUATION DISPLAT	BENDIX
40001845-()	ART-231A	TRANSMITTER, RADAR ANTENNA-RECEIVER	BENDIX
4000186-8502	AC-844B	CONTROLLER, ALTITUDE	BENDIX
4000225-8502	2203J	CONTROLLER, ALTITUDE	BENDIX
4000225-8502	2203J	CONTROLLER, ALTITUDE	BENDIX
4000225-8503	2203K	CONTROLLER, ALTITUDE	BENDIX
4000261-()	DH-841B	INDICATOR, DIRECTOR HORIZON	BENDIX
4000299-8501	DG-817A	INDICATOR, DIRECTIONAL GYRO	BENDIX
4000369-8501	DH-861A	INDICATOR, DIRECTOR HORIZON	BENDIX
4000369-8503	DH-861A	INDICATOR, DIRECTOR HORIZON	BENDIX
4000369-8504	DH-861A	INDICATOR, DIRECTOR HORIZON	BENDIX
4000369-8505	DH-861A	INDICATOR, DIRECTOR HORIZON	BENDIX
4000401-4102	RT-241A	TRANSCIEVER, VHF COMMUNICATIONS	BENDIX
4000402-4202	RN-242A	RECEIVER, VHF NAVIGATION	BENDIX
4000403-4301	PS-243A	SUPPLY, POWER	BENDIX
4000403-4301	PS-243A	SUPPLY, POWER	BENDIX
4000404-()	IN-244A	INDICATOR, VOR/LOC	BENDIX
4000404-()	IN-244A	INDICATOR, VOR/LOC	BENDIX
4000412-()	GM-247A	GLIDESLOPE / MARKER RECEIVER	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4000413-()	IN-245A	INDICATOR, VOR/ILS	BENDIX
4000413-()	IN-245A	INDICATOR, VOR/ILS	BENDIX
4000423-0101	CD-3401A	UNIT, CONTROL DISPLAY	BENDIX
4000425-()	IU-3404A	UNIT, SYSTEM INTERFACE	BENDIX
4000458-()	IN-863A	INDICATOR, SITUATION DISPLAY	BENDIX
4000460-0501	AD-3405A	UNIT, SYSTEM INTERFACE ADAPTER	BENDIX
4000474-()	2179A	GYRO, CF ATTITUDE	BENDIX
4000493-8501	5487G	CONTROLLER, FLIGHT	BENDIX
4000494-8501	5486A	SELECTOR, MODE	BENDIX
4000495-8501	5536F	AMPLIFIER, COMPUTER	BENDIX
4000502-0101	RT-1201A	TRANSMITTER, RECEIVER	BENDIX
4000502-0101	RT-1201A	TRANSMITTER, RECEIVER	BENDIX
4000503-()	IN-1202A	INDICATOR, RADAR	BENDIX
4000503-()	IN-1202A	INDICATOR, RADAR	BENDIX
4000504-()	DA-1203A	ANTENNA, RADAR DRIVE UNIT	BENDIX
4000507-8501	5485A	CONTROLLER, FLIGHT	BENDIX
4000512-()	DH-841C	INDICATOR, ARTIFICIAL HORIZON GYRO	BENDIX
4000523-8501	3013H	SERVO, PRIMARY	BENDIX
4000523-8501	3013H	SERVO, PRIMARY	BENDIX
4000524-()	3014X-2	SERVO, TRIM	BENDIX
4000524-8510	3014X-2	SERVO, TRIM	BENDIX
4000525-1210/1212	AA-1210A/1212A	ARRAYS, OPTIONAL ANTENNA	BENDIX
4000589-5401	AD-854A	ADAPTER, TRIM	BENDIX
4000589-5401	AD-854A	ADAPTER, TRIM	BENDIX
4000595-0701	TS-1207A	TEST SET, RADAR	BENDIX
4000595-0701	TS-1207A	TEST SET, RADAR	BENDIX
4000627-()	2181D	GYRO, CF ATTITUDE	BENDIX
4000627-()	2181D-CF	GYRO, ALTITUDE	BENDIX
4000627-8101/8103	2181D-CF	GYRO, ALTITUDE	BENDIX
4000650-()	VG-865A	GYRO, REMOTE VERTICAL	BENDIX
4000651-0601	DC-3406A	CONVERTER, DISTANCE	BENDIX
4000654-()	AT-143A	ANTENNA, RADAR	BENDIX
4000763-3101	RT-131A	TRANSMITTER, RECEIVER	BENDIX
4000764-()	IN-132A	INDICATOR, RADAR	BENDIX
4000765-()	AT-133A	ANTENNA, RADAR	BENDIX
4000765-()	AT-133A	ANTENNA, RADAR	BENDIX
4000765-()	AT-133A	ANTENNA, RADAR	BENDIX
4000780-8501	4100A	SENSOR, SLIP SKID	BENDIX
4000780-8501	4100A	SENSOR, SLIP SKID	BENDIX
4000780-8502	2203J	CONTROLLER, ALTITUDE	BENDIX
4000780-8503/8504	2179A-CF	GYRO, ALTITUDE	BENDIX
4000784-()	4099B	INDICATOR, TURN & BANK	BENDIX
4000784-()	4099B	INDICATOR, TURN & BANK	BENDIX
4000790-()	DA-144A	UNIT, ANTENNA DRIVE	BENDIX
4000790-()	DA-144A	UNIT, ANTENNA DRIVE	BENDIX
4000831-0101	RT-1401A	TRANSMITTERS, RECEIVER	BENDIX
4000831-0102	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000831-0103	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000831-0104	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000831-0105	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000831-0106	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000831-0112	RT-1401B	TRANSMITTER-RECEIVER	BENDIX
4000833-()	IN-1402A	INDICATOR, RADAR	BENDIX
4000833-()	IN-1402B	INDICATOR, RADAR	BENDIX
4000843-()	DH-866A	INDICATOR, FLIGHT DIRECTOR	BENDIX
4000868-()	DH-841V	INDICATOR, DIRECTOR HORIZON	BENDIX
4000869-()	SG-832C	GYRO, REMOTE SLAVED	BENDIX
4000884-()	2179B	INDICATOR, ATTITUDE GYRO	BENDIX
4000893-()	CN-2011A	UNIT, COM/NAV	BENDIX
4000896-3201	NP-2041A	PROGAMMER, NAV COMPUTER	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4000898-()	IN-2014A/B	INDICATORS	BENDIX
4000946-()	IN-152A	INDICATOR, RADAR	BENDIX
4000964-()	IN-1102A	INDICATOR, RADAR	BENDIX
4000965-()	IN-1302A	INDICATOR, RADAR	BENDIX
4000965-()	IN-1302B	INDICATOR, RADAR	BENDIX
4000966-0101	RT-1301A	TRANSMITTERS, RECEIVER	BENDIX
4000966-0103	RT-1301B	TRANSMITTER-RECEIVER	BENDIX
4000966-0106	RT-1301B	TRANSMITTER-RECEIVER	BENDIX
4000966-0108	RT-1301B	TRANSMITTER-RECEIVER	BENDIX
4000966-0109	RT-1301B	TRANSMITTER-RECEIVER	BENDIX
4000966-0110	RT-1301B	TRANSMITTER-RECEIVER	BENDIX
4000984-()	IU-2016A	UNIT, INTERFACE	BENDIX
4000995-()	AS-2015A	PANEL, AUDIO SELECTOR	BENDIX
4000A	4000A	BATTERY, VOLTABLOC	SAFT
4000C	52D54	INDICATOR, DIRECTIONAL GYRO WITH LIGHT, TANDEM OSCILLATING AIRCRAFT	SIGMA-TEK
40-0100-()		TRANSMITTER-RECEIVER, ANTENNA	GRIMES
4001018-1	ART-161A	LIGHT, ROTATING ANTI-COLLISION	BENDIX
40-0103-()		INDICATOR, RADAR	GRIMES
4001098-()	IN-1202B	SUPPLY, EMERGENCY EXIT LIGHT POWER	BENDIX
40-0129-()		ASSEMBLY, YAW CONTROL ROD	GRIMES
4001484-901	SM-484	INDICATOR, MULTIFUNCTION COLOR	HONEYWELL
4001670-()	IN-2025B	INDICATOR, MULTIFUNCTION COLOR	BENDIX
4001670-()	IN-2025B	INDICATOR, MULTIFUNCTION COLOR	BENDIX
4001808-901	VG-14	GYRO, VERTICAL	HONEYWELL
4001808-901	VG-14	GYRO, VERTICAL	HONEYWELL
4001808-901		GYRO, VERTICAL	HONEYWELL
4001921-5101	RT-1151A	TRANSMITTER, RADAR RECEIVER-	BENDIX
4001922-()	IN-1152A	INDICATOR, COLOR RADAR	BENDIX
4001948-()	IN-1152B	INDICATOR, COLOR RADAR	BENDIX
4002531-454	HZ-454	INDICATOR, HORIZON FLIGHT DIRECTOR	HONEYWELL
4002531-901	HZ-454	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4002531-902	HZ-454	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4002531-903	HZ-454	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4002531-904	HZ-454	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4002531-905	HZ-454	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
400266-4		ISOLATOR, TEMPERATURE INDICATOR	HONEYWELL
4002963-()	RH-400	INDICATOR, RADIO MAGNETIC	MARICOPA CONTROLS
4002963-444	RH-444	INDICATOR, RADIO MAGNETIC	HONEYWELL
4002963-444	RH-444	INDICATOR, RADIO HEADING	HONEYWELL
4002963-XXX	RH-444	INDICATOR, RADIO HEADING	HONEYWELL
4003733-902	RD-350F	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4003733-903	RD-350F	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4003733-905	RD-350F	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4004437-901	RT-220	TRANSCIEVER, RADIO ALTIMETER	HONEYWELL
4004437-901	RT-220	RECEIVER-TRANSMITTER	HONEYWELL
4004437-902	RT-221	TRANSCIEVER, RADIO ALTIMETER	HONEYWELL
4004437-902	RT-221	RECEIVER-TRANSMITTER	HONEYWELL
4004437-902	RT-221	RECEIVER-TRNASMITTER	HONEYWELL
4004437-903	RT-220	TRANSCIEVER, RADIO ALTIMETER	HONEYWELL
4004437-90X	RT-22X	RECEIVER-TRANSMITTER	HONEYWELL
4004444-901	RA-210	INDICATOR, RADIO ALTIMETER	HONEYWELL
4004444-902	RA-230	INDICATOR, RADIO ALTIMETER	HONEYWELL
4004512	AT-220	ANTENNA	HONEYWELL
4004512	AT-22X	ANTENNA	HONEYWELL
4005B	4005B	INDICATOR, REMOTE ATTITUDE	SMITHS
4005H	4005H	INDICATOR, REMOTE ATTITUDE	SMITHS
4006240		INDICATOR, HYDRAULIC OIL QUANTITY	SIMMONDS PRECISION
4006451-0501	2268A-1	CAPSTAN	BENDIX
4006719-9XX		DRIVE, SERVO	HONEYWELL
4006719-9XX		DRIVE, SERVO	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4007339-901	RA-220	INDICATOR, RADIO ALTIMETER	HONEYWELL
4007339-901,902	RA-220	INDICATOR, ALTITUDE - RADIO	HONEYWELL
4007339-902	RA-220	INDICATOR, RADIO ALTIMETER	HONEYWELL
4007339-VAR / 400444	RA-2XX	INDICATOR, RADIO ALTIMETER	HONEYWELL
4007393-825/925	SPZ-500	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
4007393-911	SPZ-500C	SYSTEM, AUTOPILOT/FLIGHT DIRECTION	HONEYWELL
4007393-911/941	SPZ-500C	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
4007393-912	SPZ-500	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
4007393-915	SPZ-700	SYSTEM, AUTOPILOT/FLIGHT DIRECTOR	HONEYWELL
4007393-942	SPZ-500	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
4007393-943	SPZ-500	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
4007393-9XX	SPZ-200	SYSTEM, AUTOMATIC FLIGHT CONTROL	HONEYWELL
4007637-()	AT-22X	ANTENNA	HONEYWELL
4007637-002	AT-222	ANTENNA	HONEYWELL
4007637-002	AT-222	ANTENNA	HONEYWELL
4007637-2	AT-222	ANTENNA, RADIO ALTIMETER	HONEYWELL
4007637-2	AT-222	ANTENNA, RADIO ALTIMETER	HONEYWELL
4008515		SENSOR, AIRSPEED	HONEYWELL
4008515		SENSOR, AIRSPEED	HONEYWELL
4008519-912	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4008519-91X		COMPUTER, AUTOPILOT	HONEYWELL
4008519-94X	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4008519-9XX	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4008519-9XX	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4008519-9XX	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4008519-X25	SP-200	COMPUTER, AUTOPILOT	HONEYWELL
4009506-8501	3013J	SERVO, PRIMARY	BENDIX
4009506-8501	3013J	SERVO, PRIMARY	BENDIX
4009506-8502	3013K	SERVO, PRIMARY	BENDIX
4009506-8502	3013K	SERVO, PRIMARY	BENDIX
400965-()	IN-1302B	INDICATOR, RADAR	BENDIX
400A	400A	TRENDICATORS, DIGITAL	DORIC
4010501-1	AT-224	ANTENNA	HONEYWELL
4010504	AT-223	ANTENNA	HONEYWELL
4010504	AT-223	ANTENNA	HONEYWELL
4010504-1	AT-224	ANTENNA	HONEYWELL
4010504-1	AT-224	ANTENNA	HONEYWELL
4010657-464/901	HZ-464	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4011026-902		CONTROLLER, ENGAGE	HONEYWELL
4011049-901		CONTROLLER, MANUAL	HONEYWELL
4011098-901	VC-200	COUPLER, AIRSPEED/NAVIGATION	HONEYWELL
4011098-901	VC-200	COUPLER, AIRSPEED NAVIGATION	HONEYWELL
4012373-812	SM-710	ACTUATOR, LINEAR	HONEYWELL
4012373-817	SM-710	ACTUATOR, LINEAR	HONEYWELL
4012373-90X		ACTUATORS, LINEAR	HONEYWELL
4012384-902	VS-444	INDICATOR, VERTICAL SPEED	HONEYWELL
4012395-905		CONTROLLER, MODE SELECTOR	HONEYWELL
4013013-906	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-906	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-906	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-907	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-907	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-907	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-907	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-90X	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-90X	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-90X	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-911	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-912	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-913	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4013013-914	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-914	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-914	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-915	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013013-916	VS-200	INDICATOR, VERTICAL SPEED	HONEYWELL
4013241-901	AZ-241	COMPUTER, AIR DATA	HONEYWELL
4013241-901	AZ-241	COMPUTER, AIR DATA	HONEYWELL
4013241-901/2/3/931	AZ-241	COMPUTER, AIR DATA	HONEYWELL
4013241-931	AZ-241	COMPUTER, AIR DATA	HONEYWELL
4013241-931	AZ-241	COMPUTER, AIR DATA	HONEYWELL
4013242-708	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-716	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-73X	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-742	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-7XX	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-7XX	AZ-242	COMPUTER, AIR DATA	HONEYWELL
4013242-7XX	AZ-242	COMPUTER, AIR DATA	HONEYWELL
401324X-9XX	AZ-241 / 242	COMPUTER, AIR DATA	HONEYWELL
401324X-XXX	AZ-24X	COMPUTER, AIR DATA	HONEYWELL
401324X-XXX	AZ-24X	COMPUTER, AIR DATA	HONEYWELL
4013584-901	CC-210	CONTROLLER, COMPASS	HONEYWELL
4013584-901	CC-210	CONTROLLER, COMPASS	HONEYWELL
4013584-902	CC-210	CONTROLLER, COMPASS	HONEYWELL
4014025-()		MECHANISMS, INDICATOR	HONEYWELL
4014267-901/903	RA-215	INDICATOR, RADIO ALTIMETER	HONEYWELL
4014267-902	RA-235	INDICATOR, RADIO ALTIMETER	HONEYWELL
4015373-823	SM-600	SERVO, AILERON	HONEYWELL
4015373-824	SM-600	SERVO, ELEVATOR	HONEYWELL
4015901-903	TZ-200	COMPUTER, RUDDER TRIM	HONEYWELL
4015901-904	TZ-200	COMPUTER, ROLL TRIM	HONEYWELL
4015985-904		COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4016341-90()	BA-141	INDICATOR, BAROMETRIC ALTITUDE	HONEYWELL
4016341-903	BA-141	INDICATOR, ALTITUDE	HONEYWELL
4016341-903	BA-141	INDICATOR, BAROMETRIC ALTITUDE	HONEYWELL
4016341-904	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-904	BA-141	INDICATOR, ALTITUDE	HONEYWELL
4016341-904	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-905	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-907	BA-141	INDICATOR, BARO ALTITUDE	HONEYWELL
4016341-90X	BA-141	INDICATOR, BAROMETRIC ALTITUDE	HONEYWELL
4016341-9XX	BA-141	INDICATOR, BAROMETRIC ALTITUDE	HONEYWELL
40178-24	40178-24	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
40178-26	40178-26	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4018164-901	TD-164	TRANSDUCER	HONEYWELL
4018285-903	AL-245	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-903	AL-245	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-903/904/908	AL-245	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-906	AL-285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-906	AL-285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-906	AL-285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-90X	AL-205 / 245 / 285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-90X	AL-205 / 245 / 285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018285-90X	AL-205 / 245 / 285	CONTROLLER, ALTITUDE ALERT	HONEYWELL
4018366-901	SI-225	INDICATOR, MACH AIRSPEED	HONEYWELL
4018366-902	SI-225	INDICATOR, MACH AIRSPEED	HONEYWELL
4018366-90X	SI-225	INDICATOR, MACH AIRSPEED	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4018366-90X	SI-225	INDICATOR, MACH AIRSPEED	HONEYWELL
4018368-()	MS-500	SELECTOR, MODE	HONEYWELL
4018368-902		SELECTOR, MODE	HONEYWELL
4018368-90X	MS-500	SELECTOR, MODE	HONEYWELL
4018368-90X	MS-500	SELECTOR, MODE	HONEYWELL
4018368-90X		SELECTOR, MODE	HONEYWELL
4018368-914	MS-500	SELECTOR, MODE	HONEYWELL
4018368-914	MS-500	SELECTOR, MODE	HONEYWELL
4018368-915	MS-500	SELECTOR, MODE	HONEYWELL
4018368-9XX	MS-500	SELECTOR, MODE	HONEYWELL
4018368-9XX	MS-500	SELECTOR, MODE	HONEYWELL
4018369-902		COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-902		COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-905	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018369-90X	FZ-500	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
4018639-901	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-901	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-902	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-902		CONTROLLER, AUTOPILOT	HONEYWELL
4018639-903	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-903	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-904	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4018639-909	PC-500	CONTROLLER, AUTOPILOT	HONEYWELL
4019286-()	VG-14H	GYRO, VERTICAL	HONEYWELL
4019286-901/902	VG-14H	GYRO, VERTICAL	HONEYWELL
4019700-902	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4019700-903	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4019700-904	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4019700-905	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4019700-906	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4019700-907	AD-300C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
40200-0000	R-846A	RECEIVER	HONEYWELL
40200-000X	R-846A	RECEIVER	HONEYWELL
4020501-1XX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020501-2XX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020501-3XX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020501-4XX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020501-502	GH-14	HORIZON, GYRO	HONEYWELL
4020501-5XX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020531-XXX	GH-14(X)	HORIZON, GYRO	HONEYWELL
4020547-901	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-901	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-901	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-902	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-903	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-904	AD-600	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-905	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-906	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-906	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020547-908	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020550-901	AD-300	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020550-901	AD-300D	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4020550-903	AD-300D	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020550-904	AD-300H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020550-904	AD-300H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
4020553-901	RD-600	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4020570-901	MS-205	SELECTOR, MODE	HONEYWELL
4020570-901	MS-205	SELECTOR, MODE	HONEYWELL
4020571-903	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-904	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-904	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-904	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-904	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-904	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-905	VN-212	CONTROLLER, VNAV COMPUTER	HONEYWELL
4020571-906	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020571-90X	VN-212	COMPUTER / CONTROLLER, VNAV	HONEYWELL
4020576-901	RG-203	GYROSCOPE, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020576-901	RG-203	GYRO, RATE	HONEYWELL
4020577-3	C-14D	COMPASS, GYROSYN	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-3	C-14D	GYRO, DIRECTIONAL	HONEYWELL
4020577-6	C-14D	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
4020577-8	C-14D	GYRO, DIRECTIONAL - REMOTE	HONEYWELL
4020936-90()	TARSYN-H	REFERENCE, THREE-AXIS	HONEYWELL
4020936-901	TARSYN 555H	GYRO, REFERENCE - 3 AXIS	HONEYWELL
4020936-903	TARSYN-H	REFERENCE, THREE-AXIS	HONEYWELL
4021541-390	GH-14	HORIZON, GYRO	HONEYWELL
4021541-XXX	GH-14()	HORIZON, GYRO	HONEYWELL
4021541-XXX	GH-14()	HORIZON, GYRO	HONEYWELL
4021976		ACCELEROMETER	HONEYWELL
40220-X00X	C-846A	UNIT CONTROL	HONEYWELL
4022211-100	GH-14B	HORIZON, GYRO	HONEYWELL
4024993-905		HEAD, NAV CONTROL	HONEYWELL
4024993-90X		HEAD, CONTROL	HONEYWELL
4025008-920	SP-711	COMPUTER, HELIPILOT	HONEYWELL
4025341		COUPLER, DUAL VOR / MARKER BEACON	HONEYWELL
4025342		ANTENNA, MARKER BEACON	HONEYWELL
4025343		COUPLER, DUAL GLIDE SLOPE ANTENNA	HONEYWELL
4025344		ANTENNA, VOR / LOC	HONEYWELL
402571-901		COMPUTER / CONTROLLER, VNAV	HONEYWELL
4025782-90X	RD-600A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4026206-901	RI-106	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-901	RI-106	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-901	RI-106	CONTROLLER, REMOTE INSTRUMENT	HONEYWELL
4026206-903	RI-106	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-903	RI-106	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-904	RI-206	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-905	RI-106B	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-909	RI-406	CONTROLLER, REMOTE INSTRUMENT	HONEYWELL
4026206-90X	RI-106 / 206	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
4026206-90X	RI-106 / 206	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-90X		CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-915	RI-306	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-930	RI-406	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-9XX	RI-106	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-9XX	RI-106 / 106S / 206S	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-9XX	RI-206S	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4026206-9XX	RT-106 / 106S / 206S	CONTROLLER, INSTRUMENT REMOTE	HONEYWELL
4027170-90()	RD-500	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4027170-904	RD-500	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4027170-905	RD-500	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4027170-90X	RD-500	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4029377-901	SP-600	COMPUTER, AUTOPILOT	HONEYWELL
4029377-90X	SP-600	COMPUTER, AUTOPILOT	HONEYWELL
4029516-4XX	ZC-200	CONTROLLER, FLIGHT DIRECTOR COMPUTER/	HONEYWELL
4029516-5XX	ZC-220	CONTROLLER, FLIGHT DIRECTOR COMPUTER/	HONEYWELL
4029529-90()	RD-500A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4029529-90X	RD-500A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4030182-901	AC-702	SENSOR, ALTITUDE	HONEYWELL
4031474-903	AN-600	PANEL, AUTOPILOT STATUS	HONEYWELL
4031474-910	AN-600	PANEL, AUTOPILOT STATUS	HONEYWELL
4031475-801	SZ-600	COMPUTER, STABILITY AUGMENTATION	HONEYWELL
4031607-907	RT-100A	TRANSCEIVER, RADIO ALTIMETER	HONEYWELL
4031608-901	RA-100A	INDICATOR, RADIO ALTIMETER	HONEYWELL
4031609-902	DS-125	INDICATOR, TAS TEMPERATURE	HONEYWELL
4031609-902	DS-125	INDICATOR, TAS TEMPERATURE	HONEYWELL
4031609-903	DS-125	INDICATOR, TAS TEMPERATURE	HONEYWELL
4031609-904	DS-125	INDICATOR, TAS TEMPERATURE	HONEYWELL
4031609-90X	DS-125	INDICATOR, TAS TEMPERATURE - VERTICAL	HONEYWELL
4031609-90X	DS-125	INDICATOR, TAS TEMPERATURE - VERTICAL	HONEYWELL
4032211-904	RD-600B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
4033089-901	FZ-702	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
404437-902	RT-221	TRANSMITTER, RADIO ALTIMETER RECEIVER	HONEYWELL
404437-902	RT-221	TRANSMITTER, RADIO ALTIMETER RECEIVER	HONEYWELL
4044C	4044C	INDICATOR, COURSE	SMITHS
4050	4050	BATTERY, VOLTABLOC	SAFT
40-603-1		INDICATOR, POWERED FLIGHT CONTROL	MEGGITT AVIONICS
40-603-2		INDICATOR, POWERED FLIGHT CONTROL	MEGGITT AVIONICS
40-603-3		INDICATOR, POWERED FLIGHT CONTROL	MEGGITT AVIONICS
40-603-4		INDICATOR, POWERED FLIGHT CONTROL	MEGGITT AVIONICS
40-603-4		INDICATOR, POWERED FLIGHT CONTROL	MEGGITT AVIONICS
4061400-902		TRANSPONDER, MODE S	HONEYWELL
407	407	AMPLIFIER, AUDIO CONTROL	DB SYSTEMS, INC.
4071X1	4071X1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4076	4076	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4076-1	4076-1	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4078-24	4078-24	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4078-3	4078-3	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
4085A	4085A	INDICATOR, COMPUTER	SMITHS
40980-1XXX	IN-346A/B	INDICATOR, GONIOMETER	HONEYWELL
4099B/B4050	4099B/B4050	PICKOFF	KELLY
40AD14		INDICATOR, OIL TEMPERATURE RISE	SUNDSTRAND
40AD14/22		BULB, TEMPERATURE	SUNDSTRAND
40AD20		SWITCH, THERMAL	SUNDSTRAND
40AD22		INDICATOR, DUAL TEMPERATURE	SUNDSTRAND
41-()-()		INDICATOR, PROP RPM	MEGGITT AVIONICS
41-()-1		INDICATOR, INTERSTAGE TURBINE TEMP.	MEGGITT AVIONICS
41000-X000	L-346A / 846A	ANTENNA	HONEYWELL
41105-C5A-4-E3		INDICATOR, DUAL TACHOMETER	BENDIX
41-201-1		INDICATOR, TORQUE	MEGGITT AVIONICS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
41-201-1		INDICATOR, TORQUE	MEGGITT AVIONICS
41-30(-)()		INDICATOR, PROP RPM	MEGGITT AVIONICS
41-308-1		INDICATOR, PROP RPM	MEGGITT AVIONICS
41360-1XXX	IN-346C/D	INDICATOR, GONIOMETER	HONEYWELL
41-40()-1		INDICATOR, INTERSTAGE TURBINE	MEGGITT AVIONICS
41-401-1		INDICATOR, INTERSTAGE TURBINE TEMP	MEGGITT AVIONICS
4165-21-A25	F-2	PRESSURE, FUEL AND OIL	BENDIX
4166-28-A25(-)	E-5	PRESSURE, FUEL AND OIL	BENDIX
418-02084		TRANSMITTER, OIL PRESSURE	EDISON
418-09064		TRANSMITTER, TORQUE PRESSURE	EDISON
41830		INDICATOR, ROTOR RPM TACHOMETER	THALES
4194-00(-)		ACTUATOR, MOTOR DRIVEN	DUKES
4194-00(-)		ACTUATOR, MOTOR DRIVEN	DUKES
4-2015(-)	FC-110()	SYSTEM, CONTROL - AUTO-FLIGHT	JET ELECTRONICS
4215-01		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4215-02		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4215-04		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4215-05		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4215-07		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4215-08		DIGITAL CALIBRATION TRIM UNIT	SMITHS
4224ZR21		SWITCH, PRESSURE - CABIN DIFFERENTIAL	THALES
4224ZR6		SWITCH, PRESSURE - CABIN DIFFERENTIAL	THALES
4232ZR5		SWITCH, PRESSURE - CABIN DIFFERENTIAL	THALES
42370		INDICATOR, ROTOR RPM TACHOMETER	THALES
4257-19-01		SYNCHRO, RECEIVER	MEGGITT AVIONICS
4273-38-03		SYNCHRO, TRANSMITTER	MEGGITT AVIONICS
4277-07		SYNCHRO, CONTROL TRANSFORMER	MEGGITT AVIONICS
428-0405-00	327D-1W	INDICATOR, TRIM	COLLINS
428-0405-00	327D-1W	INDICATOR, TRIM	COLLINS
42-903()	903BD()_	INDICATOR, GYROSCOPIC HORIZON	THALES
42-903()	903BD()_	INDICATOR, GYROSCOPIC HORIZON	THALES
42-904	904	INDICATOR, GYROSCOPIC HORIZON	THALES
42-904	904	INDICATOR, GYROSCOPIC HORIZON	THALES
42960		INDICATOR, ROTOR RPM TACHOMETER	THALES
42965		INDICATOR, ROTOR RPM TACHOMETER	THALES
42-99V11	923V11	INDICATOR, GYROSCOPIC HORIZON	THALES
42A12()	42A12()	TEST SETS	DUKANE CORP.
42D166_	42D166_	SWITCH, PRESSURE	CUSTOM COMPONENT
42D208-()	42D208-()	SWITCH, PRESSURE	CUSTOM COMPONENT
43-()-1		INDICATOR, TORQUE	MEGGITT AVIONICS
43-()-1		INDICATOR, TURBINE RPM	MEGGITT AVIONICS
4300-6980L		HORIZON, ARTIFICIAL - ELECTRIC	MID-CONTINENT
4300-8025-L		GYRO, ATTITUDE	MID-CONTINENT
4300-8170-1L		INDICATOR, ATTITUDE	MID-CONTINENT
4300-8220L		HORIZON, ARTIFICIAL - ELECTRIC	MID-CONTINENT
4300-XXX		INDICATOR, ELECTRIC ATTITUDE	MID-CONTINENT
4305-7150L		INDICATOR, DIRECTIONAL	MID-CONTINENT
4305-8175-1L		INDICATOR, DIRECTIONAL GYRO	MID-CONTINENT
43-20(-)-1		INDICATOR, TORQUE	MEGGITT AVIONICS
43-30(-)-1		INDICATOR, TURBINE RPM	MEGGITT AVIONICS
43310-0000	AA-801A	ALERTER, ALTITUDE	ARC
4349-150-80-10	C16268AB	INDICATOR, TRIM POSITION - RUDDER	BRION-LEROUX
4350-150-80-10	C16269AB	INDICATOR, TRIM POSITION - AILERON	BRION-LEROUX
436-2		INDICATOR, DE-ICING PSI	INSTRUMENTS INC.
4369-100-()		PANEL ASSEMBLY, MASTER CAUTION	MASTER SPECIALTIES
437	437	AMPLIFIER, AUDIO CONTROL	DB SYSTEMS, INC.
438023-2	6829276	INDICATOR, TORQUE	TEXAS INSTRUMENTS
438023-2	6829276	INDICATOR, TORQUE	TEXAS INSTRUMENTS
438023-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
438023-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
43910-1000	IN-442AR	INDICATOR, COURSE	HONEYWELL
43910-1100	IN-442BR	INDICATOR, COURSE	HONEYWELL
43910-2000	IN-443AR	INDICATOR, COURSE	HONEYWELL
43910-2100	IN-443BR	INDICATOR, COURSE	HONEYWELL
43B0()	43B0()	BATTERY, CADMIUM-NICKEL STORAGE	SAFT
43B0()		BATTERY, NI-CD__	GENERAL ELECTRIC
44090-084X-01		INDICATOR, AIRSPEED	BADIN
44090-0941-()		INDICATOR, AIRSPEED	BADIN
44090-2941-()		INDICATOR, AIRSPEED	BADIN
44090-2948		INDICATOR, AIRSPEED	BADIN
4415-300-()		PANEL, MASTER CAUTION	MASTER SPECIALTIES
4428-150-80-()		INDICATOR, FLAP POSITION	BRION-LEROUX
443147-2	6829274	INDICATOR, TORQUE	TEXAS INSTRUMENTS
443147-2	6829274	INDICATOR, TORQUE	TEXAS INSTRUMENTS
443147-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
443147-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
4440A	4440A	INDICATOR, ENCODING ALTIMETER	SMITHS
447-202-001		ASSEMBLY, MECHANISM	GULL
44929-013	44929-013	INDICATOR, ALTIMETER PNEUMATIC ENCODING	KOLLSMAN
44929-412	44929-412	INDICATOR, ALTIMETER PNEUMATIC ENCODING	KOLLSMAN
44929-903	44929-903	ALTIMETER, ENCODING	KOLLSMAN
44929-935	44929-935	INDICATOR, ALTIMETER PNEUMATIC ENCODING	KOLLSMAN
45100-()	45100-()	INDICATOR, ALTITUDE ALERTER	KOLLSMAN
45100-()		ALERTER, ALTITUDE	KOLLSMAN
451318AF-AS-4/20-50		TRANSDUCER, PRESSURE	CONRAC
454-00158-000		GYROSCOPE, VERTICAL	SFIM
454-00162-000		GYROSCOPE, VERTICAL	SFIM
455-042X-()	110-406()	TRANSMITTER, EMERGENCY LOCATOR	ARTEX
45680-0000	C-1046A	UNIT, CONTROL	HONEYWELL
45700-000X	R-1048A/B	RECEIVER, NAVIGATION	HONEYWELL
45720-0000	C-1048A	UNIT, CONTROL	HONEYWELL
457400EA03()		INDICATOR, VERTICAL SPEED - TCAS/RA/TA	THALES
458-()-00	357D-1()	INDICATOR, TRIM	COLLINS
458-()-00	357D-1()	INDICATOR, TRIM	COLLINS
458-0296-00	327D-2	INDICATOR, TRIM	COLLINS
458-0297-00	327D-1	INDICATOR, TRIM	COLLINS
458-0405-00	327D-1W	INDICATOR, TRIM	COLLINS
458-0405-00	327D-1W	INDICATOR, TRIM	COLLINS
458-0405-00	327D-1W	INDICATOR, TRIM	COLLINS
458-0405-000	327D-1W	INDICATOR, TRIM	COLLINS
458572	RG20E40	GYROSCOPE, RATE	NORDEN
458572	RG20E40	GYROSCOPE, RATE	NORDEN
4619-()-00-()		INDICATOR, LOAD - SLING	BRION-LEROUX
4619-777-00-10		INDICATOR, LOAD - SLING	BRION-LEROUX
46500-0000	RT-1038A	RECEIVER-TRANSMITTER	HONEYWELL
46880-1210	IN-1048A	INDICATOR, COURSE	HONEYWELL
46880-1310	IN-1048AC	INDICATOR, COURSE	HONEYWELL
46880-2210	IN-1049A	INDICATOR, COURSE	HONEYWELL
46880-2310	IN-1049AC	INDICATOR, COURSE	HONEYWELL
46B	46B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
471019		INDICATOR, FAN SPEED	SIMMONDS PRECISION
472015		TRANSMITTER, FLOW METER	SIMMONDS PRECISION
472015		TECHNICAL INFORMATION - FLOW TRANSMITTER	SIMMONDS PRECISION
472016		TECHNICAL INFORMATION - FLOW TRANSMITTER	SIMMONDS PRECISION
472017		INDICATOR, INTERTURBINE TEMPERATURE	SIMMONDS PRECISION
472017		TECHNICAL INFORMATION - ITT	SIMMONDS PRECISION
472018		INDICATOR, TURBINE SPEED	SIMMONDS PRECISION
472018		TECHNICAL INFORMATION - TURBINE SPEED	SIMMONDS PRECISION
472019		TECHNICAL INFORMATION - FAN SPEED	SIMMONDS PRECISION
472020		INDICATOR, OIL TEMPERATURE	SIMMONDS PRECISION

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
472020		TECHNICAL INFORMATION - OIL TEMP.	SIMMONDS PRECISION
472021		INDICATOR, OIL PRESSURE	SIMMONDS PRECISION
472021		TECHNICAL INFORMATION - OIL PRESSURE	SIMMONDS PRECISION
473203-001		CONDITIONER, SIGNAL	SIMMONDS PRECISION
473215-001		CONDITIONER, FUEL QUANTITY & LEVEL SENSING	SIMMONDS PRECISION
473215-001		CONDITIONER, SIGNAL	SIMMONDS PRECISION
473382		CONDITIONER, SIGNAL	SIMMONDS PRECISION
473393		TRANSMITTER, QUANTITY - FUEL	SIMMONDS PRECISION
473393		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
477-272-001		ASSEMBLY, MECHANISM	GULL
47B	47B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
47B()	47B()	INDICATOR, THERMOMETER	LEWIS
4-8020-()	4-8020	GYRO, DIRECTIONAL - REMOTE	JET ELECTRONICS
482-000X-()	332C-1/2	INDICATOR, DUAL RADIO MAGNETIC	COLLINS
482-0011-010/020	332C-8	INDICATOR, RADIO MAGNETIC HEADING	COLLINS
482-0011-0X0	332C-8	INDICATOR, RADIO MAGNETIC HEADING	COLLINS
482-0047-00	331H-1	INDICATOR, COURSE SELECTOR	COLLINS
482-0061-000	332C-4	INDICATOR, RADIO MAGNETIC	COLLINS
48707-()	48707-()	INDICATOR, SERVOE PNEUMATIC ALTIMETER	KOLLSMAN
48750-()		INDICATOR, RATE OF CLIMB	BADIN
49-2000-()		CLUSTER, INSTRUMENT	KELLY
49-2000-31		CLUSTER, ENGINE	KELLY
49522		EXCITER, IGNITION	SIMMONDS PRECISION
496-01730		INDICATOR, FUEL PRESSURE	EDISON
496-01740		INDICATOR, OIL PRESSURE	EDISON
49B	49B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
5000	5000	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
50-001-14		INDICATOR, TURN CO-ORDINATOR GYRO	ASTRONAUTICS
5000E-8	52D66	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
5000E-9	52D67	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
5000L	5000L	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
500E2 SERIES	500E2 SERIES	INDICATOR, HORIZON REFERENCE	JET/AIM
5010	B-2	INCLINOMETER	JAEGER
501-0001-911	300-7CF	INDICATOR, DIRECTOR HORIZON	JET/AIM
501-1005-01		GYRO, VERTICAL	JET ELECTRONICS
501-1006-()	VN-202()	GYRO, VERTICAL - REMOTE VERTISYN	JET ELECTRONICS
501-1033-()	RG-227()	GYRO, RATE - REMOTE	JET ELECTRONICS
501-1036-()	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1043-01	PS-800	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1063-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1075-01 THRU-16	PS-823	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1078-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1105-()	AI-804()	INDICATOR, ATTITUDE GYRO (115VAC)	JET ELECTRONICS
501-1113-01	VG-204D	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1114-01	VG-206A	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1114-02	VG-206E/L	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1115-01	AM-101	AMPLIFIER, SERVO	JET ELECTRONICS
501-1116-01	VG-206B	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1116-02	VG-206F/L	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1120-01	VG-204F	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1121-01	VG-208	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1125-01	VG-204G	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1131-01	AI-803M/W	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1131-02	AI-803M/R	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1142-()	AD-101()	COMPUTER, AIR DATA	JET ELECTRONICS
501-1142-()	AD-102()	SENSOR, AIR DATA	JET ELECTRONICS
501-1149-01	DG-106D	GYRO, DIRECTIONAL - REMOTE	JET ELECTRONICS
501-1150-01	VG-206C	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1150-02	VG-206G/L	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1160-01	VG-204L	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
501-1162-()	DN-104()	GYRO, DIRECTIONAL - REMOTE DIRECTISYN	JET ELECTRONICS
501-1169-()	RG-227()	GYRO, RATE - REMOTE	JET ELECTRONICS
501-1170-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1179-()	PL-100()	ADAPTER, PHASE LOCK	JET ELECTRONICS
501-1197-()	AI-804()	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1204-01	VG-206D	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1209-01	VG-208	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1210-01	VG-208	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1219-01	AI-803S	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1224-01	VG-204V	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1224-02	VG-204Z	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1228-()	PS-835	SUPPLY, EMERGENCY POWER	GOODRICH AEROSPACE
501-1228-()	PS-835	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1235-01	SI-1250A	INVERTER, STATIC	JET ELECTRONICS
501-1237-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1240-()	SI-100()	INVERTER, STATIC	JET ELECTRONICS
501-1242-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1249-01	SI-1500A	INVERTER, STATIC	JET ELECTRONICS
501-1251-()	RAI-302()	INDICATOR, ATTITUDE - REMOTE	JET ELECTRONICS
501-1255-01	VG-204Y	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1267-01	RAI-303()	INDICATOR, ATTITUDE - REMOTE	JET ELECTRONICS
501-1287-()	AV-500()	VERTICAL ACCELEROMETER	JET ELECTRONICS
501-1292-01	RAI-303()	INDICATOR, ATTITUDE - REMOTE	JET ELECTRONICS
501-1294-01	RAI-303()	INDICATOR, ATTITUDE - REMOTE	JET ELECTRONICS
501-1295-()	AI-804()	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1296-()	AI-804()	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1297-01	AI-904AD	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1318-01	SC-841A	CONVERTER, STATIC	JET ELECTRONICS
501-1321-01	BC-815A	CHARGER, BATTERY	JET ELECTRONICS
501-1386-01	AI-803AF	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1412-()	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1413-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1423-01	AI-803AH	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1426-()	AI-904	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1453-01	VG-204AB	GYRO, VERTICAL DISPLACEMENT - REMOTE	JET ELECTRONICS
501-1455-()	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1568-()	AI-330	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1646-01	AI-803BH	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1648-01	AI-804BF	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1648-02	AI-804()	INDICATOR, ATTITUDE GYRO (28VDC)	JET ELECTRONICS
501-1682-01	PS-834	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1712-()	PS-855()	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1719-()	PS-850()	SUPPLY, EMERGENCY POWER	JET ELECTRONICS
501-1753-()	ADI-335()	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
501-1798-()	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1811-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1812-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1828-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1838-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1844-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1848-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
501-1850-01	AI-804()	INDICATOR, ATTITUDE	JET ELECTRONICS
502-2270-06	AI-904P/G	INDICATOR, ATTITUDE GYRO	JET ELECTRONICS
50234		TRANSMITTER, HYDRAULIC PRESSURE	KRATOS
502BL10	EHU-15/A	INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
502BL10A	EHU-15A/A	INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
502BL3	MS24569-1	INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
50309-008	50309-008	UNIT,BUS BAR PROTECTION	SMITHS
5035()	5035 SERIES	INDICATOR, ENCODING ALTIMETER	UNITED INSTRUMENTS
50-389102		INDICATOR, TEMPERATURE	BEECHCRAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
50-389102-1		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-11		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-15		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-17		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-19		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-21		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-23		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-25		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-3		INDICATOR, TEMPERATURE	BEECHCRAFT
50-389102-9		INDICATOR, TEMPERATURE	BEECHCRAFT
504-0002-902	500ECF	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-902	500ECF-2	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-902	500ECFK	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-902	500ECFK-2	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-920	500E2C*	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-926	500E4A	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0002-926	500E4A	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0006-914	300-14()	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0006-92X	300-15()	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0016-903	300-18A	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0017-901	510-1A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-901	510-1C	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-903	510-3A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-905	510-5()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-910	510-10A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-910	510-10B	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-911	510-10C	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-913	510-17A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-913	510-17A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-914	510-17B	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-914	510-17B	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-916	510-8B	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-917	510-8C	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-927	510-8AB	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-933	510-1P	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-934	510-1R	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-9XX	510-1()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0017-9XX	510-8()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0018-90X	310-1A()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0018-90X	310-2()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0021-903	500ECFL-2	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0021-908	500ECFL-2A	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0021-913	500ECFL	INDICATOR, HORIZON REFERENCE	JET/AIM
504-0024-901	510-21A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0024-902	510-21B	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0024-903	510-21C	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0024-904	510-21D	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0024-90X	510-21()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0027-901	900-23V()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0027-901	900-23V()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0028-909	510-22J	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0028-90X	510-22()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0028-912	510-22M	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0028-913	510-22N	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0028-9XX	510-22()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0029-90X	700-6CF()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0029-90X	700-7CF()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0029-90X	700-7ECF()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-901	510-24A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-902	510-24B	INDICATOR, ATTITUDE GYRO	JET/AIM

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
504-0030-903	510-24C	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-904	510-24()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-909	510-24J	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-909	510-24J	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-910	510-24K	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-910	510-24K	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-911	510-24L	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-911	510-24L	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-912	510-24M	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-912	510-24M	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-913	510-24N	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-913	510-24N	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-914	510-24P	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-920	510-24L2	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0030-9XX	510-24()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-901	510-25A	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-909	510-27H	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-910	510-27J	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-911	510-27K	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-912	510-27L	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-913	510-27M	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-914	510-27N	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0031-9XX	510-27()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0032-90X	505-DCF()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0032-9XX	505-2C()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0032-9XX	505-A()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-91X	305-2C()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-92X	305-IC()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-933	305-2BC	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-93X	305-2C()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-9XX	302-2()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-9XX	305-1()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0033-9XX	305-2()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0035-9()	520-()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0035-9()	520-()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0037-90X	510-29()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0038-91X	510-17()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0038-9XX	510-30()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0041-90X	510-31()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0042-90X	510-32()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0043-901	510-33()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0044-901	510-34()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0045-901	510-35A	GYRO, ATTITUDE	JET/AIM
504-0045-902	510-35B	GYRO, ATTITUDE	JET/AIM
504-0045-903	510-35C	GYRO, ATTITUDE	JET/AIM
504-0045-904	510-35D	GYRO, ATTITUDE	JET/AIM
504-0045-90X	510-35()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0046-901	510-36A	GYRO, ATTITUDE	JET/AIM
504-0048-901	510-37A	INDICATOR, ATTITUDE	JET/AIM
504-0048-901	510-37A	GYRO, ATTITUDE	JET/AIM
504-0048-903	510-37C	GYRO, ATTITUDE	JET/AIM
504-0051-901	510-37B	GYRO, ATTITUDE	JET/AIM
504-0051-901	510-39A	GYRO, ATTITUDE	JET/AIM
504-0051-90X	510-39()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0052-901	510-40A	GYRO, ATTITUDE	JET/AIM
504-0052-90X	510-40()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0053-90X	510-41()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-0057-901	510-44A	GYRO, ATTITUDE	JET/AIM
504-0057-90X	510-44()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-00XX-9XX	500EFCB()-()	INDICATOR, ELECTRIC ATTITUDE	JET/AIM

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
504-011()-9()()	1100-()	INDICATOR, ATTITUDE GYRO	JET/AIM
504-9004-9XX	300-9()	HORIZON, FLIGHT DIRECTOR	JET/AIM
504CUF		INDICATOR, ALTITUDE ALERTER	SMITHS
505 SERIES	505 SERIES	INDICATOR, ATTITUDE GYRO	JET/AIM
505-0002-01		ASSEMBLY, GYRO ROTOR	KELLY
505-0002-922	200-8DCL	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0010-9XX	200-DCL()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0021-()	289-8()	GYRO, DIRECTIONAL	JET/AIM
505-0028-091	250	INDICATOR, REMOTE SLAVED DIRECTIONAL	JET/AIM
505-0031-9()()	205 SERIES	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0031-90X	205-1()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0031-90X	205-1()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0031-91X	205-2()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0031-9XX	205-2()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0032-90X	210-17A()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505-0032-90X	210-18A()	INDICATOR, DIRECTIONAL GYRO	JET/AIM
505458-1	6852536	INDICATOR, TORQUE	TEXAS INSTRUMENTS
50579		TRANSMITTER, PRESSURE	KRATOS
506	506	INDICATOR, VOLT / AMMETER	AMETEK
506/606	506/606	INDICATOR, VOLT / AMMETER	AMETEK
506-0026-90X	254-13	DETECTOR, FLUX	JET/AIM
506-2239-005	331A-2	INDICATOR, COURSE	COLLINS
50652-()/ (MOD-2)		TRANSMITTER, PRESSURE	NEGRETTI & ZAMBRA LTD
506X-1-X		SYSTEM, INTEGRATING AUDIO	AVTECH
507-0020-91X	TC-120-5	INDICATOR, TURN COORDINATOR	JET/AIM
5079-1		SYSTEM, ADDRESS/CABIN INTERPHONE	AVTECH
508X-1-X		SYSTEM, ADDRESS/CABIN INTERPHONE	AVTECH
509-0001-921	TS-200-9()	INDICATOR, TURN & SLIP	JET/AIM
509-0002-90X	TS-300-1()	INDICATOR, TURN & SLIP	JET/AIM
509-0003-90X	TS-300-2()	INDICATOR, TURN & SLIP	JET/AIM
509-0004-9XX	TS-400-1A()	INDICATOR, ELECTRIC TURN AND SLIP	JET/AIM
510 SERIES	510 SERIES	INDICATOR, ATTITUDE GYRO	JET/AIM
510 SERIES	510 SERIES	INDICATOR, ATTITUDE GYRO	JET/AIM
51010-1113		INDICATOR, CABIN PRESSURE	AEROSONIC
510604B01M03	DA-810	DATA ACQUISITION UNIT	HONEYWELL
51065-()	51065-()	REGULATOR, VOLTAGE	SMITHS
51065-()	51065-()	REGULATOR, VOLTAGE	SMITHS
511-()	35	INDICATOR, ALTIMETER	JAEGER
51-1226		INDICATOR, BATTERY TEMPERATURE	KELLY
51-1226-1		INDICATOR, BATTERY TEMPERATURE	KELLY
511-7		TACHOMETER, DUAL	INSTRUMENTS INC.
511-95()	55	ALTIMETERS	JEAGER
51-2004-()		INDICATOR, CABIN TEMPERATURE	KELLY
512-01		TACHOMETER, DUAL	INSTRUMENTS INC.
514-()		SPECIFICATION, PROCUREMENT	JET ELECTRONICS
515 CUF/()		SELECTOR, ALTITUDE	SMITHS
51509-001	51509-001	REGULATOR, VOLTAGE	SMITHS
51509-002()	51509-002()	REGULATOR, VOLTAGE	SMITHS
51509-006B/Z	51509-006B/Z	REGULATOR, VOLTAGE	SMITHS
51522-()	51522-()	CONTROLLER, DC GENERATOR REGULATOR/	SMITHS
51522-()	51522-()	CONTROLLER, DC GENERATOR REGULATOR/	SMITHS
51528-000()	51528-000()	REGULATOR, VOLTAGE	SMITHS
51530-()	51530-()	UNITS, DC GENERATOR CONTROL	SMITHS
51530-001	51530-001	REGULATOR, VOLTAGE	SMITHS
51538-001A	51538-001A	UNIT, DC GENERATOR CONTROL	SMITHS
51538-001A	51538-001A	UNIT, DC GENERATOR CONTROL	SMITHS
51565-()	51565-()	REGULATOR, VOLTAGE	SMITHS
51565-016()	51565-016()	REGULATOR, VOLTAGE	SMITHS
51608-002	51608-002	UNIT, AC GENERATOR CONTROL	SMITHS
51610-0006	C-1046B	UNIT, CONTROL	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
51630-0000	C-1048B	UNIT, CONTROL	HONEYWELL
51640-0000	G-549A	INDICATOR, ATTITUDE GYRO	HONEYWELL
51640-0008	G-549A	INDICATOR, ATTITUDE GYRO	HONEYWELL
51640-0010	G-549B	INDICATOR, ATTITUDE GYRO	HONEYWELL
51640-0016	G-549B	INDICATOR, ATTITUDE GYRO	HONEYWELL
51-9000()		UNIT, BATTERY TEMPERATURE	KELLY
51-9002		TEMPERATURE, BATTERY MONITOR	KELLY
519-22702-()		ALTIMETER, ENCODING	IDC
51B2214/1		INDICATOR, CABIN TEMPERATURE	KELLY
5-2000-()	DN-101()	GYRO, DIRECTIONAL - REMOTE DIRECTISYN	JET ELECTRONICS
520-0250-()	250	INDICATOR, RADIO MAGNETIC	AERONETICS
520-0250-000	RMI-250	INDICATOR, RADIO MAGNETIC	AERONETICS
520-0875-006	346D-1	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
520-1351-008	ID-1351	INDICATOR, BEARING DISTANCE HEADING	AERONETICS
520192	1122-50LW	INDICATOR, RPM%	AMETEK
520-210()-00()	2100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
520223	1824-28LW	INDICATOR, ANTI-ICE PRESSURE	AMETEK
520-3150-002	HSI-315A	INDICATOR, HORIZONTAL SITUATION - STBY	AERONETICS
520-31XX-XXXX	3100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
520-41XX-XXX	4100 SERIES	INDICATOR, RADIO MAGNETIC	AERONETICS
520-5160-()	CDI-5160()-()	INDICATOR, COURSE SELECTOR	AERONETICS
520-7100-001	7100 SERIES	UNIT, DUAL CONVERTER ELECTRONICS - NO	AERONETICS
520-7100-002	7100 SERIES	UNIT, DUAL CONCERTER ELECTRONICS -	AERONETICS
520-8100-001	8000 SERIES	SYSTEM, HSI SLAVED COMPASS	AERONETICS
520-8140-()	8140	DETECTOR, MAGNETIC FLUX	AERONETICS
520-9100-()	9100	GYRO, DIRECTIONAL - REMOTE	AERONETICS
520-9110-()	9110	ACCESSORY, SLAVING	AERONETICS
521164		INDICATOR, TEMPERATURE	AMETEK
521216	1825-18	INDICATOR, ENGINE OIL TEMPERATURE &	AMETEK
521299	1822-120LW	INDICATOR, BATTERY TEMPERATURE	AMETEK
521-3120-004	344C-1D	AMPLIFIER, INSTRUMENT	COLLINS
521372	1825-21	INDICATOR, OIL TEMP / PRESSURE (DUAL)	AMETEK
521389	1822-124LW	INDICATOR, OUTSIDE AIR TEMPERATURE	AMETEK
521644		LOADMETER, D.C.	AMETEK
521677	1812-11LW	INDICATOR, AILERON TRIM	AMETEK
521679	1812-12LW	INDICATOR, RUDDER TRIM	AMETEK
521696	1812-151LW	INDICATOR, AIR CONDITIONING TEMPERATURE	AMETEK
521701	1812-14LW	INDICATOR, LUBE OIL TEMPERATURE	AMETEK
521716	1822-152LW	INDICATOR, FLAP POSITION WITH AIDS	AMETEK
522-()-()	351B-()	MOUNT, SERVO	COLLINS
522-()-00	334D-2-33()	SERVO, TRIM TAB	COLLINS
522-()-00	334D-2-33()	SERVO, TRIM TAB	COLLINS
522-()-00	334D-2-33()	SERVO, TRIM TAB	COLLINS
522-()-00	334D-2-33()	SERVO, TRIM TAB	COLLINS
522-()-00	614E-2()	CONTROLLER, PEDESTAL	COLLINS
522-()-003	334D-1-()	SERVO, TRIM TAB	COLLINS
522-()-004	562A-5/5A	COMPUTER, STEERING	COLLINS
522-()-004	562A-5/5A	COMPUTER, STEERING	COLLINS
522-()-004	614L-()	UNITS, CONTROL	COLLINS
522-()-004	614L-()	UNITS, CONTROL	COLLINS
522-()-004	618M-1()	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-()-004	618M-1()	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-()-005	331A-4()	INDICATOR, COURSE	COLLINS
522-()-005	331A-4()	INDICATOR, COURSE	COLLINS
522-()-005	331A-4()	INDICATOR, COURSE	COLLINS
522-()-005	336A-3/3W/3A	SELECTOR, OMNIBEARING	COLLINS
522-()-005	336A-3/3W/3A	SELECTOR, OMNIBEARING	COLLINS
522-()-005	338B-1/1A	INDICATOR, DOPPLER	COLLINS
522-()-005	338B-1/1A	INDICATOR, DOPPLER	COLLINS
522-()-005	338B-1/1A	INDICATOR, DOPPLER	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-()-005	344B-1/1A	UNIT, INSTRUMENTATION	COLLINS
522-()-005	562A-4()	COMPUTER, STEERING	COLLINS
522-()-00X	329B-4()	HORIZON, APPROACH	COLLINS
522-()-00X	329B-4()	HORIZON, APPROACH	COLLINS
522-()-00X	329B-4()	HORIZON, APPROACH	COLLINS
522-()-00X	334D-1-()	SERVO, TRIM TAB	COLLINS
522-()-00X	614E-2()	CONTROLLER, PEDESTAL	COLLINS
522-()-015	338B-1/1A	INDICATOR, DOPPLER	COLLINS
522-()-015	338B-1/1A	INDICATOR, DOPPLER	COLLINS
522-()-015	338B-1/1A	INDICATOR, DOPPLER	COLLINS
522-0157-004	329B-2	HORIZON, APPROACH	COLLINS
522-0175-004	329B-2A	HORIZON, APPROACH	COLLINS
522-0225-004	323A-1	DETECTOR, FLUX	COLLINS
522-0225-004	323A-1	DETECTOR, FLUX	COLLINS
522-0225-004	323A-1	DETECTOR, FLUX	COLLINS
522-0225-004	323A-1	DETECTOR, FLUX	COLLINS
522-0227-003	345A-2	UNIT, SENSING	COLLINS
522-0236-003	327C-1	INDICATOR, SLAVE	COLLINS
522-0236-003	327C-1	INDICATOR, SLAVE	COLLINS
522-0236-003	327C-1	INDICATOR, SLAVE	COLLINS
522-0364-015	346A-1	UNITS, INTERPHONE AND ISOLATION AMPLIFIER	COLLINS
522-0387-005	346B-1	UNITS, INTERPHONE AND ISOLATION AMPLIFIER	COLLINS
522-0527-005	137A-1	ANTENNA, LOOP	COLLINS
522-0552-004	614L-1	CONTROL, ADF	COLLINS
522-0552-004	614L-1	CONTROL, ADF	COLLINS
522-0553-004	614L-1B	CONTROL, ADF	COLLINS
522-0553-004	614L-1B	CONTROL, ADF	COLLINS
522-0554-004	614L-4	CONTROL, ADF	COLLINS
522-0554-004	614L-4	CONTROL, ADF	COLLINS
522-0599-005	331A-2W	INDICATOR, COURSE	COLLINS
522-0601-004	329B-2W	HORIZON, APPROACH	COLLINS
522-0601-004	329B-2W	HORIZON, APPROACH	COLLINS
522-0602-004	329B-2AW	HORIZON, APPROACH	COLLINS
522-0673-004	614L-2	CONTROL, ADF	COLLINS
522-0673-004	614L-2	CONTROL, ADF	COLLINS
522-0674-004	614L-5	CONTROL, ADF	COLLINS
522-0674-004	614L-5	CONTROL, ADF	COLLINS
522-0678-002	327B-1W	MONITOR, GYRO	COLLINS
522-0685-004	345A-3	UNIT, SENSING	COLLINS
522-0688-013	37P-4	ANTENNA, GLIDESLOPE	COLLINS
522-0690-003	331C-4	INDICATOR, BEARING DISTANCE HEADING	COLLINS
522-0700-023	37P-5	ANTENNA, DUAL GLIDESLOPE	COLLINS
522-0710-005	614E-2	CONTROLLER, PEDESTAL	COLLINS
522-0710-005	614E-2	CONTROLLER, PEDESTAL	COLLINS
522-0710-005	614E-2	CONTROLLER, PEDESTAL	COLLINS
522-0710-005	614E-2	CONTROLLER, PEDESTAL	COLLINS
522-0711-004	614E-3	UNIT, SWITCHING	COLLINS
522-0712-003	590A-2	CONTROLLER, ALTITUDE	COLLINS
522-0712-003	590A-2	CONTROLLER, ALTITUDE	COLLINS
522-0712-003	590A-2	CONTROLLER, ALTITUDE	COLLINS
522-0716-004	334C-2	SERVO, PRIMARY	COLLINS
522-0716-004	334C-2	SERVO, PRIMARY	COLLINS
522-0753-00	331A-2AW	INDICATOR, COURSE	COLLINS
522-0769-004	51Y-3	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
522-0769-004	51Y-3	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
522-0771-005	137A-2	ANTENNA, LOOP	COLLINS
522-0789-004	562C-1A	AMPLIFIER, COMPUTER	COLLINS
522-0801-0XX	390D-11/11A	SHOCKMOUNT	COLLINS
522-0854-003	37X-2	ANTENNA, MARKER BEACON	COLLINS
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS
522-0890-005	331A-4A	INDICATOR, COURSE	COLLINS
522-0890-0XX	331A-4A	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-005	331A-4	INDICATOR, COURSE	COLLINS
522-0891-0XX	331A-4	INDICATOR, COURSE	COLLINS
522-0892-005	329B-4	HORIZON, APPROACH	COLLINS
522-0892-005	329B-4	HORIZON, APPROACH	COLLINS
522-0892-005	329B-4	HORIZON, APPROACH	COLLINS
522-0892-005	329B-4	HORIZON, APPROACH	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0893-004	344C-1	AMPLIFIER, INSTRUMENT	COLLINS
522-0894-004	562A-5	COMPUTER, STEERING	COLLINS
522-0894-004	562A-5	COMPUTER, STEERING	COLLINS
522-0894-004	562A-5	COMPUTER, STEERING	COLLINS
522-0925-005	331A-3C	INDICATOR, COURSE	COLLINS
522-0925-005	331A-3C	INDICATOR, COURSE	COLLINS
522-0925-005	331A-3C	INDICATOR, COURSE	COLLINS
522-0928-004	614L-6	CONTROL, ADF	COLLINS
522-0928-004	614L-6	CONTROL, ADF	COLLINS
522-0954-003	331A-2B	INDICATOR, COURSE	COLLINS
522-0959-004	562A-5A	COMPUTER, STEERING	COLLINS
522-0959-004	562A-5A	COMPUTER, STEERING	COLLINS
522-0959-004	562A-5A	COMPUTER, STEERING	COLLINS
522-0960-005	329B-4B	HORIZON, APPROACH	COLLINS
522-0960-005	329B-4B	HORIZON, APPROACH	COLLINS
522-0960-005	329B-4B	HORIZON, APPROACH	COLLINS
522-0969-005	331A-2CW	INDICATOR, COURSE	COLLINS
522-0969-005	331A-2CW	INDICATOR, COURSE	COLLINS
522-0973-005	344A-1	UNIT, VOR / LOC INSTRUMENTATION	COLLINS
522-0973-005	344A-1	UNIT, INSTRUMENTATION	COLLINS
522-0974-003	331C-4A	INDICATOR, BEARING DISTANCE HEADING	COLLINS
522105	1812-18LW	INDICATOR, LUBE OIL TEMPERATURE	AMETEK
522106	1822-260LW	INDICATOR, FLAP POSITION WITH AIDS	AMETEK
522-1079-00	334D-1-44	SERVO, TRIM TAB	COLLINS
522-1082-00	245A-2A	UNIT, SENSING	COLLINS
522-1136-011	137X-1	ANTENNA, NAV / COMM	COLLINS
522-1171-004	328A-2	AMPLIFIER, COMPASS	COLLINS
522-1171-004	328A-2	AMPLIFIER, COMPASS	COLLINS
522-1171-004	328A-2	AMPLIFIER, COMPASS	COLLINS
522-1171-004	328A-2	AMPLIFIER, COMPASS	COLLINS
522-1171-005	328A-2	AMPLIFIER, COMPASS	COLLINS
522-1173-004	562A-7	COMPUTER, STEERING	COLLINS
522-1173-004	562A-7	COMPUTER, STEERING	COLLINS
522-1215-00	562C-3	COMPUTER / AMPLIFIER	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-1215-00	562C-3	COMPUTER / AMPLIFIER	COLLINS
522-1215-00	562C-3	COMPUTER / AMPLIFIER	COLLINS
522-1215-00	562C-3	COMPUTER / AMPLIFIER	COLLINS
522-1216-001	121A-2	DISCONNECT, EMERGENCY	COLLINS
522-1217-00	590B-1	COMPENSATOR, AIR SPEED	COLLINS
522-1217-00	590B-1	COMPENSATOR, AIR SPEED	COLLINS
522-1217-00	590B-1	COMPENSATOR, AIR	COLLINS
522-1217-00	590B-1	COMPENSATOR, AIR	COLLINS
522-1218-00	345A-4	UNIT, SENSING	COLLINS
522-1218-00	345A-4	UNIT, SENSING	COLLINS
522-1218-00	345A-4	UNIT, SENSING	COLLINS
522-1218-00	345A-4	UNIT, SENSING	COLLINS
522-1218-00	345A-4	UNIT, SENSING	COLLINS
522-1219-00	329B-4	HORIZON, APPROACH	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00	334C-3	SERVO, PRIMARY	COLLINS
522-1225-00X	334C-3	SERVO, PRIMARY	COLLINS
522-1226-00	351B-3()	MOUNT, SERVO	COLLINS
522-1226-00	351B-3()	MOUNT, SERVO	COLLINS
522-1226-00	351B-3()	MOUNT, SERVO	COLLINS
522-1226-00	351B-3()	MOUNT, SERVO	COLLINS
522-1226-00	351B-3()	MOUNT, SERVO	COLLINS
522-1226-000	351B-3	MOUNT, SERVO	COLLINS
522-1226-000	351B-3()	SERVO, PRIMARY	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1227-00	332D-9	REFERENCE, VERTICAL	COLLINS
522-1228-00	860E-1	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-1228-00	860E-1	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-1228-00	860E-1	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-1228-00	860E-1	SET, RADIO	COLLINS
522-1228-00	860E-1	SET, RADIO	COLLINS
522-1228-00	860E-1	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-122X-003	614U-1/2	CONTROL	COLLINS
522-1230-()	618T-1	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1230-()	618T-1	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1230-()	618T-1	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1261-00	714E-1	CONTROL, RADIO SET	COLLINS
522-1348-00	344D-1	UNIT, VOR INSTRUMENTATION	COLLINS
522-1356-00	334D-2-33()	SERVO, TRIM TAB	COLLINS
522-1394-003	333F-1	AMPLIFIER, REMOTE	COLLINS
522-1400-00	341C-1	AMPLIFIER, RMI SERVO	COLLINS
522-1400-00	341C-1	AMPLIFIER, RMI SERVO	COLLINS
522-1428-005	329B-4AX	HORIZON, APPROACH	COLLINS
522-1428-005	329B-4AX	HORIZON, APPROACH	COLLINS
522-1428-005	329B-4AX	HORIZON, APPROACH	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-005	331A-4AX	INDICATOR, COURSE	COLLINS
522-1429-0XX	331A-4AX	INDICATOR, COURSE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-1438-004	17L-7A	TRANSMITTER, VHF	COLLINS
522-1438-004	17L-7A	RECEIVER, COMMUNICATIONS	COLLINS
522-1439-004	51X-2B	RECEIVER, VHF	COLLINS
522-1439-004	51X-2B	RECEIVER, COMMUNICATIONS	COLLINS
522-1441-003	614U-6	UNIT, CONTROL	COLLINS
522-1441-003	614U-6	UNIT, REMOTE CONTROL	COLLINS
522-1501-()	618T-2	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1501-()	618T-2	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1501-()	618T-2	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1513-005	332E-2	GYRO, DIRECTIONAL	COLLINS
522-1513-005	332E-2	GYRO, DIRECTIONAL	COLLINS
522-1513-005	332E-2	GYRO, DIRECTIONAL	COLLINS
522-157X-00	621A-2	TRANSPONDER, ATC	COLLINS
522-157X-00	621A-2	TRANSPONDER, ATC	COLLINS
522-1619-004	328A-2A	AMPLIFIER, COMPASS	COLLINS
522-1619-004	328A-2A	AMPLIFIER, COMPASS	COLLINS
522-1619-004	328A-2A	AMPLIFIER, COMPASS	COLLINS
522-1619-004	328A-2A	AMPLIFIER, COMPASS	COLLINS
522-1619-046	328A-2A	AMPLIFIER, COMPASS	COLLINS
522-1660-()	618T-3	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1660-()	618T-3	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1660-()	618T-3	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-1688-00	614E-3A	UNIT, SWITCHING	COLLINS
522176	1822-265LW	INDICATOR, EXHAUST GAS TEMPERATURE	AMETEK
522177	1822-266LW	INDICATOR, RPM	AMETEK
522-1771-003	331C-4E	INDICATOR, BEARING DISTANCE HEADING	COLLINS
522-1776-004	349H-6	MOUNT, VIBRATION	COLLINS
522-1836-00	51Y-4	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
522-1837-000	137A-5	ANTENNA, LOOP	COLLINS
522-1838-()	578D-1	TEST SET, DME BENCH	COLLINS
522-1839-()	578X-1	TEST SET, ATC TRANSPONDER BENCH	COLLINS
522-1859-()	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-003	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-003	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-013	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-023	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-033	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-043	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-053	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-063	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-064	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-065	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-066	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-067	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-068	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-069	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-070	339D-1	INDICATOR, DISTANCE	COLLINS
522-1859-071	339D-1	INDICATOR, DISTANCE	COLLINS
522-1920-001	899S-1	ADAPTER, D/S RANGE	COLLINS
522-1921-004	614L-7	CONTROL, ADF	COLLINS
522-1921-004	614L-7	CONTROL, ADF	COLLINS
522-1936-0XX	327C-2	INDICATOR, SLAVE	COLLINS
522-1936-0XX	327C-2	INDICATOR, SLAVE	COLLINS
522-1936-0XX	327C-2	INDICATOR, SLAVE	COLLINS
522-1939-004	614L-7A	CONTROL, ADF	COLLINS
522-1939-004	614L-7A	CONTROL, ADF	COLLINS
522-2066-00	578Q-1	PANEL, FREQUENCY DISCRIMINATOR TEST	COLLINS
522-212X-00	334D-1-A/B	SERVO, TRIM TAB	COLLINS
522-2175-006	714Y-1	CONTROL, RADIO SET	COLLINS
522-2213-()	714E-2	CONTROL, RADIO SET	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-2228-000	351B-3A	MOUNT, SERVO	COLLINS
522-2301-005	137A-4	ANTENNA, LOOP	COLLINS
522-2305-()	621A-2A	TRANSPONDER, ATC	COLLINS
522-2357-()	614K-8	UNIT, ADF CONTROL	COLLINS
522-2357-0XX	614L-8	UNIT, ADF CONTROL	COLLINS
522-2359-()	621C-1B	RECEIVER, TRANSMITTER	COLLINS
522-2377-003	331C-4F	INDICATOR, BEARING DISTANCE HEADING	COLLINS
522-2385-00	334D-2-33E	SERVO, TRIM TAB	COLLINS
522-2401-00	344D-1A	UNIT, VOR INSTRUMENTATION	COLLINS
522-2402-00	344D-2	UNIT, VOR INSTRUMENTATION	COLLINS
522-2405-00	476X-2	TEST SET, TRANSPONDER SET	COLLINS
522-2411-003	331D-2/2A/2B	INDICATOR, HORIZONTAL SITUATION	COLLINS
522-2457-()	714E-3	CONTROL, RADIO SET	COLLINS
522-2458-01X	618F-1A	TRANSCEIVER, VHF COMMUNICATION	COLLINS
522-2576-00	332D-10	REFERENCE, VERTICAL	COLLINS
522-2576-00	332D-10	REFERENCE, VERTICAL	COLLINS
522-2576-00	332D-10	REFERENCE, VERTICAL	COLLINS
522-2587-00	51Y-4A	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
522-2604-()	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-003	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-013	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-023	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-024	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-025	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-026	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2604-0XX	339D-1A	INDICATOR, DISTANCE	COLLINS
522-2615-00X	137A-6	ANTENNA, LOOP	COLLINS
522-2635-007	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-000	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-001	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-002	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-003	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-005	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-006	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-008	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-009	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-00X	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-00X	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-00X	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-00X	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-00X	331A-3G	INDICATOR, COURSE	COLLINS
522-2638-010	331A-3G	INDICATOR, COURSE	COLLINS
522-2643-00	323A-3G	DETECTOR, FLUX	COLLINS
522-2643-00	323A-3G	DETECTOR, FLUX	COLLINS
522-2643-00	323A-3G	DETECTOR, FLUX	COLLINS
522-2643-00	323A-3G	DETECTOR, FLUX	COLLINS
522-2643-000	323A-3G	DETECTOR, FLUX	COLLINS
522-2644-011	328A-3G	ACCESSORY, SLAVING	COLLINS
522-2644-011	328A-3G	ACCESSORY, SLAVING	COLLINS
522-2644-0XX	328A-3G	ACCESSORY, SLAVING	COLLINS
522-2644-0XX	328A-3G	ACCESSORY, SLAVING	COLLINS
522-2644-0XX	328A-3G	ACCESSORY, SLAVING	COLLINS
522-2644-0XX	328A-3G	AMPLIFIER, SLAVING	COLLINS
522-2645-00	332E-3G	GYRO, DIRECTIONAL	COLLINS
522-2645-00	332E-3G	GYRO, DIRECTIONAL	COLLINS
522-2645-00	332E-3G	GYRO, DIRECTIONAL	COLLINS
522-2668-00	562A-5B	COMPUTER, STEERING	COLLINS
522-2668-00	562A-5B	COMPUTER, STEERING	COLLINS
522-2668-00	562A-5B	COMPUTER, STEERING	COLLINS
522-2668-00	562A-5B	COMPUTER, STEERING	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-2668-00	562A-5B	COMPUTER, STEERING	COLLINS
522-2702-()	860E-2	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-2702-()	860E-2	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-2703-00	621A-3	TRANSPONDER, ATC	COLLINS
522-2703-00	621A-3	TRANSPONDER, ATC	COLLINS
522-2710-004	477U-2	SIMULATOR, ADF ANTENNA	COLLINS
522-2711-00X	477V-2	TEST SET, ADF	COLLINS
522-2762-000	VHF-201	SYSTEM, GROUND COMMUNICATION	COLLINS
522-2782-()	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-001	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-004	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-014	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-024	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-034	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-035	331A-6A	INDICATOR, COURSE	COLLINS
522-2782-037	331A-6A	INDICATOR, COURSE	COLLINS
522-2787-00	161A-1	COUPLER, TRIM	COLLINS
522-2787-00	161A-1	COUPLER, TRIM	COLLINS
522-2852-001	562C-4	AMPLIFIER, AUTOPILOT	COLLINS
522-2852-001	562C-4	AMPLIFIER, AUTOPILOT	COLLINS
522-2857-001	334C-3A	SERVO, PRIMARY	COLLINS
522-2857-001	334C-3A	SERVO, PRIMARY	COLLINS
522-2866-00	356C-4	AMPLIFIER, ISOLATION	COLLINS
522-2866-00	356C-4	AMPLIFIER, ISOLATION	COLLINS
522-2867-00	354F-3	AMPLIFIER, SPEAKER	COLLINS
522-2867-00	356F-3	AMPLIFIER, SPEAKER	COLLINS
522-2867-00	356F-3	AMPLIFIER, SPEAKER	COLLINS
522-2867-00	356F-3	AMPLIFIER, SPEAKER	COLLINS
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS
522-2882-00	562A-5E	COMPUTER, STEERING	COLLINS
522-2892-()	714E-2A	CONTROL, RADIO SET	COLLINS
522-2899-000	387C-4	CONTROL, AUDIO	COLLINS
522-2899-012	387C-4	CONTROL, AUDIO	COLLINS
522-2900-()	562C-5	AMPLIFIER, AUTOPILOT	COLLINS
522-2900-()	562C-5	AMPLIFIER, AUTOPILOT	COLLINS
522-2900-0XX	562C-5	AMPLIFIER, AUTOPILOT	COLLINS
522-2900-0XX	562C-5	AMPLIFIER, AUTOPILOT	COLLINS
522-2900-XXX	562C-5	AMPLIFIER, AUTOPILOT	COLLINS
522-2901-002	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-003	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-007	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-009	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-010	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-011	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-015	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-016	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-017	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-018	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-020	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-021	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-022	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-023	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-024	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-025	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-028	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-029	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-031	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-032	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-033	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-034	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-035	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-036	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-131	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2901-XXX	APC-80	COMPUTER, AUTOPILOT	COLLINS
522-2919-()	339D-3B	INDICATOR, DISTANCE	COLLINS
522-2919-00	339D-3B	INDICATOR, DISTANCE	COLLINS
522-2919-003	339D-1B	INDICATOR, DISTANCE	COLLINS
522-2919-013	339D-1B	INDICATOR, DISTANCE	COLLINS
522-2919-015	339D-1B	INDICATOR, DISTANCE	COLLINS
522-2919-016	339D-1B	INDICATOR, DISTANCE	COLLINS
522-2920-00	339D-3C	INDICATOR, DISTANCE	COLLINS
522-2920-003	339D-3C	INDICATOR, DISTANCE	COLLINS
522-2980-00	334C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-2980-00	334C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-2980-00	334C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-2980-00	344C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-2980-00	344C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-2980-00	344C-1B	AMPLIFIER, INSTRUMENT	COLLINS
522-3022-000	878L-1	TEST SET, AMPLIFIER	COLLINS
522-3071-00	329B-6D	INDICATOR, APPROACH HORIZON	COLLINS
522-3071-00	329B-6D	INDICATOR, APPROACH HORIZON	COLLINS
522-3071-00	329B-6D	HORIZON, APPROACH	COLLINS
522-3073-00	331A-6D	INDICATOR, COURSE	COLLINS
522-3073-00	331A-6D	INDICATOR, COURSE	COLLINS
522-3073-000	331A-6D	INDICATOR, COURSE	COLLINS
522-3073-012	331A-6D	INDICATOR, COURSE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3121-124	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-154	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-154	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-164	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-164	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-166	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-166	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-166	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-168	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-168	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-169	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-169	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-169	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-169	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-170	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-170	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-171	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-171	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-171	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-172	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-172	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-173	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-173	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-174	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-174	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-175	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-175	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-176	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-176	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-178	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-178	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-179	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-179	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-180	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-180	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-180	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-181	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-181	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-181	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-182	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-182	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-182	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-183	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-183	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-184	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-184	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-185	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-185	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-185	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-186	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-186	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-188	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-188	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-189	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-189	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-189	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-190	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-190	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-191	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-191	562A-5F	COMPUTER, STEERING	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3121-192	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-192	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-193	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-193	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-194	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-194	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-195	562A-5F	COMPUTER, STEERING	COLLINS
522-3121-195	562A-5F	COMPUTER, STEERING	COLLINS
522-3122-004	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-005	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-005	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-006	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-006	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-006	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-006	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-007	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-007	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-008	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-009	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-010	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-011	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-012	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3122-013	329B-7	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3130-000	590A-3A	CONTROLLER, ALTITUDE	COLLINS
522-3130-000	590A-3A	CONTROLLER, ALTITUDE	COLLINS
522-3130-000	590A-3A	CONTROLLER, ALTITUDE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-004	331A-7	INDICATOR, COURSE	COLLINS
522-3138-00X	331A-7	INDICATOR, COURSE	COLLINS
522-3198-()	614E-7	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-004	614E-7	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-004	614E-7	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-004	614E-7	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-005	614E-7	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-005	614E-7K	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-00X	314E-7K/L	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3198-00X	614E-7/7K	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3206-004	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-004	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-005	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-005	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-006	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-006	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-006	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-006	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-006	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-007	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-008	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3206-009	329B-7A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3207-()	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5F	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3207-003	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3207-00X	562A-5G	COMPUTER, FLIGHT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-001	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3226-00X	344C-1F	AMPLIFIER, INSTRUMENT	COLLINS
522-3241-00	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3241-00	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3241-00	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3241-000	332E-4	INDICATOR, DIRECTIONAL GYRO	COLLINS
522-3241-000	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3241-000	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3241-000	332E-4	GYRO, DIRECTIONAL	COLLINS
522-3266-00	562C-3D	COMPUTER / AMPLIFIER	COLLINS
522-3272-00	878L-3	TEST SET, DISCRIMINATOR	COLLINS
522-3306-000	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-3306-000	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-3306-011	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-3306-011	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-3306-014	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-3306-014	331H-3G	INDICATOR, COURSE SELECTOR	COLLINS
522-332X-00	614E-2()	CONTROLLER, PEDESTAL	COLLINS
522-3341-00	329B-6E	INDICATOR, APPROACH HORIZON	COLLINS
522-3341-00	329B-6E	INDICATOR, APPROACH HORIZON	COLLINS
522-3342-001	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-001	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-001	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-002	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-003	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-003	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-004	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-005	331A-6E	INDICATOR, COURSE	COLLINS
522-3342-005	331A-6E	INDICATOR, COURSE	COLLINS
522-3343-()	339D-3D	INDICATOR, DISTANCE	COLLINS
522-3343-00	339D-3D	INDICATOR, DISTANCE	COLLINS
522-3343-000	339D-1D	INDICATOR, DISTANCE	COLLINS
522-3343-011	339D-1D	INDICATOR, DISTANCE	COLLINS
522-3343-013	339D-1D	INDICATOR, DISTANCE	COLLINS
522-3389-000	351B-3B	MOUNT, SERVO	COLLINS
522-3390-000	351B-3C	MOUNT, SERVO	COLLINS
522-3400-00X	678P-2	HARNES, RADIO SET TEST	COLLINS
522-3423-00	978F-3M	TEST SET, MODE CONTROL	COLLINS
522-3424-00	978F-1D	TEST SET, INSTRUMENT	COLLINS
522-3426-000	978F-6P	TEST SET, STEERING COMPUTER	COLLINS
522-3427-00	978F-4A	TEST SET, AMPLIFIER	COLLINS
522-3443-00	490T-1	COUPLER, ANTENNA	COLLINS
522-3444-00	490-T-1A	COUPLER, ANTENNA	COLLINS
522-3466-00	334D-2-33D	SERVO, TRIM TAB	COLLINS
522-3466-00	334D-2-33D	SERVO, TRIM TAB	COLLINS
522-3466-000	334D-2-33()	SERVO, TRIM	COLLINS
522-3466-000	334D-2-33()	SERVO, TRIM	COLLINS
522-3478-00	578X-2	TEST SET, ATC TRANSPONDER BENCH	COLLINS
522-3487-()	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-()	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-001	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-001	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-002	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-003	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-003	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-003	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-004	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-007	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-009	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3487-010	329B-7C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3491-00	345A-4A	UNIT, SENSING	COLLINS
522-3491-00	345A-4A	UNIT, SENSING	COLLINS
522-3498-00	978F-2S	SIMULATOR, SYNCHRO	COLLINS
522-3501-000	978F-5R	TEST SET, STEERING COMPUTER	COLLINS
522-351X-004	790H-1/2	SHOCKMOUNT	COLLINS
522-3546-004	614E-7B	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3549-004	614E-7C	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3550-004	331A-7A	INDICATOR, COURSE	COLLINS
522-3551-001	614E-4	CONTROLLER, AUTOPILOT	COLLINS
522-3618-001	329B-7F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3618-001	329B-7F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3618-003	329B-7F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-362X-002	327J-2A/C	ANNUNCIATOR	COLLINS
522-3636-001	714E-5	CONTROL	COLLINS
522-3637-()	614E-2F	CONTROLLER, PEDESTAL	COLLINS
522-3667-001	329B-7G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3680-00	562C-3E	COMPUTER / AMPLIFIER	COLLINS
522-3698-002	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-002	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-003	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-003	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-004	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-004	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-005	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-005	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-006	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-006	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-011	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-011	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-011	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-012	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-013	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-013	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-013	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-014	860F-1	ALTIMETER, RADIO	COLLINS
522-3698-014	860F-1	ALTIMETER, RADIO	COLLINS
522-3700-004	329B-8A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3700-004	329B-8A	INDICATOR, FLIGHT CONTROL	COLLINS
522-3700-004	329B-8A	INDICATOR, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3700-004	329B-8A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3700-004	329B-8A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3700-009	329B-8A	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3701-001	978F-8W	TEST SET, COMPARATOR WARNING MONITOR	COLLINS
522-3712-()	562P-1	COMPUTER, PITCH STEERING	COLLINS
522-3712-()	562P-1	COMPUTER, PITCH STEERING	COLLINS
522-3712-014	562P-1	COMPUTER, PITCH STEERING	COLLINS
522-3712-014	562P-1	COMPUTER, PITCH STEERING	COLLINS
522-3712-014	562P-1	COMPUTER, PITCH STEERING	COLLINS
522-3713-()	562R-1	COMPUTER, ROLL STEERING	COLLINS
522-3713-()	562R-1	COMPUTER, ROLL STEERING	COLLINS
522-3713-017	562R-1	COMPUTER, ROLL STEERING	COLLINS
522-3713-017	562R-1	COMPUTER, ROLL STEERING	COLLINS
522-3713-017	562R-1	COMPUTER, ROLL STEERING	COLLINS
522-3747-001	384C-1A	SWITCH, ALTITUDE HOLD	COLLINS
522-3748-001	344C-1E	AMPLIFIER, INSTRUMENT	COLLINS
522-3750-002	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-002	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-002	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-002	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-003	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-004	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-004	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-004	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-005	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-005	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-005	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-005	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-006	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-006	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-006	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-006	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-007	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-007	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-007	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-008	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-008	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-008	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-009	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-009	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-009	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-022	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-022	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-022	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-023	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-023	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-023	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-023	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-025	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-025	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-025	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-026	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-026	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-026	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-027	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-027	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-027	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-028	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-028	562A-5F1	COMPUTER, STEERING	COLLINS
522-3750-028	562A-5F1	COMPUTER, STEERING	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3752-001	329B-7F1	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3752-001	329B-7F-1	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3752-002	329B-7F-1	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3761-00X	137A-6A	ANTENNA, LOOP	COLLINS
522-3763-001	346B-3	CENTER, AUDIO CONTROL	COLLINS
522-3763-002	346B-3	CENTER, AUDIO CONTROL	COLLINS
522-3763-003	346B-3	CENTER, AUDIO CONTROL	COLLINS
522-3768-001	614E-7E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3768-001	614E-7E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3768-002	614E-7E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3768-00X	614E-7E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3787-00X	614E-7F	CONTROL, FLIGHT DIRECTOR	COLLINS
522-3851-00	345A-4B	UNIT, SENSING	COLLINS
522-3851-000	345A-4B	UNIT, SENSING	COLLINS
522-3851-000	345A-4B	SENSOR, RATE	COLLINS
522-3851-001	345A-4B	UNIT, SENSING	COLLINS
522-3866-001	344C-1G	AMPLIFIER, INSTRUMENT	COLLINS
522-3866-002	344C-1G	AMPLIFIER, INSTRUMENT	COLLINS
522-3866-00X	344C-1G	AMPLIFIER, INSTRUMENT	COLLINS
522-3867-001	329B-7J	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3867-002	329B-7J	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3867-003	329B-7J	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3867-003	329B-7J	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3874-001	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-001	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-003	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3874-005	344C-1K	AMPLIFIER, INSTRUMENT	COLLINS
522-3875-001	331A-6K	INDICATOR, COURSE	COLLINS
522-3875-001	331A-6K	INDICATOR, COURSE	COLLINS
522-3877-001	329B-7K	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3877-002	329B-7K	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3903-00X	714E-3B	CONTROL, RADIO SET	COLLINS
522-3908-001	329B-7M	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3908-001	329B-7M	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3908-003	329B-7M	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-3918-()	914G-1/1A	INDICATOR, WARNING MONITOR	COLLINS
522-3918-()	914G-1/1A	INDICATOR, WARNING MONITOR	COLLINS
522-3919-()	914G-2/2A	INDICATOR, WARNING MONITOR	COLLINS
522-3919-()	914G-2/2A	INDICATOR, WARNING MONITOR	COLLINS
522-3962-001	329P-1D	INDICATOR, PERIPHERAL COMMAND	COLLINS
522-3962-001	329P-1D	INDICATOR, PERIPHERAL COMMAND	COLLINS
522-3964-001	344C-4A	AMPLIFIER, PERIPHERAL COMMAND INDICATOR	COLLINS
522-3964-001	344C-4A	INDICATOR, PERIPHERAL COMMAND	COLLINS
522-3971-001	878L-13	TESTER, ANTENNA COUPLER MODULE	COLLINS
522-3978-001	599B-1	ADAPTER, SPEED COMMAND	COLLINS
522-3985-001	332D-11	REFERENCE, VERTICAL	COLLINS
522-3985-001	332D-11	GYRO, VERTICAL	COLLINS
522-3985-001	332D-11	REFERENCE, VERTICAL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-3985-001	332D-11	GYRO, VERTICAL	COLLINS
522-3985-001	332D-11	GYRO, VERTICAL	COLLINS
522-3985-001	332D-11	REFERENCE, VERTICAL	COLLINS
522-3XX1-00	329B-6D/E	HORIZON, APPROACH	COLLINS
522-3XX1-00	329B-6D/E	HORIZON, APPROACH	COLLINS
522-4017-()	614E-2G	CONTROLLER, PEDESTAL	COLLINS
522-4057-001	642C-1	SYSTEM, AIRBORNE VOICE RECORDER	COLLINS
522-4057-002	642C-1	SYSTEM, AIRBORNE VOICE RECORDER	COLLINS
522-4057-00X	642C-1	RECORDER, COCKPIT VOICE	COLLINS
522-4057-00X	642C-1	RECORDER, COCKPIT VOICE	COLLINS
522-4058-00X	914F-1	UNIT, CONTROL	COLLINS
522-4063-001	329B-8C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4063-003	329B-8C	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4085-001	978F-9A	ADAPTER, AMPLIFIER TEST	COLLINS
522-4086-001	978F-10R	ADAPTER, STEERING COMPUTER TEST	COLLINS
522-4088-()	618M-2B	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-4088-()	618M-2B	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-4089-()	618M-2D	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-4089-()	618M-2D	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
522-4099-001	790S-1	SHOCKMOUNT - SINGLE	COLLINS
522-4113-001	978F-11P	ADAPTER, STEERING COMPUTER TEST	COLLINS
522-4114-002	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-002	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-003	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-003	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-004	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-004	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-006	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-006	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-008	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4114-008	339H-1	INDICATOR, RADIO ALTITUDE	COLLINS
522-4140-001	437X-1	ANTENNA	COLLINS
522-4140-001	437X-1	ANTENNA	COLLINS
522-4140-002	437X-1	ANTENNA	COLLINS
522-4140-002	437X-1	ANTENNA	COLLINS
522-4140-002	437X-1	ANTENNA	COLLINS
522-4140-003	437X-1	ANTENNA	COLLINS
522-4140-003	437X-1	ANTENNA	COLLINS
522-4140-003	437X-1	ANTENNA	COLLINS
522-4140-004	437X-1	ANTENNA	COLLINS
522-4140-004	437X-1	ANTENNA	COLLINS
522-4140-004	437X-1	ANTENNA	COLLINS
522-4140-004	437X-1	ANTENNA	COLLINS
522-4140-006	437X-1	ANTENNA	COLLINS
522-4140-006	437X-1	ANTENNA	COLLINS
522-4140-006	437X-1	ANTENNA	COLLINS
522-4140-007	437X-1	ANTENNA	COLLINS
522-4140-007	437X-1	ANTENNA	COLLINS
522-4140-007	437X-1	ANTENNA	COLLINS
522-4140-007	437X-1	ANTENNA	COLLINS
522-4190-002	437M-2	ANTENNA, ADF SENSE	COLLINS
522-4194-001	329B-8B	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4209-001	860E-3	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-4209-002	860E-3	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-4209-003	860E-3	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-4209-00X	860E-3	EQUIPMENT, DISTANCE MEASURING	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS
522-4219-001	161E-1	COUPLER, MODE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-4237-()	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-()	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-()	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-001	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-001	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-001	562A-5F-2	COMPUTER, STEERING	COLLINS
522-4237-002	562A-5F2	COMPUTER, STEERING	COLLINS
522-4237-002	562A-5F2	COMPUTER, STEERING	COLLINS
522-4255-001	437X-1	ANTENNA	COLLINS
522-4255-001	437X-1	ANTENNA	COLLINS
522-4255-001	437X-1A	ANTENNA	COLLINS
522-4255-001	437X-1A	ANTENNA	COLLINS
522-4255-001	437X-1A	ANTENNA	COLLINS
522-4255-001	437X-1A	ANTENNA	COLLINS
522-4255-001	437X-1A	ANTENNA	COLLINS
522-4255-002	437X-1A	ANTENNA	COLLINS
522-4255-002	437X-1A	ANTENNA	COLLINS
522-4255-002	437X-1A	ANTENNA	COLLINS
522-4255-003	437X-1A	ANTENNA	COLLINS
522-4255-003	437X-1A	ANTENNA	COLLINS
522-4255-003	437X-1A	ANTENNA	COLLINS
522-4255-003	437X-1A	ANTENNA	COLLINS
522-4255-004	437X-1A	ANTENNA	COLLINS
522-4255-004	437X-1A	ANTENNA	COLLINS
522-4255-004	437X-1A	ANTENNA	COLLINS
522-4255-006	437X-1A	ANTENNA	COLLINS
522-4255-006	437X-1A	ANTENNA	COLLINS
522-4255-007	437X-1A	ANTENNA	COLLINS
522-4255-007	437X-1A	ANTENNA	COLLINS
522-4255-007	437X-1A	ANTENNA	COLLINS
522-4279-001	331A-6A1	INDICATOR, COURSE	COLLINS
522-4279-003	331A-6A1	INDICATOR, COURSE	COLLINS
522-4280-001	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-001	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-002	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-002	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-003	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-003	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-004	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-004	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-005	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-005	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-006	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-006	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-007	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-007	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-008	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-008	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-009	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-009	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-101	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-101	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-102	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-102	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-104	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-104	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-105	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-105	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-106	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-106	51RV-2B	RECEIVER, VOR / ILS	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-4280-107	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-107	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-108	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-108	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-109	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-109	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-110	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4280-110	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4319-001	578E-2	PANEL, VERTICAL REFERENCE TEST	COLLINS
522-4322-00X	614E-9B	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4323-002	614E-9C	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4323-002	614E-9C	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4323-002	614E-9C	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4323-00X	614E-9C	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-001	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-002	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-00X	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4329-00X	345C-2A	SENSOR, ACCELERATION	COLLINS
522-4353-001	346D-1A	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4353-001	346D-1A	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4354-002	339H-1A	INDICATOR, RADIO ALTITUDE	COLLINS
522-4354-002	339H-1A	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-002	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-002	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-004	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-004	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-006	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-006	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-007	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4363-007	339H-1B	INDICATOR, RADIO ALTITUDE	COLLINS
522-4380-001	980H-1	TEST SET, COUPLER	COLLINS
522-4389-00X	614E-8B	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4407-00X	790S-2	SHOCKMOUNT - DUAL	COLLINS
522-4409-001	878L-18	TESTER, ANTENNA COUPLER MODULE	COLLINS
522-4410-001	878L-19	TESTER, ANTENNA COUPLER MODULE	COLLINS
522-4414-002	331H-3GB	INDICATOR, COURSE SELECTOR	COLLINS
522-4414-002	331H-3GB	INDICATOR, COURSE SELECTOR	COLLINS
522-4428-()	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-002	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-006	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-008	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-008	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-009	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4428-010	562R-1E	COMPUTER, ROLL STEERING	COLLINS
522-4429-001	562P-1E	COMPUTER, PITCH STEERING	COLLINS
522-4430-001	329B-8F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4430-002	329B-8F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4430-002	329B-8F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4430-005	329B-8F	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4431-001	614E-9E	CONTROL, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-4431-002	614E-9E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4431-00X	614E-9E	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4458-002	477U-3	TEST SET, ADF	COLLINS
522-4459-001	476U-3	TEST SET, VOR / ILS	COLLINS
522-4466-001	714E-6	CONTROL, RADIO SET	COLLINS
522-4466-001	714E-6	CONTROL, RADIO SET	COLLINS
522-4475-001	476X-3	TEST SET, ATC TRANSPONDER RAMP	COLLINS
522-4496-001	980L-1	TEST SET	COLLINS
522-4496-001	980L-1	TEST SET	COLLINS
522-4504-001	339H-1C	INDICATOR, RADIO ALTITUDE	COLLINS
522-4504-001	339H-1C	INDICATOR, RADIO ALTITUDE	COLLINS
522-4517-001	161A-1A	COUPLE, TRIM	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-002	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4529-004	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
522-4538-002	346D-1B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4538-003	346D-1B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4538-004	346D-1B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4538-005	346D-1B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522-4538-00X	346D-1B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
522456	1822-339LW	INDICATOR, HYDRAULIC BREAK PRESSURE	AMETEK
522457	1825-88LW	INDICATOR, DUAL DEICING PRESSURE	AMETEK
522458	1825-89LW	INDICATOR, DUAL HYDRUALIC PRESSURE	AMETEK
522459	1812-214LW	INDICATOR, CABIN DUCT TEMPERATURE	AMETEK
522-4606-001	440Y-1	ADAPTER	COLLINS
522-4606-001	440Y-1	ADAPTER, TEST	COLLINS
522-4607-001	440Y-2	ADAPTER	COLLINS
522-4607-001	440Y-2	ADAPTER, TEST	COLLINS
522-4609-001	440Y-3	ADAPTER	COLLINS
522-4610-001	980N-1	TEST SET, ALTIMETER	COLLINS
522-4625-001	339H-1D	INDICATOR, RADIO ALTITUDE	COLLINS
522-4625-001	339H-1D	INDICATOR, RADIO ALTITUDE	COLLINS
522-4648-001	U-1301	AMPLIFIER, POWER	COLLINS
522-4649-001	161A-1B	COUPLER, TRIM	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4655-002	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4656-001	614E-11	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4700-001	161F-1	COUPLER, AIR DATA	COLLINS
522-4700-001	161F-1	COUPLER, AIR DATA	COLLINS
522-4700-002	161F-1	COUPLER, AIR DATA	COLLINS
522-4700-00X	161F-1	COUPLER, AIR DATA	COLLINS
522-4701-001	590A-5	SENSOR, AIR DATA	COLLINS
522-4701-001	590A-5	SENSOR, AIR DATA	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-4701-001	590A-5	SENSOR, AIR DATA	COLLINS
522-4701-00X	590A-5	SENSOR, AIR DATA	COLLINS
522-4703-()	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-004	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-004	562A-5F4	COMPUTER, STEERING	COLLINS
522-4703-004	562A-5FA	COMPUTER, STEERING	COLLINS
522-4703-005	562A-5F4	COMPUTER, STEERING	COLLINS
522-4707-001	614E-13	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4748-002	980H-3	TEST SET, COUPLER	COLLINS
522-4757-001	947A-1	RECEIVER, TRANSLATOR	COLLINS
522-4759-001	947A-1B	RECEIVER, TRANSLATOR	COLLINS
522-4760-001	947A-1C	RECEIVER, TRANSLATOR	COLLINS
522-4762-001	947A-1E	RECEIVER, TRANSLATOR	COLLINS
522-4787-001	490R-4	SYSTEM, ANTENNA COUPLER	COLLINS
522-4798-001	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4798-001	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4798-001	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4798-001	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4798-001	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4798-001	590A-5M	COMPUTER, FLIGHT	COLLINS
522-4798-00X	590A-3E	CONTROLLER, ALTITUDE	COLLINS
522-4825-001	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-001	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-002	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-002	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-004	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-004	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-005	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-005	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-006	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-006	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-006	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-007	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-007	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-008	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-008	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4825-011	339H-2	INDICATOR, RADIO ALTITUDE	COLLINS
522-4828-00X	618T-1B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4828-00X	618T-1B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4828-00X	618T-1B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4829-00X	618T-2B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4829-00X	618T-2B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4829-00X	618T-2B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4829-00X	618T-2B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4830-00X	618T-3B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4830-00X	618T-3B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4830-00X	618T-3B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
522-4836-()	651S-1	RECEIVER, GENERAL PURPOSE HF	COLLINS
522-4836-()	651S-1	RECEIVER, GENERAL PURPOSE HF	COLLINS
522-4839-001	651S-1	RECEIVER, GENERAL PURPOSE HF	COLLINS
522484		INDICATOR, RUDDER TRIM	AMETEK
522-4853-001	137A-6B	ANTENNA, LOOP	COLLINS
522486	1812-218LW	INDICATOR, AILERON TRIM	AMETEK
522-4865-00	334D-2-33F	SERVO, TRIM TAB	COLLINS
522487	8602-8	MONITOR, BATTERY TEMPERATURE	AMETEK
522-4872-()	578D-1C	TEST SET, DME BENCH	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
522-4880-001	614E-7A1	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4880-001	614E-7A1	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4892-()	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-006	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-006	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-006	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-006	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-006	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-008	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-008	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-009	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-010	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4892-014	562P-1E1	COMPUTER, PITCH STEERING	COLLINS
522-4896-001	488A-4	INVERTER, POWER	COLLINS
522-4899-001	440Y-5	ADAPTER	COLLINS
522-4900-001	440Y-6	ADAPTER	COLLINS
522-4903-001	614E-2G1	CONTROLLER, PEDESTAL	COLLINS
522-4940-001	614E-10A	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4940-001	614E-10A	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4940-001	614E-10A	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4940-002	614E-10A	CONTROL, FLIGHT DIRECTOR	COLLINS
522-4944-001	440Y-7	ADAPTER	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4945-001	323A-2G	DETECTOR, FLUX	COLLINS
522-4957-001	440Y-8	ADAPTER	COLLINS
522-4958-001	440Y-9	ADAPTER	COLLINS
522-4960-001	440Y-11	ADAPTER	COLLINS
522-4961-001	440Y-12	ADAPTER	COLLINS
522-4962-001	440Y-13	ADAPTER	COLLINS
522-4963-001	440Y-14	ADAPTER	COLLINS
522-4964-001	440Y-15	ADAPTER	COLLINS
522-4977-001	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-4977-001	51RV-2B	RECEIVER, VOR / ILS	COLLINS
522-5121-0XX	437C-2	ANTENNA, BROADBAND H-F MONOPOLE	COLLINS
522-5126-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
522-5730-004	979A-2	KIT, RADAR MAINTENANCE	COLLINS
522-5731-005	978G-1	TEST SET, RADAR	COLLINS
522-5883-004	561G-4	UNIT, COCKPIT CONTROL	COLLINS
522636	1888-206LW	INDICATOR, RPM%	AMETEK
522-6454-001	590A-3D	CONTROLLER, ALTITUDE	COLLINS
522760	1825-115LW	INDICATOR, DUAL FUEL TEMPERATURE	AMETEK
522778	8604-4	MONITOR, D.C. POWER	AMETEK
522808	8604-5	MONITOR, A.C. POWER	AMETEK
522848	1825-117LW	INDICATOR, ENGINE OIL TEMPERATURE &	AMETEK
522848		INDICATOR, ENGINE OIL TEMPERATURE &	AMETEK
522849	1815-3LW	INDICATOR, LOW PRESSURE ROTOR SPEED	AMETEK
522-8961-005	493A-3	INDICATOR	COLLINS
522-8963-000	561G-3	KIT, COCKPIT CONTROL	COLLINS
522-9073-012	331A-6D	INDICATOR, COURSE	COLLINS
522942	1822-378LW	INDICATOR, FLAP POSITION	AMETEK
522942		INDICATOR, FLAP POSITION	AMETEK
522945	1812-222LW	INDICATOR, FUEL TANK TEMPERATURE	AMETEK
523115	1812-224LW	INDICATOR, RUDDER TRIM	AMETEK
523115		INDICATOR, RUDDER TRIM	AMETEK
523188		INDICATOR, FLAP POSITION	AMETEK
523244	1825-129LW	INDICATOR, TEMPERATURE - DUAL FUEL	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
523244	1825-129LW	INDICATOR, DUAL FUEL TEMPERATURE	AMETEK
523281		INDICATOR, ENGINE OIL TEMPERATURE &	AMETEK
523-3750-()	562A-5F1	COMPUTER, STEERING	COLLINS
52-4703-002	562A-5F4	COMPUTER, STEERING	COLLINS
5260-1		UNIT, AUDIO REMOTE ELECTRONICS	AVTECH
5261-1		PANEL, AUDIO CONTROL	AVTECH
5264-1-1		UNIT, ELECTRONICS	AVTECH
5287-1		UNIT, ATTENDANT #2 CONTROL	AVTECH
5289-1		UNIT, ATTENDANT #1 CONTROL	AVTECH
52C77-()	52C77-()	HORIZON, FLIGHT DIRECTOR STEERING	SIGMA-TEK
52C77-2	52D107	INDICATOR, ATTITUDE	SIGMA-TEK
52D136-0033	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D136-1032	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D136-1037	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D136-1303	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D136-1333	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-()	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-()	NSD360()	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-1332	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-1333	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-2331	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-2334	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-2335	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D137-2336	NSD360	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D177()	52D177()	INDICATOR, FLIGHT DIRECTOR STEERING	SIGMA-TEK
52D178	52D178	HORIZON, FLIGHT DIRECTOR STEERING	SIGMA-TEK
52D189-()	NSD1000	DISPLAY, NAVIGATION SITUATION	SIGMA-TEK
52D54	4000C	INDICATOR, DIRECTIONAL GYRO WITH	SIGMA-TEK
52D55	52D55	GYRO, ATTITUDE	JET/AIM
52D66	5000E-8	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
52D66	52D66	INDICATOR, HORIZON REFERENCE	SIGMA-TEK
52D67	5000E-9	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
52D67	52D67	INDICATOR, HORIZON REFERENCE	SIGMA-TEK
52D75-3/-4	52D75-3/-4	STABILIZER, PICTORIAL TURN AND BANK	SIGMA-TEK
52D75-3/-4	52D75-3/-4	STABILIZER, PICTORIAL TURN AND BANK	SIGMA-TEK
52D75-3/-4	52D75-3/-4	STABILIZER, PICTORIAL TURN AND BANK	SIGMA-TEK
52D75-3/-4M	52D75-3/-4M	STABILIZER, PICTORIAL TURN AND BANK	SIGMA-TEK
5301-6		TRANSMITTER, TORQUE	LABEM
5301-6		TRANSMITTER, TORQUE	LABEM
5301-6		TRANSMITTER, TORQUE	LABEM
531643		VOLTMETER, D.C.	AMETEK
5346-220-80-10		INDICATOR, CABIN DUCT TEMP.	BRION-LEROUX
5347-700-80-10		INDICATOR, DUAL LOW PRESS ROTOR	BRION-LEROUX
5348-200-80-10		INDICATOR, FUEL TANK TEMPERATURE	BRION-LEROUX
5351-6		TRANSMITTER, TORQUE	LABEM
53-51-6		TRANSMITTER, TORQUE	LABEM
535201-1		ASSEMBLY, LANDING GEAR CONTROL	AVTECH
53-52-6		TRANSMITTTER, TORQUE	LABEM
53-52-6		TRANSMITTTER, TORQUE	LABEM
53-52-6		TRANSMITTTER, TORQUE	LABEM
5383-1		INTERPHONE HANDSET/CRADLE	AVTECH
5396-213-1		INDICATOR, TEMPERATURE - ENGINE OIL	BRION-LEROUX
5-4000-()	VG-301()	INDICATOR, VERTICAL GYRO	JET ELECTRONICS
5400-7295-()		COORDINATOR, TURN	MID-CONTINENT
5400-7425-()		COORDINATOR, TURN	MID-CONTINENT
540-22722-()		ALERTER, ALTITUDE	IDC
540-7374-003	323A-1	COMPENSATOR	COLLINS
540-7374-003	323A-3G-2	COMPENSATOR	COLLINS
540-7856-002	384A-1	SWITCH, SLAVE	COLLINS
540-7856-002	384A-1	SWITCH, SLAVE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
540-7856-002	384A-1	SWITCH, SLAVE	COLLINS
5412		INDICATOR, SUB-ASSEMBLY	MID-CONTINENT
5427-115-80-10		INDICATOR, DUAL HYDRAULIC PRESSURE	BRION-LEROUX
5427-218-80-10		INDICATOR, DUAL FUEL TEMPERATURE	BRION-LEROUX
5427-361-80-10		INDICATOR, ENGINE OIL TEMP / PRESSURE	BRION-LEROUX
5428-150-80-10		INDICATOR, PRESSURE - HYD (PARK BRAKE)	BRION-LEROUX
545	545	INDICATOR, D.C TACHOMETER	AMETEK
545R	545R	INDICATOR, A.C TACHOMETER	AMETEK
5468002G1	MO-1	TEST SET, FUEL FLOWMETER	AMETEK
547-3914-00	678P-1	HARNESS, RADIO SET TEST	COLLINS
5473B	5473B	SELECTOR, MODE	SMITHS
548408-1		SENSOR, DUCT TEMPERATURE CONTROL	GARRETT
548-8001-005	678Z-1	TEST SET, FUNCTION	COLLINS
548-9948-00	332G-2	INDICATOR, RATE GYRO	COLLINS
548-994X-00	332G-2	GYRO, RATE	COLLINS
5494-611-1		INDICATOR, TRIPLE	BRION-LEROUX
549B(-)	549B(-)	SYNCHROSCOPES, 2-ENGINE	KOLLSMAN
549B(-)	549B(-)	SYNCHROSCOPES	KOLLSMAN
550(-)		SPECIFICATION, PROCUREMENT	JET ELECTRONICS
5500()	5500 SERIES	INDICATOR, SERVOED ENCODING	UNITED INSTRUMENTS
55035-1138		INDICATOR, CABIN ALTIEMTER DIFFERENTIAL	AEROSONIC
5506-1001-0901	2254-013B	DETECTOR, MAGNETIC FLUX	CASTLEBERRY
5506-S()	5506-S SERIES	INDICATOR, SERVOED ENCODING	UNITED INSTRUMENTS
5510	5510	AMPLIFIER, INSTRUMENT	SMITHS
5519	5519	COMPUTER, AMPLIFIER	SMITHS
5536E(-)	5536E(-)	AMPLIFIER, COMPUTER	BENDIX
555(-)	555(-)	SWITCH, PRESSURE	COOK
5550-7485N()		INDICATOR, TURN & SLIP	MID-CONTINENT
5550-8340N1L		INDICATOR, TURN & SLIP	MID-CONTINENT
5550-N2		INDICATOR, TURN & SLIP	MID-CONTINENT
5560-7615N3L		INDICATOR, TURN & SLIP	MID-CONTINENT
5560N1		INDICATOR, TURN & BANK	MID-CONTINENT
556-10-1		INDICATOR, CABIN TEMPERATURE	INSTRUMENTS INC.
557(-)-902	IVA 557	INDICATOR, RADIO MAGNETIC	AEROSPATIALE
557-3		INDICATOR, FLAP POSITION	INSTRUMENTS INC.
5590F1-1	SPS48	INVERTER, STATIC POWER	SPAR AEROSPACE
5617(-)-91(-)		INDICATOR, DUAL ENGINE OIL PRESSURE TEMP.	BRION LEROUX
5617-352-91-11,12		INDICATOR, ENGINE OIL TEMP / PRESSURE (BAR)	BRION-LEROUX
5617-355-91-11		INDICATOR, ENGINE OIL TEMP / PRESSURE (PSI)	BRION-LEROUX
5617-357-91-10		INDICATOR, ENGINE OIL TEMP / PRESSURE (PSI)	BRION-LEROUX
5622-522.00		INDICATOR, TEMPERATURE - T4	BRION-LEROUX
5626(-)-(-)-(-)		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-5(-)-(-)		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-514.0		PIROMETER	BRION-LEROUX
5626-517.0		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-518-00		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-522-00		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-523-91		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-524-00-00		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-524-00-00		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-525-0		INDICATOR, TEMPERATURE	BRION-LEROUX
5626-555-00-11		INDICATOR, TEMPERATURE	BRION-LEROUX
562-98()		INDICATOR, OIL TEMP / PRESSURE	HICKOK
563-031		INDICATOR, OIL TEMP / PRESSURE (DUAL)	HICKOK
563-031		INDICATOR, OIL TEMP / PRESSURE (DUAL)	HICKOK
563-039		INDICATOR, ANGLE OF ATTACK	HICKOK
563-069		INDICATOR, PRESSURE - HYDRAULIC	HICKOK
563-070		INDICATOR, PRESSURE - OXYGEN CYLINDER	HICKOK
563-071		INDICATOR, PRESSURE - DE-ICE	HICKOK
563-073		INDICATOR, TEMPERATURE - CABIN AIR	HICKOK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
563-074		INDICATOR, PRESSURE - OXYGEN CYLINDER	HICKOK
563-084		INDICATOR, QUANTITY - ALCOHOL/WATER	HICKOK
563-085		INDICATOR, QUANTITY - ALCOHOL/WATER	HICKOK
563-193		INDICATOR, AMMETER - PROP (DUAL)	HICKOK
563-203		INDICATOR, TEMP / PRESSURE	HICKOK
563-23()		INDICATOR, OIL TEMP / PRESSURE	HICKOK
563-266		INDICATOR, OIL TEMP / PRESSURE	HICKOK
563-267		INDICATOR, AMMETER - PROP (DUAL)	HICKOK
563-280		INDICATOR, TEMP / PRSSURE	HICKOK
5633-()-()-()		INDICATOR, TACHOMETER - NG LIMIT	BRION-LEROUX
563-305		INDICATOR, OIL TEMP / PRESSURE	HICKOK
563-306		INDICATOR, OIL TEMP / PRESSURE	HICKOK
5637-551-00-12		INDICATOR, TEMPERATURE - T4	BRION-LEROUX
565X-1-()		SYSTEM, AUDIO CONTROL	AVTECH
5690-1		ACCELEROMETER	LORAL
570-31400-()	570-31400-()	ALTIMETER, PNEUMATIC	KOLLSMAN
570-382		INDICATOR, VOLTS/AMMETER - 400HZ	HICKOK
570-518		INDICATOR, FREQUENCY / VOLTS	HICKOK
570-529		INDICATOR, VOLTS/FREQUENCY - AC	HICKOK
570-536		INDICATOR, AC VOLTS / FREQUENCY	HICKOK
570-542		INDICATOR, VOLTS/AMMETER - 400HZ	HICKOK
571-()		SPECIFICATION, PROCUREMENT	JET ELECTRONICS
571-29020-()		PNEUMATIC ALTIMETER	INTERCONTINENTAL
57-4AW	57 SERIES	INDICATOR, TACHOMETER - DUAL (MECHANICAL)	CONSOLIDATED INSTRUMENT
575-0758	831-0002	DETECTOR, ICE	COOK
575-127	575-127	SWITCH, PRESSURE	COOK
575407		GYRO, RATE	HAMILTON STANDARD
575474		GYRO, RATE	HAMILTON STANDARD
577792-()		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
577792-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
577792-2		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
5795-6		CONTROLLER, SERVO	MID-CONTINENT
5802-01		INDICATOR, INNER TURBINE TEMPERATURE	AERO-MACH
58057-()	130	COMPASS, GYROMAGNETIC	SFIM
586()	586()	INDICATOR, AIRSPEED	KOLLSMAN
586BK-()	586BK-()	INDICATOR, AIRSPEED	KOLLSMAN
586BK-0110	586BK-0110	INDICATOR, AIRSPEED	KOLLSMAN
586BK-0142	586BK-0142	INDICATOR, AIRSPEED	KOLLSMAN
586BK-1-0153	586BK-1-0153	INDICATOR, AIRSPEED	KOLLSMAN
586BK-13-0155	586BK-13-0155	INDICATOR, AIRSPEED	KOLLSMAN
586CK-()	586CK-()	INDICATOR, AIRSPEED	KOLLSMAN
586CK-4-0158	586CK-4-0158	INDICATOR, AIRSPEED	KOLLSMAN
586CK-4-0160	586CK-4-0160	INDICATOR, AIRSPEED	KOLLSMAN
586K-026	586K-026	INDICATOR, AIRSPEED	KOLLSMAN
586K-028	586K-028	INDICATOR, AIRSPEED	KOLLSMAN
58BL	58BL	INDICATOR, COMPASS	KOLLSMAN
590BK-()-01	590BK-()-01	INDICATOR, SENSITIVE ELECTRIC TACHOMETER	KOLLSMAN
5915, 5916, 5997	AY-()	INDICATOR, COMPASS - RADIO	BENDIX
5934()	5934 SERIES	ALTIMETER, SENSITIVE PRESSURE	UNITED INSTRUMENTS
593-8655-001	714E-3C	CONTROL, RADIO SET	COLLINS
5958-92B-15-A	C-27	PRESSURE, FUEL AND OIL	BENDIX
5958-96B-15A	B-16	PRESSURE, FUEL AND OIL	BENDIX
597-2790	597-2790	FLOATS, AMPHIBIOUS	SIGMA-TEK
5979-116-1		INDICATOR, VOLTS - DC	BRION-LEROUX
60-0304-31		POWER SUPPLY, EMERGENCY - RECHARGEABLE	GRIMES
60-0304-33		POWER SUPPLY, EMERGENCY - RECHARGEABLE	GRIMES
60-0304-51		POWER SUPPLY, EMERGENCY - RECHARGEABLE	GRIMES
6007--A,B		INDICATOR, AUTOSYN - DUAL	BENDIX
6009--A		INDICATOR, AUTOSYN - DUAL	BENDIX
60-1	60-1	AUTOPILOT	S-TEC

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
60-10()____		SUPPLY, STROBE LIGHT POWER	HOSKINS (SYMBOLIC)
601285-()		CLUSTER, INSTRUMENT	JAEGER
60-1321-1		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1321-1LB		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1321-5		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1321-5LB		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1321-7		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1321-7LB		POWER SUPPLY, EMERGENCY - EXIT LIGHT	GRIMES
60-1376		LIGHT, STROBE	GRIMES
60-1431		LIGHT, STROBE	GRIMES
60-1473		LIGHT, STROBE	GRIMES
60-1592		LIGHT, STROBE	GRIMES
60-1750		LIGHT, STROBE	GRIMES
60-1750-()		FLASHTUBE, POWER SUPPLY	GRIMES
60-1750-()		SUPPLY, FLASHTUBE POWER	GRIMES
60-1750-()		SUPPLY, FLASHTUBE POWER	MIDLAND ROSS
6019--A,B		INDICATOR, AUTOSYN - DUAL	BENDIX
602	602	INDICATOR, CYLINDER TEMPERATURE	AMETEK
60-2	60-2	AUTOPILOT	S-TEC
60-2	60-2	AUTOPILOT	S-TEC
602/606	602/606	INDICATOR, RESISTANCE THERMOMETER	AMETEK
60-2000	OM-60-2000	SUPPLY, TWILIGHTER POWER	HOSKINS (SYMBOLIC)
60-2250		SUPPLY, STROBE POWER	GRIMES
60-2388-1		LIGHT, FLASHTUBE ANTI-COLLISION	GRIMES
60-2388-101		LIGHT, FLASHTUBE ANTI-COLLISION	GRIMES
60-2502-1		PACK, BATTERY	GRIMES
60-2502-5		PACK, BATTERY	GRIMES
60-2799-()		SUPPLY, POWER	GRIMES
60-2836		SUPPLY, FLASHTUBE POWER	GRIMES
60-3269-1		SUPPLY, RECHARGEABLE BATTERY POWER	GRIMES
60-3269-3		SUPPLY, RECHARGEABLE BATTERY POWER	GRIMES
60-3274-1		SUPPLY, STROBE LIGHT POWER	GRIMES
60-3274-5		SUPPLY, STROBE LIGHT POWER	GRIMES
60-3550-1		SUPPLY, EMERGENCY EXIT LIGHT BATTERY	GRIMES
60-3557		SUPPLY, FLASHTUBE POWER	GRIMES
60-3742		SUPPLY, STROBE LIGHT POWER	GRIMES
60-3844-()		SUPPLY, EMERGENCY POWER BATTERY	GRIMES
60-3844-1		SUPPLY, EMERGENCY POWER BATTERY	GRIMES
60-3844-1LB		SUPPLY, EMERGENCY POWER BATTERY	GRIMES
60-3844-3		SUPPLY, EMERGENCY POWER BATTERY	GRIMES
60-3844-3LB		SUPPLY, EMERGENCY POWER BATTERY	GRIMES
6058--A		INDICATOR, AUTOSYN - DUAL	BENDIX
606-3853-001	A6	MODULE, RECEIVER	COLLINS
607690-()	RESCU 99	TRANSMITTER, EMERGENCY LOCATOR -	GARRETT
607690-()	RESCU 99	TRANSMITTER, EMERGENCY LOCATOR -	GARRETT
607742-1-1		INVERTER, STATIC	GARRETT
608-5651-001	A4	MODULE, DISTANCE	COLLINS
6097768-100	1014A	TRANSPONDER, ATC	HONEYWELL
6097768-100	1014A	TRANSPONDER	HONEYWELL
6097768-101	1014A	TRANSPONDER	HONEYWELL
6097768-200	TP-114B	SYSTEM, ATC TRANSPONDER	HONEYWELL
6097768-200	TP-114B	TRANSPONDER	HONEYWELL
6097768-201	1014B	TRANSPONDER	HONEYWELL
6097936-400	CT-107B	SYSTEM, VHF COMMUNICATIONS	HONEYWELL
6098025-400	GS-100A	RECEIVER, GLIDESLOPE	HONEYWELL
6098027-400	NR-106A	RECEIVER, AUTOMATIC NAVGATION	HONEYWELL
6098027-401	NR-106A	RECEIVER, AUTOMATIC NAVGATION	HONEYWELL
6098027-410	NR-106A	RECEIVER, AUTOMATIC NAVGATION	HONEYWELL
6098027-411	NR-106A	RECEIVER, AUTOMATIC NAVGATION	HONEYWELL
6098027-4XX	NR-106A	SYSTEM, NAVIGATION	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
6098032-400	GS-100B	GLIDESLOPE / MARKER RECEIVER	HONEYWELL
60980XX-400	GS-100A/B	SYSTEM, NAVIGATION	HONEYWELL
61015-00()-()		INDICATOR, DUAL TORQUE	JAEGER
61111-()		INDICATOR, PERCENT RPM	LEWIS
61111-14		INDICATOR, PERCENT RPM	LEWIS
61-2004/2008__	OM-60-2000	SUPPLY, STROBE LIGHT POWER	HOSKINS (SYMBOLIC
6132-1		HEAD, VHF COMM CONTROL	AVTECH
613260-()		GYRO, DIRECTION	HONEYWELL
613937	H-6A	INDICATOR, GYRO HORIZON	HONEYWELL
613K-()-023	613K-()-023	INDICATOR, VERTICAL SPEED	KOLLSMAN
61461-01		INDICATOR, DUAL FUEL QUANTITY	LEWIS
61474-()-1		INDICATOR, TACHOMETER	JAEGER
61475-()-1		INDICATOR, TACHOMETER - NG	JAEGER
614937-()	C-()	SYSTEM, COMPASS RACK	HONEYWELL
614937-()		RACK, COMPASS SYSTEM	HONEYWELL
614K-()-023	614K-()-023	INDICATOR, VERTICAL SPEED	KOLLSMAN
614U-5	522-1347-00	CONTROL	COLLINS
61533-()-1		INDICATOR, TEMPERATURE	JAEGER
615794		ACCELEROMETER, LINEAR	HONEYWELL
617452-3		CONTROLLER, TEMPERATURE	GARRETT
617454-()	RESCU 99 DAL	LOCATOR, AUTOMATIC DOWNED AIRCRAFT	GARRETT
618319-3	MA-4A	AMPLIFIER, MULTIPLE CHANNEL ELECTRONIC	HONEYWELL
618379	C-()	AMPLIFIER, SERVO	HONEYWELL
620359	FX-120	VALVE, THIN FLUX	HONEYWELL
620359		VALVE, FLUX	HONEYWELL
620399		CONTROL, ALTITUDE	HONEYWELL
620783	CS-211	COMPENSATOR	HONEYWELL
620783		COMPENSATOR, FLUX DETECTOR	HONEYWELL
621107	C-()	AMPLIFIER, SLAVING	HONEYWELL
6214-02		GENERATOR, MOTOR-TACHOMETER	MEGGITT AVIONICS
621-9278-001	917A-2	ASSEMBLY, TRANSMITTER-MODULATOR PLANAR	COLLINS
621KN-02	621KN-02	INDICATOR, TACHOMETER	KOLLSMAN
622-()-001	332D-12/12A	INDICATOR, VERTICAL GYRO	COLLINS
622-0047-00X	614E-20G	SELECTOR, FLIGHT MODE	COLLINS
622-0049-001	974R-1	TEST SET, RATE GYRO	COLLINS
622-0080-001	699K-1	ADAPTER, TRIM	COLLINS
622-0080-001	699K-1	ADAPTER, TRIM	COLLINS
622-0141-001	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-002	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-003	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-004	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-005	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-005	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-006	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-007	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-008	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-009	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-010	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-011	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-012	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-013	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-014	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-015	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-016	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-017	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-018	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-019	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-020	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-021	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-022	APP-80	PANEL, AUTOPILOT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-0141-023	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-024	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-025	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-026	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-027	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-028	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-029	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-030	APP-80	PANEL, AUTOPILOT	COLLINS
622-0141-XXX	APP-80	PANEL, AUTOPILOT	COLLINS
622-0142-001	614E-22D	SELECTOR, ERMOTE HEADING AND COURSE	COLLINS
622-0142-001	614E-22D	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-0142-001	614E-22D	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-0142-00X	614E-22D	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-0142-00X	614E-22D	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-0143-00X	614E-20H	SELECTOR, MODE	COLLINS
622-0158-001	447W-7	HARNESS, TEST BENCH	COLLINS
622-0171-00X	339H-3	INDICATOR, RADIO ALTITUDE	COLLINS
622-0171-00X	339H-3	INDICATOR, RADIO ALTITUDE	COLLINS
622-0181-003	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0181-00X	345A-7B	SENSOR, RATE OF TURN	COLLINS
622-0210-00X	614E-23G	SELECTOR, FLIGHT MODE	COLLINS
622-0213-001	FD-112A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-0213-001	FD-112A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-0214-001	FD-112B	INDICATOR, COMPUTER	COLLINS
622-0214-001	FD-112B	INDICATOR-COMPUTER	COLLINS
622-0214-001	FD-112B	INDICATOR-COMPUTER	COLLINS
622-0218-001	614E-20H	SELECTOR, MODE	COLLINS
622-0218-00X	614E-20H	SELECTOR, FLIGHT MODE	COLLINS
622-0224-001	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-002	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-003	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-004	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-005	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-006	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0224-00X	ADI-85	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0263-00X	614E-20I	SELECTOR, FLIGHT MODE	COLLINS
622-0283-001	161F-1B/1C	COUPLER, AIR DATA	COLLINS
622-0283-00X	161F-1B	COUPLER, AIR DATA	COLLINS
622-0283-00X	161F-1B/1C	COUPLER, AIR DATA	COLLINS
622-0308-001	329B-8Z	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-0317-00X	614E-20K	SELECTOR, FLIGHT MODE	COLLINS
622-0410-001	860F-2	ALTIMETER, RADIO	COLLINS
622-0555-001	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-002	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-003	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-004	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-005	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-006	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-007	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-008	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-010	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0555-011	332C-10	INDICATOR, RADIO MAGNETIC	COLLINS
622-0591-()	718U-5	TRANSCEIVER, LIGHTWEIGHT HF AIRBORNE	COLLINS
622-0646-001	947A-1F	RECEIVER, TRANSLATOR	COLLINS
622-0673-001	345N-1C	SENSOR, CONTROL WHEEL STEERING	COLLINS
622-0757-001	FD-112C	INDICATOR, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-0757-001	FD-112C	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-0757-00X	FD-112C	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-0846-001	980L-1A	TEST SET	COLLINS
622-0876-XXX	VIR-30A	RECEIVER, NAVIGATION	COLLINS
622-0877-XXX	VIR-30M	RECEIVER, NAVIGATION	COLLINS
622-0917-001	614E-10D	CONTROL, FLIGHT DIRECTOR	COLLINS
622-0917-002	614E-10D	CONTROL, FLIGHT DIRECTOR	COLLINS
622-0938-00X	161F-1C	COUPLER, AIR DATA	COLLINS
622-0941-3XX	345E-1B	UNIT, INERTIAL NAVIGATION	COLLINS
622-0944-003	614E-20R	SELECTOR, MODE	COLLINS
622-0944-003	614E-20R	SELECTOR, MODE	COLLINS
622-0944-003	614E-20R	SELECTOR, FLIGHT MODE	COLLINS
622-0944-00X	614E-20R	SELECTOR, FLIGHT MODE	COLLINS
622-0944-00X	614E-20R	SELECTOR, MODE	COLLINS
622-0945-003	614E-23R	SELECTOR, MODE	COLLINS
622-0945-003	614E-23R	SELECTOR, MODE	COLLINS
622-0945-003	614E-23R	SELECTOR, FLIGHT MODE	COLLINS
622-0945-003	614E-23R	SELECTOR, FLIGHT MODE	COLLINS
622-0945-00X	614E-23R	SELECTOR, FLIGHT MODE	COLLINS
622-0945-00X	614E-23R	SELECTOR, MODE	COLLINS
622-0950-00X	614E-37	SELECTOR, FLIGHT MODE	COLLINS
622-0954-001/002	437X-1B	ANTENNA	COLLINS
622-0964-001	334C-9	SERVO, PRIMARY	COLLINS
622-0964-002	334C-9	SERVO, PRIMARY	COLLINS
622-0964-003	334C-9	SERVO, PRIMARY	COLLINS
622-0964-004	334C-9	SERVO, PRIMARY	COLLINS
622-0964-00X	334C-9	SERVO, PRIMARY	COLLINS
622-0964-00X	334C-9	SERVO, PRIMARY	COLLINS
622-0965-()	334D-6	SERVO, TRIM	COLLINS
622-0965-001	334D-6	SERVO, TRIM	COLLINS
622-0965-001	334D-6	SERVO, TRIM	COLLINS
622-0965-001	334D-6	SERVO, TRIM	COLLINS
622-0965-001	334D-6	SERVO, TRIM	COLLINS
622-0965-002	334D-6	SERVO, TRIM	COLLINS
622-0965-002	334D-6	SERVO, TRIM	COLLINS
622-0965-00X	334D-6	SERVO, TRIM	COLLINS
622-0965-00X	334D-6	SERVO, TRIM	COLLINS
622-0965-XXX	334D-6	SERVO, TRIM	COLLINS
622-0966-00X	913K-1	COMPUTER / CONTROL	COLLINS
622-0966-00X	913K-1	COMPUTER / CONTROL	COLLINS
622-1001-001	590A-3J	CONTROLS, AIR DATA	COLLINS
622-1001-001	590A-3J	CONTROL, AIR DATA	COLLINS
622-1001-001	590A-3J	CONTROL, AIR DATA	COLLINS
622-1001-001	590A-3J	CONTROL, AIR DATA	COLLINS
622-1001-001	590A-3J	CONTROLLER, AIR DATA	COLLINS
622-1001-001	590A-3J	CONTROL, AIR DATA	COLLINS
622-1001-002	590A-3J	CONTROLS, AIR DATA	COLLINS
622-1001-00X	590A-3J	CONTROL, AIR DATA	COLLINS
622-1001-019	590A-3J	CONTROLS, AIR DATA	COLLINS
622-1032-001	699Z-1	DRIVER, RMI	COLLINS
622-1032-001	699Z-1	ADAPTER, RMI	COLLINS
622-1032-001	699Z-1A	ADAPTER, RMI	COLLINS
622-1036-001	161H-1	PROGRAMMER, GAIN	COLLINS
622-1038-001	339H-1L	INDICATOR, RADIO ALTITUDE	COLLINS
622-1038-001	339H-1L	INDICATOR, RADIO ALTITUDE	COLLINS
622-1062-001	651S-1A	RECEIVER, GENERAL PURPOSE HF	COLLINS
622-1062-001	651S-1A	RECEIVER, GENERAL PURPOSE HF	COLLINS
622-1064-001	AT-107B	SYSTEM, HF PROBE ANTENNA COUPLER	COLLINS
622-1064-001	AT-107B	SYSTEM, HF PROBE ANTENNA COUPLER	COLLINS
622-1065-001	180R-17B	COUPLER, ANTENNA	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-1065-001	180R-17B	COUPLER, ANTENNA	COLLINS
622-1101-001	479S-4A	GENERATOR, ILS SIGNAL	COLLINS
622-1116-()	562C-5B	AMPLIFIER, AUTOPILOT	COLLINS
622-1116-()	562C-5B	AMPLIFIER, AUTOPILOT	COLLINS
622-1116-0XX	562C-5B	AMPLIFIER, AUTOPILOT	COLLINS
622-1116-0XX	562C-5B	AMPLIFIER, AUTOPILOT	COLLINS
622-1120-001	CTL-22C	CONTROL	COLLINS
622-1120-002	CTL-22C	CONTROL	COLLINS
622-1120-003	CTL-22C	CONTROL	COLLINS
622-1120-004	CTL-22C	CONTROL	COLLINS
622-1120-005	CTL-22C	CONTROL	COLLINS
622-1120-006	CTL-22C	CONTROL	COLLINS
622-1120-007	CTL-22C	CONTROL	COLLINS
622-1120-008	CTL-22C	CONTROL	COLLINS
622-1120-009	CTL-22C	CONTROL	COLLINS
622-1120-010	CTL-22C	CONTROL	COLLINS
622-1120-011	CTL-22C	CONTROL	COLLINS
622-1120-012	CTL-22C	CONTROL	COLLINS
622-1120-013	CTL-22C	CONTROL	COLLINS
622-1120-014	CTL-22C	CONTROL	COLLINS
622-1120-015	CTL-22C	CONTROL	COLLINS
622-1120-016	CTL-22C	CONTROL	COLLINS
622-1180-00X	8564B-2A	UNIT, NAVIGATION COMPUTER	COLLINS
622-1181-00X	618M-3	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
622-1181-00X	618M-3	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
622-1181-00X	618M-3	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
622-1181-00X	618M-3	TRANSCEIVER, VHF COMMUNICATIONS	COLLINS
622-1194-001	390R-18	KITS, UNIVERSAL MOUNT	COLLINS
622-1194-301	390R-18	KITS, UNIVERSAL MOUNT	COLLINS
622-1195-001	390R-19	KITS, UNIVERSAL MOUNT	COLLINS
622-1195-301	390R-19	KITS, UNIVERSAL MOUNT	COLLINS
622-1195-301	390R-19	MOUNT, UNIVERSAL	COLLINS
622-1196-001	390R-20	KITS, UNIVERSAL MOUNT	COLLINS
622-1196-301	390R-20	KITS, UNIVERSAL MOUNT	COLLINS
622-119X-0001	390R-18/19/20	KITS, UNIVERSAL MOUNT	COLLINS
622-1204-001	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-002	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-003	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-004	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-005	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-006	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-008	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-00X	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1204-010	339H-4	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-001	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-002	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-003	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-004	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-005	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-006	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1205-00X	339H-4A	INDICATOR, RADIO ALTITUDE	COLLINS
622-1210-00X	614E-41	CONTROL, PITCH / TURN	COLLINS
622-1233-001	DME-40	RECEIVER-TRANSMITTER	COLLINS
622-1234-002	339F-12	INDICATOR	COLLINS
622-1234-003	339F-12	INDICATOR	COLLINS
622-1234-004	339F-12	INDICATOR	COLLINS
622-1234-005	339F-12	INDICATOR	COLLINS
622-1234-006	339F-12	INDICATOR	COLLINS
622-1234-007	339F-12	INDICATOR	COLLINS
622-1234-012	339F-12	INDICATOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-1234-013	339F-12	INDICATOR	COLLINS
622-1234-016	339F-12	INDICATOR	COLLINS
622-1234-017	339F-12	INDICATOR	COLLINS
622-1234-102	339F-12	INDICATOR	COLLINS
622-1234-103	339F-12	INDICATOR	COLLINS
622-1234-113	339F-12	INDICATOR	COLLINS
622-1234-206	339F-12	INDICATOR	COLLINS
622-1234-207	339F-12	INDICATOR	COLLINS
622-1234-207	339F-12	INDICATOR	COLLINS
622-1234-313	339F-12	INDICATOR	COLLINS
622-1239-001	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-002	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-003	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-004	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-007	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-008	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-009	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-011	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-012	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1239-014	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1270-001	TDR-90	TRANSPONDER	COLLINS
622-1270-001	TDR-90	TRANSPONDER	COLLINS
622-1281-00X	562C-5C	AMPLIFIER, AUTOPILOT	COLLINS
622-1281-00X	562C-5C	AMPLIFIER, AUTOPILOT	COLLINS
622-1281-00X	562C-5C	AMPLIFIER, AUTOPILOT	COLLINS
622-1281-00X	562C-5C	AMPLIFIER, AUTOPILOT	COLLINS
622-1329-013	VIR-31A	RECEIVER, RADIO NAVIGATION	COLLINS
622-1329-027	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-1334-00X	VHF-20B	TRANSCIVER, VHF	COLLINS
622-1352-00X	FD-112V	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-1352-00X	FD-112V	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-1377-001	332D-12	REFERENCE, VERTICAL GYRO	COLLINS
622-1396-()	618M-3A	TRANSCIVER, VHF COMMUNICATIONS	COLLINS
622-1396-()	618M-3A	TRANSCIVER, VHF COMMUNICATIONS	COLLINS
622-1396-()	618M-3A	TRANSCIVER, VHF COMMUNICATIONS	COLLINS
622-1396-()	618M-3A	TRANSCIVER, VHF COMMUNICATIONS	COLLINS
622-1405-001	614E-10E	CONTROL, FLIGHT DIRECTOR	COLLINS
622-1405-002	614E-10E	CONTROL, FLIGHT DIRECTOR	COLLINS
622-1406-001	614E-22F	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-1522-00X	562C-13	COMPUTER, AUTOPILOT	COLLINS
622-1522-00X	562C-13	COMPUTER, AUTOPILOT	COLLINS
622-1523-001	614E-42	SELECTOR, MODE	COLLINS
622-1523-00X	614E-42	SELECTOR, MODE	COLLINS
622-1626-001	972S-1	TEST SET, AUTOPILOT RAMP	COLLINS
622-1668-001	972S-2	TEST SET, AUTOPILOT BENCH	COLLINS
622-1668-001	972S-2	TEST SET, AUTOPILOT BENCH	COLLINS
622-1734-001	ANS-31	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-1734-002	ANS-31	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-1736-01X	NCS-31	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-1737-00X	899P-1	UNIT, RADIO ADAPTER	COLLINS
622-1738-00X	899P-1	UNIT, MODE SELECT	COLLINS
622-1738-00X	913Y-1	UNIT, MODE SELECT	COLLINS
622-1738-00X	913Y-1	UNIT, MODE SELECT	COLLINS
622-1739-00X	913Y-2	UNIT, MODE SELECT	COLLINS
622-1739-00X	913Y-2	UNIT, MODE SELECT	COLLINS
622-173X-00X	913Y-X	UNIT, MODE SELECT	COLLINS
622-1816-001	699K-2	ADAPTER, TRIM	COLLINS
622-1816-001	699K-2	ADAPTER, TRIM	COLLINS
622-1816-001	699K-2	ADAPTER, TRIM	COLLINS
622-1879-00X	VHF-20A	TRANSCIVER, VHF	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-1910-001	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-002	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-003	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-004	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-005	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-006	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-007	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-008	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1910-0XX	VSI-80	INDICATOR, VERTICAL SPEED	COLLINS
622-1939-001	339R-1	UNIT, PROGRESS REMOTE READOUT	COLLINS
622-1939-011	339R-1	UNIT, REMOTE READOUT	COLLINS
622-1939-011	339R-1	UNIT, REMOTE READOUT	COLLINS
622-1940-011	339R-2	UNIT, REMOTE READOUT	COLLINS
622-1941-011	339R-3	UNIT, REMOTE READOUT	COLLINS
622-1942-011	339R-4	UNIT, REMOTE READOUT	COLLINS
622-1943-011	339R-5	UNIT, REMOTE READOUT	COLLINS
622-1944-011	339R-6	UNIT, REMOTE READOUT	COLLINS
622-1945-011	339R-7	UNIT, REMOTE READOUT	COLLINS
622-1946-011	339R-8	UNIT, REMOTE READOUT	COLLINS
622-1947-011	339R-9	UNIT, REMOTE READOUT	COLLINS
622-1948-011	339R-10	UNIT, REMOTE READOUT	COLLINS
622-1949-011	339R-11	UNIT, REMOTE READOUT	COLLINS
622-194X-001	339R-X	UNIT, REMOTE READOUT	COLLINS
622-194X-011	339R-X	UNIT, REMOTE READOUT	COLLINS
622-1950-011	339R-12	UNIT, REMOTE READOUT	COLLINS
622-1951-011	339R-13	UNIT, REMOTE READOUT	COLLINS
622-1952-011	339R-14	UNIT, REMOTE READOUT	COLLINS
622-1953-011	339R-15	UNIT, REMOTE READOUT	COLLINS
622-1954-011	339R-16	UNIT, REMOTE READOUT	COLLINS
622-1955-011	339R-17	UNIT, REMOTE READOUT	COLLINS
622-1958-011	339R-1B	UNIT, REMOTE READOUT	COLLINS
622-195X-001	339R-X	UNIT, REMOTE READOUT	COLLINS
622-195X-011	339R-1B/20	UNIT, REMOTE READOUT	COLLINS
622-195X-011	339R-1X	UNIT, REMOTE READOUT	COLLINS
622-2012-011	339F-12A	INDICATOR	COLLINS
622-2012-012	339F-12A	INDICATOR	COLLINS
622-2012-013	339F-12A	INDICATOR	COLLINS
622-2012-014	339F-12A	INDICATOR	COLLINS
622-2012-201	339F-12A	INDICATOR	COLLINS
622-2013-001	971F-1	TEST SET	COLLINS
622-2014-001	947A-1G	RECEIVER, TRANSLATOR	COLLINS
622-2078-00X	VHF-251	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-2080-001	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-002	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-003	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-004	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-005	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-006	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-011	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-012	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-013	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-014	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-015	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-016	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-111	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-112	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-113	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-114	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-115	VIR-351	RECEIVER, NAVIGATION	COLLINS
622-2080-116	VIR-351	RECEIVER, NAVIGATION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-2081-XXX	VIR-350	RECEIVER, NAVIGATION	COLLINS
622-2082-001	IND-350	INDICATOR	COLLINS
622-2082-002	IND-350	INDICATOR	COLLINS
622-2082-003	IND-350	INDICATOR	COLLINS
622-2083-001	IND-351	INDICATOR	COLLINS
622-2085-001	MKR-350	RECEIVER, MARKER	COLLINS
622-2087-001	AMR-350	PANEL, AUDIO / MARKER	COLLINS
622-2087-002	AMR-350	PANEL, AUDIO	COLLINS
622-2087-003	AMR-350	PANEL, AUDIO	COLLINS
622-2087-004	AMR-350	PANEL, AUDIO	COLLINS
622-2087-005	AMR-350	PANEL, AUDIO	COLLINS
622-2087-006	AMR-350	PANEL, AUDIO	COLLINS
622-2087-011	AMR-350	PANEL, AUDIO	COLLINS
622-2087-012	AMR-350	PANEL, AUDIO	COLLINS
622-2087-013	AMR-350	PANEL, AUDIO	COLLINS
622-2087-014	AMR-350	PANEL, AUDIO	COLLINS
622-2087-015	AMR-350	PANEL, AUDIO	COLLINS
622-2087-016	AMR-350	PANEL, AUDIO	COLLINS
622-2087-017	AMR-350	PANEL, AUDIO	COLLINS
622-2087-021	AMR-350	PANEL, AUDIO	COLLINS
622-2087-023	AMR-350	PANEL, AUDIO	COLLINS
622-2087-024	AMR-350	PANEL, AUDIO	COLLINS
622-2087-025	AMR-350	PANEL, AUDIO	COLLINS
622-2087-026	AMR-350	PANEL, AUDIO	COLLINS
622-2087-027	AMR-350	PANEL, AUDIO	COLLINS
622-2087-028	AMR-350	PANEL, AUDIO	COLLINS
622-2088-001	AUD-250	PANEL, AUDIO	COLLINS
622-2088-002	AUD-250	PANEL, AUDIO	COLLINS
622-2088-003	AUD-250	PANEL, AUDIO	COLLINS
622-2088-004	AUD-250	PANEL, AUDIO	COLLINS
622-2088-005	AUD-250	PANEL, AUDIO	COLLINS
622-2088-011	AUD-250	PANEL, AUDIO	COLLINS
622-2088-012	AUD-250	PANEL, AUDIO	COLLINS
622-2088-013	AUD-250	PANEL, AUDIO	COLLINS
622-2088-014	AUD-250	PANEL, AUDIO	COLLINS
622-2088-015	AUD-250	PANEL, AUDIO	COLLINS
622-2088-016	AUD-250	PANEL, AUDIO	COLLINS
622-2088-017	AUD-250	PANEL, AUDIO	COLLINS
622-2092-00X	TDR-950	TRANSPONDER	COLLINS
622-2093-001	PWC-150	CONVERTER, POWER	COLLINS
622-2175-001	339F-12B	INDICATOR	COLLINS
622-2175-002	339F-12B	INDICATOR	COLLINS
622-2175-003	339F-12B	INDICATOR	COLLINS
622-2175-004	339F-12B	INDICATOR	COLLINS
622-2175-201	339F-12B	INDICATOR	COLLINS
622-2176-001	339F-12C	INDICATOR	COLLINS
622-2176-002	339F-12C	INDICATOR	COLLINS
622-2176-201	339F-12C	INDICATOR	COLLINS
622-2177-001	339F-12D	INDICATOR	COLLINS
622-2193-002	462A-1	UNIT, RELAY	COLLINS
622-2211-002	972Q-4	TEST SET, VOR / ILS / MB RAMP	COLLINS
622-2224-001	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-001	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-002	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-002	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-003	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-003	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-101	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-101	621A-6A	TRANSPONDER, ATC	COLLINS
622-2224-201	621A-6A	TRANSPONDER, ATC	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-2224-201	621A-6A	TRANSPONDER, ATC	COLLINS
622-2240-001	614E-10F	CONTROL, FLIGHT DIRECTOR	COLLINS
622-2240-002	614E-10F	CONTROL, FLIGHT DIRECTOR	COLLINS
622-2256-OXX	FGC-80	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-2263-001	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-001	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-002	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-003	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-006	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-007	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-007	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-009	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-010	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-011	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-015	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-016	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-017	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-018	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-019	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-021	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-022	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-023	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-024	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-025	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-027	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-028	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-029	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-031	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-032	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-033	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-035	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2263-036	APA-80	AMPLIFIER, AUTOPILOT	COLLINS
622-2265-OXX	FGP-81	PANEL, FLIGHT GUIDANCE	COLLINS
622-2265-XXX	FGP-81	PANEL, FLIGHT GUIDANCE	COLLINS
622-2290-XXX	ADC-80F	COMPUTER, AIR DATA	COLLINS
622-2290-XXX	ADC-80F	COMPUTER, AIR DATA	COLLINS
622-2292-001	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-002	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-003	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-004	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-005	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-006	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-007	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-008	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2292-XXX	ALI-80	ALTIMETER, BAROMETRIC	COLLINS
622-2293-001	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-001	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-002	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-003	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-004	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-005	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-006	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-007	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-008	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-011	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-012	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-013	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-014	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-015	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-016	MSI-80A	INDICATOR, MACH SPEED	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-2293-017	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-018	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2293-0XX	MSI-80A	INDICATOR, MACH SPEED	COLLINS
622-2294-0XX	TAI-80A	INDICATOR, TEMPERATURE / TAS	COLLINS
622-2294-0XX	TAI-80A	INDICATOR, TEMP / TAS	COLLINS
622-2313-0XX	FGP-80	PANEL, FLIGHT GUIDANCE	COLLINS
622-2313-1XX	FGP-80	PANEL, FLIGHT GUIDANCE	COLLINS
622-2313-XXX	FGP-80	PANEL, FLIGHT GUIDANCE	COLLINS
622-2366-001	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-002	334C9A	SERVO, PRIMARY	COLLINS
622-2366-003	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-004	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-007	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-008	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-009	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-00X	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-010	334C-9A	SERVO, PRIMARY	COLLINS
622-2366-0XX	334C-9A	SERVO, PRIMARY	COLLINS
622-2367-001	614E-10G	CONTROL, FLIGHT DIRECTOR	COLLINS
622-2425-001	IND-351C	INDICATOR	COLLINS
622-2425-002	IND-351C	INDICATOR	COLLINS
622-2462-001	AMR-350H	PANEL, AUDIO / MARKER	COLLINS
622-2462-002	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-003	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-004	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-005	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-011	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-012	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-013	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-014	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-015	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-016	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-017	AMR-350H	PANEL, AUDIO	COLLINS
622-2462-018	AMR-350H	PANEL, AUDIO	COLLINS
622-2463-001	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-002	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-003	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-004	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-005	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-011	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-012	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-013	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-014	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-015	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-016	AUD-250H	PANEL, AUDIO	COLLINS
622-2463-017	AUD-250H	PANEL, AUDIO	COLLINS
622-2485-001	WXT-150	RECEIVER-TRANSMITTER	COLLINS
622-2486-00X	IND-150	INDICATOR	COLLINS
622-2487-00X	ANT-152	ANTENNA, WEATHER RADAR	COLLINS
622-2492-001	WXT-200	RECEIVER-TRANSMITTER	COLLINS
622-2493-00X	IND-201	INDICATOR	COLLINS
622-2494-001	ANT-212	ANTENNA	COLLINS
622-2494-00X	ANT-212	ANTENNA, WEATHER RADAR	COLLINS
622-2494-00X	ANT-212	ANTENNA	COLLINS
622-2494-00X	ANT-212	ANTENNA	COLLINS
622-2495-00X	ANT-210	ANTENNA, WEATHER RADAR	COLLINS
622-2495-00X	ANT-210	ANTENNA	COLLINS
622-2499-00X	IND-250	INDICATOR	COLLINS
622-2500-00X	562A-5F5	COMPUTER, STEERING	COLLINS
622-2501-001	ANT-312	ANTENNA, WEATHER RADAR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2501-001	ANT-312	ANTENNA	COLLINS
622-2502-000	ANT-310	ANTENNA, WEATHER RADAR	COLLINS
622-2504-001	ANT-318	ANTENNA, WEATHER RADAR	COLLINS
622-2506-XXX	RMI-36	INDICATOR, RADIO MAGNETIC	COLLINS
622-2506-XXX	RMI-36	INDICATOR, RADIO MAGNETIC	COLLINS
622-2536-001	IND-650	INDICATOR, ADF	COLLINS
622-2562-001	972S-3	TEST SET, SERVO	COLLINS
622-2586-00X	618T-4	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2586-00X	618T-4	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2586-00X	618T-4	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2587-001	618T-4B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2587-001	618T-4B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2587-001	618T-4B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2588-00X	618T-5	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2588-00X	618T-5	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2588-00X	618T-5	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2589-001	618T-5B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2589-001	618T-5B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2589-001	618T-5B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2590-00X	618T-6	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2590-00X	618T-6	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2590-00X	618T-6	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2591-001	618T-6B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2591-001	618T-6B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2591-001	618T-6B	TRANSCEIVERS, AIRBORNE SSB	COLLINS
622-2614-012	562C-5F	AMPLIFIER, AUTOPILOT	COLLINS
622-2614-012	562C-5F	AMPLIFIER, AUTOPILOT	COLLINS
622-2614-012	562C-5F	AMPLIFIER, AUTOPILOT	COLLINS
622-2614-012	562C-5F	AMPLIFIER, AUTOPILOT	COLLINS
622-2615-XXX	FPC-75	COMPARATOR, FLIGHT PROFILE	COLLINS
622-2687-001	639U-1	UNIT, LIGHTING POWER	COLLINS
622-2700-001	VSI-80M	INDICATOR, VERTICAL SPEED	COLLINS
622-2700-001	VSI-80M	INDICATOR, VERTICAL SPEED	COLLINS
622-2701-001	ALI-80M	ALTIMETER, BAROMETRIC	COLLINS
622-2701-001	ALI-80M	ALTIMETER, BAROMETRIC	COLLINS
622-2702-001	MSI-80M	INDICATOR, MACH SPEED	COLLINS
622-2702-001	MSI-80M	INDICATOR, MACH SPEED	COLLINS
622-2703-002	PRE-80M	PRESELECTOR / ALERTER	COLLINS
622-2703-0XX	PRE-80M	PRESELECTOR / ALERTER	COLLINS
622-2704-XXX	ADC-80M	COMPUTER, AIR DATA	COLLINS
622-2704-XXX	ADC-80M	COMPUTER, AIR DATA	COLLINS
622-2733-001	334C-11	SERVO, PRIMARY	COLLINS
622-2733-002	334C-11	SERVO, PRIMARY	COLLINS
622-2733-003	334C-11	SERVO, PRIMARY	COLLINS
622-2733-004	334C-11	SERVO, PRIMARY	COLLINS
622-2733-005	334C-11	SERVO, PRIMARY	COLLINS
622-2733-006	334C-11	SERVO, PRIMARY	COLLINS
622-2733-007	334C-11	SERVO, PRIMARY	COLLINS
622-2733-008	334C-11	SERVO, PRIMARY	COLLINS
622-2733-009	334C-11	SERVO, PRIMARY	COLLINS
622-2733-00X	334C-11	SERVO, PRIMARY	COLLINS
622-2733-00X	334C-11	SERVO, PRIMARY	COLLINS
622-2745-00X	991X-1	CARDHOLDER, UNIVERSAL	COLLINS
622-2746-012	ANS-31R	HEAD, REMOTE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-2747-01X	NCS-31R	HEAD, REMOTE	COLLINS
622-2748-001	RPU-31A	UNIT, REMOTE PREPROCESSOR	COLLINS
622-2748-001	RPU-31A	UNIT, REMOTE PROCESSOR	COLLINS
622-2757-001	RPU-31N	UNIT, REMOTE PROCESSOR	COLLINS
622-2819-002	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-2819-003	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-2819-004	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-2819-00X	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-2819-013	VIR-31H	RECEIVER, RADIO NAVIGATION	COLLINS
622-2855-001	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-001	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-002	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-011	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-011	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-011	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-012	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2855-0XX	ALT-55B	ALTIMETER, RADIO	COLLINS
622-2882-00X	TCR-200	TRANSCEIVER	COLLINS
622-2883-001	PWR-200	AMPLIFIER, POWER	COLLINS
622-2884-00X	AAC-200	COUPLER, AUTOMATIC ANTENNA	COLLINS
622-2885-00X	CTL-200	HEAD, CONTROL	COLLINS
622-2892-00X	IND-200	INDICATOR	COLLINS
622-2895-()	718U-5N	TRANSCEIVER, LIGHTWEIGHT HF AIRBORNE	COLLINS
622-2898-012	ANS-31A	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-2898-012	ANS-31A	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-2899-01X	NCS-31A	UNIT, CONTROL DISPLAY PROCESSOR	COLLINS
622-2913-00X	462A-1	UNIT, RELAY	COLLINS
622-2914-001	970E-1	TEST SET, RMI	COLLINS
622-2919-001	462B-1	UNIT, RELAY	COLLINS
622-2920-001	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-001	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-002	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-002	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-003	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-003	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-004	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-004	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-005	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2920-005	860E-4	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2921-001	860E-5	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2921-002	860E-5	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2921-004	860E-5	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2921-005	860E-5	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2921-006	860E-5	EQUIPMENT, DISTANCE MEASURING	COLLINS
622-2923-0XX	PRE-80A	PRESELECTOR / ALERTER	COLLINS
622-2923-0XX	PRE-80A	PRESELECTOR / ALERTER	COLLINS
622-2937-001	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-002	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-003	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-004	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-005	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-008	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2937-009	ALI-55	INDICATOR, RADIO ALTITUDE	COLLINS
622-2938-001	ALI-55A	INDICATOR, RADIO ALTITUDE	COLLINS
622-2938-002	ALI-55A	INDICATOR, RADIO ALTITUDE	COLLINS
622-2938-003	ALI-55A	INDICATOR, RADIO ALTITUDE	COLLINS
622-2938-004	ALI-55A	INDICATOR, RADIO ALTITUDE	COLLINS
622-3001-001	339F-12	INDICATOR	COLLINS
622-3004-00X	TDR-950L	TRANSPONDER	COLLINS
622-3014-001	SVO-80	SERVO, PRIMARY	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-3015-00X	SVO-80A	SERVO, PRIMARY	COLLINS
622-3016-001	SVO-80B	SERVO, PRIMARY	COLLINS
622-3017-001	SVO-80C	SERVO, PRIMARY	COLLINS
622-30XX-XXX	SVO-80()	SERVO, PRIMARY	COLLINS
622-3101-001	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-002	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-003	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-004	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-005	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-006	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-011	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-012	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-013	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-014	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-015	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-016	AUD-251H	PANEL, AUDIO	COLLINS
622-3101-021	AUD-251H	PANEL, AUDIO	COLLINS
622-3102-001	MKL-351	LIGHTS, REMOTE MARKER	COLLINS
622-3104-001	FGC-80A	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-3106-00X	FGC-80B	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-3106-XXX	FGC-80B	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-3108-001	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-001	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-002	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-003	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-004	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-005	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-006	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-007	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-009	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-010	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-011	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-015	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-016	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-017	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-018	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-019	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-021	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-022	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-023	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-024	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-025	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-027	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-028	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-029	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-031	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-032	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-035	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-036	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-131	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3108-XXX	APA-80A	AMPLIFIER, AUTOPILOT	COLLINS
622-3109-001	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-002	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-003	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-004	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-005	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-006	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-007	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-008	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-009	APP-80A	PANEL, AUTOPILOT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-3109-010	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-011	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-012	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-013	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-014	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-015	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-016	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-017	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-018	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-019	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-020	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-021	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-022	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-023	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-024	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-025	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-026	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-027	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-028	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-029	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-030	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3109-XXX	APP-80A	PANEL, AUTOPILOT	COLLINS
622-3167-()	562C-8F	COMPUTER, YAW DAMPER	COLLINS
622-3167-0XX	562C-8F	COMPUTER, YAW DAMPER	COLLINS
622-3167-0XX	562C-8F	COMPUTER, YAW DAMPER	COLLINS
622-3167-XXX	562C-8F	COMPUTER, YAW DAMPER	COLLINS
622-3178-00X	51Y-7C	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-3179-00X	51Y-7D	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-3201-001/002	ALT-50A	ALTIMETER, RADIO	COLLINS
622-3201-011	ALT-50A	ALTIMETER, RADIO	COLLINS
622-3202-0XX	913K-1A	COMPUTER / CONTROL	COLLINS
622-3202-0XX	913K-1A	COMPUTER / CONTROL	COLLINS
622-3204-001	590A-3K	CONTROLS, AIR DATA	COLLINS
622-3204-00X	390A-3K	CONTROL, AIR DATA	COLLINS
622-3204-00X	390A-3K	CONTROL, AIR DATA	COLLINS
622-3204-00X	590A-3K	CONTROL, AIR DATA	COLLINS
622-3204-042	590A-3K	CONTROLS, AIR DATA	COLLINS
622-3234-0XX	TAI-80B	INDICATOR, TEMPERATURE / TAS	COLLINS
622-3234-0XX	TAI-80B	INDICATOR, TEMP / TAS	COLLINS
622-3246-00X	614E-41A	CONTROL, PITCH / TURN	COLLINS
622-3255-001	51RV-4	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3255-002	51RV-4	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3255-003	51RV-4	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3255-004	51RV-4	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3255-XXX	51RV-4	VOR/ILS NAVIGATION RECEIVER	COLLINS
622-3256-001	51RV-4A	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-001	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-001	51RV-4C	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-002	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-003	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-004	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-005	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-006	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-007	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-008	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-009	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-010	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-011	51RV-4B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3257-XXX	51RV-4B	VOR/ILS NAVIGATION RECEIVER	COLLINS
622-3259-001	51RV-4D	RECEIVER, VOR / ILS NAVIGATION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-3259-002	51RV-4D	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3259-003	51RV-4D	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3259-004	51RV-4D	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3259-005	51RV-4D	RECEIVER, VOR / ILS NAVIGATION	COLLINS
622-3259-XXX	51RV-4D	VOR/ILS NAVIGATION RECEIVER	COLLINS
622-325X-()	51RV-4/4()	RECEIVER, VOR/ILS NAVIGATION	COLLINS
622-3260-()	334D-6A	SERVO, TRIM	COLLINS
622-3260-00X	334D-6A	SERVO, TRIM	COLLINS
622-3304-001	970D-2	TEST SET, AIR DATA ELECTRONIC	COLLINS
622-3307-00X	VHF-251S	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-3347-00X	718U-5M	TRANSCEIVER, LIGHTWEIGHT HF AIRBORNE	COLLINS
622-3363-00X	VHF-251E	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-3366-001	GLS-350E	RECEIVER, GLIDESLOPE	COLLINS
622-338-001	WXT-250	RECEIVER-TRANSMITTER	COLLINS
622-3586-001	ANT-650A	ANTENNA, ADF	COLLINS
622-3587-00X	RCR-650	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-3587-00X	RCR-650A	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-3594-001	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-001	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-002	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-003	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-004	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-005	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-006	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-007	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-008	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-011	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-012	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-013	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-014	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-015	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-016	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-017	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-018	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3594-0XX	ADI-84A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-3594-XXX	ADI-84A	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-3595-0XX	562C-13A	COMPUTER, AUTOPILOT	COLLINS
622-3595-0XX	562C-13A	COMPUTER, AUTOPILOT	COLLINS
622-3670-001	TCR-451	TRANSCEIVER	COLLINS
622-3671-001	IND-450	INDICATOR	COLLINS
622-3672-001	IND-451	INDICATOR	COLLINS
622-3698-001	ANT-50A	ANTENNA	COLLINS
622-3702-0XX	BDI-36	INDICATOR, BEARING DISTANCE	COLLINS
622-3702-XXX	BMI-36	INDICATOR, BEARING DISTANCE	COLLINS
622-3711-001	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-002	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-003	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-004	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-005	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-006	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-007	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-008	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3711-0XX	MSI-80B	INDICATOR, MACH SPEED	COLLINS
622-3767-00X	ANS-351	COMPUTER, AREA NAVIGATION	COLLINS
622-3768-()	599W-2	ADAPTER, ATC TRANSPONDER	COLLINS
622-3881-001	IND-40C	INDICATOR	COLLINS
622-3881-002	IND-40C	INDICATOR	COLLINS
622-3890-003	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-004	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-005	860F-4	ALTIMETER, RADIO	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-3890-006	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-011	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-014	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-018	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-102	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-103	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-104	860F-4	ALTIMETER, RADIO	COLLINS
622-3890-114	860F-4	ALTIMETER, RADIO	COLLINS
622-3891-00X	614E-42A	SELECTOR, MODE	COLLINS
622-3891-00X	614E-42A	SELECTOR, MODE	COLLINS
622-3896-001	FGC-80M	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-3897-001	FGP-80M	PANEL, FLIGHT GUIDANCE	COLLINS
622-3898-001	FGP-81M	PANEL, FLIGHT GUIDANCE	COLLINS
622-3899-006	APC-80M	COMPUTER, AUTOPILOT	COLLINS
622-3900-006	APA-80M	AMPLIFIER, AUTOPILOT	COLLINS
622-3901-001	APP-80M	PANEL, AUTOPILOT	COLLINS
622-3915-001	IND-40	INDICATOR, DME	COLLINS
622-3915-002	IND-40	INDICATOR	COLLINS
622-3916-001	IND-40A	INDICATOR	COLLINS
622-3916-002	IND-40A	INDICATOR	COLLINS
622-3917-001	IND-40B	INDICATOR	COLLINS
622-3917-002	IND-40B	INDICATOR	COLLINS
622-3918-001	IND-41	INDICATOR	COLLINS
622-3918-002	IND-41	INDICATOR	COLLINS
622-3919-001	IND-41A	INDICATOR	COLLINS
622-3919-002	IND-41A	INDICATOR	COLLINS
622-3920-001	IND-41B	INDICATOR	COLLINS
622-3920-002	IND-41B	INDICATOR	COLLINS
622-3921-001	IND-41C	INDICATOR, DME	COLLINS
622-3921-002	IND-41C	INDICATOR, DME	COLLINS
622-3922-012	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-013	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-014	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-015	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-016	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-017	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-018	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3922-019	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3975-001	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-002	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-003	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-004	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-005	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-006	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-007	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-008	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3975-XXX	ALI-80A	ALTIMETER, BAROMETRIC	COLLINS
622-3986-00X	714E-2C	CONTROL, RADIO SET	COLLINS
622-3987-00X	714E-3H	CONTROL, RADIO SET	COLLINS
622-3992-006	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3992-007	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3992-008	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3992-009	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3992-010	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-3992-011	APC-80A	COMPUTER, AUTOPILOT	COLLINS
622-4011-001	ANT-451	ANTENNA	COLLINS
622-4020-001	ANT-212D	ANTENNA, WEATHER RADAR	COLLINS
622-4021-001	WXT-200A	RECEIVER-TRANSMITTER, WEATHER RADAR	COLLINS
622-4022-001	WXT-250A	RECEIVER-TRANSMITTER, WEATHER RADAR	COLLINS
622-4023-001	IND-200A	INDICATOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4023-00X	IND-200A	INDICATOR, WEATHER RADAR	COLLINS
622-4025-00X	IND-250C	INDICATOR, WEATHER RADAR	COLLINS
622-4027-00X	IND-250A	INDICATOR, WEATHER RADAR	COLLINS
622-4093-00X	514A-7	CONTROL, RADIO SET	COLLINS
622-4096-00X	346D-2B	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
622-4151-001	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-002	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-003	HIS-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-004	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-005	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-006	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-007	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-008	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-011	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-012	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-013	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-014	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-015	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-016	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-017	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-018	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-0XX	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4151-XXX	HSI-84	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4152-001	REU-84	UNIT, REMOTE ELECTRONICS	COLLINS
622-4160-001	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-002	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-003	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-004	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-005	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-006	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-007	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-008	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-011	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-012	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-013	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-014	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-015	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-016	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-017	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4160-018	DRI-55	INDICATOR, DIGITAL RADIO ALTITUDE	COLLINS
622-4176-001	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-002	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-003	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-004	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-005	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-006	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-007	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-008	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-009	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-010	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-011	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-012	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-013	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4176-0XX	HSI-85	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4177-00X	HCP-85	PANEL, HEADING COURSE	COLLINS
622-4177-00X	HCP-85	PANEL, HEADING COURSE	COLLINS
622-4178-00X	HCP-86	PANEL, HEADING COURSE	COLLINS
622-4178-00X	HCP-86	PANEL, HEADING COURSE	COLLINS
622-4182-001	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-002	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4185-003	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-004	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-005	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-006	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-007	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-008	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-011	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-012	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-013	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-014	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-015	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-016	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-017	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4185-018	VNI-80A	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-4211-001	678P-1C	HARNESSE, RADIO SET TEST	COLLINS
622-4248-001	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-002	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-002	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-003	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-006	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-007	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-009	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-010	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-011	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-015	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-016	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-017	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-018	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-019	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-021	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-022	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-023	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-024	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-025	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-027	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-028	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-029	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-031	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-032	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-033	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-035	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-036	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4248-XXX	APA-80C	AMPLIFIER, AUTOPILOT	COLLINS
622-4298-001	HSI-45	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4331-001	IND-300	INDICATOR	COLLINS
622-4331-00X	IND-300	INDICATOR, WEATHER RADAR	COLLINS
622-4365-XXX	ADC-80H	COMPUTER, AIR DATA	COLLINS
622-4365-XXX	ADC-80H	COMPUTER, AIR DATA	COLLINS
622-4371-XXX	ADC-80G	COMPUTER, AIR DATA	COLLINS
622-4371-XXX	ADC-80G	COMPUTER, AIR DATA	COLLINS
622-4382-00	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-002	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-003	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-004	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-005	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-006	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-007	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-008	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-011	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-012	MSI-80C	INDICATOR, MACH SPEED	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4382-013	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-014	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-015	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-016	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-017	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-018	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-024	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4382-0XX	MSI-80C	INDICATOR, MACH SPEED	COLLINS
622-4393-001	590A-3J1	CONTROLS, AIR DATA	COLLINS
622-4393-002	590A-3J1	CONTROLS, AIR DATA	COLLINS
622-4393-019	590A-3J1	CONTROLS, AIR DATA	COLLINS
622-4393-0XX	590A-3J1	CONTROL, AIR DATA	COLLINS
622-4393-0XX	590A-3J1	CONTROL, AIR DATA	COLLINS
622-4394-001	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-002	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-004	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-005	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-008	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-009	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-00X	590A-3K1	CONTROL, AIR DATA	COLLINS
622-4394-00X	590A-3K1	CONTROL, AIR DATA	COLLINS
622-4394-013	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-019	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-025	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4394-042	590A-3K1	CONTROLS, AIR DATA	COLLINS
622-4401-XXX	ADC-81A	COMPUTER, AIR DATA	COLLINS
622-4404-00X	SVO-85A	SERVO, PRIMARY	COLLINS
622-4404-00X	SVO-85A	SERVO, PRIMARY	COLLINS
622-4424-001	332D-11V	REFERENCE, VERTICAL	COLLINS
622-4425-001	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-002	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-003	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-004	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-005	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-006	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-007	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-008	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4425-XXX	ALI-80B	ALTIMETER, BAROMETRIC	COLLINS
622-4449-0XX	FGP-81A	PANEL, FLIGHT GUIDANCE	COLLINS
622-4471-0XX	CTL-201	HEAD, CONTROL	COLLINS
622-4477-001	IND-350A	INDICATOR	COLLINS
622-4478-001	IND-351A	INDICATOR	COLLINS
622-4479-001	IND-351D	INDICATOR	COLLINS
622-4480-001	IND-650A	INDICATOR, ADF	COLLINS
622-4481-001	IND-30	INDICATOR	COLLINS
622-4481-002	IND-30	INDICATOR	COLLINS
622-4482-001	IND-31	INDICATOR	COLLINS
622-4482-002	IND-31	INDICATOR	COLLINS
622-4487-001	346D-2	AMPLIFIER, AIRCRAFT PASSENGER ADDRESS	COLLINS
622-4488-001	332D-11B	REFERENCE, VERTICAL	COLLINS
622-4490-0XX	CTL-201A	HEAD, CONTROL	COLLINS
622-4493-001	IND-31C	INDICATOR	COLLINS
622-4493-002	IND-31C	INDICATOR	COLLINS
622-4507-001	ADI-55V-2	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4511-XXX	DCE-400	EQUIPMENT, DISTANCE COMPUTING	COLLINS
622-4523-001	CTL-20	CONTROL	COLLINS
622-4523-002	CTL-20	CONTROL	COLLINS
622-4523-003	CTL-20	CONTROL	COLLINS
622-4523-004	CTL-20	CONTROL	COLLINS
622-4523-005	CTL-20	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4523-006	CTL-20	CONTROL	COLLINS
622-4523-007	CTL-20	CONTROL	COLLINS
622-4523-008	CTL-20	CONTROL	COLLINS
622-4523-009	CTL-20	CONTROL	COLLINS
622-4523-010	CTL-20	CONTROL	COLLINS
622-4523-011	CTL-20	CONTROL	COLLINS
622-4523-012	CTL-20	CONTROL	COLLINS
622-4523-013	CTL-20	CONTROL	COLLINS
622-4523-014	CTL-20	CONTROL	COLLINS
622-4523-015	CTL-20	CONTROL	COLLINS
622-4523-016	CTL-20	CONTROL	COLLINS
622-4523-017	CTL-20	CONTROL	COLLINS
622-4523-018	CTL-20	CONTROL	COLLINS
622-4523-201	CTL-20	CONTROL	COLLINS
622-4523-202	CTL-20	CONTROL	COLLINS
622-4523-203	CTL-20	CONTROL	COLLINS
622-4523-204	CTL-20	CONTROL	COLLINS
622-4523-205	CTL-20	CONTROL	COLLINS
622-4523-206	CTL-20	CONTROL	COLLINS
622-4523-207	CTL-20	CONTROL	COLLINS
622-4523-208	CTL-20	CONTROL	COLLINS
622-4523-209	CTL-20	CONTROL	COLLINS
622-4523-210	CTL-20	CONTROL	COLLINS
622-4523-211	CTL-20	CONTROL	COLLINS
622-4523-212	CTL-20	CONTROL	COLLINS
622-4523-213	CTL-20	CONTROL	COLLINS
622-4523-214	CTL-20	CONTROL	COLLINS
622-4523-215	CTL-20	CONTROL	COLLINS
622-4523-216	CTL-20	CONTROL	COLLINS
622-4523-217	CTL-20	CONTROL	COLLINS
622-4523-218	CTL-20	CONTROL	COLLINS
622-4523-801	CTL-20	CONTROL	COLLINS
622-4523-802	CTL-20	CONTROL	COLLINS
622-4523-803	CTL-20	CONTROL	COLLINS
622-4523-804	CTL-20	CONTROL	COLLINS
622-4524-041	CTL-30	CONTROL	COLLINS
622-4524-042	CTL-30	CONTROL	COLLINS
622-4524-043	CTL-30	CONTROL	COLLINS
622-4524-044	CTL-30	CONTROL	COLLINS
622-4524-049	CTL-30	CONTROL	COLLINS
622-4524-050	CTL-30	CONTROL	COLLINS
622-4524-051	CTL-30	CONTROL	COLLINS
622-4524-052	CTL-30	CONTROL	COLLINS
622-4524-053	CTL-30	CONTROL	COLLINS
622-4524-054	CTL-30	CONTROL	COLLINS
622-4524-055	CTL-30	CONTROL	COLLINS
622-4524-056	CTL-30	CONTROL	COLLINS
622-4524-057	CTL-30	CONTROL	COLLINS
622-4524-058	CTL-30	CONTROL	COLLINS
622-4524-059	CTL-30	CONTROL	COLLINS
622-4524-060	CTL-30	CONTROL	COLLINS
622-4524-061	CTL-30	CONTROL	COLLINS
622-4524-062	CTL-30	CONTROL	COLLINS
622-4524-063	CTL-30	CONTROL	COLLINS
622-4524-064	CTL-30	CONTROL	COLLINS
622-4524-065	CTL-30	CONTROL	COLLINS
622-4524-066	CTL-30	CONTROL	COLLINS
622-4524-067	CTL-30	CONTROL	COLLINS
622-4524-068	CTL-30	CONTROL	COLLINS
622-4524-073	CTL-30	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4524-074	CTL-30	CONTROL	COLLINS
622-4524-075	CTL-30	CONTROL	COLLINS
622-4524-076	CTL-30	CONTROL	COLLINS
622-4524-077	CTL-30	CONTROL	COLLINS
622-4524-078	CTL-30	CONTROL	COLLINS
622-4524-079	CTL-30	CONTROL	COLLINS
622-4524-080	CTL-30	CONTROL	COLLINS
622-4524-085	CTL-30	CONTROL	COLLINS
622-4524-086	CTL-30	CONTROL	COLLINS
622-4524-087	CTL-30	CONTROL	COLLINS
622-4524-088	CTL-30	CONTROL	COLLINS
622-4524-097	CTL-30	CONTROL	COLLINS
622-4524-098	CTL-30	CONTROL	COLLINS
622-4524-099	CTL-30	CONTROL	COLLINS
622-4524-100	CTL-30	CONTROL	COLLINS
622-4524-101	CTL-30	CONTROL	COLLINS
622-4524-102	CTL-30	CONTROL	COLLINS
622-4524-103	CTL-30	CONTROL	COLLINS
622-4524-104	CTL-30	CONTROL	COLLINS
622-4526-001	CTL-60	CONTROL	COLLINS
622-4526-002	CTL-60	CONTROL	COLLINS
622-4526-003	CTL-60	CONTROL	COLLINS
622-4526-004	CTL-60	CONTROL	COLLINS
622-4526-005	CTL-60	CONTROL	COLLINS
622-4526-006	CTL-60	CONTROL	COLLINS
622-4526-007	CTL-60	CONTROL	COLLINS
622-4526-008	CTL-60	CONTROL	COLLINS
622-4526-009	CTL-60	CONTROL	COLLINS
622-4526-010	CTL-60	CONTROL	COLLINS
622-4526-011	CTL-60	CONTROL	COLLINS
622-4526-012	CTL-60	CONTROL	COLLINS
622-4526-013	CTL-60	CONTROL	COLLINS
622-4526-014	CTL-60	CONTROL	COLLINS
622-4526-015	CTL-60	CONTROL	COLLINS
622-4526-016	CTL-60	CONTROL	COLLINS
622-4526-017	CTL-60	CONTROL	COLLINS
622-4526-018	CTL-60	CONTROL	COLLINS
622-4526-019	CTL-60	CONTROL	COLLINS
622-4526-020	CTL-60	CONTROL	COLLINS
622-4526-021	CTL-60	CONTROL	COLLINS
622-4526-022	CTL-60	CONTROL	COLLINS
622-4526-023	CTL-60	CONTROL	COLLINS
622-4526-024	CTL-60	CONTROL	COLLINS
622-4526-025	CTL-60	CONTROL	COLLINS
622-4526-026	CTL-60	CONTROL	COLLINS
622-4526-027	CTL-60	CONTROL	COLLINS
622-4526-028	CTL-60	CONTROL	COLLINS
622-4526-029	CTL-60	CONTROL	COLLINS
622-4526-030	CTL-60	CONTROL	COLLINS
622-4526-031	CTL-60	CONTROL	COLLINS
622-4526-032	CTL-60	CONTROL	COLLINS
622-4526-033	CTL-60	CONTROL	COLLINS
622-4526-034	CTL-60	CONTROL	COLLINS
622-4526-801	CTL-60	CONTROL	COLLINS
622-4526-802	CTL-60	CONTROL	COLLINS
622-4526-803	CTL-60	CONTROL	COLLINS
622-4526-804	CTL-60	CONTROL	COLLINS
622-4526-805	CTL-60	CONTROL	COLLINS
622-4526-806	CTL-60	CONTROL	COLLINS
622-4526-807	CTL-60	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4526-808	CTL-60	CONTROL	COLLINS
622-4527-001	CTL-90	CONTROL	COLLINS
622-4527-002	CTL-90	CONTROL	COLLINS
622-4527-003	CTL-90	CONTROL	COLLINS
622-4527-004	CTL-90	CONTROL	COLLINS
622-4527-005	CTL-90	CONTROL	COLLINS
622-4527-006	CTL-90	CONTROL	COLLINS
622-4527-007	CTL-90	CONTROL	COLLINS
622-4527-008	CTL-90	CONTROL	COLLINS
622-4527-009	CTL-90	CONTROL	COLLINS
622-4527-010	CTL-90	CONTROL	COLLINS
622-4527-011	CTL-90	CONTROL	COLLINS
622-4527-012	CTL-90	CONTROL	COLLINS
622-4527-013	CTL-90	CONTROL	COLLINS
622-4527-014	CTL-90	CONTROL	COLLINS
622-4527-015	CTL-90	CONTROL	COLLINS
622-4527-016	CTL-90	CONTROL	COLLINS
622-4527-017	CTL-90	CONTROL	COLLINS
622-4527-018	CTL-90	CONTROL	COLLINS
622-4527-019	CTL-90	CONTROL	COLLINS
622-4527-020	CTL-90	CONTROL	COLLINS
622-4527-021	CTL-90	CONTROL	COLLINS
622-4527-801	CTL-90	CONTROL	COLLINS
622-4527-802	CTL-90	CONTROL	COLLINS
622-4527-803	CTL-90	CONTROL	COLLINS
622-4527-804	CTL-90	CONTROL	COLLINS
622-4530-001	CTL-21	CONTROL	COLLINS
622-4530-002	CTL-21	CONTROL	COLLINS
622-4530-003	CTL-21	CONTROL	COLLINS
622-4530-004	CTL-21	CONTROL	COLLINS
622-4530-005	CTL-21	CONTROL	COLLINS
622-4530-006	CTL-21	CONTROL	COLLINS
622-4530-007	CTL-21	CONTROL	COLLINS
622-4530-008	CTL-21	CONTROL	COLLINS
622-4530-009	CTL-21	CONTROL	COLLINS
622-4530-010	CTL-21	CONTROL	COLLINS
622-4530-011	CTL-21	CONTROL	COLLINS
622-4530-012	CTL-21	CONTROL	COLLINS
622-4530-013	CTL-21	CONTROL	COLLINS
622-4530-014	CTL-21	CONTROL	COLLINS
622-4530-015	CTL-21	CONTROL	COLLINS
622-4530-016	CTL-21	CONTROL	COLLINS
622-4530-201	CTL-21	CONTROL	COLLINS
622-4530-202	CTL-21	CONTROL	COLLINS
622-4530-203	CTL-21	CONTROL	COLLINS
622-4530-204	CTL-21	CONTROL	COLLINS
622-4530-205	CTL-21	CONTROL	COLLINS
622-4530-206	CTL-21	CONTROL	COLLINS
622-4530-207	CTL-21	CONTROL	COLLINS
622-4530-208	CTL-21	CONTROL	COLLINS
622-4530-209	CTL-21	CONTROL	COLLINS
622-4530-210	CTL-21	CONTROL	COLLINS
622-4530-211	CTL-21	CONTROL	COLLINS
622-4530-212	CTL-21	CONTROL	COLLINS
622-4530-213	CTL-21	CONTROL	COLLINS
622-4530-214	CTL-21	CONTROL	COLLINS
622-4530-215	CTL-21	CONTROL	COLLINS
622-4530-216	CTL-21	CONTROL	COLLINS
622-4530-801	CTL-21	CONTROL	COLLINS
622-4530-802	CTL-21	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4530-803	CTL-21	CONTROL	COLLINS
622-4530-804	CTL-21	CONTROL	COLLINS
622-4531-001	CTL-31	CONTROL	COLLINS
622-4531-002	CTL-31	CONTROL	COLLINS
622-4531-003	CTL-31	CONTROL	COLLINS
622-4531-004	CTL-31	CONTROL	COLLINS
622-4531-005	CTL-31	CONTROL	COLLINS
622-4531-006	CTL-31	CONTROL	COLLINS
622-4531-007	CTL-31	CONTROL	COLLINS
622-4531-008	CTL-31	CONTROL	COLLINS
622-4531-009	CTL-31	CONTROL	COLLINS
622-4531-010	CTL-31	CONTROL	COLLINS
622-4531-011	CTL-31	CONTROL	COLLINS
622-4531-012	CTL-31	CONTROL	COLLINS
622-4531-013	CTL-31	CONTROL	COLLINS
622-4531-014	CTL-31	CONTROL	COLLINS
622-4531-015	CTL-31	CONTROL	COLLINS
622-4531-016	CTL-31	CONTROL	COLLINS
622-4531-017	CTL-31	CONTROL	COLLINS
622-4531-018	CTL-31	CONTROL	COLLINS
622-4531-019	CTL-31	CONTROL	COLLINS
622-4531-020	CTL-31	CONTROL	COLLINS
622-4531-021	CTL-31	CONTROL	COLLINS
622-4531-022	CTL-31	CONTROL	COLLINS
622-4531-023	CTL-31	CONTROL	COLLINS
622-4531-024	CTL-31	CONTROLS	COLLINS
622-4531-025	CTL-31	CONTROLS	COLLINS
622-4531-026	CTL-31	CONTROLS	COLLINS
622-4531-027	CTL-31	CONTROLS	COLLINS
622-4531-028	CTL-31	CONTROLS	COLLINS
622-4531-029	CTL-31	CONTROLS	COLLINS
622-4531-030	CTL-31	CONTROLS	COLLINS
622-4531-031	CTL-31	CONTROLS	COLLINS
622-4531-032	CTL-31	CONTROLS	COLLINS
622-4531-033	CTL-31	CONTROLS	COLLINS
622-4531-034	CTL-31	CONTROLS	COLLINS
622-4531-035	CTL-31	CONTROLS	COLLINS
622-4531-036	CTL-31	CONTROLS	COLLINS
622-4531-037	CTL-31	CONTROLS	COLLINS
622-4531-038	CTL-31	CONTROLS	COLLINS
622-4531-039	CTL-31	CONTROLS	COLLINS
622-4531-040	CTL-31	CONTROLS	COLLINS
622-4531-041	CTL-31	CONTROLS	COLLINS
622-4531-042	CTL-31	CONTROLS	COLLINS
622-4531-043	CTL-31	CONTROLS	COLLINS
622-4531-044	CTL-31	CONTROLS	COLLINS
622-4531-045	CTL-31	CONTROLS	COLLINS
622-4531-046	CTL-31	CONTROLS	COLLINS
622-4531-047	CTL-31	CONTROLS	COLLINS
622-4531-048	CTL-31	CONTROLS	COLLINS
622-4531-049	CTL-31	CONTROLS	COLLINS
622-4531-050	CTL-31	CONTROLS	COLLINS
622-4531-051	CTL-31	CONTROLS	COLLINS
622-4531-052	CTL-31	CONTROLS	COLLINS
622-4531-053	CTL-31	CONTROLS	COLLINS
622-4531-054	CTL-31	CONTROLS	COLLINS
622-4531-055	CTL-31	CONTROLS	COLLINS
622-4531-056	CTL-31	CONTROLS	COLLINS
622-4531-057	CTL-31	CONTROLS	COLLINS
622-4531-058	CTL-31	CONTROLS	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4531-059	CTL-31	CONTROLS	COLLINS
622-4531-060	CTL-31	CONTROLS	COLLINS
622-4531-061	CTL-31	CONTROLS	COLLINS
622-4531-062	CTL-31	CONTROLS	COLLINS
622-4531-063	CTL-31	CONTROLS	COLLINS
622-4531-064	CTL-31	CONTROLS	COLLINS
622-4531-065	CTL-31	CONTROLS	COLLINS
622-4531-066	CTL-31	CONTROLS	COLLINS
622-4531-067	CTL-31	CONTROLS	COLLINS
622-4531-068	CTL-31	CONTROLS	COLLINS
622-4531-073	CTL-31	CONTROLS	COLLINS
622-4531-074	CTL-31	CONTROLS	COLLINS
622-4531-075	CTL-31	CONTROLS	COLLINS
622-4531-076	CTL-31	CONTROLS	COLLINS
622-4531-077	CTL-31	CONTROLS	COLLINS
622-4531-078	CTL-31	CONTROLS	COLLINS
622-4531-079	CTL-31	CONTROLS	COLLINS
622-4531-080	CTL-31	CONTROLS	COLLINS
622-4531-085	CTL-31	CONTROLS	COLLINS
622-4531-086	CTL-31	CONTROLS	COLLINS
622-4531-087	CTL-31	CONTROLS	COLLINS
622-4531-088	CTL-31	CONTROLS	COLLINS
622-4531-089	CTL-31	CONTROLS	COLLINS
622-4531-090	CTL-31	CONTROLS	COLLINS
622-4531-091	CTL-31	CONTROLS	COLLINS
622-4531-092	CTL-31	CONTROLS	COLLINS
622-4531-093	CTL-31	CONTROLS	COLLINS
622-4531-094	CTL-31	CONTROLS	COLLINS
622-4531-095	CTL-31	CONTROLS	COLLINS
622-4531-096	CTL-31	CONTROLS	COLLINS
622-4531-097	CTL-31	CONTROLS	COLLINS
622-4531-098	CTL-31	CONTROLS	COLLINS
622-4531-099	CTL-31	CONTROLS	COLLINS
622-4531-100	CTL-31	CONTROLS	COLLINS
622-4531-101	CTL-31	CONTROLS	COLLINS
622-4531-102	CTL-31	CONTROLS	COLLINS
622-4531-103	CTL-31	CONTROLS	COLLINS
622-4531-104	CTL-31	CONTROLS	COLLINS
622-4531-105	CTL-31	CONTROLS	COLLINS
622-4531-106	CTL-31	CONTROLS	COLLINS
622-4531-107	CTL-31	CONTROLS	COLLINS
622-4531-108	CTL-31	CONTROLS	COLLINS
622-4531-109	CTL-31	CONTROLS	COLLINS
622-4531-110	CTL-31	CONTROLS	COLLINS
622-4531-111	CTL-31	CONTROLS	COLLINS
622-4531-112	CTL-31	CONTROLS	COLLINS
622-4531-113	CTL-31	CONTROLS	COLLINS
622-4531-801	CTL-31	CONTROLS	COLLINS
622-4531-802	CTL-31	CONTROLS	COLLINS
622-4531-803	CTL-31	CONTROLS	COLLINS
622-4531-804	CTL-31	CONTROLS	COLLINS
622-4531-805	CTL-31	CONTROLS	COLLINS
622-4531-806	CTL-31	CONTROLS	COLLINS
622-4531-807	CTL-31	CONTROLS	COLLINS
622-4531-808	CTL-31	CONTROLS	COLLINS
622-4531-809	CTL-31	CONTROLS	COLLINS
622-4531-810	CTL-31	CONTROLS	COLLINS
622-4531-811	CTL-31	CONTROLS	COLLINS
622-4531-812	CTL-31	CONTROLS	COLLINS
622-4531-813	CTL-31	CONTROLS	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4531-814	CTL-31	CONTROLS	COLLINS
622-4531-815	CTL-31	CONTROLS	COLLINS
622-4531-816	CTL-31	CONTROLS	COLLINS
622-4531-817	CTL-31	CONTROLS	COLLINS
622-4531-818	CTL-31	CONTROLS	COLLINS
622-4531-819	CTL-31	CONTROLS	COLLINS
622-4531-820	CTL-31	CONTROLS	COLLINS
622-4531-822	CTL-31	CONTROLS	COLLINS
622-4531-823	CTL-31	CONTROLS	COLLINS
622-4531-824	CTL-31	CONTROLS	COLLINS
622-4531-825	CTL-31	CONTROLS	COLLINS
622-4531-826	CTL-31	CONTROLS	COLLINS
622-4531-827	CTL-31	CONTROLS	COLLINS
622-4531-828	CTL-31	CONTROLS	COLLINS
622-4532-001	CTL-61	CONTROLS	COLLINS
622-4532-002	CTL-61	CONTROLS	COLLINS
622-4532-003	CTL-61	CONTROLS	COLLINS
622-4532-004	CTL-61	CONTROLS	COLLINS
622-4532-005	CTL-61	CONTROLS	COLLINS
622-4532-006	CTL-61	CONTROLS	COLLINS
622-4532-007	CTL-61	CONTROLS	COLLINS
622-4532-008	CTL-61	CONTROLS	COLLINS
622-4532-009	CTL-61	CONTROLS	COLLINS
622-4532-010	CTL-61	CONTROLS	COLLINS
622-4532-011	CTL-61	CONTROLS	COLLINS
622-4532-012	CTL-61	CONTROLS	COLLINS
622-4532-013	CTL-61	CONTROLS	COLLINS
622-4532-014	CTL-61	CONTROLS	COLLINS
622-4532-015	CTL-61	CONTROLS	COLLINS
622-4532-016	CTL-61	CONTROLS	COLLINS
622-4532-017	CTL-61	CONTROLS	COLLINS
622-4532-801	CTL-61	CONTROLS	COLLINS
622-4532-802	CTL-61	CONTROLS	COLLINS
622-4532-803	CTL-61	CONTROLS	COLLINS
622-4532-804	CTL-61	CONTROLS	COLLINS
622-4533-001	CTL-91	CONTROLS	COLLINS
622-4533-002	CTL-91	CONTROLS	COLLINS
622-4533-003	CTL-91	CONTROLS	COLLINS
622-4533-004	CTL-91	CONTROLS	COLLINS
622-4533-005	CTL-91	CONTROLS	COLLINS
622-4533-006	CTL-91	CONTROLS	COLLINS
622-4533-007	CTL-91	CONTROLS	COLLINS
622-4533-008	CTL-91	CONTROLS	COLLINS
622-4533-009	CTL-91	CONTROLS	COLLINS
622-4533-010	CTL-91	CONTROLS	COLLINS
622-4533-011	CTL-91	CONTROLS	COLLINS
622-4533-012	CTL-91	CONTROLS	COLLINS
622-4533-013	CTL-91	CONTROLS	COLLINS
622-4533-014	CTL-91	CONTROLS	COLLINS
622-4533-015	CTL-91	CONTROLS	COLLINS
622-4533-016	CTL-91	CONTROLS	COLLINS
622-4533-017	CTL-91	CONTROLS	COLLINS
622-4533-801	CTL-91	CONTROLS	COLLINS
622-4533-802	CTL-91	CONTROLS	COLLINS
622-4533-803	CTL-91	CONTROLS	COLLINS
622-4533-804	CTL-91	CONTROLS	COLLINS
622-4545-0XX	CTL-220	HEAD, HF CONTROL	COLLINS
622-4548-001	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-002	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-003	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4548-004	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-005	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-006	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-007	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-008	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4548-0XX	VSI-80B	INDICATOR, VERTICAL SPEED	COLLINS
622-4550-001	ANT-51A	ANTENNA	COLLINS
622-4551-001	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-002	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-003	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-004	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-005	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-006	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-007	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-008	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4551-0XX	VSI-80C	INDICATOR, VERTICAL SPEED	COLLINS
622-4561-001	CTS-10	BOX, UNIVERSAL ATR BREAKOUT	COLLINS
622-4562-00X	CTS-82	TEST SET, AUTOPILOT	COLLINS
622-4563-001	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-002	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-004	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-005	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-006	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-007	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-008	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4563-011	339H-6	INDICATOR, RADIO ALTITUDE	COLLINS
622-4565-001	YRS-65	REFERENCE, VERTICAL	COLLINS
622-4565-001/002	332D-11T	REFERENCE, VERTICAL	COLLINS
622-4569-001	REU-84A	UNIT, REMOTE ELECTRONICS	COLLINS
622-4569-001	REU-84A	UNIT, REMOTE ELECTRONICS	COLLINS
622-4569-001	REU-84A	UNIT, REMOTE ELECTRONICS	COLLINS
622-4570-001	ADI-70C	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4570-002	ADI-70C	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4570-00X	ADI-70C	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4571-001	ADI-84C	INDICATOR, FLIGHT DIRECTOR	COLLINS
622-4571-001	ADI-84C	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4572-001	HSI-70C	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4572-002	HSI-70C	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4572-00X	HSI-70C	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4659-001	CWC-65	COMPUTER, COMPARATOR WARNING	COLLINS
622-4730-0XX	FPA-80	ADVISORY, FLIGHT PROFILE	COLLINS
622-4782-001	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-002	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-003	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-004	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-005	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-006	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-007	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-008	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4782-0XX	VSI-80A	INDICATOR, VERTICAL SPEED	COLLINS
622-4808-001	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-002	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-003	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-004	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-005	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-006	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-007	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-008	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-009	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-010	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-4808-011	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-012	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-013	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4808-0XX	ADI-85A	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4866-001	ADI-55V-1	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4912-001	ADI-70	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4912-002	ADI-70	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4912-00X	ADI-70	INDICATOR, ATTITUDE DIRECTOR	COLLINS
622-4913-001	HSI-70	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4913-002	HSI-70	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4913-00X	HSI-70	INDICATOR, HORIZONTAL SITUATION	COLLINS
622-4924-001	614E-22M	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
622-4938-0XX	RMI-30	INDICATOR, RADIO MAGNETIC	COLLINS
622-4938-XXX	RMI-30	INDICATOR, RADIO MAGNETIC	COLLINS
622-4964-001	APC-80F	COMPUTER, AUTOPILOT	COLLINS
622-5026-()	334D-6B	SERVO, TRIM	COLLINS
622-5026-00X	334D-6B	SERVO, TRIM	COLLINS
622-5027-002	SVO-85B	SERVO, AILERON	COLLINS
622-5027-00X	SVO-85B	SERVO, PRIMARY	COLLINS
622-5027-00X	SVO-85B	SERVO, PRIMARY	COLLINS
622-5027-00X	SVO-85B	SERVO, PRIMARY	COLLINS
622-5027-XXX	SVO-85B	SERVO, PRIMARY	COLLINS
622-5082-()	334D-6C	SERVO, TRIM	COLLINS
622-5082-00X	334D-6C	SERVO, TRIM	COLLINS
622-5108-001	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-001	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-002	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-003	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-004	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-005	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-006	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-007	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-008	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-101	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-102	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-103	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5108-104	DCP-320	PANEL, DISPLAY CONTROL	COLLINS
622-5109-005	DCP-300	PANEL, DISPLAY CONTROL	COLLINS
622-5109-006	DCP-300	PANEL, DISPLAY CONTROL	COLLINS
622-5109-007	DCP-300	PANEL, DISPLAY CONTROL	COLLINS
622-5109-008	DCP-300	PANEL, DISPLAY CONTROL	COLLINS
622-5110-001	RDP-300	PROGRAMMER, REMOTE DATA	COLLINS
622-5112-001	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-002	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-003	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-004	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-005	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-006	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-007	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-008	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5112-00X	ANS-31C	UNIT, CONTROL DISPLAY	COLLINS
622-5115-001	ATM-200	METER, ANTENNA TUNING	COLLINS
622-5150-001	351B-6F	MOUNT, SERVO	COLLINS
622-5150-002	351B-6F	MOUNT, SERVO	COLLINS
622-5151-001	351B-6G	MOUNT, SERVO	COLLINS
622-5151-002	351B-6G	MOUNT, SERVO	COLLINS
622-5152-001	351B-6H	MOUNT, SERVO	COLLINS
622-5152-002	351B-6H	MOUNT, SERVO	COLLINS
622-5192-001	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-001	APC-841	COMPUTER / CONTROL	COLLINS
622-5192-002	AAM-830	COMPUTER, AUTOPILOT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-5192-002	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-003	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-004	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-005	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-006	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5192-007	APC-841	COMPUTER, AUTOPILOT	COLLINS
622-5193-001	AAM-830	MONITOR, AIRCRAFT ATTITUDE	COLLINS
622-5193-001	AAM-830	MONITOR, AIRCRAFT ATTITUDE	COLLINS
622-5194-00X	SVO-830	SERVO, PRIMARY	COLLINS
622-5194-00X	SVO-830	SERVO, PRIMARY	COLLINS
622-5206-XXX	ADC-80J	COMPUTER, AIR DATA	COLLINS
622-5206-XXX	ADC-80J	COMPUTER, AIR DATA	COLLINS
622-5212-001	UMT-12	MOUNT, UNIVERSAL	COLLINS
622-5213-001	UMT-13	MOUNT, UNIVERSAL	COLLINS
622-5224-XXX	FGC-80F	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-5224-XXX	FGC-80F	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-5229-001	351B-6E	MOUNT, SERVO	COLLINS
622-5229-002	351B-6E	MOUNT, SERVO	COLLINS
622-5337-00X	TCR-220	TRANSCEIVER	COLLINS
622-5349-0XX	ASI-80A	INDICATOR, AIRSPEED	COLLINS
622-5350-0XX	ASI-80B	INDICATOR, AIRSPEED	COLLINS
622-5352-0XX	ASI-80D	INDICATOR, AIRSPEED	COLLINS
622-5353-0XX	ASI-80E	INDICATOR, AIRSPEED	COLLINS
622-5354-0XX	ASI-80G	INDICATOR, AIRSPEED	COLLINS
622-5367-001	ALI-55B	INDICATOR, RADIO ALTITUDE	COLLINS
622-5374-002	ASA-701	ANNUNCIATOR, AUTOLAND STATUS	COLLINS
622-5374-003	ASA-701	ANNUNCIATOR, AUTOLAND STATUS	COLLINS
622-5376-001	998K-1	UNIT, BEARING / DISTANCE ADAPTER	COLLINS
622-5376-001	998K-1	UNIT, BEARING/DISTANCE ADAPTER	COLLINS
622-5441-02X	APA-80F	AMPLIFIER, AUTOPILOT	COLLINS
622-5445-00X	SVO-830A	SERVO, PRIMARY	COLLINS
622-5445-00X	SVO-830A	SERVO, PRIMARY	COLLINS
622-5459-001	614E-10J	CONTROL, FLIGHT DIRECTOR	COLLINS
622-5465-XXX	ADC-80K	COMPUTER, AIR DATA	COLLINS
622-5465-XXX	ADC-80K	COMPUTER, AIR DATA	COLLINS
622-5476-00X	HCP-87	PANEL, HEADING COURSE	COLLINS
622-5476-00X	HCP-87	PANEL, HEADING COURSE	COLLINS
622-5486-001	614E-20S	SELECTOR, FLIGHT MODE	COLLINS
622-5487-00X	CRU-70	UNIT, COMPUTER RECEIVER	COLLINS
622-5488-001	CDU-70	UNIT, CONTROL DISPLAY	COLLINS
622-5489-00X	CIU-80	UNIT, COMPUTER INTERFACE	COLLINS
622-5490-001	CDU-80	UNIT, CONTROL DISPLAY	COLLINS
622-5491-001	REU-80	UNIT, RECEIVER ELECTRONIC	COLLINS
622-5526-001	ASU-80	UNIT, AVIONICS SWITCHING	COLLINS
622-5588-001	IND-450C	INDICATOR	COLLINS
622-5598-001	ATC-830A	COUPLER, AUTOMATIC TRIM	COLLINS
622-5640-00X	VHF-253	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-5641-00X	VHF-253S	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-5656-001	PAC-200	COUPLER, PROBE ANTENNA	COLLINS
622-5691-001	ACA-80	COUPLER, ADF SENSE ANTENNA	COLLINS
622-5691-001	ACA-80	COUPLER, ADF SENSE ANTENNA	COLLINS
622-5692-001	ANE-80	ANTENNA, E-FIELD	COLLINS
622-5692-001	ANE-80	ANTENNA, E-FIELD	COLLINS
622-5693-001	ACE-80	UNIT, ANTENNA COUPLER	COLLINS
622-5710-001	AAM-830A	MONITOR, AIRCRAFT ATTITUDE	COLLINS
622-5710-002	AAM-830A	COMPUTER, AUTOPILOT	COLLINS
622-5734-001	SVO-65	SERVO, PRIMARY/TRIM	COLLINS
622-5734-002	SVO-65	SERVO, PRIMARY/TRIM	COLLINS
622-5735-00X	SVO-65	SERVO, PRIMARY	COLLINS
622-5773-001	RAI-742	INDICATOR, RADIO ALTITUDE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-5796-107	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-108	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-109	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-110	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-113	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-209	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-309	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-409	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5796-XXX	APC-65	COMPUTER, AUTOPILOT	COLLINS
622-5797-001	ADS-65	SENSOR, AIR DATA	COLLINS
622-5798-001	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-002	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-003	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-004	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-005	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-006	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-007	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-008	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-009	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-010	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-011	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-012	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-013	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-014	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-015	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-016	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-017	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-018	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-019	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-020	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-021	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-022	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-023	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-024	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-025	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-026	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-027	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-028	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5798-029	FCP-65	PANEL, FLIGHT CONTROL	COLLINS
622-5799-001	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-002	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-003	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-004	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-005	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-101	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-102	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-103	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-104	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-105	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5799-XXX	MAP-65	PANEL, MODE ANNUNCIATOR	COLLINS
622-5801-001	ATC-80	COUPLER, AUTOMATIC TRIM	COLLINS
622-5812-001	FDU-70	UNIT, FLUX DETECTOR	COLLINS
622-5812-00X	FDU-70	UNIT, FLUX DETECTOR	COLLINS
622-5855-001	ATC-830A	COUPLER, AUTOMATIC TRIM	COLLINS
622-5940-001	IND-220	INDICATOR	COLLINS
622-5940-00X	IND-220	INDICATOR, WEATHER RADAR	COLLINS
622-5941-001	IND-270	INDICATOR	COLLINS
622-5941-001	IND-270	INDICATOR	COLLINS
622-5941-00X	IND-270	INDICATOR, WEATHER RADAR	COLLINS
622-5942-001	RNC-300A	COMPUTER, RADAR NAVIGATION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-5952-020	FGC-65	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-5952-0XX	FGC-65	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-5953-001	FCP-65A	PANEL, FLIGHT CONTROL	COLLINS
622-5953-002	FCP-65A	PANEL, FLIGHT CONTROL	COLLINS
622-5953-003	FCP-65A	PANEL, FLIGHT CONTROL	COLLINS
622-5953-004	FCP-65A	PANEL, FLIGHT CONTROL	COLLINS
622-60006-002	RBA-701	ANNUNCIATOR, RMI BEARING	COLLINS
622-6019-001	SSS-65	SENSOR, SLIP SKID	COLLINS
622-6020-011	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6020-012	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6020-01X	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6020-021	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6020-022	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6020-0XX	EFD-85	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6021-001	DCP-85B	PANEL, DISPLAY CONTROL	COLLINS
622-6021-002	DCP-85B	PANEL, DISPLAY CONTROL	COLLINS
622-6021-003	DCP-85B	PANEL, DISPLAY CONTROL	COLLINS
622-6021-00X	DCP-85B	PANEL, DISPLAY CONTROL	COLLINS
622-6021-0XX	DCP-85B	PANEL, DISPLAY CONTROL	COLLINS
622-6022-002	DPU-85	UNIT, DISPLAY PROCESSOR	COLLINS
622-6022-006	DPU-85	UNIT, DISPLAY PROCESSOR	COLLINS
622-6022-012	DPU-85	PANEL, DISPLAY PROCESSOR	COLLINS
622-6022-126	DPU-85	UNIT, DISPLAY PROCESSOR	COLLINS
622-6090-00X	MFD-85	DISPLAY, MULTIFUNCTION	COLLINS
622-6090-00X	MFD-85	DISPLAY, MULTIFUNCTION	COLLINS
622-6090-0XX	MFD-85	DISPLAY, MULTIFUNCTION	COLLINS
622-6091-002	MPU-85	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-6091-012	MPU-85	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-6091-0XX	MPU-85	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-6092-00X	WXP-85A	PANEL, WEATHER RADAR	COLLINS
622-6092-01X	WXP-85A	PANEL, WEATHER RADAR	COLLINS
622-6092-0XX	WXP-85A	PANEL, WEATHER RADAR	COLLINS
622-6093-0XX	WXP-85B	PANEL, WEATHER RADAR	COLLINS
622-6105-003	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-013	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-023	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-024	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-033	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-043	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-053	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6105-0XX	MSI-80D	INDICATOR, MACH SPEED	COLLINS
622-6107-()	562C-8G	COMPUTER, YAW DAMPER	COLLINS
622-6135-0XX	CCU-65	UNIT, COMPENSATION AND CONTROL	COLLINS
622-6136-00X	DGS-65	GYRO, DIRECTIONAL - REMOTE	COLLINS
622-6137-001	VIR-32	RECEIVER, NAVIGATION	COLLINS
622-6155-001	351B-6J	MOUNT, SERVO	COLLINS
622-6156-001	351B-6K	MOUNT, SERVO	COLLINS
622-6157-001	351B-6L	MOUNT, SERVO	COLLINS
622-6158-001	351B-6M	MOUNT, SERVO	COLLINS
622-6174-001	RCP-65	UNIT, REMOTE COMPENSATION	COLLINS
622-6174-001	RCP-65	UNIT, REMOTE COMPENSATION	COLLINS
622-6189-001	ICU-85	UNIT, INTERNAL COMPENSATION	COLLINS
622-6189-002	ICU-85	UNIT, INTERNAL COMPENSATION	COLLINS
622-6190-002	AHC-85	COMPUTER, ATTITUDE HEADING	COLLINS
622-6190-003	AHC-85	COMPUTER, ATTITUDE HEADING	COLLINS
622-6190-004	AHC-85	COMPUTER, ATTITUDE HEADING	COLLINS
622-6190-113	AHS-85	COMPUTER, ATTITUDE HEADING	COLLINS
622-6190-204	AHC-85	COMPUTER, ATTITUDE HEADING	COLLINS
622-6193-0XX	FCC-85	COMPUTER, FLIGHT CONTROL	COLLINS
622-6195-0XX	FCC-86	COMPUTER, FLIGHT CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6197-001	EFD-74	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6197-00X	EFD-74	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6198-0XX	HPU-74	UNIT, HSI PROCESSOR	COLLINS
622-6198-XXX	HPU-74	UNIT, HSI PROCESSOR	COLLINS
622-6199-001	HPU-74A	UNIT, HSI PROCESSOR	COLLINS
622-6200-00X	HCP-74	PANEL, HSI CONTROL	COLLINS
622-6208-001	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-002	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-003	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-004	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-005	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-006	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-007	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-008	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-101	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-102	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-103	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-104	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-105	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-106	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-107	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-108	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-201	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-202	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-203	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-204	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-204	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-205	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-301	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-302	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-303	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-304	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-305	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-306	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-307	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-308	APP-85	PANEL, AUTOPILOT	COLLINS
622-6208-XXX	APP-85	PANEL, AUTOPILOT	COLLINS
622-6209-001	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-002	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-003	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-004	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-005	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-006	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-007	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-008	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-103	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-104	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-105	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-106	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-109	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-203	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-204	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-205	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-206	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-303	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-304	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-305	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-306	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-405	MSP-85	PANEL, MODE SELECT	COLLINS
622-6209-XXX	MPS-85	PANEL, MODE SELECT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6222-002	SVO-75	SERVO, PRIMARY	COLLINS
622-6232-001	ADP-80	PROCESSOR, AIR DATA	COLLINS
622-6233-XXX	ADC-80L	COMPUTER, AIR DATA	COLLINS
622-6233-XXX	ADC-80L	COMPUTER, AIR DATA	COLLINS
622-6234-0XX	PRE-80L	PRESELECTOR / ALERTER	COLLINS
622-6234-0XX	PRE-80L	PRESELECTOR / ALERTER	COLLINS
622-6238-001	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-002	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-003	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-004	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-005	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-006	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-007	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-008	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6238-XXX	ALI-80L	ALTIMETER, BAROMETRIC	COLLINS
622-6263-001	DME-42	TRANSCEIVER, DME	COLLINS
622-6263-003	DME-42	TRANSCEIVER, DME	COLLINS
622-6318-001	CHP-85A	PANEL, COURSE HEADING	COLLINS
622-6318-002	CHP-85A	PANEL, COURSE HEADING	COLLINS
622-6318-00X	CHP-85A	PANEL, COURSE HEADING	COLLINS
622-6319-001	CHP-85B	PANEL, COURSE HEADING	COLLINS
622-6319-002	CHP-85B	PANEL, COURSE HEADING	COLLINS
622-6319-00X	CHP-85B	PANEL, COURSE HEADING	COLLINS
622-6319-00X	CHP-85B	PANEL, COURSE HEADING	COLLINS
622-6319-XXX	CHP-85B	PANEL, COURSE HEADING	COLLINS
622-6320-001	DCP-85A	PANEL, DISPLAY CONTROL	COLLINS
622-6320-002	DCP-85A	PANEL, DISPLAY CONTROL	COLLINS
622-6320-00X	DCP-85A	PANEL, DISPLAY CONTROL	COLLINS
622-6332-001	ADS-65C	SENSOR, AIR DATA	COLLINS
622-6332-001	ADS-65C	SENSOR, AIR DATA	COLLINS
622-6334-002	CTL-30R	CONTROL	COLLINS
622-6334-003	CTL-30R	CONTROL	COLLINS
622-6334-004	CTL-30R	CONTROL	COLLINS
622-6334-801	CTL-30R	CONTROL	COLLINS
622-6334-802	CTL-30R	CONTROL	COLLINS
622-6342-011	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-012	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-013	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-014	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-01X	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-01X	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-021	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-022	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-023	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-024	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-02X	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6342-0XX	EFD-86	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6382-001	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-002	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-003	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-004	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-005	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-006	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-007	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6382-008	VNI-80B	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-6383-00X	RSP-85A	PANEL, REVERSIONARY SWITCH	COLLINS
622-6392-001	CWC-80	COMPUTER, COMPARATOR WARNING	COLLINS
622-6392-002	CWC-80	COMPUTER, COMPARATOR WARNING	COLLINS
622-6404-001	CHP-85C	PANEL, COURSE HEADING	COLLINS
622-6404-002	CHP-85C	PANEL, COURSE HEADING	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6404-00X	CHP-85C	PANEL, COURSE HEADING	COLLINS
622-6405-001	DCP-85C	PANEL, DISPLAY CONTROL	COLLINS
622-6405-002	DCP-85C	PANEL, DISPLAY CONTROL	COLLINS
622-6405-003	DCP-85C	PANEL, DISPLAY CONTROL	COLLINS
622-6405-004	DCP-85C	PANEL, DISPLAY CONTROL	COLLINS
622-6405-00X	DCP-85C	PANEL, DISPLAY CONTROL	COLLINS
622-6408-001	CHP-86A	PANEL, COURSE HEADING	COLLINS
622-6408-002	CHP-86A	PANEL, COURSE HEADING	COLLINS
622-6408-00X	CHP-86A	PANEL, COURSE HEADING	COLLINS
622-6408-00X	CHP-86A	PANEL, COURSE HEADING	COLLINS
622-6408-XXX	CHP-86A	PANEL, COURSE HEADING	COLLINS
622-6415-011	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-012	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-013	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-014	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-015	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-016	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-017	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-018	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6415-0XX	MSI-80E	INDICATOR, MACH SPEED	COLLINS
622-6459-001	CTS-64	TEST SET	COLLINS
622-6464-011	EFD-85A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6464-012	EFD-85A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6464-021	EFD-85A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6464-022	EFD-85A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6470-00X	AAC-200P	COUPLER, AUTOMATIC ANTENNA	COLLINS
622-6471-00X	AAC-220P	COUPLER, AUTOMATIC ANTENNA	COLLINS
622-6475-XXX	ADC-82A	COMPUTER, AIR DATA	COLLINS
622-6513-001	ANT-312A	ANTENNA, WEATHER RADAR	COLLINS
622-6520-001	CTL-22	CONTROL	COLLINS
622-6520-002	CTL-22	CONTROL	COLLINS
622-6520-003	CTL-22	CONTROL	COLLINS
622-6520-004	CTL-22	CONTROL	COLLINS
622-6520-005	CTL-22	CONTROL	COLLINS
622-6520-006	CTL-22	CONTROL	COLLINS
622-6520-007	CTL-22	CONTROL	COLLINS
622-6520-008	CTL-22	CONTROL	COLLINS
622-6520-009	CTL-22	CONTROL	COLLINS
622-6520-010	CTL-22	CONTROL	COLLINS
622-6520-011	CTL-22	CONTROL	COLLINS
622-6520-012	CTL-22	CONTROL	COLLINS
622-6520-013	CTL-22	CONTROL	COLLINS
622-6520-014	CTL-22	CONTROL	COLLINS
622-6520-015	CTL-22	CONTROL	COLLINS
622-6520-016	CTL-22	CONTROL	COLLINS
622-6520-801	CTL-22	CONTROL	COLLINS
622-6520-802	CTL-22	CONTROL	COLLINS
622-6521-001	CTL-32	CONTROL	COLLINS
622-6521-002	CTL-32	CONTROL	COLLINS
622-6521-003	CTL-32	CONTROL	COLLINS
622-6521-004	CTL-32	CONTROL	COLLINS
622-6521-005	CTL-32	CONTROL	COLLINS
622-6521-006	CTL-32	CONTROL	COLLINS
622-6521-007	CTL-32	CONTROL	COLLINS
622-6521-008	CTL-32	CONTROL	COLLINS
622-6521-009	CTL-32	CONTROL	COLLINS
622-6521-010	CTL-32	CONTROL	COLLINS
622-6521-011	CTL-32	CONTROL	COLLINS
622-6521-012	CTL-32	CONTROL	COLLINS
622-6521-013	CTL-32	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6521-014	CTL-32	CONTROL	COLLINS
622-6521-015	CTL-32	CONTROL	COLLINS
622-6521-016	CTL-32	CONTROL	COLLINS
622-6521-025	CTL-32	CONTROL	COLLINS
622-6521-026	CTL-32	CONTROL	COLLINS
622-6521-027	CTL-32	CONTROL	COLLINS
622-6521-028	CTL-32	CONTROL	COLLINS
622-6521-029	CTL-32	CONTROL	COLLINS
622-6521-030	CTL-32	CONTROL	COLLINS
622-6521-031	CTL-32	CONTROL	COLLINS
622-6521-032	CTL-32	CONTROL	COLLINS
622-6521-801	CTL-32	CONTROL	COLLINS
622-6521-802	CTL-32	CONTROL	COLLINS
622-6521-803	CTL-32	CONTROL	COLLINS
622-6521-804	CTL-32	CONTROL	COLLINS
622-6522-001	CTL-62	CONTROL	COLLINS
622-6522-002	CTL-62	CONTROL	COLLINS
622-6522-003	CTL-62	CONTROL	COLLINS
622-6522-004	CTL-62	CONTROL	COLLINS
622-6522-005	CTL-62	CONTROL	COLLINS
622-6522-006	CTL-62	CONTROL	COLLINS
622-6522-007	CTL-62	CONTROL	COLLINS
622-6522-008	CTL-62	CONTROL	COLLINS
622-6522-009	CTL-62	CONTROL	COLLINS
622-6522-010	CTL-62	CONTROL	COLLINS
622-6522-011	CTL-62	CONTROL	COLLINS
622-6522-012	CTL-62	CONTROL	COLLINS
622-6522-013	CTL-62	CONTROL	COLLINS
622-6522-014	CTL-62	CONTROL	COLLINS
622-6522-015	CTL-62	CONTROL	COLLINS
622-6522-016	CTL-62	CONTROL	COLLINS
622-6522-017	CTL-62	CONTROL	COLLINS
622-6522-018	CTL-62	CONTROL	COLLINS
622-6522-019	CTL-62	CONTROL	COLLINS
622-6522-020	CTL-62	CONTROL	COLLINS
622-6522-021	CTL-62	CONTROL	COLLINS
622-6522-022	CTL-62	CONTROL	COLLINS
622-6522-023	CTL-62	CONTROL	COLLINS
622-6522-024	CTL-62	CONTROL	COLLINS
622-6522-025	CTL-62	CONTROL	COLLINS
622-6522-026	CTL-62	CONTROL	COLLINS
622-6522-027	CTL-62	CONTROL	COLLINS
622-6522-028	CTL-62	CONTROL	COLLINS
622-6522-029	CTL-62	CONTROL	COLLINS
622-6522-030	CTL-62	CONTROL	COLLINS
622-6522-031	CTL-62	CONTROL	COLLINS
622-6522-032	CTL-62	CONTROL	COLLINS
622-6522-801	CTL-62	CONTROL	COLLINS
622-6522-802	CTL-62	CONTROL	COLLINS
622-6522-803	CTL-62	CONTROL	COLLINS
622-6522-804	CTL-62	CONTROL	COLLINS
622-6523-001	CTL-92	CONTROL	COLLINS
622-6523-002	CTL-92	CONTROL	COLLINS
622-6523-002	CTL-92A	CONTROL	COLLINS
622-6523-003	CTL-92	CONTROL	COLLINS
622-6523-003	CTL-92A	CONTROL	COLLINS
622-6523-004	CTL-92	CONTROL	COLLINS
622-6523-004	CTL-92A	CONTROL	COLLINS
622-6523-005	CTL-92	CONTROL	COLLINS
622-6523-005	CTL-92A	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6523-006	CTL-92	CONTROL	COLLINS
622-6523-006	CTL-92A	CONTROL	COLLINS
622-6523-007	CTL-92	CONTROL	COLLINS
622-6523-007	CTL-92A	CONTROL	COLLINS
622-6523-008	CTL-92	CONTROL	COLLINS
622-6523-008	CTL-92A	CONTROL	COLLINS
622-6523-009	CTL-92	CONTROL	COLLINS
622-6523-009	CTL-92A	CONTROL	COLLINS
622-6523-010	CTL-92	CONTROL	COLLINS
622-6523-010	CTL-92A	CONTROL	COLLINS
622-6523-011	CTL-92	CONTROL	COLLINS
622-6523-011	CTL-92A	CONTROL	COLLINS
622-6523-012	CTL-92	CONTROL	COLLINS
622-6523-012	CTL-92A	CONTROL	COLLINS
622-6523-013	CTL-92	CONTROL	COLLINS
622-6523-013	CTL-92A	CONTROL	COLLINS
622-6523-014	CTL-92	CONTROL	COLLINS
622-6523-014	CTL-92A	CONTROL	COLLINS
622-6523-015	CTL-92	CONTROL	COLLINS
622-6523-015	CTL-92A	CONTROL	COLLINS
622-6523-016	CTL-92	CONTROL	COLLINS
622-6523-016	CTL-92A	CONTROL	COLLINS
622-6523-201	CTL-92	CONTROL	COLLINS
622-6523-201	CTL-92A	CONTROL	COLLINS
622-6523-202	CTL-92	CONTROL	COLLINS
622-6523-202	CTL-92A	CONTROL	COLLINS
622-6523-203	CTL-92	CONTROL	COLLINS
622-6523-203	CTL-92A	CONTROL	COLLINS
622-6523-204	CTL-92	CONTROL	COLLINS
622-6523-204	CTL-92A	CONTROL	COLLINS
622-6523-205	CTL-92	CONTROL	COLLINS
622-6523-205	CTL-92A	CONTROL	COLLINS
622-6523-206	CTL-92	CONTROL	COLLINS
622-6523-206	CTL-92A	CONTROL	COLLINS
622-6523-207	CTL-92	CONTROL	COLLINS
622-6523-207	CTL-92A	CONTROL	COLLINS
622-6523-208	CTL-92	CONTROL	COLLINS
622-6523-208	CTL-92A	CONTROL	COLLINS
622-6523-209	CTL-92	CONTROL	COLLINS
622-6523-209	CTL-92A	CONTROL	COLLINS
622-6523-210	CTL-92	CONTROL	COLLINS
622-6523-210	CTL-92A	CONTROL	COLLINS
622-6523-211	CTL-92	CONTROL	COLLINS
622-6523-211	CTL-92A	CONTROL	COLLINS
622-6523-212	CTL-92	CONTROL	COLLINS
622-6523-212	CTL-92A	CONTROL	COLLINS
622-6523-213	CTL-92	CONTROL	COLLINS
622-6523-213	CTL-92A	CONTROL	COLLINS
622-6523-214	CTL-92	CONTROL	COLLINS
622-6523-214	CTL-92A	CONTROL	COLLINS
622-6523-215	CTL-92	CONTROL	COLLINS
622-6523-215	CTL-92A	CONTROL	COLLINS
622-6523-216	CTL-92	CONTROL	COLLINS
622-6523-216	CTL-92A	CONTROL	COLLINS
622-6523-305	CTL-92	CONTROL	COLLINS
622-6523-306	CTL-92	CONTROL	COLLINS
622-6523-307	CTL-92	CONTROL	COLLINS
622-6523-308	CTL-92	CONTROL	COLLINS
622-6523-313	CTL-92	CONTROL	COLLINS
622-6523-314	CTL-92	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6523-315	CTL-92	CONTROL	COLLINS
622-6523-316	CTL-92	CONTROL	COLLINS
622-6523-801	CTL-92	CONTROL	COLLINS
622-6523-802	CTL-92	CONTROL	COLLINS
622-6524-001	IND-42A	INDICATOR, DME	COLLINS
622-6524-002	IND-42A	INDICATOR, DME	COLLINS
622-6524-003	IND-42A	INDICATOR, DME	COLLINS
622-6524-004	IND-42A	INDICATOR, DME	COLLINS
622-6535-011	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-012	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-01X	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-021	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-022	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-02X	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6535-0XX	EFD-86A	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-6548-001	390R-23	KITS, UNIVERSAL MOUNT	COLLINS
622-6549-001	390R-24	KITS, UNIVERSAL MOUNT	COLLINS
622-6557-XXX	TCR-230	TRANSCEIVER	COLLINS
622-6563-001	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-002	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-003	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-004	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-005	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-006	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-007	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-008	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-103	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-104	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-105	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-106	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-109	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-203	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-204	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-205	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-206	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-303	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-304	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-305	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-306	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-405	MSP-85A	PANEL, MODE SELECT	COLLINS
622-6563-XXX	MPS-85A	PANEL, MODE SELECT	COLLINS
622-6590-001	CAD-62	ADAPTER, CONTROL	COLLINS
622-6590-002	CAD-62	ADAPTER, CONTROL	COLLINS
622-6607-001	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-002	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-003	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-004	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-005	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-006	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-007	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-008	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-009	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6607-012	DCP-270	PANEL, DISPLAY CONTROL	COLLINS
622-6608-001	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-002	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-003	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-004	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-005	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-006	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-007	DCP-325	PANEL, DISPLAY CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-6608-008	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6608-009	DCP-325	PANEL, DISPLAY CONTROL	COLLINS
622-6614-0XX	CTL-230	HEAD, HF CONTROL	COLLINS
622-6633-001	ANT-318A	ANTENNA, WEATHER RADAR	COLLINS
622-6667-001	PWR-230	AMPLIFIER, POWER	COLLINS
622-6668-00X	AAC-220	COUPLER, AUTOMATIC ANTENNA	COLLINS
622-6684-001	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-002	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-003	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-004	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-005	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-006	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-007	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-008	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-009	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-010	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-011	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6684-0XX	APP-65A	PANEL, AUTOPILOT	COLLINS
622-6717-004	SVO-85C	SERVO, ELECATOR AND RUDDER	COLLINS
622-6717-00X	SVO-85C	SERVO, PRIMARY	COLLINS
622-6717-XXX	SVO-85C	SERVO, PRIMARY	COLLINS
622-6720-001	CTS-9	BOX, UNIVERSAL ATR BREAKOUT	COLLINS
622-6728-0XX	ASI-80F	INDICATOR, AIRSPEED	COLLINS
622-6785-011	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-012	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-013	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-014	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-015	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-016	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-017	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-018	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-025	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6785-0XX	MSI-80F	INDICATOR, MACH SPEED	COLLINS
622-6793-001	ANT-52	ANTENNA	COLLINS
622-6794-002	DCP-85E	PANEL, DISPLAY CONTROL	COLLINS
622-6794-00X	DCP-85E	PANEL, DISPLAY CONTROL	COLLINS
622-6795-001	DSP-85	PANEL, DISPLAY SELECT	COLLINS
622-6795-002	DSP-85	PANEL, DISPLAY SELECT	COLLINS
622-6795-003	DSP-85	PANEL, DISPLAY SELECT	COLLINS
622-6795-004	DSP-85	PANEL, DISPLAY SELECT	COLLINS
622-6795-00X	DSP-85	PANEL, DISPLAY SELECT	COLLINS
622-683-002	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-6898-001	CHP-85D	PANEL, COURSE HEADING	COLLINS
622-6898-002	CHP-85D	PANEL, COURSE HEADING	COLLINS
622-6898-00X	CHP-85D	PANEL, COURSE HEADING	COLLINS
622-6899-001	CHP-86B	PANEL, COURSE HEADING	COLLINS
622-6899-002	CHP-86B	PANEL, COURSE HEADING	COLLINS
622-6899-00X	CHP-86B	PANEL, COURSE HEADING	COLLINS
622-6900-0X7	APP-85A	PANEL, AUTOPILOT	COLLINS
622-7139-001	PAC-230	COUPLER, PROBE ANTENNA	COLLINS
622-7154-00X	FMM-85	MODULE, FAN MONITOR	COLLINS
622-7194-101	VIR-432	RECEIVER, VHF NAVIGATION	COLLINS
622-7194-XXX	VIR-432, 433	RECEIVER, NAVIGATION	COLLINS
622-7194-XXX	VTR-432	RECEIVER, VHF NAVIGATION	COLLINS
622-7207-002	SDD-640	UNIT, DISPLAY DRIVER	COLLINS
622-7208-002	ADC-850	COMPUTER, AIR DATA	COLLINS
622-7209-002	RAC-870	CONVERTER, RADIO ALTITUDE	COLLINS
622-7236-00X	MFD-85A	DISPLAY, MULTIFUNCTION	COLLINS
622-7236-01X	MFD-85A	DISPLAY, MULTIFUNCTION	COLLINS
622-7236-0XX	MFD-85A	DISPLAY, MULTIFUNCTION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-7244-001	DPU-85A	UNIT, DISPLAY PROCESSOR	COLLINS
622-7244-00X	DPU-85A	UNIT, DISPLAY PROCESSOR	COLLINS
622-7245-001	DPU-85B	UNIT, DISPLAY PROCESSOR	COLLINS
622-7247-001	DPU-86A	UNIT, DISPLAY PROCESSOR	COLLINS
622-7247-00X	DPU-86A	UNIT, DISPLAY PROCESSOR	COLLINS
622-7248-00X	DPU-86C	UNIT, DISPLAY PROCESSOR	COLLINS
622-7249-001	DPU-86D	UNIT, DISPLAY PROCESSOR	COLLINS
622-7250-001	MPU-85A	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7251-001	MPU-85B	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7253-001	MPU-86A	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7253-00X	MPU-86A	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7254-001	MPU-86C	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7255-001	MPU-86D	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7292-001	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7292-002	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7292-101	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7292-102	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7292-122	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7292-123	VHF-422A	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-001	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-002	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-101	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-102	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-121	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-122	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7293-123	VHF-422B	TRANSCEIVER, COMMUNICATIONS	COLLINS
622-7309-001	DME-442	TRANSCEIVER, DME	COLLINS
622-7309-101	DME-442	TRANSCEIVER, DME	COLLINS
622-7318-001	IND-42C	INDICATOR, DME	COLLINS
622-7318-002	IND-42C	INDICATOR, DME	COLLINS
622-7318-003	IND-42C	INDICATOR, DME	COLLINS
622-7318-004	IND-42C	INDICATOR, DME	COLLINS
622-7337-001	WXT-250B	RECEIVER-TRANSMITTER, WEATHER RADAR	COLLINS
622-7337-002	WXT-250B	RECEIVER-TRANSMITTER, WEATHER RADAR	COLLINS
622-7338-00X	WXP-85C	PANEL, WEATHER RADAR	COLLINS
622-7338-01X	WXP-85C	PANEL, WEATHER RADAR	COLLINS
622-7338-02X	WXP-85C	PANEL, WEATHER RADAR	COLLINS
622-7346-001	CAD-870	ADAPTER, TRANSPONDER	COLLINS
622-7382-()	ADF-462	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-7382-101	ADF-462	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
622-7383-001	ANT-462A	ANTENNA, ADF	COLLINS
622-7384-001	ANT-462B	ANTENNA, ADF	COLLINS
622-7397-002	CHP-850	PANEL, COURSE/HEADING	COLLINS
622-7398-002	AAP-850	PANEL, ALTITUDE AWARENESS	COLLINS
622-7400-004	DBU-850	UNIT, DATA BASE	COLLINS
622-7410-102	FCC-850	COMPUTER, FLIGHT CONTROL	COLLINS
622-7410-202	FCC-850	COMPUTER, FLIGHT CONTROL	COLLINS
622-7410-302	FCC-850	COMPUTER, FLIGHT CONTROL	COLLINS
622-7411-204	APP-85D	PANEL, AUTOPILOT	COLLINS
622-7444-001	ANT-310A	ANTENNA, WEATHER RADAR	COLLINS
622-7448-0XX	DPU-85G	UNIT, DISPLAY PROCESSOR	COLLINS
622-7449-00X	DPU-85H	UNIT, DISPLAY PROCESSOR	COLLINS
622-7454-00X	MPU-85G	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7455-00X	MPU-85H	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7478-XXX	FCC-86D	COMPUTER, FLIGHT CONTROL	COLLINS
622-7491-XXX	FCC-85B	COMPUTER, FLIGHT CONTROL	COLLINS
622-7492-XXX	FCC-86B	COMPUTER, FLIGHT CONTROL	COLLINS
622-7493-XXX	FCC-86C	COMPUTER, FLIGHT CONTROL	COLLINS
622-7562-034	APA-80G	AMPLIFIER, AUTOPILOT	COLLINS
622-7576-XXX	ADC-80N	COMPUTER, AIR DATA	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-7577-XXX	ADC-80Q	COMPUTER, AIR DATA	COLLINS
622-7580-00X	WXP-85D	PANEL, WEATHER RADAR	COLLINS
622-7580-02X	WXP-85D	PANEL, WEATHER RADAR	COLLINS
622-7648-0XX	PRE-80B	PRESELECTOR / ALERTER	COLLINS
622-7651-XXX	FCC-86F	COMPUTER, FLIGHT CONTROL	COLLINS
622-7665-011	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-012	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-013	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-014	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-015	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-016	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-017	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-018	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-025	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7665-0XX	MSI-80G	INDICATOR, MACH SPEED	COLLINS
622-7667-001	DDA-42	ADAPTER, DISTANCE DATA	COLLINS
622-7689-001	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-002	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-003	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-004	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-005	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-006	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-007	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7689-008	VNI-80C	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-001	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-002	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-003	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-004	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-005	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-006	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-007	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7690-008	VNI-80D	INDICATOR, VERTICAL NAVIGATION	COLLINS
622-7711-00X	DPU-86H	UNIT, DISPLAY PROCESSOR	COLLINS
622-7713-001	DPU-86K	UNIT, DISPLAY PROCESSOR	COLLINS
622-7713-00X	DPU-86K	UNIT, DISPLAY PROCESSOR	COLLINS
622-7715-00X	MPU-86G	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7716-00X	MPU-86H	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7718-001	MPU-86K	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7728-001	DSP-85A	PANEL, DISPLAY SELECT	COLLINS
622-7728-002	DSP-85A	PANEL, DISPLAY SELECT	COLLINS
622-7728-003	DSP-85A	PANEL, DISPLAY SELECT	COLLINS
622-7728-004	DSP-85A	PANEL, DISPLAY SELECT	COLLINS
622-7728-00X	DSP-85A	PANEL, DISPLAY SELECT	COLLINS
622-7737-007	ADM-850	COMPUTER, AIR DATA	COLLINS
622-7874-001	MPU-86L	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-7875-001	CHP-86C	PANEL, COURSE HEADING	COLLINS
622-7875-002	CHP-86C	PANEL, COURSE HEADING	COLLINS
622-7875-00X	CHP-86C	PANEL, COURSE HEADING	COLLINS
622-7876-01X	MFD-85B	DISPLAY, MULTIFUNCTION	COLLINS
622-7877-001	CEU-85	UNIT, CHECKLIST ENTRY	COLLINS
622-7890-018	APC-65A	COMPUTER, AUTOPILOT	COLLINS
622-7890-018	APC-65A	COMPUTER, AUTOPILOT	COLLINS
622-7937-001	CTL-22A	CONTROL	COLLINS
622-7978-XXX	FCC-86D	COMPUTER, FLIGHT CONTROL	COLLINS
622-8022-001	DPU-85L	UNIT, DISPLAY PROCESSOR	COLLINS
622-8023-001	MPU-85L	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-8051-00X	ADC-85	COMPUTER, AIR DATA	COLLINS
622-8070-XXX	ADC-80R	COMPUTER, AIR DATA	COLLINS
622-8084-001	GLS-350	RECEIVER, GLIDESLOPE	COLLINS
622-8105-XXX	ADC-82L	COMPUTER, AIR DATA	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-8111-001	HF-9010	HEAD, RADIO SET CONTROL	COLLINS
622-8111-00X	HF-9010	CONTROLS, RADIO SET	COLLINS
622-8112-001	HF-9030	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8112-00X	HF-9030	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8113-001	HF-9040	COUPLER, HF ANTENNA	COLLINS
622-8113-00X	HF-9040	COUPLER, HF ANTENNA	COLLINS
622-8114-001	HF-9041	COUPLER, HF ANTENNA	COLLINS
622-8114-00X	HF-9041	COUPLER, HF ANTENNA	COLLINS
622-8125-001	HF-9031	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8125-00X	HF-9031	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8126-001	HF-9070	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8126-00X	HF-9070	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8128-001	HF-9032	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8128-00X	HF-9032	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8129-001	HF-9071	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8129-00X	HF-9071	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8132-001	HF-9072	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8132-00X	HF-9072	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-8148-00X	DCP-85F	PANEL, DISPLAY CONTROL	COLLINS
622-8154-00X	FDU-70A	UNIT, FLUX DETECTOR	COLLINS
622-8196-XXX	FCC-86E	COMPUTER, FLIGHT CONTROL	COLLINS
622-8304-00X	UMT-16A	MOUNT, UNIVERSAL	COLLINS
622-8315-023	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8315-102	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8315-123	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8315-202	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8315-302	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8315-XXX	APC-65B	COMPUTER, AUTOPILOT	COLLINS
622-8329-XXX	ADC-82C	COMPUTER, AIR DATA	COLLINS
622-8330-003	MSP-850A	PANEL, MODE SELECT	COLLINS
622-8330-004	MSP-850A	PANEL, MODE SELECT	COLLINS
622-8332-001	CAD-31	ADAPTER, CONTROL	COLLINS
622-8332-002	CAD-31	ADAPTER, CONTROL	COLLINS
622-8336-001	SDU-640A	UNIT, SENSOR DISPLAY	COLLINS
622-8390-002	860F-4	ALTIMETER, RADIO	COLLINS
622-8393-00X	WXP-850A	PANEL, WEATHER RADAR	COLLINS
622-8393-0XX	WXP-850A	PANEL, WEATHER RADAR CONTROL	COLLINS
622-8394-00X	WXP-850B	PANEL, WEATHER RADAR	COLLINS
622-8394-0XX	WXP-850B	PANEL, WEATHER RADAR CONTROL	COLLINS
622-8434-003	APC-65C	COMPUTER, AUTOPILOT	COLLINS
622-8439-004	RTA-852	RECEIVER/TRANSMITTER/ANTENNA	COLLINS
622-8439-0XX	RTA-852	UNIT, RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-8440-003	RTA-854	RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-8440-011	RTA-854	RECEIVER/TRANSMITTER/ANTENNA	COLLINS
622-8440-0XX	RTA-854	UNIT, RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-8441-0XX	RTA-858	UNIT, RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-8442-001	MPU-85M	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-8444-001	DPU-85M	UNIT, DISPLAY PROCESSOR	COLLINS
622-8444-101	DPU-85M	UNIT, DISPLAY PROCESSOR	COLLINS
622-8445-101	MPU-85M	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-8613-001	BIA-32	ADAPTER, BEARING INTERFACE	COLLINS
622-8613-002	BIA-32	ADAPTER, BEARING INTERFACE	COLLINS
622-8614-00X	UMT-16B	MOUNT, UNIVERSAL	COLLINS
622-8624-001	970D-2A	TEST SET, AIR DATA ELECTRONIC	COLLINS
622-8630-002	FGC-80G	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-8678-0XX	DPU-85N	UNIT, DISPLAY PROCESSOR	COLLINS
622-8679-XXX	MPU-85N	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-8680-00X	DCP-85G	PANEL, DISPLAY CONTROL	COLLINS
622-8680-00X	DCP-85G	PANEL, DISPLAY CONTROL	COLLINS
622-8680-00X	DCP-85G	PANEL, DISPLAY CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-8692-XXX	ADM-85	MODULE, AIRCRAFT DATA	COLLINS
622-8713-XXX	DPU-86N	UNIT, DISPLAY PROCESSOR	COLLINS
622-8737-002	CTL-22A	CONTROL	COLLINS
622-8737-003	CTL-22A	CONTROL	COLLINS
622-8737-004	CTL-22A	CONTROL	COLLINS
622-8737-005	CTL-22A	CONTROL	COLLINS
622-8737-006	CTL-22A	CONTROL	COLLINS
622-8737-007	CTL-22A	CONTROL	COLLINS
622-8737-008	CTL-22A	CONTROL	COLLINS
622-8737-009	CTL-22A	CONTROL	COLLINS
622-8737-010	CTL-22A	CONTROL	COLLINS
622-8737-011	CTL-22A	CONTROL	COLLINS
622-8737-012	CTL-22A	CONTROL	COLLINS
622-8737-013	CTL-22A	CONTROL	COLLINS
622-8737-014	CTL-22A	CONTROL	COLLINS
622-8737-015	CTL-22A	CONTROL	COLLINS
622-8737-016	CTL-22A	CONTROL	COLLINS
622-8737-801	CTL-22A	CONTROL	COLLINS
622-8737-802	CTL-22A	CONTROL	COLLINS
622-8738-001	CTL-32A	CONTROL	COLLINS
622-8738-002	CTL-32A	CONTROL	COLLINS
622-8738-003	CTL-32A	CONTROL	COLLINS
622-8738-004	CTL-32A	CONTROL	COLLINS
622-8738-005	CTL-32A	CONTROL	COLLINS
622-8738-006	CTL-32A	CONTROL	COLLINS
622-8738-007	CTL-32A	CONTROL	COLLINS
622-8738-008	CTL-32A	CONTROL	COLLINS
622-8738-009	CTL-32A	CONTROL	COLLINS
622-8738-010	CTL-32A	CONTROL	COLLINS
622-8738-011	CTL-32A	CONTROL	COLLINS
622-8738-012	CTL-32A	CONTROL	COLLINS
622-8738-013	CTL-32A	CONTROL	COLLINS
622-8738-014	CTL-32A	CONTROL	COLLINS
622-8738-015	CTL-32A	CONTROL	COLLINS
622-8738-016	CTL-32A	CONTROL	COLLINS
622-8738-025	CTL-32A	CONTROL	COLLINS
622-8738-026	CTL-32A	CONTROL	COLLINS
622-8738-027	CTL-32A	CONTROL	COLLINS
622-8738-028	CTL-32A	CONTROL	COLLINS
622-8738-029	CTL-32A	CONTROL	COLLINS
622-8738-030	CTL-32A	CONTROL	COLLINS
622-8738-031	CTL-32A	CONTROL	COLLINS
622-8738-032	CTL-32A	CONTROL	COLLINS
622-8738-801	CTL-32A	CONTROL	COLLINS
622-8738-802	CTL-32A	CONTROL	COLLINS
622-8738-803	CTL-32A	CONTROL	COLLINS
622-8738-804	CTL-32A	CONTROL	COLLINS
622-8739-001	CTL-62A	CONTROL	COLLINS
622-8739-002	CTL-62	CONTROL	COLLINS
622-8739-003	CTL-62	CONTROL	COLLINS
622-8739-004	CTL-62	CONTROL	COLLINS
622-8739-005	CTL-62	CONTROL	COLLINS
622-8739-006	CTL-62	CONTROL	COLLINS
622-8739-007	CTL-62	CONTROL	COLLINS
622-8739-008	CTL-62	CONTROL	COLLINS
622-8739-009	CTL-62	CONTROL	COLLINS
622-8739-010	CTL-62	CONTROL	COLLINS
622-8739-011	CTL-62	CONTROL	COLLINS
622-8739-012	CTL-62	CONTROL	COLLINS
622-8739-013	CTL-62	CONTROL	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-8739-014	CTL-62	CONTROL	COLLINS
622-8739-015	CTL-62	CONTROL	COLLINS
622-8739-016	CTL-62	CONTROL	COLLINS
622-8739-017	CTL-62	CONTROL	COLLINS
622-8739-018	CTL-62	CONTROL	COLLINS
622-8739-019	CTL-62	CONTROL	COLLINS
622-8739-020	CTL-62	CONTROL	COLLINS
622-8739-021	CTL-62	CONTROL	COLLINS
622-8739-022	CTL-62	CONTROL	COLLINS
622-8739-023	CTL-62	CONTROL	COLLINS
622-8739-024	CTL-62	CONTROL	COLLINS
622-8739-025	CTL-62	CONTROL	COLLINS
622-8739-026	CTL-62	CONTROL	COLLINS
622-8739-027	CTL-62	CONTROL	COLLINS
622-8739-028	CTL-62	CONTROL	COLLINS
622-8739-029	CTL-62	CONTROL	COLLINS
622-8739-030	CTL-62	CONTROL	COLLINS
622-8739-031	CTL-62	CONTROL	COLLINS
622-8739-032	CTL-62	CONTROL	COLLINS
622-8739-801	CTL-62	CONTROL	COLLINS
622-8739-802	CTL-62	CONTROL	COLLINS
622-8739-803	CTL-62	CONTROL	COLLINS
622-8739-804	CTL-62	CONTROL	COLLINS
622-8740-001	CTL-92A	CONTROL	COLLINS
622-8778-003	FGC-65C	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-8778-003	FGC-65C	COMPUTER, FLIGHT GUIDANCE	COLLINS
622-8793-001	HCP-74A	PANEL, HSI CONTROL	COLLINS
622-8793-00X	HCP-74A	PANEL, HSI CONTROL	COLLINS
622-8849-100	RFU-900	UNIT, RADIO FREQUENCY	COLLINS
622-8971-120	TTR-920	RECEIVER, TCAS II TRANSMITTER	COLLINS
622-8971-120	TTR-920	TRANSMITTER-RECEIVER, TCAS II	COLLINS
622-8973-001	TRE-920	ANTENNA, TCAS II DIRECTIONAL	COLLINS
622-9007-00X	DPU-85R	UNIT, DISPLAY PROCESSOR	COLLINS
622-9008-00X	MPU-85R	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-9009-00X	DPU-86R	UNIT, DISPLAY PROCESSOR	COLLINS
622-9046-022	APC-65E	COMPUTER, AUTOPILOT	COLLINS
622-9046-025	APC-65E	COMPUTER, AUTOPILOT	COLLINS
622-9046-026	APC-65E	COMPUTER, AUTOPILOT	COLLINS
622-9046-02X	APC-65E	COMPUTER, AUTOPILOT	COLLINS
622-9080-0XX	RTA-852L	UNIT, RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-9116-00X	DSP-85B	PANEL, DISPLAY SELECT	COLLINS
622-9116-XXX	DSP-85B	PANEL, DISPLAY SELECT	COLLINS
622-9117-00X	DSP-85C	PANEL, DISPLAY SELECT	COLLINS
622-9117-XXX	DSP-85C	PANEL, DISPLAY SELECT	COLLINS
622-9165-00X	DCP-85H	PANEL, DISPLAY CONTROL	COLLINS
622-9171-001	ANS-351C	COMPUTER, AREA NAVIGATION	COLLINS
622-9210-003	TDR-94D	TRANSPONDER, MODE S	COLLINS
622-9210-00X	TRD-94D	SYSTEM, ATC / MODE S TRANSPONDER	COLLINS
622-9210-XXX	TDR-94D	ATC TRANSPONDER	COLLINS
622-9213-001	699K-3	ADAPTER, TRIM	COLLINS
622-9221-001	HPU-74B	UNIT, HSI PROCESSOR	COLLINS
622-9221-011	HPU-74B	UNIT, HSI PROCESSOR	COLLINS
622-9222-00X	HCP-74B	PANEL, HSI CONTROL	COLLINS
622-9227-00X	ARP-86	PANEL, AIR DATA REFERENCE	COLLINS
622-9237-00X	ADC-86	COMPUTER, AIR DATA	COLLINS
622-9238-0XX	ALI-850B	INDICATOR, ALTITUDE	COLLINS
622-9266-024	APC-65G	COMPUTER, AUTOPILOT	COLLINS
622-9267-027	APC-65F	COMPUTER, AUTOPILOT	COLLINS
622-9282-00X	ADM-86	MODULE, AIRCRAFT DATA	COLLINS
622-9285-00X	DPU-86S	UNIT, DISPLAY PROCESSOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-9286-00X	MPU-86S	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-9292-001	ARP-850	PANEL, AIR DATA REFERENCE	COLLINS
622-9301-00X	RTA-842	RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-9302-003	RTA-844	RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-9302-00X	RTA-844	RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-9302-011	RTA-844	RECEIVER/TRANSMITTER/ANTENNA	COLLINS
622-9303-00X	RTA-848	RECEIVER / TRANSMITTER / ANTENNA	COLLINS
622-9304-01X	WXP-840A	PANEL, WEATHER RADAR	COLLINS
622-9304-0XX	WXP-840A	PANEL, WEATHER RADAR	COLLINS
622-9305-01X	WXP-840B	PANEL, WEATHER RADAR	COLLINS
622-9305-0XX	WXP-840B	PANEL, WEATHER RADAR	COLLINS
622-9336-001	AHS-85E	COMPUTER, ATTITUDE HEADING	COLLINS
622-9336-002	AHC-85E	COMPUTER, ATTITUDE HEADING	COLLINS
622-9336-002	AHC-85E	COMPUTER, ATTITUDE READING	COLLINS
622-9336-400	AHC-85E	COMPUTER, ATTITUDE HEADING	COLLINS
622-9337-001	CDC-850B	COUPLER, CONTROL DISPLAY	COLLINS
622-9338-001	FMC-851B	COMPUTER, FLIGHT MANAGEMENT	COLLINS
622-9339-001	FMC-852B	COMPUTER, NAVIGATION	COLLINS
622-9344-001	DAU-650	UNIT, DATA ACQUISITION	COLLINS
622-9344-101	DAU-650	UNIT, DATA ACQUISITION	COLLINS
622-9345-001	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-003	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-005	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-021	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-025	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-027	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9345-201	EFD-871	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9346-012	RTU-870A	UNIT, RADIO TUNING	COLLINS
622-9347-001	SDD-640A	UNIT, DISPLAY DRIVER	COLLINS
622-9352-003	TDR-94	TRANSPONDER	COLLINS
622-9352-00X	TDR-94	TRANSPONDER, MODE S	COLLINS
622-9352-XXX	TDR-94	ATC TRANSPONDER	COLLINS
622-9377-001	ATC-850	COUPLER, AUTOMATIC TRIM	COLLINS
622-9395-001	699K-4	ADAPTER, TRIM	COLLINS
622-9405-001	HF-9042	COUPLER, ANTENNA	COLLINS
622-9405-00X	HF-9042	COUPLER, HF ANTENNA	COLLINS
622-9424-00X	HF-9074	RECEIVER-TRANSMITTER, RADIO	COLLINS
622-9434-001	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-003	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-011	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-031	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-035	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-037	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9434-211	MFD-871	DISPLAY, MULTIFUNCTION	COLLINS
622-9462-0XX	PRE-80C	PRESELECTOR / ALERTER	COLLINS
622-9462-0XX	PRE-80C	PRESELECTOR / ALERTER	COLLINS
622-9500-011	ARP-851	PANEL, AIR DATA REFERENCE	COLLINS
622-9576-011	CDU-860	UNIT, CONTROL DISPLAY	COLLINS
622-9578-001	CDU-851	UNIT, CONTROL DISPLAY	COLLINS
622-9617-001	HCP-74C	PANEL, HSI CONTROL	COLLINS
622-9618-001	EFD-74C	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9619-001	HPU-74C	UNIT, HSI PROCESSOR	COLLINS
622-9627-005	FYD-65	COMPUTER, FLIGHT GUIDANCE / YAW DAMPER	COLLINS
622-9627-017	FYD-65	COMPUTER, FLIGHT GUIDANCE / YAW DAMPER	COLLINS
622-9627-0XX	FYD-65	COMPUTER, FLIGHT GUIDANCE / YAW DAMPER	COLLINS
622-9681-001	EFD-84	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9681-002	EFD-84	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9681-011	EFD-84	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9681-012	EFD-84	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9681-0XX	EFD-84	DISPLAY, ELECTRONIC FLIGHT	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
622-9682-002	DPU-84	UNIT, DISPLAY PROCESSOR	COLLINS
622-9682-002	DPU-84	UNIT, DISPLAY PROCESSOR	COLLINS
622-9683-001	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9683-00X	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9683-011	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9683-012	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9683-021	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9683-022	DSP-84	PANEL, DISPLAY SELECT	COLLINS
622-9684-002	MPU-84	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-9722-0XX	PRE-80D	PRESELECTOR / ALERTER	COLLINS
622-9724-005	APC-65H	COMPUTER, AUTOPILOT	COLLINS
622-9724-017	APC-65H	COMPUTER, AUTOPILOT	COLLINS
622-9724-028	APC-65H	COMPUTER, AUTOPILOT	COLLINS
622-9724-128	APC-65H	COMPUTER, AUTOPILOT	COLLINS
622-9724-XXX	APC-65H	COMPUTER, AUTOPILOT	COLLINS
622-9732-001	SIA-850	ADAPTER, SIGNAL INTERFACE	COLLINS
622-9732-002	AIS-850	ADAPTER, SIGNAL INTERFACE	COLLINS
622-9736-22X	WXI-711A	INDICATOR, WEATHER RADAR	COLLINS
622-9814-80X	IOC-4000	CONCENTRATOR	COLLINS
622-9817-001	ATC-4000	COUPLER, AUTOMATIC TRIM	COLLINS
622-9818-6XX	MDC-4000	COMPUTER, MAINTENANCE DIAGNOSTIC	COLLINS
622-9842-()	UMT-16C	MOUNT, UNIVERSAL	COLLINS
622-9843-01X	MFD-85C	DISPLAY, MULTIFUNCTION	COLLINS
622-9849-0XX	MFD-85C	DISPLAY, MULTIFUNCTION	COLLINS
622-9856-111	RTU-870T	UNIT, RADIO TUNING	COLLINS
622-9856-131	RTU-870T	UNIT, RADIO TUNING	COLLINS
622-9865-001	DBU-4000	UNIT, DATA BASE	COLLINS
622-9924-002	CDC-850C	COUPLER, CONTROL DISPLAY	COLLINS
622-9924-101	CDC-850C	COUPLER, CONTROL DISPLAY	COLLINS
622-9925-002	FMC-851C	COMPUTER, FLIGHT MANAGEMENT	COLLINS
622-9925-101	FMC-851C	COMPUTER, FLIGHT MANAGEMENT	COLLINS
622-9925-207	FMC-851C	COMPUTER, FLIGHT MANAGEMENT	COLLINS
622-9926-002	FMC-852C	COMPUTER, NAVIGATION	COLLINS
622-9926-101	FMC-852C	COMPUTER, NAVIGATION	COLLINS
622-9926-207	FMC-852C	COMPUTER, NAVIGATION	COLLINS
622-9929-002	WXP-4120	PANEL, WEATHER RADAR CONTROL	COLLINS
622-9945-02X	PWR-4000	SUPPLY, POWER	COLLINS
622-9957-011	CDU-860A	UNIT, CONTROL DISPLAY	COLLINS
622-9965-002	DPU-85U	UNIT, DISPLAY PROCESSOR	COLLINS
622-9966-002	MPU-85U	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-9967-002	MPU-86U	UNIT, MULTIFUNCTION PROCESSOR	COLLINS
622-9976-001	IND-42M	INDICATOR, DME	COLLINS
622-9976-002	IND-42M	INDICATOR, DME	COLLINS
622-9976-003	IND-42M	INDICATOR, DME	COLLINS
622-9976-004	IND-42M	INDICATOR, DME	COLLINS
622-9978-102	EFD-4077	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9978-110	EFD-4077	DISPLAY, ELECTRONIC FLIGHT	COLLINS
622-9996-002	INC-4000	INCLINOMETER	COLLINS
622-XXXX-XXX	ADC-80()	COMPUTER, AIR DATA	COLLINS
6233-()-()		HEAD, NAV 1/2 CONTROL	AVTECH
6233-3		HEAD, NAV VOR DME CONTROL	AVTECH
6247813-001		ANTENNA	HONEYWELL
6247925-001		ANTENNA, GLIDE SLOPE	HONEYWELL
625692-2		FAN/SENSOR	ALLIEDSIGNAL AEROSPACE
627578-1		SELECTOR, TEMPERATURE CONTROL	GARRETT
627934-()	RESCU 88C	LOCATOR, EMERGENCY	GARRETT
627934-()	RESCU 88C	TRANSMITTER, EMERGENCY LOCATOR	GARRETT
627934-2	RESCU 88C	TRANSMITTER, VERTICAL MOUNT	GARRETT
628-7990-001	28-14V DC	ADAPTER	COLLINS
629-8597-001		KIT, ARTHUR MONITOR INSTALLATION	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
6300-C38-A155-B1		INDICATOR, PERCENT TORQUE	BENDIX
6300-C49-A155-B1		INDICATOR, PERCENT TORQUE	BENDIX
6330GA	6330GA	SENSOR, MACH/AIRSPEED	HORIZON
634-4320-005	INC	INCLINOMETER	COLLINS
635	635	INDICATOR, DUAL CYLINDER TEMPERATURE	AMETEK
636-0172	873-0009	ASSEMBLY, RELAY (400 CYCLE)	COOK
637934-3	RESCU 88C	TRANSMITTER, HORIZONTAL MOUNT	GARRETT
6394-1		HEAD, ATC CONTROL	AVTECH
6405-()		INDICATOR, TURN COORDINATOR	S-TEC
64052-()-1		SWITCHES, AIRSPEED	JEAGER
6407-()		INDICATOR, TURN COORDINATOR	S-TEC
64279-00X-X		INDICATOR, PRESSURE TRANSDUCER	THALES
643710		INDICATOR, GYRO-HORIZON	HONEYWELL
643715		INDICATOR, DIRECTIONAL GYRO	HONEYWELL
643720		INDICATOR, GYRO-HORIZON	HONEYWELL
644066		INDICATOR, GYRO-HORIZON	HONEYWELL
64500-()-()		SWITCH, AIRSPEED	JAEGER
64530-068-4		INDICATOR, TACHOMETER	JAEGER
64550-005-1		GENERATOR, TACHOMETER	JAEGER
64550-023-1		GENERATOR, TACHOMETER	JAEGER
646040		INDICATOR, GYRO-HORIZON	HONEYWELL
646050		INDICATOR, DIRECTIONAL GYRO	HONEYWELL
646050-H	AN5735-1	INDICATOR, ARTIFICIAL HORIZON GYRO	HONEYWELL
6461-1		HEAD, ADF CONTROL	AVTECH
647K-02	647K-02	INDICATOR, HORSEPOWER	KOLLSMAN
647T	647T	TRANSMITTETR, HORSEPOWER	KOLLSMAN
64807-()-1		INDICATOR, TEMPERATURE	JAEGER
64809-()-1		INDICATOR, PRESSURE (0-10 BAR)	JAEGER
64809-401-1		INDICATOR, PRESSURE (0-70 PSI)	JAEGER
64905-()-1		INDICATOR, POSITION	JAEGER
649742	AN5735-1()	INDICATOR, GYRO-HORIZON	HONEYWELL
650-1101-932	HSI-651	INDICATOR, HORIZONTAL SITUATION	AEROSPATIALE
65-0878-()		PANEL, ANNUNCIATOR	GRIMES
65-0879-()		PANEL, ANNUNCIATOR	GRIMES
65155-00017-106		TRANSDUCER, PRESSURE BIM	SIKORSKY AIRCRAFT
652832	H-5	CONTROL, POWER	HONEYWELL
653-1154-001	CSDB-402	CARD, PRO LINE II INTERFACE	COLLINS
653894-()B	C-2A	COMPASS, GYROSYN	HONEYWELL
653895	C-2()	AMPLIFIER, COMPASS	HONEYWELL
653897-()B	C-2	COMPASS, GYROSYN	HONEYWELL
654744	H-5	INDICATOR, HORIZON	HONEYWELL
656518	K-2	CONTROL, VERTICAL GYRO FLIGHT	HONEYWELL
656520	C-2	VALVE, FLUX	HONEYWELL
656520	C-2()	VALVE, FLUX	HONEYWELL
656520	FX-125	VALVE, FLUX	HONEYWELL
656767	C-2	COMPENSATOR, FLUX DETECTOR	HONEYWELL
656768	AN5736()	INDICATOR, GYRO HORIZON	HONEYWELL
65840-()		INDICATOR, FUEL FLOW & FLOW TOTALIZER	AEROSONIC
65840-0107		INDICATOR, TOTALIZER FUEL FLOW	AEROSONIC
65BL	65BL	INDICATOR, COMPASS	KOLLSMAN
6607		SWITCH, PRESSURE	EATON
6607-()-()		SWITCH, PRESSURE	EATON
6607-1-105		SWITCH, PRESSURE	EATON
6607-1-134		SWITCH, PRESSURE	EATON
6607-1-16		SWITCH, PRESSURE	EATON
6607-1-41		SWITCH, PRESSURE	EATON
6607-1-83		SWITCH, PRESSURE	EATON
6607-1-83A		SWITCH, PRESSURE	EATON
6607-1-86		SWITCH, PRESSURE	EATON
6607-2-1		SWITCH, PRESSURE	EATON

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
6607-2-12		SWITCH, PRESSURE	EATON
6607-2-12A		SWITCH, PRESSURE	EATON
6607-2-13		SWITCH, PRESSURE	EATON
6607-2-28		SWITCH, PRESSURE	EATON
6607-3-141		SWITCH, PRESSURE	EATON
6607-3-21		SWITCH, PRESSURE	EATON
6607-6-28A		SWITCH, PRESSURE	EATON
6607A3-99		SWITCH, PRESSURE - TORQUE LIMIT	EATON
6607H		SWITCH, PRESSURE	EATON
661062	AN5736()	INDICATOR, GYRO HORIZON	HONEYWELL
661102B		PHASE ADAPTER	HONEYWELL
664543	C-2/C	SYSTEM, GYROSYN COMPASS	HONEYWELL
666-0112	873-0007	RELAY, A.C. 400 HZ	COOK
667-0020	832-0002	INTERPRETER, ICE	COOK
667258-2	C-2()	COMPASS, GYROSYN	HONEYWELL
669556-()	C-2()	COMPASS, GYROSYN	HONEYWELL
669780	A-1	BOX, AUTOMATIC PILOT REALY	HONEYWELL
669926-()	C-2()	COMPASS, GYROSYN	HONEYWELL
66D()		CONSOLE, GYRO TEST	SIGMA-TEK
66D1000	CENTURY II/III/IV	CONSOLE, TEST	SIGMA-TEK
6700-300-80-10		MONITOR, POWER - AC	BRION-LEROUX
6700-400-80-10		MONITOR, POWER - DC	BRION-LEROUX
671()-()-()	671()-()-()	ALTIMETER, PRESSURE	KOLLSMAN
671C()-10-()	671C()-10-()	ALTIMETER, SENSITIVE	KOLLSMAN
671CK()-01	671CK()-01	ALTIMETER, SENSITIVE	KOLLSMAN
671CLU()-()		ALTIMETERS, SENSITIVE	KOLLSMAN
671CP()-01	671CP()-01	ALTIMETERS, SENSITIVE	KOLLSMAN
671CP-8-016	671CP-8-016	ALTIMETER, PRESSURE	KOLLSMAN
671CPU-19-015		ALTIMETERS, SENSITIVE	KOLLSMAN
671CPX-4-()		ALTIMETERS, SENSITIVE	KOLLSMAN
671CPX-6-051		ALTIMETER, SENSITIVE	KOLLSMAN
673391	H-6	INDICATOR, GYRO HORIZON	HONEYWELL
673447		DIRECTIONAL GYRO	HONEYWELL
674090	C-5C	INDICATOR, DIRECTIONAL GYRO	HONEYWELL
6742	6742	INDICATOR, PRESSURE - MANIFOLD	MANNING, MAXWELL &
6743-108	D-10	INDICATOR, PRESSURE - MANIFOLD	MANNING, MAXWELL &
6748-()	AN5770-1	INDICATOR, PRESSURE - MANIFOLD	MANNING, MAXWELL &
6748-157	D-10	INDICATOR, PRESSURE - MANIFOLD	MANNING, MAXWELL &
6770-161	AN5770-2	INDICATOR, PRESSURE - MANIFOLD (DUAL)	MANNING, MAXWELL &
678601	H-6A	INDICATOR, GYRO HORIZON	HONEYWELL
6799111		TESTER, TEMPERATURE DATUM SYSTEM	ALLISON
6800-()-()-()__	6800 TYPES	PRESSURE, FUEL AND OIL	BENDIX
6800-100-80-10		MONITOR, TEMPERATURE - BATTERY	BRION-LEROUX
6801-A1C-25-A1		INDICATOR, AUTOSYN - DUAL	BENDIX
6809-A	C-2	UNIT, PRESSURE WARNING - FUEL	MARSHALLTOWN
682010-11-()	682010-11-()	VIBRATOR	KOLLSMAN
6829274	443147-2	INDICATOR, TORQUE	ALLISON
6829276	438023-2	INDICATOR, TORQUE	ALLISON
6840003		INDICATOR, UNITIZED TORQUEMETER	TEXAS INSTRUMENTS
684471	H-6B	INDICATOR, GYRO HORIZON	HONEYWELL
685-0365-001	HF-9040	COUPLER, HF ANTENNA	COLLINS
6852536	505458-1	INDICATOR, TORQUE	ALLISON
6857199		INDICATOR, TORQUE	ALLISON
6858476		INDICATOR, TORQUE	ALLISON
686531	H-6	INDICATOR, GYRO HORIZON	HONEYWELL
6871139		INDICATOR, TORQUE	ALLISON
6874754		INDICATOR, TORQUE	ALLISON
6895-()		SWITCH, IMPACT	AERODYNE CONTROLS
6895-A-3-X-3-3		SWITCH, IMPACT	AEROSONIC
691-()()		VALVE, SUCTION RELIEF	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
691CU-8-06	AN5745-T2A	ACCELEROMETER	KOLLSMAN
70()		BATTERY, STAND-BY	ECE
700 SERIES	251/300/700 SERIES	INDICATORS, AUTOPILOT HORIZON REFERENCE	CASTLEBERRY
7000	7000	SYSTEM, AIRBORNE LORAN-C NAVIGATION	L3 COMMUNICATIONS
7000	7000 SERIES	RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS
70000125-90X	CD-125	DISPLAY, AIR DATA COMMAND	HONEYWELL
7000116-902	SPZ-800	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
7000120-901	PC-800	CONTROLLER, AUTOPILOT	HONEYWELL
7000125-901	CD-125	DISPLAY, AIR DATA COMMAND	HONEYWELL
7000125-902	CD-125	DISPLAY, AIR DATA COMMAND	HONEYWELL
7000125-90X	CD-124	DISPLAY, AIR DATA COMMAND	HONEYWELL
70002-1128		INDICATOR, TURN & SLIP	AEROSONIC
7000254-90X	SZ-800	COMPUTER, STABILITY AUGMENTATION	HONEYWELL
7000298-901	TZ-701	COMPUTER, TRIM	HONEYWELL
7000299-901	PC-702	CONTROLLER, HELIPILOT	HONEYWELL
7000300-901	AS-702	SENSOR, AIRSPEED	HONEYWELL
7000466-901	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-902	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-903	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-904	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-905	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-906	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-907	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-908	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-909	AD-650C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-910	AD-650C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-911	AD-600C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-912	AD-600C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-913	AD-600H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-914	AD-600H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-915	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-916	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-917	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-918	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-920	AD-650C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-925	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-926	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-935	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-936	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-93X	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-945	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-946	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-951	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-953	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-955	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-957	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-959	AD-650C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-961	AD-600C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-966	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-986	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-600A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-600B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-600C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-600H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-650A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-650B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-650C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-650H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000466-9XX	AD-650X	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000469-901	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7000469-902	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-903	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-904	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-905	RD-650	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-906	RD-650	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-906	RD-650	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-907	RD-650R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-908	RD-650R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-909	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-910	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-911	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-912	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-913	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-914	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-915	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-916	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-917	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-918	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-919	RD-650	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-920	RD-650	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-921	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-922	RD-650A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-923	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-924	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-925	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-926	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-938	RD-650B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000469-9XX	RD-650X	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7000472-901	VN-800	CONTROL / DISPLAY, VNAV	HONEYWELL
7000472-902	VN-800	CONTROL / DISPLAY, VNAV	HONEYWELL
7000472-904	AL-800	CONTROLLER, ALTITUDE PRESELECT	HONEYWELL
7000472-906	AL-800	CONTROLLER, ALTITUDE PRESELECT	HONEYWELL
7000473-90X	SP-650	COMPUTER, AUTOPILOT	HONEYWELL
70-0054-1		CONTROL, DIMMER - LIGHTS	GRIMES
7000605-901	MS-702	SELECTOR, MODE	HONEYWELL
7000605-902	MS-700	SELECTOR, MODE	HONEYWELL
7000605-9XX	MS-700	SELECTOR, FLIGHT DIRECTOR MODE	HONEYWELL
7000605-9XX	MS-702	SELECTOR, FLIGHT DIRECTOR MODE	HONEYWELL
7000622-901	VG-14	GYRO, VERTICAL	HONEYWELL
7000622-901	VG-14A	GYRO, VERTICAL	HONEYWELL
7000622-901/902	VG-14A	GYRO, VERTICAL	HONEYWELL
7000622-902	VG-14A	GYRO, VERTICAL DISPLACEMENT	HONEYWELL
7000700-612	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-616	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-622	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-637	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-647	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-656	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-662	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-665	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-668	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-669	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-834	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-864	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-901	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-902	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-903	AZ-600	COMPUTER, AIR DATA	HONEYWELL
7000700-903	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-904	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-906	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7000700-907	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-909	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-911	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-912	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-914	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-917	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-918	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-919	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-920	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-921	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-922	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-923	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-924	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-925	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-926	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-928	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-929	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-930	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-931	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-932	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-933	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-934	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-935	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-936	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-937	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-938	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-939	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-940	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-940	AZ-810	COMPUTER, AIR DATA	HONEYWELL
7000700-942	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-943	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-944	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-945	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-946	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-947	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-948	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-949	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-950	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-951	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-952	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-953	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-954	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-955	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-956	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-957	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-958	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-959	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-960	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-961	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-962	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-963	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-964	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-965	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-965	AZ-810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-966	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-967	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-968	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-969	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-974	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-975	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7000700-976	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-977	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-984	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-9XX	AZ-800	COMPUTER, AIR DATA	HONEYWELL
7000700-9XX	AZ-800	COMPUTER, AIR DATA	HONEYWELL
7000700-9XX	AZ-810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-VAR	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000700-XXX	AZ-800/810	COMPUTER, DIGITAL AIR DATA	HONEYWELL
7000788-()	GH-206	INDICATOR, GYRO HORIZON ATTITUDE	HONEYWELL
7000788-XXX	GH-206	INDICATOR, GYRO, HORIZON	HONEYWELL
7000836-901	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-901	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-902	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-903	AD-500B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-904	AD-500B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-905	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-906	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-907	AD-500H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-908	AD-500H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-909	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-910	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-911	AD-500B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-912	AD-500B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-913	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-914	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-915	AR-500	INDICATOR, ATTITUDE REFERENCE	HONEYWELL
7000836-916	AR-500	INDICATOR, ATTITUDE REFERENCE	HONEYWELL
7000836-917	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-918	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-919	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-920	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-921	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-922	AD-500C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-923	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-924	AD-500A	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-925	AD-500H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-926	AD-500H	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000836-9XX	AD-500 SERIES	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000839-901	RA-315	INDICATOR, RADIO ALTIMETER	HONEYWELL
7000839-903	RA-315	INDICATOR, RADIO ALTIMETER	HONEYWELL
7000839-904	RA-335	INDICATOR	HONEYWELL
7000839-90X	RA-315 / 335	INDICATOR	HONEYWELL
7000839-9XX	RA-315	INDICATOR, RADIO ALTIMETER	HONEYWELL
7000839-9XX	RA-335	INDICATOR, RADIO ALTIMETER	HONEYWELL
7000850-571	GH-222	INDICATOR, GYRO HORIZON ATTITUDE DIRECTOR	HONEYWELL
7000850-571	GH-222	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7000992	AG-222	ACCELEROMETER	HONEYWELL
7000B	7000B	GYROSCOPE, ROLL AND PITCH DISPLACEMENT	SMITHS
7001179-901	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-902	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-903	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-904	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-905	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-906	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-907	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-908	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-909	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-910	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-911	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-912	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7001179-913	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-914	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-914	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-915	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-916	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-951	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-951	RD-551A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-952	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-953	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-954	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-955	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-956	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-957	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-958	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-959	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-960	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-961	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-962	RD-550	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-963	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-964	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-965	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-966	RD-550R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-971	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-972	RD-550A	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-975	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-976	RD-550B	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-9XX	RD-550 SERIES	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001179-9XX	RD-550 SERIES	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001182-()	AD-550()	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7001182-904	AD-550B	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7001182-913	AD-550C	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7001182-9XX	AD-550 SERIES	INDICATOR, ATTITUDE DIRECTOR	HONEYWELL
7001182-9XX	AS-550 SERIES	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7001305-901	AN-700	INDICATOR, ACTUATOR POSITION	HONEYWELL
7001433-901	VA-100	ADVISORY, VOICE	HONEYWELL
7001482-901	SM-482	ASSEMBLY, PITCH CONTROL ROD	HONEYWELL
7001483-901	SM-483	ASSEMBLY, ROLL CONTROL ROD	HONEYWELL
70-0158-1		CONTROL, DIMMER	GRIMES
7001676-901	MS-206	SENSOR, MODE	HONEYWELL
7001676-902	MS-206	SELECTOR, MODE	HONEYWELL
70-0180		CONTROL, DUMMER	GRIMES
7001840-901	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-902	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-903	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-904	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-905	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-905	RT-300	RECEIVER-TRANSMITTER	HONEYWELL
7001840-906	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-90X	RT-300	RECEIVER-TRANSMITTER	HONEYWELL
7001840-911	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-912	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-912	RT-300	RECEIVER-TRANSMITTER	HONEYWELL
7001840-913	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-914	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-915	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-916	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-917	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-918	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-922	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-924	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7001840-926	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-928	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-931	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-932	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-934	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-936	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-937	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-938	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7001840-9XX	RT-300	TRANSCEIVER, RADIO ALTITUDE	HONEYWELL
7002353-901	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002353-902	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002353-90X	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002353-90X	AZ-649	SENSOR, AIR DATA	SPERRY
7002353-911	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002353-912	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002353-913	AZ-649	SENSOR, AIR DATA	HONEYWELL
7002412-904	AL-300	PRESELECT, ALTITUDE	HONEYWELL
7002493-901 THRU 906	RD-450	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7002493-903	RD-450	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
7002493-907 THRU 912	RD-450R	INDICATOR, HORIZONTAL SITUATION	HONEYWELL
70-0253-()		CONTROL UNIT, ADVISORY LIGHTS	GRIMES
7002638-90X	DS-125A	INDICATOR, TAS TEMPERATURE - HORIZONTAL	HONEYWELL
7002638-90X	DS-125A	INDICATOR, TAS TEMPERATURE - HORIZONTAL	HONEYWELL
7002800-804	SM-725	ACTUATOR, LINEAR - RUDDER	HONEYWELL
7002860-902	SI-225A	INDICATOR, MACH AIRSPEED	HONEYWELL
7002860-902	SI-225A	INDICATOR, MACH AIRSPEED	HONEYWELL
700299-903	PC-700	CONTROLLER, AUTOPILOT	HONEYWELL
700-2CF	52D66	INDICATOR, HORIZON REFERENCE	SIGMA-TEK
7003110-90X	ED-800	DISPLAY, ELECTRONIC	HONEYWELL
7003110-921	ED-800	DISPLAY, ELECTRONIC	HONEYWELL
7003180-904	SZ-400	COMPUTER, STABILITY AUGMENTATION	HONEYWELL
7003183-9XX	FZ-700	COMPUTER, DIGITAL FLIGHT CONTROL	HONEYWELL
7003360-()	AH-600	UNIT, STRAPDOWN ATTITUDE AND HEADING	HONEYWELL
7003360-932	AH-600	AHRU, STRAPDOWN	HONEYWELL
7003360-94X	AH-600	AHRU, STRAPDOWN	HONEYWELL
7003400-9X1	SG-800X	GENERATOR, SYMBOL	HONEYWELL
7003400-9X2	SG-60X	GENERATOR, SYMBOL	HONEYWELL
7003420-9XX	DC-800	CONTROLLER, DISPLAY	HONEYWELL
7003430-90X	ED-600	DISPLAY, ELECTRONIC	HONEYWELL
700348-7		DETECTOR, RPM LIMIT WARNING	HOSKINS (SYMBOLIC)
7003586	AT-300	ANTENNA	HONEYWELL
7003652-611	ID-802	DISPLAY, ADVISORY	HONEYWELL
7003652-621	ID-802	DISPLAY, ADVISORY	HONEYWELL
7003652-6XX	ID-802	DISPLAY, ADVISORY	HONEYWELL
7003897-9XX	PC-400	CONTROLLER, AUTOPILOT	HONEYWELL
7003938-906	MS-400	SELECTOR, MODE	HONEYWELL
7003974-707	FZ-800	COMPUTER, FLIGHT GUIDANCE	HONEYWELL
7003974-710	FZ-800	COMPUTER, FLIGHT GUIDANCE	HONEYWELL
7003974-7XX	FZ-800	COMPUTER, FLIGHT GUIDANCE	HONEYWELL
700-3CF	52D67	INDICATOR, HORIZON REFERENCE	SIGMA-TEK
700-3CF	700-3CF	INDICATORS, HORIZON REFERENCE	CASTLEBERRY
700-3CFB	700-3CFB	INDICATORS, HORIZON REFERENCE	CASTLEBERRY
7004123-XXX	SC-800	CONTROLLER, SENSOR SOURCE	HONEYWELL
7004126-904	FZ-400	COMPUTER, FLIGHT DIRECTOR	HONEYWELL
7004402-6XX	NZ-600 / 610 / 620	COMPUTER, NAVIGATION	HONEYWELL
7004402-8XX	NZ-800 / 810 / 820	COMPUTER, NAVIGATION	HONEYWELL
7004402-9XX	NZ-900 / 910 / 920	COMPUTER, NAVIGATION	HONEYWELL
7004403-901 / 902	CD-800	UNIT, CONTROL DISPLAY	HONEYWELL
7004544-212	SG-811	GENERATOR, SYMBOL	HONEYWELL
7004545-901	AC-801	COMPENSATOR, AHRS CONTROLLER / REMOTE	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7004577-901	VN-801	CONTROL / DISPLAY, VNAV	HONEYWELL
7004577-902	VN-801	CONTROL / DISPLAY, VNAV	HONEYWELL
7004577-903	AL-801	CONTROLLER, ALTITUDE PRESELECT	HONEYWELL
7004577-904	AL-801	CONTROLLER, ALTITUDE PRESELECT	HONEYWELL
7004607-VAR	DL-800	LOADER, DATA	HONEYWELL
7004609-VAR	PZ-800	COMPUTER, PERFORMANCE	HONEYWELL
7004609-VAR	PZ-800	COMPUTER, PERFORMANCE	HONEYWELL
7005358-902	SI-225S	INDICATOR, MACH AIRSPEED	HONEYWELL
7005358-902	SI-225S	INDICATOR, MACH AIRSPEED	HONEYWELL
7005819-72X	DC-810	CONTROLLER, DISPLAY	HONEYWELL
700-5CF	700-5CF	INDICATORS, HORIZON REFERENCE	CASTLEBERRY
7006921-301	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-302	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-303	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-304	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-311	WC-810	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-312	WC-810	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-401	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-402	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-403	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-404	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-412	WC-810	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-413	WC-874	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-414	WC-874	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-415	WC-874	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-416	WC-874	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-815	WC-884	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-816	WC-884	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-81X	WC-884	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-825	WC-884	CONTROLLER, WEATHER RADAR	HONEYWELL
7006921-826	WC-884	CONTROLLER, WEATHER RADAR	HONEYWELL
7007010-923	AZ-800	COMPUTER, AIR DATA	HONEYWELL
7007062-90X	MC-800	CONTROLLER, MFD	HONEYWELL
7007062-92X	MC-800	CONTROLLER, MFD	HONEYWELL
7007062-939	MC-800	CONTROLLER, MFD	HONEYWELL
7007453-903	RG-204	GYRO, RATE	HONEYWELL
7007549-901 / 902	CD-810	UNIT, CONTROL DISPLAY	HONEYWELL
7007549-905	CD-810	UNIT, CONTROL DISPLAY	HONEYWELL
7007549-90X	CD-810	UNIT, CONTROL DISPLAY	HONEYWELL
7007700-201	WI-450	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-202	WI-450	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-20X	WI-450	INDICATOR	HONEYWELL
7007700-301	WI-650	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-302	WI-650	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-303	WI-650	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-304	WI-650	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-30X	WI-650	INDICATOR	HONEYWELL
7007700-801	WI-870	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-802	WI-870	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-803	WI-870	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-804	WI-870	INDICATOR, WEATHER RADAR	HONEYWELL
7007700-80X	WI-870	INDICATOR	HONEYWELL
7007700-XXX	WI-880/660/650/440	INDICATOR, WEATHER RADAR	HONEYWELL
700801		SILVER STAR	HOSKINS (SYMBOLIC)
700801		SILVER STAR (APPENDIX A)	HOSKINS (SYMBOLIC)
70084700-922	WU-650	UNIT, ANTENNA AND RCVR / XMTR	HONEYWELL
7008470-721	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-722	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-901	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-902	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7008470-903	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-904	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-911	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-912	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-913	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-914	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-921	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-922	WU-650	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-922	WU-650	ANTENNA, WEATHER RADAR RECEIVER	HONEYWELL
7008470-923	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-924	WU-450	ANTENNA, RECEIVER-TRANSMITTER-	HONEYWELL
7008470-9XX	WU-450	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
7008470-9XX	WU-650	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
7008471-415, 417	WC-880	CONTROLLER, RADAR - WEATHER	HONEYWELL
7008471-601	WC-650	CONTROLLER, WEATHER RADAR	HONEYWELL
7008471-601	WU-650	CONTROLLER, WEATHER RADAR	HONEYWELL
7008471-607	WU-650	CONTROLLER, WEATHER RADAR	HONEYWELL
7008471-60X	WU-650	CONTROLLER	HONEYWELL
7008471-80X	WC-870	CONTROLLER	HONEYWELL
7008471-XXX	WC-880/660/440	CONTROLLER, WEATHER RADAR	HONEYWELL
7008471-XXX	WU-450	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
7009621-()	WC-800	CONTROLLER, WEATHER RADAR	HONEYWELL
7009621-()	WC-810	CONTROLLER, WEATHER RADAR	HONEYWELL
7009621-()	WC-874	CONTROLLER, WEATHER RADAR	HONEYWELL
7010133	FX-600	VALVE, FLUX	HONEYWELL
701020-1		PULSTAR	HOSKINS (SYMBOLIC
701021		PULSTAR	HOSKINS (SYMBOLIC
701023		PULSTAR	HOSKINS (SYMBOLIC
701023-()		SYSTEM, PULSTAR	HOSKINS (SYMBOLIC
701062-901	AT-855	ANTENNA, LIGHTNING SENSOR	HONEYWELL
701144		NOVASTAR	HOSKINS (SYMBOLIC
7011672-70X	SG-705	GENERATOR, SYMBOL	HONEYWELL
7011674-116	SG-816	GENERATOR, SYMBOL	HONEYWELL
7011674-316	SG-816	GENERATOR, SYMBOL	HONEYWELL
7011675-116	MG-816	GENERATOR, MFD SYMBOL	HONEYWELL
7011675-316	MG-816	GENERATOR, MFD SYMBOL	HONEYWELL
7011702-901	GC810	CONTROLLER, FLIGHT GUIDANCE	HONEYWELL
7011702-901	GC810	CONTROLLER, FLIGHT GUIDANCE	HONEYWELL
7011822-904	LP-860	PROCESSOR, LIGHTNING SENSOR	HONEYWELL
7012100-801	RM-850	UNIT, RADIO MANAGEMENT	HONEYWELL
7012100-8XX / 9XX	RM-850	UNIT, RADIO MANAGEMENT	HONEYWELL
7012100-913	RM-850	UNIT, RADIO MANAGEMENT	HONEYWELL
7012100-914	RM-850	UNIT, RADIO MANAGEMENT	HONEYWELL
7012640-XXX	WU-870	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
7012977-7XX	DC-811	CONTROLLER, DISPLAY	HONEYWELL
7013270-967	RM-855	UNIT, MANAGEMENT - RADIO	HONEYWELL
7013270-9XX	RM-855	UNIT, RADIO MANAGEMENT	HONEYWELL
7013711-901	AN-701	INDICATOR, ACTUATOR POSITION	HONEYWELL
7014300-901	DU870	DISPLAY UNIT	HONEYWELL
7014300-901	DU-870	UNIT, DISPLAY	HONEYWELL
7014331-9X1	BL-870	CONTROLLER, BEZEL	HONEYWELL
7014332-X41	BL-871	CONTROLLER, MFD BEZEL	HONEYWELL
7014700-905	AZ-850	COMPUTER, MICRO AIR DATA	HONEYWELL
7014700-923	AZ-840	COMPUTER, MICRO AIR DATA	HONEYWELL
7014940-901	IM-803	MODULE, INSTALLATION - IAC	HONEYWELL
7015327	GP-300	CONTROLLER, GUIDANCE PANEL	HONEYWELL
701620		BRITESTAR	HOSKINS (SYMBOLIC
7016341-90X		INDICATOR, BAROMETRIC ALTITUDE	HONEYWELL
7016600-901	DL-900	LOADER, DATA	HONEYWELL
7016600-90X	DL-900	LOADER, DATA	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7016683-943	DC-840	CONTROLLER, DISPLAY	HONEYWELL
7016954-90X	RI-553	CONTROLLER, REMOTE INSTRUMENT	HONEYWELL
7016986-XXX	DC-550	CONTROLLER, DISPLAY	HONEYWELL
7017300-61002	IC-800	COMPUTER, INTEGRATED AVIONICS	HONEYWELL
7018341-90X	MS-560	SELECTOR, MODE	HONEYWELL
7018366-90X		INDICATOR, MACH AIRSPEED	HONEYWELL
7018879-XXX	NZ-800	COMPUTER, NAVIGATION	HONEYWELL
701921-()	CFS1000/1001	SYSTEMS, COMPUTERIZED FUEL MANAGEMENT	HOSKINS (SYMBOLIC
701921-1	CFS1000	SYSTEM, FUEL MANAGEMENT	HOSKINS (SYMBOLIC
701921-2	CFS2000	SYSTEM, FUEL MANAGEMENT	HOSKINS (SYMBOLIC DESIGN)
701A	701A	INDICATOR, ADF FREQUENCY	DAVTRON
701B	701B	INDICATOR, ADF FREQUENCY	DAVTRON
702047-()	CFS1001/2001	COMPUTER, FUEL FLOW	HOSKINS (SYMBOLIC
702048-()	FT100/200	SYSTEM, FUEL TOTALIZER	HOSKINS (SYMBOLIC
7021450-331	WU-331	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-401	WU-440	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-411	WU-440	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-421	WU-440	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-601	WU-660	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-601	WU-660	ANTENNA, WEATHER RADAR RECEIVER	HONEYWELL
7021450-611	WU-660	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-621	WU-660	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-801	WU-880	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-811	WU-880	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-821	WU-880	ANTENNA, RECEIVER TRANSMITTER	HONEYWELL
7021450-XXX	WU-880/660/440	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
7022010-905	GP-400	PANEL, GUIDANCE	HONEYWELL
7022016-905	RC-900	CONTROLLER, REVERSIONARY	HONEYWELL
7022361-90X	CD-815	UNIT, CONTROL DISPLAY	HONEYWELL
7023300-905	AM-200	ACCESS TERMINAL, MAINTENANCE ACCESS	HONEYWELL
704A37.721.026		SWITCH, PRESSURE	JULES RICHARD
705-7V4		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V42M1		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V4M1		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V81		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V9		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V91M1		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V96		INDICATOR, GYROSCOPIC HORIZON	THALES
705-7V9M1		INDICATOR, GYROSCOPIC HORIZON	THALES
706-()-()		AMPLIFIERS	INTER-TECHNIQUE
7060		RATE OF CLIMB INDICATOR	UNITED INSTRUMENTS
708554-5		PANEL, CAUTION	AEROSPACE AVIONICS, INC.
71()		BATTERY, STAND-BY	ECE
7100	7100	SYSTEM, RMI	AERONETICS
7100	7100 SERIES	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS
710101-35-()	710101-35-()	VIBRATOR, ELECTRO-MECHANICAL	KOLLSMAN
7101-013-500X		VIBRATOR, ELECTRO-MECHANICAL	SENSONICS
71042-()_	71042-()_	SWITCH, MACH AIRSPEED	HYDRA-ELECTRIC
712333	5607	RECEIVER, GLIDESLOPE	LEAR
712336	5608	RECEIVER, MARKER BEACON	LEAR
7125-1		TRANSMITTER, RATE OF TURN	MID-CONTINENT
7125-1, 2		TRANSMITTER, RATE OF TURN	MID-CONTINENT
7137	7137	SYSTEM, RMI	AERONETICS
716-()-()		PANEL, AUXILIARY TANK - INDICATING	INTER-TECHNIQUE
716K-()-()	716K-()-()	INDICATOR, VERTICAL SPEED	KOLLSMAN
716U-03	716U-03	INDICATOR, VERTICAL SPEED	KOLLSMAN
71700-18		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
717-0304	717-0304	SWITCH, PRESSURE	COOK
7185-()		ACTUATOR, LINEAR	MID-CONTINENT
7202-1A-()-()	ID-249()/ARN	INDICATOR, COURSE	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7202-1A-()-()	ID-249X/ARN	INDICATOR, COURSE	BENDIX
7202-1A-()-()	ID-249X/ARN	INDICATOR, COURSE	BENDIX
720-264	R72-250AN	INDICATOR, FLAP POSITION	HICKOK
7204-1A-4-()1	ID-387/ARN	INDICATOR, COURSE	BENDIX
7204-1A-4-()1	ID-387/ARN	INDICATOR, COURSE	BENDIX
7204-1A-4-()1	ID-387/ARN	INDICATOR, COURSE	BENDIX
724	724	MAGNETO, D.C TACHOMETER	AMETEK
724-0012-01		ASSEMBLY, GYRO ROTOR	KELLY
724BK-()-01	724BK-()-01	INDICATOR, TRUE AIRSPEED	KOLLSMAN
727	727	INDICATOR, RATIO TYPE RESISTANCE	AMETEK
728	728	INDICATOR, RATIO TYPE RESISTANCE	AMETEK
728BK-()	728BK-()	INDICATOR, PRESSURE - MANIFOLD (DUAL)	KOLLSMAN
731KN-()-01	731KN-()-01	INDICATOR, VERTICAL SPEED	KOLLSMAN
7350721-5		MOUNT, PT6 TURBODROP ENGINE	ROBINTECH
7350849-1		MOUNT, PT6 TURBOPROP ENGINE	ROBINTECH
739BK-()-07	739BK-()-07	INDICATOR, SENSITIVE AIRSPEED	KOLLSMAN
740CK-()	740CK-()	INDICATORS, DUAL TACHOMETER	KOLLSMAN
740CK-4-()	740CK-4-()	INDICATOR, DUAL TACHOMETER	KOLLSMAN
74AM, AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
7500655-901	AT-852	ANTENNA, MLS	HONEYWELL
75-0148-1TO 41 ODD		ANNUNCIATOR, EXTERNAL DOOR	GRIMES
75017_	75017_	SWITCH, PRESSURE	HYDRA-ELECTRIC
7502-15-A5-1		TRANSMITTER, PRESSURE	BENDIX
75-0434-()		ANNUNCIATOR, CAUTION AND ADVISORY PANEL	GRIMES
751()	751()	INDICATORS, DUAL TACHOMETER	KOLLSMAN
751()-()	751()-()	INDICATOR, DUAL TACHOMETER	KOLLSMAN
7510100-8XX / 9XX	RNZ-85X	UNIT, INTEGRATED NAVIGATION	HONEYWELL
7510100-901	RNZ-850	UNIT, INTEGRATED NAVIGATION	HONEYWELL
7510100-9X1	RNZ-850	UNIT, INTEGRATED NAVIGATION	HONEYWELL
7510100-9X3	RNZ-850B	UNIT, INTEGRATED NAVIGATION	HONEYWELL
7510134-901	NV-850	MODULE, VHF NAV RECEIVER	HONEYWELL
7510300-901	AT-860	ANTENNA, ADF	HONEYWELL
7510300-901	AT-860	ANTENNA, ADF	HONEYWELL
7510600-801, 901	ML-85X	RECEIVER, MLS	HONEYWELL
7510638-901	AT-851	ANTENNA, MLS	HONEYWELL
7510700-766	RCZ-833E	UNIT, COMMUNICATIONS - INTEGRATED	HONEYWELL
7510700-807	RCZ-851F	UNIT, INTEGRATED COMM	HONEYWELL
7510700-833	RCZ-833	UNIT, COMMUNICATIONS - INTEGRATED__	HONEYWELL
7510700-8XX / 9XX	RCZ-85X	UNIT, INTEGRATED COMMUNICATION	HONEYWELL
7510700-901	RCZ-850	UNIT, INTEGRATED COMMUNICATION	HONEYWELL
7510774-901	XS-850	MODULE, MODE S TRANSPONDER	HONEYWELL
7511000	AV-850	UNIT, AUDIO CONTROL	HONEYWELL
7511001-913	AV-850A	PANEL, AUDIO	HONEYWELL
7511001-941, 951	AV-850A	CONTROL UNIT, AUDIO	HONEYWELL
751100X-9XX	AV-850()	UNIT, AUDIO CONTROL	HONEYWELL
7511200-90X	TX-850	HEAD, AUXILIARY COMM CONTROL	HONEYWELL
7511201-90X	NX-850	HEAD, AUXILIARY NAV CONTROL	HONEYWELL
7511400-901	RU-850	UNIT, RADIO TEST ITNERFACE	HONEYWELL
7513000-805	CD-850	HEAD, CLEARANCE DELIVERY CONTROL	HONEYWELL
7513000-XXX	CD-850	UNIT, CLEARANCE DELIVERY CONTROL / DISPLAY	HONEYWELL
7513006-911	DI-851	INDICATOR, DME	HONEYWELL
7513006-9XX	DI-851	INDICATOR, DME	HONEYWELL
7514081-914	AT-910	ANTENNA, DIRECTIONAL - TCAS	HONEYWELL
7516100-55055	MCS-6000	DATA UNIT, SATELLITE	HONEYWELL
7516240-60050	MCS-6000	UNIT, RADIO FREQUENCY	HONEYWELL
7516250-60050	MCS-6000	AMPLIFIER, HIGH POWER	HONEYWELL
7517900-10001	RT-950	RECEIVER/TRANSMITTER, TCAS	HONEYWELL
751CK-()	751CK-()	INDICATORS, DUAL TACHOMETER	KOLLSMAN
752	752	MAGNETO, A.C TACHOMETER	AMETEK
75-258V()		COMPUTER	THALES

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
757-0701-()	844A-1	ASSEMBLY, VOR / LOC INSTRUMENTATION	COLLINS
758-5703-001	837B-1	ANTENNA, VOR / LOC	COLLINS
758-5703-001	837B-1	ANTENNA, VOR/LOC	COLLINS
758-5843-001	U-1402B	TRANSCEIVER, AM / FM / FSK	COLLINS
758L	758L	INDICATOR, COMPASS	KOLLSMAN
7601-2-A5-1	F-3	PRESSURE, FUEL AND OIL	BENDIX
7609-33-A5-1		TRANSMITTER, PRESSURE	BENDIX
7609-37-()5-2		TRANSMITTER, PRESSURE	BENDIX
761110-()		ASSEMBLY, APLIFIER - AFCS	HAMILTON STANDARD
7612-10-A5-1		TRANSMITTER, GAGE PRESSURE	BENDIX
761272-3		PANEL, CONTROL - AUTO-FLIGHT (AFCS)	HAMILTON STANDARD
761281-1		SWITCH, CONTROL - AFCS CYCLIC	HAMILTON STANDARD
761281-2		SWITCH, CONTROL - AFCS CYCLIC	HAMILTON STANDARD
761282-1		SWITCH, CONTROL - AFCS YAW	HAMILTON STANDARD
762MV-BM-44-791		INDICATOR, MILLIVOLTMETER TEMPERATURE	SMITHS
76-300		INDICATOR, TEMPERATURE - TIT	AVMAR
7643-48-A5-1		TRANSMITTER, PRESSURE	BENDIX
7643-48-A5-1		TRANSMITTER, PRESSURE	BENDIX
76590-()		ACTUATOR, LINEAR - AFCS	HAMILTON STANDARD
768720-3		AMPLIFIER, HEADING HOLD - AFCS	HAMILTON STANDARD
768720-3		AMPLIFIER, HEADING HOLD - AFCS	HAMILTON STANDARD
76AT()	76AT()	INDICATOR, THERMOCOUPLE THERMOMETER	LEWIS
76B	76B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
770170-1		GYRO, RATE - AFCS	HAMILTON STANDARD
7707-111-A25-1	3567707-9801	TRANSMITTER, PRESSURE	BENDIX
7707-2-C5-1	3567707-0202	TRANSMITTER, PRESSURE	BENDIX
7707-2-D5-1	3567707-0203	TRANSMITTER, PRESSURE	BENDIX
7707-30-A23-1	3567707-3004	TRANSMITTER, PRESSURE	BENDIX
7707-30-B8-2	3567707-3005	TRANSMITTER, PRESSURE	BENDIX
7707-30-D5-1	3567707-3001	TRANSMITTER, PRESSURE	BENDIX
7707-30-D5-1		TRANSMITTER, OIL PRESSURE	BENDIX
7707-30-D5-2	3567707-3002	TRANSMITTER, PRESSURE	BENDIX
7707-7-A5-1	3567707-0701	TRANSMITTER, PRESSURE (0-100 PSI)	BENDIX
7707-99-A5-1	3567707-9901	TRANSMITTER, PRESSURE	BENDIX
7709-15-A8-1		TRANSMITTER, PRESSURE - DIFFERENTIAL	BENDIX
7712-()-C5-1		TRANSMITTERS	BENDIX
771K()-()-()	771K()-()-()	INDICATORS, ELECTRIC TACHOMETER	KOLLSMAN
772-()-001	334C-3B/C	SERVO, PRIMARY	COLLINS
772-0738-00X	680T-1	ASSEMBLY, VHF SYNTHESIZER PLANAR	COLLINS
772-0792-001	1051A-1	ASSEMBLY, VHF RECEIVER PLANAR	COLLINS
772-0792-001	1051A-1	ASSEMBLY, VHF RECEIVER PLANAR	COLLINS
772-0821-001	917A-1	ASSEMBLY, TRANSMITTER-MODULATOR PLANAR	COLLINS
7724-30-()-1		TRANSMITTER, PRESSURE - OIL	BENDIX
7724-30-()-1		TRANSMITTER, PRESSURE - OIL	BENDIX
772-5005-001	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-002	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-003	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-004	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-005	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-006	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-007	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5005-011	329B-8J	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-001	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-003	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-005	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-006	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-007	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-009	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-010	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5006-011	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
772-5006-012	329B-9A	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5025-001	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-002	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-004	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-006	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-008	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-009	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-010	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-011	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-012	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5025-014	331A-8A	INDICATOR, HORIZONTAL SITUATION	COLLINS
772-5027-001	351B-3E	MOUNT, SERVO	COLLINS
772-5126-001	614E-10	CONTROL, FLIGHT DIRECTOR	COLLINS
772-5130-()	562A-5M	COMPUTER, FLIGHT	COLLINS
772-5130-001	562A-5M	COMPUTER, FLIGHT	COLLINS
772-5130-002	562A-5M	COMPUTER, FLIGHT	COLLINS
772-5131-()	562C-4A	AMPLIFIER, AUTOPILOT	COLLINS
772-5131-001	562C-4A	AMPLIFIER, AUTOPILOT	COLLINS
772-5132-001	161E-2	COUPLER, MODE	COLLINS
772-5140-00	345A-7	SENSOR, RATE OF TURN	COLLINS
772-5140-001	345A-7	SENSOR, RATE OF TURN	COLLINS
772-5140-00X	345A-7	SENSOR, RATE OF TURN	COLLINS
772-5140-00X	345A-7	SENSOR, RATE OF TURN	COLLINS
772-5232-001	614E-20	SELECTOR, MODE	COLLINS
772-5232-00X	614E-20	SELECTOR, FLIGHT MODE	COLLINS
772-5271-00X	714E-6	CONTROL, RADIO SET	COLLINS
772-5272-001	714E-6	CONTROL, RADIO SET	COLLINS
772-5299-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5370-001	331A-8G	INDICATOR, COURSE	COLLINS
772-5370-002	331A-8G	INDICATOR, COURSE	COLLINS
772-5370-003	331A-8G	INDICATOR, COURSE	COLLINS
772-5370-005	331A-8G	INDICATOR, COURSE	COLLINS
772-5370-00X	331A-8G	INDICATOR, COURSE	COLLINS
772-5378-001	614E-11A	CONTROL, FLIGHT DIRECTOR	COLLINS
772-5378-001	614E-11A	CONTROL, FLIGHT DIRECTOR	COLLINS
772-5403-001	614E-22	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
772-5403-00X	614E-22	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
772-5410-001	614E-23	SELECTOR, COPILOT'S MODE	COLLINS
772-5410-00X	614E-23	SELECTOR, FLIGHT MODE	COLLINS
772-5429-002	562P-1F	COMPUTER, PITCH STEERING	COLLINS
772-5430-002	562R-1F	COMPUTER, ROLL STEERING	COLLINS
772-5431-001	329B-8N	INDICATOR, FLIGHT DIRECTOR	COLLINS
772-5432-002	344C-1P	AMPLIFIER, INSTRUMENT	COLLINS
772K	772K	SYCHROSCOPE, 4-ENGINE	KOLLSMAN
7749-40-A5-1		TRANSMITTER, PRESSURE	BENDIX
777-()-001	334C-3D/E/F	SERVO, PRIMARY	COLLINS
777-()-001	493A-5/5A/5B	INDICATOR	COLLINS
777-0056-00X	917A-2	ASSEMBLY, TRANSMITTER-MODULATOR PLANAR	COLLINS
777-0062-001	1051A-2	ASSEMBLY, VHF RECEIVER PLANAR	COLLINS
777-1026-001	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1026-002	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1026-003	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1026-004	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1026-005	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1026-006	331A-8H	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1029-00X	714E-3D	CONTROL, RADIO SET	COLLINS
777-1034-001	345A-7A	SENSOR, RATE OF TURN	COLLINS
777-1034-001	345A-7A	SENSOR, RATE OF TURN	COLLINS
777-1034-00X	345A-7A	SENSOR, RATE OF TURN	COLLINS
777-1035-001	440Y-16	ADAPTER	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
777-1036-001	440Y-17	ADAPTER	COLLINS
777-1038-001	440Y-19	ADAPTER	COLLINS
777-1039-001	440Y-20	ADAPTER	COLLINS
777-1042-001	440Y-23	ADAPTER	COLLINS
777-1043-001	440Y-24	ADAPTER	COLLINS
777-1044-001	440Y-25	ADAPTER	COLLINS
777-1061-001	334C-6	SERVO, PRIMARY	COLLINS
777-1062-001	351B-6	MOUNT, SERVO	COLLINS
777-1062-003	351B-6	MOUNT, SERVO	COLLINS
777-1083-001	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-002	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-003	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-004	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-006	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-007	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-011	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1083-012	331A-8D	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1128-001	614E-10C	CONTROL, FLIGHT DIRECTOR	COLLINS
777-1129-001	614E-10C	CONTROL, FLIGHT DIRECTOR	COLLINS
777-1224-001	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
777-1224-002	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
777-1224-003	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
777-1225-00X	714E-6A	CONTROL, RADIO SET	COLLINS
777-1244-004	329B-8G	INDICATOR, FLIGHT DIRECTOR	COLLINS
777-1253-001	G-2915	CONTROL, FLIGHT DIRECTOR	COLLINS
777-1256-001	614E-13A	CONTROL, FLIGHT DIRECTOR	COLLINS
777-1258-001	331A-6K1	INDICATOR, COURSE	COLLINS
777-1328-001	180R-17	COUPLER, ANTENNA	COLLINS
777-1329-001	309A-17	COUPLER, CONTROL	COLLINS
777-1335-00	678Z-2	MONITOR, TURNING	COLLINS
777-1356-001	977A-1	PANEL, TEST	COLLINS
777-1358-001	977C-1	PANEL, TEST	COLLINS
777-1359-001	977D-1	PANEL, TEST	COLLINS
777-1397-001	331A-8K	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1397-002	331A-8K	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1397-003	331A-8K	INDICATOR, HORIZONTAL SITUATION	COLLINS
777-1406-()	562C-8A	COMPUTER, YAW DAMPER	COLLINS
777-1406-0XX	562C-8A	COMPUTER, YAW DAMPER	COLLINS
777-1467-001	562C-4C	AMPLIFIER, AUTOPILOT	COLLINS
777-1480-001	51RV-2B	RECEIVER, VOR / ILS	COLLINS
777-1492-00X	51Y-7	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
777-1493-001	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-002	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-003	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-004	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-005	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-006	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-007	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-008	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-009	614L-11	UNIT, ADF CONTROL	COLLINS
777-1493-00X	614L-11	CONTROL, ADF	COLLINS
777-1493-010	614L-11	UNIT, ADF CONTROL	COLLINS
777-1554-001	334C-7	ACTUATOR, LINEAR	COLLINS
777-1555-()	332E-5	INDICATOR, DIRECTIONAL GYROSCOPE	COLLINS
777-1555-001	332E-5	GYROSCOPE, DIRECTIONAL	COLLINS
777-1556-001	328A-5	AMPLIFIER, COMPASS	COLLINS
777-1556-002	328A-5	AMPLIFIER, COMPASS	COLLINS
777-1557-001	351B-7	MOUNT, SERVO	COLLINS
777-1563-00X	614E-20A	SELECTOR, FLIGHT MODE	COLLINS
777-1572-004	374A-4S	RECEIVER-TRANSMITTER	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
777-1694-00X	U-1402B	TRANSCEIVER, AM / FM / FSK	COLLINS
777-1768-003	776C-4S	SYNCHRONIZER	COLLINS
777-1769-001	614E-20C	SELECTOR, MODE	COLLINS
777-1770-003	493A-5S	INDICATOR	COLLINS
777-1770-003	493A-5S	INDICATOR	COLLINS
777-1771-001	537F-7A	ANTENNA	COLLINS
777-1772-001	537F-8A	ANTENNA	COLLINS
777-1795-001	161E-7	COUPLER, MODE	COLLINS
777-1861-001	678P-1B	HARNES, RADIO SET TEST	COLLINS
777-1949-001	562C-4E	AMPLIFIER, AUTOPILOT	COLLINS
777-1979-00X	614E-20D	SELECTOR, FLIGHT MODE	COLLINS
777-1980-00X	614E-20E	SELECTOR, FLIGHT MODE	COLLINS
779-5845-001	A5	MODULE, DECODER	COLLINS
77B	77B	INDICATOR, ELECTRICAL TEMPERATURE	LEWIS
78035-()		INDICATOR, TACHOMETER	AEROSONIC
78035-()		INDICATOR, TACHOMETER	AEROSONIC
78035-0179/180		INDICATOR, TACHOMETER	AEROSONIC
780926-1		AMPLIFIER, AIRSPEED HOLD - AFCS	HAMILTON STANDARD
7813-173-00-13		INDICATOR, TRIPLE TACHOMETER	BRION-LEROUX
7813-175-00-13	NR-N,TL1-N,TL2	INDICATOR, TRIPLE TACHOMETER	BRION-LEROUX
78200000-01, 03	782	INDICATOR, TORQUE - TRIPLE	CLIFTON PRECISION
78300000-03, 04	783	INDICATOR, TRIPLE TORQUE	CLIFTON PRECISION
787-6017-001	137A-5A	ANTENNA, LOOP	COLLINS
787-6028-001	914G-3	INDICATOR, AFCS WARNING	COLLINS
787-6034-001	345A-9	INDICATOR, RATE GYROSCOPE	COLLINS
787-6043-001	916B-1	PANEL, PFCS	COLLINS
787-6044-001	916B-2	PANEL, FCES	COLLINS
787-6073-001	440Y-27	ADAPTER	COLLINS
787-6142-001	440Y-33	ADAPTER	COLLINS
787-6143-001	440Y-34	ADAPTER	COLLINS
787-6171-001	329B-8R	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6171-002	329B-8R	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6171-003	329B-8R	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6173-001	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-001	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-002	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-003	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-004	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-005	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-006	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-007	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-008	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-011	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-012	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-013	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-014	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-015	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-016	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-017	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-018	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-0XX	ADI-84	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6173-201	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-202	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-203	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-204	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-205	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-206	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-207	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-208	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-211	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
787-6173-212	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-213	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-214	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-215	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-216	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-217	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6173-218	ADI-84	INDICATOR, FLIGHT DIRECTOR	COLLINS
787-6189-001	652U-2	BATTERY	COLLINS
787-6211-001	621A-6	TRANSPONDER, ATC	COLLINS
787-6211-002	621A-6	TRANSPONDER, ATC	COLLINS
787-6211-003	621A-6	TRANSPONDER, ATC	COLLINS
787-6226-001	339F-8B	INDICATOR, DME	COLLINS
787-6232-001	U-1201B	TRANSMITTER, AM / FM / FSK	COLLINS
787-6238-001	U-1301B	AMPLIFIER, POWER	COLLINS
787-6259-001	661F-1	RECEIVER-TRANSMITTER	COLLINS
787-6260-001	614J-1	CONTROL	COLLINS
787-6261-00X	UHF-601	SYSTEM, GROUND COMMUNICATIONS	COLLINS
787-6262-001	599W-1	ADAPTER, ATC TRANSPONDER	COLLINS
787-6302-00X	714E-6B	CONTROL, RADIO SET	COLLINS
787-6366-001	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-002	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-003	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-004	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-005	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-006	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-007	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-008	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-009	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-010	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-011	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-012	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-013	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-014	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-015	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-016	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-017	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-018	614L-12	UNIT, ADF CONTROL	COLLINS
787-6366-0XX	614L-12	CONTROL, ADF	COLLINS
787-6370-001	AT-107	SYSTEM, HF PROBE ANTENNA COUPLER	COLLINS
787-6377-00X	714E-2B	CONTROL, RADIO SET	COLLINS
787-6385-001	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-002	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-002	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-002	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-003	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-004	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-005	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-006	331A-6P	INDICATOR, COURSE	COLLINS
787-6385-00X	331A-6P	INDICATOR, COURSE	COLLINS
787-6389-00X	714E-3F	CONTROL, RADIO SET	COLLINS
787-6393-001	916A-5	PANEL, THRUST	COLLINS
787-6394-001	916A-6	PANEL, ALTITUDE SELECT	COLLINS
787-6472-001	837B-1A	ANTENNA, VOR / LOC	COLLINS
787-6557-001	714E-3G	CONTROL, RADIO SET	COLLINS
787-6643-001	137A-6D	ANTENNA, LOOP	COLLINS
787-6766-001	329B-8U	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6810-001	440Y-36	ADAPTER	COLLINS
787-6892-001	329B-8V	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6892-002	329B-8V	INDICATOR, ATTITUDE DIRECTOR	COLLINS
787-6892-003	329B-8V	INDICATOR, ATTITUDE DIRECTOR	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
788K-()-()	788K-()-()	INDICATOR, PRESSURE - MANIFOLD	KOLLSMAN
791-0012-001	A7	MODULE, SYNTHESIZER / DRIVER	COLLINS
791-0047-00X	A8	MODULE, TRANSMITTER MODULATOR	COLLINS
791-0048-001	A6	MODULE, RECEIVER	COLLINS
791-0125-001	A1	MODULE, MONITOR	COLLINS
791-0126-001	A2	MODULE, MONITOR	COLLINS
791-0127-001	A3	MODULE, DISTANCE	COLLINS
791-0128-001	A4	MODULE, DISTANCE	COLLINS
791-0129-00X	A9	MODULE, CONTROL / IDENT	COLLINS
791-1A		D.C. LAMP DIMMER	AVTECH
791-8892-001	A5	MODULE, DECORDER	COLLINS
792-()-001	440U-()	ADAPTER, TEST	COLLINS
792-300		PANEL, MASTER CAUTION	MASTER SPECIALTIES
792-4348-001	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-4348-002	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-4348-003	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-4348-004	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6008-001	514J-2	CONTROL	COLLINS
792-6010-001	137A-6C	ANTENNA, LOOP	COLLINS
792-6018-001	329B-9L	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6021-00X	ILS-70	RECEIVER, INSTRUMENT LANDING	COLLINS
792-6021-00X	ILS-70	RECEIVER, INSTRUMENT LANDING	COLLINS
792-6072-001	U-1201D	TRANSMITTER, AM / FM / FSK	COLLINS
792-6074-001	U-1301D	AMPLIFIER, POWER	COLLINS
792-6075-00X	U-1402D	TRANSCEIVER, AM / FM / FSK	COLLINS
792-6091-001	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-002	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-005	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-006	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-007	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-008	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-009	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-00X	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-00X	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-010	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-011	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-012	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-013	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-014	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-015	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-016	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-017	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-019	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-020	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-021	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-022	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6091-0XX	331A-9G	INDICATOR, COURSE	COLLINS
792-6091-0XX	331A-9G	INDICATOR, COURSE	COLLINS
792-6091-XXX	331A-9G	INDICATOR, HORIZONTAL SITUATION	COLLINS
792-6116-001	719R-1	TRANSMITTER, RECEIVER	COLLINS
792-6116-001	719R-1	RECEIVER-TRANSMITTER	COLLINS
792-6117-001	495R-1	INDICATOR	COLLINS
792-6117-00X	495R-1	INDICATOR	COLLINS
792-6118-001	937R-1	ANTENNA	COLLINS
792-6134-001	323A-2G/3G/4	COMPENSATOR	COLLINS
792-6134-001	323A-3G-1	COMPENSATOR	COLLINS
792-6209-001	477V-3	PANEL, FAULT ISOLATION	COLLINS
792-621-00X	614E-22B	SELECTOR, REMOTE HEADING AND COURSE	COLLINS
792-6216-00X	51Y-7A	RECEIVER, AUTOMATIC DIRECTION FINDER	COLLINS
792-6221-00X	614E-22B	SELECTOR, REMOTE HEADING AND COURSE	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
792-6229-001	678P-2B	HARNESS, RADIO SET TEST	COLLINS
792-6255-001	161E-2A	COUPLER, MODE	COLLINS
792-6255-001	161E-2A	COUPLER, MODE	COLLINS
792-6255-00X	161E-2A	COUPLER, MODE	COLLINS
792-6264-001	661F-2	RECEIVER-TRANSMITTER	COLLINS
792-6265-001	661F-3	RECEIVER-TRANSMITTER	COLLINS
792-6266-001	661F-4	RECEIVER-TRANSMITTER	COLLINS
792-6275-001	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-002	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-003	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-004	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-005	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-006	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-007	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-008	614L-13	UNIT, ADF CONTROL	COLLINS
792-6275-00X	614L-13	CONTROL, ADF	COLLINS
792-6346-001	323A-4	DETECTOR, FLUX	COLLINS
792-6348-001	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-002	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-003	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-004	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-005	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-00X	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-00X	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-101	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-102	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-103	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-104	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6348-105	614E-5A	CONTROLLER, AUTOPILOT	COLLINS
792-6355-001	329B-7R	INDICATOR, FLIGHT DIRECTOR	COLLINS
792-6355-001	329B-7R	INDICATOR, FLIGHT DIRECTOR	COLLINS
792-6355-001	329B-7R()	INDICATOR, FLIGHT DIRECTOR	COLLINS
792-6356-001	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-001	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-002	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-003	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-004	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-00X	331A-6R	INDICATOR, COURSE	COLLINS
792-6356-00X	331A-6R	INDICATOR, COURSE	COLLINS
792-6357-001	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-002	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-003	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-005	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-006	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-007	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-008	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-009	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-00X	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-00X	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-00X	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-00X	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-00X	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-011	329B-8Y	INDICATOR, ATTITUDE DIRECTOR	COLLINS
792-6357-XXX	329B-8Y	INDICATOR, FLIGHT DIRECTOR	COLLINS
792-6384-001	440Y-39	ADAPTER	COLLINS
792-6443-001	937R-2	ANTENNA	COLLINS
792-6444-001	937R-3	ANTENNA	COLLINS
792-6445-001	937R-4	ANTENNA	COLLINS
792-6470-00X	614E-23C	SELECTOR, FLIGHT MODE	COLLINS
792-6472-001	479S-4	GENERATOR, ILS AUDIO SIGNAL	COLLINS
792-6501-001	137A-11	ANTENNA, LOOP	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
792-6550-3XX	916K-2	UNIT, CONTROL DISPLAY	COLLINS
792-6554-XXX	916S-1	UNIT, MODE SELECT	COLLINS
792-6657-00X	VHF-20	TRANSCEIVER, COMMUNICATIONS	COLLINS
792-6669-001	614E-23E	SELECTOR MODE	COLLINS
792-6669-00X	614E-23E	SELECTOR, FLIGHT MODE	COLLINS
792-6669-00X	614E-23E	SELECTOR, MODE	COLLINS
792-6672-001	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6672-002	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6672-004	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6672-005	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6672-008	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6672-00X	590A-3H	CONTROL, AIR DATA	COLLINS
792-6672-019	590A-3H	CONTROLS, AIR DATA	COLLINS
792-6694-000	332D-11A	REFERENCE, VERTICAL	COLLINS
792-6694-001	332D-11A	REFERENCE, VERTICAL	COLLINS
792-6694-002/004	332D-11A	REFERENCE, VERTICAL	COLLINS
792-6694-00X	332D-11A	REFERENCE, VERTICAL	COLLINS
792-6703-001	562A-5M5	COMPUTER, FLIGHT	COLLINS
792-6703-002	562A-5M5	COMPUTER, FLIGHT	COLLINS
792-6703-003	562A-5M5	COMPUTER, FLIGHT	COLLINS
792-6703-00X	562A-5M5	COMPUTER, FLIGHT	COLLINS
792-6780-001	334C-6A	SERVO, PRIMARY	COLLINS
792-6781-001/003	334C-6B	SERVO, PRIMARY	COLLINS
792-6782-001	351B-7A	MOUNT, SERVO	COLLINS
792-6783-001	351B-7B	MOUNT, SERVO	COLLINS
792-6784-001	351B-6A	MOUNT, SERVO	COLLINS
792-6784-003	351B-6A	MOUNT, SERVO	COLLINS
792-6784-004	351B-6A	MOUNT, SERVO	COLLINS
792-6785-001	351B-6B	MOUNT, SERVO	COLLINS
792-6785-002	351B-6B	MOUNT, SERVO	COLLINS
792-6785-003	351B-6B	MOUNT, SERVO	COLLINS
792-6792-001	334C-6C	SERVO, PRIMARY	COLLINS
792-6827-001	8564B-2	UNIT, NAVIGATION COMPUTER	COLLINS
792-6864-3XX	345E-1A	UNIT, INERTIAL NAVIGATION	COLLINS
792-6889-001	440Y-43	SIMULATOR, ADAPTER/SYNCHRO	COLLINS
792-6931-001	137A-4A	ANTENNA, LOOP	COLLINS
792-6972-001	334C-6C	SERVO, PRIMARY	COLLINS
792-6972-001/003	334C-6C	SERVO, PRIMARY	COLLINS
792-6973-001	351B-6C	MOUNT, SERVO	COLLINS
792-6973-002	351B-6C	MOUNT, SERVO	COLLINS
792-6973-003	351B-6C	MOUNT, SERVO	COLLINS
792-6974-001	351B-7C	MOUNT, SERVO	COLLINS
792-6975-001	351B-8C	MOUNT, SERVO	COLLINS
793-20		CONTROL, AUDIO	AVTECH
797-1000-001	680T-2	SYNTHESIZER, VHF DIGITAL - PLANAR ASSEMBLY	COLLINS
797-1000-002	680T-2	SYNTHESIZER, VHF DIGITAL - PLANAR ASSEMBLY	COLLINS
797-1000-003	680T-2	SYNTHESIZER, VHF DIGITAL - PLANAR ASSEMBLY	COLLINS
797-1000-004	680T-2	SYNTHESIZER, VHF DIGITAL - PLANAR ASSEMBLY	COLLINS
797-1000-005	680T-2	SYNTHESIZER, VHF DIGITAL - PLANAR ASSEMBLY	COLLINS
797-3814-001	A2	MODULE, DISTANCE	COLLINS
797-3817-001	A3	MODULE, DISTANCE	COLLINS
797-7240-001	323A-4	COMPENSATOR	COLLINS
797-8007-00X	345D-1	TRANSDUCER, SINGLE POSITION	COLLINS
797-8008-00X	345D-1A	TRANSDUCER, DUAL POSITION	COLLINS
797-8009-00X	960G-1	SHAKER, STICK	COLLINS
7G198	7G198	SWITCH, PRESSURE - GAGE	CUSTOM COMPONENT
7G54	7G54	SWITCH, PRESSURE	CUSTOM COMPONENT
7G547	7G547	SWITCH, PRESSURE	CUSTOM COMPONENT
7G63	7G63	SWITCH, PRESSURE	CUSTOM COMPONENT
7G761_	7G761_	SWITCH, PRESSURE	CUSTOM COMPONENT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
7G82	7G82	SWITCH, PRESSURE	CUSTOM COMPONENT
7G84	7G84	SWITCH, PRESSURE	CUSTOM COMPONENT
8.039.XXX-()-()		INDICATOR, AIRSPEED	AERITALIA
8.040.XXX-()		INDICATOR, THREE POINTER ALTIMETER	AERITALIA
8.048.00X.()		INDICATOR, HORIZON GYRO	AERITALIA
8.110AD	G-32	GENERATOR, TACHOMETER	JAEGER
8.218		RESISTOR, CALIBRATING	JAEGER
8.220.05X		INDICATOR, DIRECTIONAL GYRO	AERITALIA
8.383AV		INDICATOR, TEMPERATURE	JAEGER
8.385AI	350	INDICATOR, COMBINE TRIPLE	JAEGER
8.461BB	220	GENERATOR, TACHOMETER	JAEGER
8.470BC/BF		GENERATORS, TACHOMETER	JAEGER
8.548DB		INDICATOR, TRIPLE TEMP / PRESSURE	JAEGER
8000	8000	SYSTEM, COMPASS - SLAVED	AERONETICS
80-0070-1		PANEL, FAULT FUNCTION	GRIMES
80-0093		ASSEMBLY, LIGHT PANEL - MASTER CAUTION	GRIMES
80-0099-()		PANEL ASSEMBLY, MASTER CAUTION	GRIMES
8000T	8000 SERIES	INDICATOR, AIRSPEED	UNITED INSTRUMENTS
80-0203-3		PANEL ASSEMBLY, MASTER CAUTION	GRIMES
80-0203-5		PANEL ASSEMBLY, MASTER CAUTION	GRIMES
80-0203-9		PANEL ASSEMBLY, MASTER CAUTION	GRIMES
80-0324-17	E63/E166	PANEL, ANNUNCIATOR	GRIMES
80-0324-17	SA227 SERIES	ANNUNCIATOR PANEL	FAIRCHILD
80-0331		PANEL ASSEMBLY, MASTER CAUTION	GRIMES
80-0500-1		PANEL, ANNUNCIATOR	GRIMES
80-0535-()		ASSEMBLY, ANNUNCIATOR PANEL - CAUTION-	GRIMES
80-0535-1		ANNUNCIATOR, PANEL - CAUTION/ADVISORY	GRIMES
800-G6685	800-G6685	PANEL, NAV / COMM CONTROL	GABLES
801 CUF/()		CONTROLLER, AUTOPILOT AND ENGAGE PANEL	SMITHS
802100-5		INDICATOR, COURSE DEVIATION	EXECUTIVE INSTRUMENTS
8025T	8000 SERIES	INDICATOR, AIRSPEED	UNITED INSTRUMENTS
803	M803	CLOCK, DIGITAL	DAVTRON
8030T	8000 SERIES	INDICATOR, AIRSPEED	UNITED INSTRUMENTS
803-2		INDICATOR, GYROSCOPE HORIZON	THALES
804	804	UNIT, ENGINE GAUGE	SIGMA-TEK
8047/SERIES	8047/()	INDICATOR, 2" COUNTER-POINTER ALTIMETER	HORIZON
8059-2B	8059-2B	INDICATOR, AIRSPEED	HORIZON
8095296-()	CP-123()	PANELS, RADAR CONTROL	TELEPHONICS
8107-101-00-12		SENSOR, 10 BAR PRESSURE	BRION-LEROUX
81-1797		PANEL SUBASSY, CAUTION	GRIMES
811B	811B	INDICATOR, CLOCK - AIRCRAFT	DAVTRON
81-208-1		INDICATOR, FUEL QUANTITY	MEGGITT AVIONICS
8140	8140-()	INDICATOR, 3" TRI-POINTER	HORIZON
8142-()	8142-()	INDICATOR, 3" DRUM POINTER	HORIZON
814B	814B	INDICATOR, COMPASS - STANDBY	KOLLSMAN
8161-600	8161-600	INDICATOR, DUAL ALTIMETER AND AIRSPEED	HORIZON
82100000-()	821	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
821101-()	TEL82	LOCATOR, EMERGENCY	TECHNISONIC IND. LTD
821101-1	TEL82	LOCATOR, EMERGENCY	TECHNISONIC IND. LTD
821101-2	TEL82	LOCATOR, EMERGENCY	TECHNISONIC IND. LTD
821101-3	TEL82	LOCATOR, EMERGENCY	TECHNISONIC IND. LTD
8220	8200 SERIES	INDICATOR, AIRSPEED - MAXIMUM ALLOWABLE	UNITED INSTRUMENTS
822-0014-002	DBU-4100	UNIT, DATA BASE	COLLINS
822-0039-40X	UMT-169D	MOUNT, UNIVERSAL	COLLINS
822-0049-002	CSU-4000	UNIT, CONFIGURATION STRAPPING	COLLINS
822-0074-XXX	RTU-4020	UNIT, RADIO TUNING	COLLINS
822-0090-002	HF-9034	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-0095-00X	HF-9079	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-0101-00X	HF-9031A	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-0102-001	HF-9034A	RECEIVER-TRANSMITTER, RADIO	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
822-0108-001	HF-9080	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-0109-001	HF-9081	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-011X-001	HF-9084	RECEIVER-TRANSMITTER, RADIO	COLLINS
822-0175-XXX	FCC-86G	COMPUTER, FLIGHT CONTROL	COLLINS
822-0201-001	ICC-4005	CAGE, CARD	COLLINS
822-0273-002	RSP-4000	PANEL, REVERSIONARY SWITCH	COLLINS
822-0287-501	LHP-4000	PROTECTOR, HIRF LIGHTNING	COLLINS
822-031X-101	SDU-906-X	UNIT, SATELLITE DATA	COLLINS
822-0321-002	DCP-4002	PANEL, DISPLAY CONTROL	COLLINS
822-0321-006	DCP-4002	PANEL, DISPLAY CONTROL	COLLINS
822-0326-002	ARP-4002	PANEL, AIR DATA REFERENCE	COLLINS
822-0328-011	AAP-851	PANEL, ALTITUDE AWARENESS	COLLINS
822-0328-011	AAP-851	PANEL, ALTITUDE AWARENESS	COLLINS
822-0332-501	LHP-4001	PROTECTOR, HIRF LIGHTNING	COLLINS
822-0370-XXX	ADC-85A	COMPUTER, AIR DATA	COLLINS
822-0374-121	ADC-850C	COMPUTER, AIR DATA	COLLINS
822-0374-410	ADC-850C	COMPUTER, AIR DATA	COLLINS
822-0385-002	FCP-4004	PANEL, FLIGHT CONTROL	COLLINS
822-0389-110	ADC-85OD	COMPUTER, AIR DATA	COLLINS
822-0389-112	ADC-85OD	COMPUTER, AIR DATA	COLLINS
822-0389-118	ADC-85OD	COMPUTER, AIR DATA	COLLINS
822-0389-129	ADC-85OD	COMPUTER, AIR DATA	COLLINS
822-0389-130	ADC-85OD	COMPUTER, AIR DATA	COLLINS
822-0393-001	VIR-433	RECEIVER, NAVIGATION	COLLINS
822-0400-001	VIR-33	RECEIVER, NAVIGATION	COLLINS
822-0416-001	IND-270A	INDICATOR	COLLINS
822-0416-00X	IND-270A	INDICATOR, WEATHER RADAR	COLLINS
822-0730-204	RTU-4220	UNIT, RADIO TUNING	COLLINS
822-0760-()	51RV-5	RECEIVER, VOR / ILS NAVIGATION	COLLINS
822-0760-XXX	51RV-5	VOR/ILS NAVIGATION RECEIVER	COLLINS
822-0761-()	51RV-5B	RECEIVER, VOR / ILS NAVIGATION	COLLINS
822-0761-XXX	51RV-5B	VOR/ILS NAVIGATION RECEIVER	COLLINS
822-0762-()	51RV-5D	RECEIVER, VOR / ILS NAVIGATION	COLLINS
822-0762-XXX	51RV-5D	VOR/ILS NAVIGATION RECEIVER	COLLINS
822-076X-()	51RV-5/5()	RECEIVER, VOR/ILS NAVIGATION	COLLINS
822-0807-003	FCC-4005	COMPUTER, FLIGHT CONTROL	COLLINS
822-0807-203	FCC-4005	COMPUTER, FLIGHT CONTROL	COLLINS
822-0825-001	DAU-4002	UNIT, DATA, ACQUISITION	COLLINS
822-0854-001	CTC-429	TEST CARD, CSDB / ARINC INTERFACE	COLLINS
822-0891-001	FMC-5000	COMPUTER, FLIGHT MANAGEMENT	COLLINS
822-0892-011	CDU-5000	UNIT, CONTROL DISPLAY	COLLINS
822-0931-002	GPS-4000	SYSTEM, GLOBAL POSITIONING	COLLINS
822-0953-001	HPA-901A	AMPLIFIER, HIGH-POWER	COLLINS
822-0967-201	DSP-85M	PANEL, DISPLAY SELECT	COLLINS
822-1000-021	EFD-85M	DISPLAY, ELECTRONIC FLIGHT	COLLINS
822-1001-001	MFD-85M	DISPLAY, MULTIFUNCTION	COLLINS
822-1011-XXX	FCC-86H	COMPUTER, FLIGHT CONTROL	COLLINS
822-1019-013	FCC-4007	COMPUTER, FLIGHT CONTROL	COLLINS
822-1028-011	DCP-5000	PANEL, DISPLAY CONTROL	COLLINS
822-1050-001	RTA-800	RECEIVER/TRANSMITTER/ANTENNA	COLLINS
822-1050-004	RTA-800	RECEIVER/TRANSMITTER/ANTENNA	COLLINS
822-1058-002	CCP-4000	PANEL, CHECKLIST CONTROL	COLLINS
822-1084-102	AFD-3010	DISPLAY, ADAPTIVE FLIGHT	COLLINS
822-1084-104	AFD-3010	DISPLAY, ADAPTIVE FLIGHT	COLLINS
822-1084-108	AFD-3010	DISPLAY, ADAPTIVE FLIGHT	COLLINS
822-1084-110	AFD-3010	DISPLAY, ADAPTIVE FLIGHT	COLLINS
822-1108-018	FGC-3000	COMPUTER, FLIGHT GUIDANCE	COLLINS
822-1108-118	FGC-3000	COMPUTER, FLIGHT GUIDANCE	COLLINS
822-1109-()	ADC-3000	COMPUTER, AIR DATA	COLLINS
822-1109-002	ADC-3000	COMPUTER, AIR DATA	COLLINS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
822-1110-001	AHC-3000	COMPUTER, ATTITUDE HEADING	COLLINS
822-1110-002	AHC-3000	COMPUTER, ATTITUDE HEADING	COLLINS
822-1110-00X	AHC-3000	COMPUTER, ATTITUDE HEADING	COLLINS
822-1115-001	VHF-422C	TRANSCEIVER, COMMUNICATIONS	COLLINS
822-1115-021	VHF-422C	TRANSCEIVER, COMMUNICATIONS	COLLINS
822-1116-001	VHF-422D	TRANSCEIVER, COMMUNICATIONS	COLLINS
822-1116-021	VHF-422D	TRANSCEIVER, COMMUNICATIONS	COLLINS
822-1134-002	DCP-3000	DISPLAY, CONTRAL PANEL	COLLINS
822-1134-102	DCP-3000	DISPLAY, CONTRAL PANEL	COLLINS
822-1193-001	FDU-3000	DETECTOR UNIT, FLUX	COLLINS
822-1193-001	FDU-3000	UNIT, FLUX DETECTOR	COLLINS
822-1200-()	ECU-3000	UNIT, EXTERNAL COMPENSATION	COLLINS
822-1200-001	ECU-3000	COMPENSATION UNIT, EXTERNAL	COLLINS
822-1200-003	ECU-3000	COMPENSATION UNIT, EXTERNAL	COLLINS
822-1279-002	CHP-3000	PANEL, COURSE HEADING	COLLINS
822-1281-002	CKP-3000	PANEL, COURSE KNOB	COLLINS
822-1378-001	AHC-3000A	COMPUTER, ATTITUDE HEADING	COLLINS
822-1399-00X	DSP-2000	PANEL, DISPLAY SELECT	COLLINS
822-1399-10X	DSP-2000	PANEL, DISPLY SELECT	COLLINS
822-1444-01X	AFD-2000	DISPLAY, ADAPTIVE FLIGHT	COLLINS
822-2083-001, 002	ADS-3010	COMPUTER, AIR DATA	COLLINS
8230	8200 SERIES	INDICATOR, AIRSPEED - MAXIMUM ALLOWABLE	UNITED INSTRUMENTS
82300000-()	823	INDICATOR, TACHOMETER - TRIPLE	CLIFTON PRECISION
8235	8200 SERIES	INDICATOR, AIRSPEED - MAXIMUM ALLOWABLE	UNITED INSTRUMENTS
8240	8200 SERIES	INDICATOR, AIRSPEED - MAXIMUM ALLOWABLE	UNITED INSTRUMENTS
827	827	INDICATOR,	AMETEK
827/840/841	827/840/841	INDICATOR, THERMOCOUPLE THERMOMETER	AMETEK
828	828	INDICATOR, RATIO TYPE DUAL RESISTANCE	AMETEK
83-()-1		INDICATOR, OIL PRESSURE/TEMP.	MEGGITT AVIONICS
83-104-1		INDICATOR, FUEL QUANTITY	MEGGITT AVIONICS
83-18()-1		INDICATOR, OIL/PRESSURE TEMP	MEGGITT AVIONICS
833	833	INDICATOR, VOLT / AMMETER	AMETEK
8350/8360/8370		BALANCER, PHAZOR	CHADWICK-HELMUTH
840	840	INDICATOR,	AMETEK
841	841	INDICATOR,	AMETEK
843-13-1		INDICATOR, COLLECTIVE PITCH	BRION-LEROUX
8436AT		INDICATOR, DUAL TACHOMETER	JAEGER
843766		PANEL, MASTER CAUTION/WARNING	TELEDYNE
843772		PANEL, CAUTION/ADVISORY	TELEDYNE
84500-021-1,-2		INDICATOR, TACHOMETER	JAEGER
847-0006-010	GPS-ANT	ANTENNA, GPS	COLLINS
850	M850	INDICATOR, CLOCK - CHRONOMETER	DAVTRON
8500	8500	SYSTEM, BALANCER/ANALYZER	CHADWICH-HELMUTH
852B3M4		INDICATOR, THERMOCOUPLE TEMPERATURE	LEWIS
85429200400		ASSEMBLY, VIBRATOR POWER SUPPLY	KOLLSMAN
86000-1107		INDICATOR, AIRCRAFT CLOCK	AEROSONIC
861CAL	861CAL	TRANSMITTER, ANGLE OF ATTACK	ROSEMOUNT
8620	135M-12	STROBEX	CHADWICH-HELMUTH
86400-1163		INDICATOR, AIRCRAFT CLOCK	AEROSONIC
865()-()-()	865()-()-()	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
865D- ()-01	865D- ()-01	INDICATOR, MACH AIRSPEED	KOLLSMAN
865F-()-()	865F-()-()	INDICATOR, MACH AIRSPEED	KOLLSMAN
870729		UNIT, CONTROL - SINGLE CIRCUIT	KIDDE
870730		UNIT, CONTROL - SINGLE CIRCUIT	KIDDE
8812344000		TEST STAND, TORQUE	TURBOMECA
885590-00-001	A55901-10-010	INDICATOR, ELECTRIC TACHOMETER	KOLLSMAN
888	888	INDICATOR, BLIND APPROACH	AMETEK
888TT	888TT	MICROPHONE, DTMF AIRCRADT	SHURE
88AM, AM/PC		INDICATOR, SENSITIVE ALTIMETER	SMITHS
88-I-()	88-I-()	INDICATOR, AIRSPEED	KOLLSMAN

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
892121		UNITE, CONTROL - DETECTING SYSTEM	KIDDE
89AM/M, AM/PC/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
8AW43AAA2()	AW-43	VOLTMETER, AMMETERS AND	AMETEK
8AW43V()	AW-43	VOLTMETER, AMMETERS AND	AMETEK
8AW59HAA	A-1	INDICATOR, WATT-VARMETER	AMETEK
8C, 10C, 18C	8C, 10C, 18C	SWITCH, PENDULUM INERTIA	GRAVINER
8DJ()		DC SELSYN - XMTRS & INDICATORS	AMETEK
8DJ100WAA()	EHU-15/A	INDICATOR, TEMPERATURE - SERVOED	AMETEK
8DJ11PEZ	TJ-11	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ11PKA	TJ-11	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ120AAE1	DJ-120	INDICATOR, TACHOMETER	AMETEK
8DJ121()	DJ-121	INDICATOR, FLOWMETER	AMETEK
8DJ125()	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125GAD2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125GAD4		INDICATOR, FLOWMETER	AMETEK
8DJ125LAA3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LAA4		INDICATOR, FLOWMETER	AMETEK
8DJ125LAB3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LAB4		INDICATOR, FLOWMETER	AMETEK
8DJ125LAE4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWA1	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWB2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWB4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWC2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWC4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWE2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWE4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWF2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWF4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWG1, -2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWG4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWH2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWK2, -3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWK4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWR3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWR4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWS3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWS4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWT3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWT4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWV3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWV4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWX3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWX4		INDICATOR, FLOWMETER	AMETEK
8DJ125LWY3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LWY4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXB3	DJ-125	INDICATOR, FLOWMETER	AMETEK
8DJ125LXB4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXC4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXD4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXE4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXF4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXG4		INDICATOR, FLOWMETER	AMETEK
8DJ125LXK4		INDICATOR, FLOWMETER	AMETEK
8DJ125MWA4		INDICATOR, FLOWMETER	AMETEK
8DJ125MWB4		INDICATOR, FLOWMETER	AMETEK
8DJ125MWC4		INDICATOR, FLOWMETER	AMETEK
8DJ125MWD4		INDICATOR, FLOWMETER	AMETEK
8DJ126()	DJ-126	INDICATOR, FLOWMETER	AMETEK
8DJ13()		INDICATOR, TACHOMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ131AAB1	DJ-131	INDICATOR, TRIPLE TACHOMETER	AMETEK
8DJ131AAB1	DJ-131	INDICATOR, TRIPLE TACHOMETER	AMETEK
8DJ131AAE1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131AAJ1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131AAT2	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LAB-1	6680-724-7616	INDICATOR, TRIPLE TACH	AMETEK
8DJ131LAB-1	6680-724-7616	INDICATOR, TRIPLE TACH	AMETEK
8DJ131LAE1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LAN1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LAV1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LAW1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LAZ1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ131LBA1	DJ-131	INDICATOR, TACHOMETER	AMETEK
8DJ13ABN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13ABN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13ABN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13ABN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13AFN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13AFN	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13AKD	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ13AKD	DJ-13	TACHOMETERS, ELECTRIC	AMETEK
8DJ142()	DJ-142	INDICATOR, FLOWMETER	AMETEK
8DJ148CAB1	DJ-148	INDICATOR, TACHOMETER	AMETEK
8DJ150()	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAC1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAD1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAE1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAF1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAH1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ150FAK1	DJ-150	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ162LYB2	DJ-162	INDICATOR, PROP SPEED	AMETEK
8DJ162LZC2	DJ-162	INDICATOR, PROP SPEED	AMETEK
8DJ162LZZ2	DJ-162	INDICATOR, PROP SPEED	AMETEK
8DJ163LXK4	DJ-163	INDICATOR, TEMPERATURE	AMETEK
8DJ163LXM4	DJ-163	INDICATOR, TEMPERATURE	AMETEK
8DJ163LXY4	DJ-163	INDICATOR, TEMPERATURE	AMETEK
8DJ163LYM4	DJ-163	INDICATOR, TEMPERATURE	AMETEK
8DJ175LWX1		INDICATOR, TEMPERATURE - TURBINE	AMETEK
8DJ181()	DJ-181	INDICATOR, ENGINE TORQUE	AMETEK
8DJ19()		INDICATOR, TACHOMETER	AMETEK
8DJ19AAR	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19AAS	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19AAW	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19AAX	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19ABE	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19ABF	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19ABF	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19ACA	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19ACB	DJ-19	TACHOMETERS, ELECTRIC	AMETEK
8DJ19GAF6	DJ-19	INDICATOR, DUAL TACHOMETER	AMETEK
8DJ20AGD()	DJ-20	INDICATOR, DC SELSYN LIQUID LEVEL	AMETEK
8DJ20AGE()	DJ-20	INDICATOR, DC SELSYN LIQUID LEVEL	AMETEK
8DJ20AGE50	DJ-20	INDICATOR, DC SELSYN LIQUID LEVEL	AMETEK
8DJ21	DJ-21	INDICATOR, FUEL CONTENTS	AMETEK
8DJ22AAA/AAB	AN5525-()	BULB, TEMPERATURE - SENSOR	AMETEK
8DJ23AAA	AN5790-6	INDICATOR, THERMOMETER	AMETEK
8DJ24AAA/AAB	AN5795-6	INDICATOR, THERMOMETER	AMETEK
8DJ26AAA()	AN5780-()	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ26AAH51	AN5780-T3	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ26AAK51W	AN5780-3	INDICATOR, DC SELSYN POSITION	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ278 WAC 1	8DJ278	INDICATOR, FAN SPEED N1 TACHOMETER	AMETEK
8DJ278WAC1	DJ-278	INDICATOR, ENGINE FAN SPEED	AMETEK
8DJ30()	AN5730-()	INDICATOR, COMPASS	AMETEK
8DJ313WAA1		INDICATOR, TEMPERATURE - ITT	AMETEK
8DJ43AAD	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAE	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAF14	DJ-43	INDICATOR, TACHOMETER	AMETEK
8DJ43AAH	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAK1	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAK3	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAK5	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43AAL14	DJ-43	INDICATOR, TACHOMETER	AMETEK
8DJ43AAM	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43BAD	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43BAE	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ43BAH	DJ-43	TACHOMETERS, ELECTRIC	AMETEK
8DJ48AAD	TJ-48	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ48CAB1	TJ-48	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ48CAD	TJ-48	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ48FAH	TJ-48	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ49()	DJ-49	INDICATOR, DC SELSYN POSITION	AMETEK
8DJ51GA()	C-1	INDICATOR, LANDING GEAR POSITION	AMETEK
8DJ54GAF()	DJ-54	INDICATOR, FUEL QUANTITY - TRIPLE	AMETEK
8DJ54GAH()	DJ-54	INDICATOR, FUEL QUANTITY - TRIPLE	AMETEK
8DJ64GAF1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GAS1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GAT1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GAX1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GBA1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GBC1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GBH1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ64GBW1	DJ-64	INDICATOR, FLOWMETER	AMETEK
8DJ67AAC1	DJ-67	INDICATOR, TACHOMETER	AMETEK
8DJ67FAB1	DJ-67	INDICATOR, TACHOMETER	AMETEK
8DJ67FAT1	DJ-67	INDICATOR, TACHOMETER	AMETEK
8DJ77()	DJ-77	INDICATOR, FUEL-MASS FLOWMETER	AMETEK
8DJ81()	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81AAA1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81AAB1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81AAC1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81BAA1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81BLB4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81BLC4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAA1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAA4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAC1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAE1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAF1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAH1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAK1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAL1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAM1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAN4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAS2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAX2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CAZ2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CBA2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CBB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CBD4	DJ-81	INDICATOR, TACHOMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ81CBK2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CBX2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CCK2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CCL2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CCM2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDE2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDH2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDR4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDS4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDW4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDX4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDY2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDY4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CDZ4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CER4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81CFA4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81FAA1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAA1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAA4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAC1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAD1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAE1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAK1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAN2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAT1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAV1	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAW1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAX2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAY2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LAZ2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBD2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBE2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBF2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBH2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBK2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBL2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBS2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBT2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LBX2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCD2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCF2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCK2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCP4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCR4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LCT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LSC4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LSC4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVA4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVB4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVB4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVF4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVG4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVL4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LVL4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWA1,2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWA4	DJ-81	INDICATOR, TACHOMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ81LWB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWC4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWH2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWM2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWN2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWR2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWR4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWS2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWS4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWT2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWT4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWV2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWY2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWY4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWZ2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LWZ4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXD2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXE2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXF2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXF4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXF4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXG2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXG4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXG4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXH2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXH4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXH4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXK2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXK4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXL2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXM2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXN2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXP2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXT2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXV2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXW2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXY2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LXZ2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYA2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYP2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYP4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYT2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYT4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYV2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYV4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYV4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYW2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYX2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYX4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LYZ2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZB2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZC2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZC4	DJ-81	INDICATOR, TACHOMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ81LZE2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZE4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZF2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81LZF4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAG2	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAG4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAG4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAL4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAP4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WAY4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBA4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBB4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBC4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBD4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBF4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBF4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBG4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBG4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBL4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBM4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBS4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WBT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCF4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCF4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCG4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCG4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCR4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCS4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCT4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCT4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCW4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCW4U	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WCX4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WDK4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ81WDL4	DJ-81	INDICATOR, TACHOMETER	AMETEK
8DJ82()	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82()		INDICATOR, TACHOMETER	AMETEK
8DJ82CAA1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82CAF1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82CAX1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82CBH1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82CBK1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82FAA1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ82FAH1	DJ-82	INDICATOR, TACHOMETER	AMETEK
8DJ88GAC1	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88GAJ3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LAB1,2,3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWB1	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWC2,3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWD2,3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWE3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWF2,3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWG3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWH3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWK3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWM3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWN3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWS3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWX3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LWY3	DJ-88	INDICATOR, FLOWMETER	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
8DJ88LXA3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LXC3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DJ88LYF3	DJ-88	INDICATOR, FLOWMETER	AMETEK
8DW53ABH203		INDICATOR, AMMETER	AMETEK
8DW53B()2()	DW53	INDICATOR, VOLT / AMMETER	AMETEK
8DW53VBA10		INDICATOR, VOLTMETER	AMETEK
8G361-()		SWITCH, PRESSURE	CUSTOM COMPONENT
8G597-()	8G597-()	SWITCH, PRESSURE	CUSTOM COMPONENT
8G648	8G648	SWITCH, PRESSURE	CUSTOM COMPONENT
8K291AAB()	KE-91	UNIT, ENGINE TORQUE ELECTRONIC	AMETEK
8KD1A()	G-2	INDICATOR, DIRECTION - MASTER	AMETEK
8KJ1AA	AN5730-3	TRANSMITTER, COMPASS	AMETEK
8TJ()		TRANSMITTER & INDICATOR, DC SELSYN	AMETEK
8TJ17()		TRANSMITTER, DC SELSYN LIQUID LEVEL	AMETEK
8TJ50()	TJ-50	TRANSMITTER, FLOWMETER	AMETEK
8TJ64GAL1		TRANSMITTER, FLOW - FUEL	AMETEK
8TJ80GAA1	8TJ80	SUPPLY, FUEL FLOW POWER	AMETEK
8TJ80GAA1	TJ-80	SUPPLY, FUEL FLOW POWER	AMETEK
8TJ80GAA1	TJ-80	SUPPLY, FUEL FLOW POWER	AMETEK
8TJ80GAA2	8TJ80	SUPPLY, FUEL FLOW POWER	AMETEK
8TJ85()	TJ-85	TRANSMITTER, FLOW - FUEL	AMETEK
8TJ88GAC1	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAD1	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAD3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAE1	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAF1	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAH1	TJ-88	SUPPLY, POWER - FLOWMETER	AMETEK
8TJ88GAH3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAH3	TJ-88	SUPPLY, POWER - FLOWMETER	AMETEK
8TJ88GAN1	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAN3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAP1	TJ-88	SUPPLY, POWER	AMETEK
8TJ88GAP3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAR1	TJ-88	SUPPLY, POWER	AMETEK
8TJ88GAR3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GAT1	TJ-88	SUPPLY, POWER	AMETEK
8TJ88GAV1	TJ-88	SUPPLY, POWER	AMETEK
8TJ88GAV3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ88GBN3	TJ-88	SUPPLY, POWER - FUEL FLOW	AMETEK
8TJ9PEL	TJ-9	TRANSMITTER, DC SELSYN POSITION	AMETEK
8TJ9PFF	TJ-9	TRANSMITTER, DC SELSYN POSITION	AMETEK
900-23V()	900-23V()	INDICATOR, FLIGHT DIRECTOR	JET/AIM
9013		BAROGRAPH	E.W. AVIONICS
9013B0060		BAROGRAPH	E.W. AVIONICS
9016-3902		SERVO, ACCELERATION - LINEAR	GULTON
9026		INDICATOR, BY PASS SPOOL	SPECTRUM PRESSURESTAT
90-384026-1		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-11		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-13		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-15		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-17		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-19		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-21		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-23		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-25		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-27		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-29		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-3		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-31		INDICATOR, TEMPERATURE	BEECHCRAFT
90-384026-5		INDICATOR, TEMPERATURE	BEECHCRAFT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
90-384026-7		INDICATOR, TEMPERATURE	BEECHCRAFT
906(-)(-)(-)	906(-)(-)(-)	GAGES, DUAL ALTIMETER AND DIFFERENTIAL	KOLLSMAN
906(-)(-)(-)	906(-)(-)(-)	GAGES, DUAL ALTIMETER AND DIFFERENTIAL	KOLLSMAN
9061		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
90AM/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
90AM/M, PC/M		INDICATOR, SENSITIVE ALTIMETER	SMITHS
90AM/PC/M/OH		INDICATOR, SENSITIVE ALTIMETER	SMITHS
9100 (SERIES)	9100 (SERIES)	SYSTEM, COMPASS - SLAVED	AERONETICS
9100(-)(-)		TRANSMITTER, FLOW - FUEL	BENDIX
9133(-)(-)		TRANSMITTER, FUEL FLOW	BENDIX
9133(-)(-)		TRANSMITTER, FUEL FLOW	BENDIX
9136(-)(-)		TRANSMITTER, FUEL FLOW	BENDIX
9136(-)(-)		TRANSMITTER, FUEL FLOW	BENDIX
914F5B5-1		REGULATOR, VOLTAGE	WESTINGHOUSE
9200		TRANSMITTER, MAGNESYN (ROTARY)	BENDIX
925G-0120304	925G-0120304	GENERATOR, ELECTRIC TACHOMETER	KOLLSMAN
92G47	92G47	SWITCH, PRESSURE	CUSTOM COMPONENT
9300A165(-)	A55B	MODULES, SSCBR MICROPHONE	L3 COMMUNICATIONS
9300A860(-)	A860	PANEL, CVR TEST	L3 COMMUNICATIONS
9-30C1011		INDICATOR, ANGLE OF ATTACK	ROSEMOUNT
93A055(-)	A55	MODULES, SSCVR MICROPHONE	L3 COMMUNICATIONS
93A055(-)	A55/A55B	MODULES, CVR MIC	L3 COMMUNICATIONS
93A100(-)	A100/A100A	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
93A151(-)	A151()	UNITS, CONTROL	LORAL
93A15X(-)	A15XX	UNITS, CVR CONTROL	L3 COMMUNICATIONS
93A15X(-)	A15XX	UNITS, SSCVR CONTROL	L3 COMMUNICATIONS
9449-5	8500() / 8510	BALANCER/ANALYZER, PRINTER/DISK DRIVE	CHADWICH-HELMUTH
9500/9550	9500/9550 SERIES	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS
9500A-N.518	9500A-N.518	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9500A-N.519	9500A-N.519	INDICATOR, TURN & SLIP - 14V LTS (PGTLS)	UNITED INSTRUMENTS
9500B-N.531	9500B-N.531	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS
9500B-N.534	9500B-N.534	INDICATOR, TURN & SLIP - 14V LTS (CONN)	UNITED INSTRUMENTS
9500-N.516	9500-N.516	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9501A-N.523	9501A-N.523	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9501A-N.524	9501A-N.524	INDICATOR, TURN & SLIP - 14V LTS (PGTLS)	UNITED INSTRUMENTS
9501B-N.532	9501B-N.532	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS
9501B-N.535	9501B-N.535	INDICATOR, TURN & SLIP - 14V LTS (CONN)	UNITED INSTRUMENTS
9501-N.521	9501-N.521	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9502A-N.528	9502A-N.528	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9502A-N.529	9502A-N.529	INDICATOR, TURN & SLIP - 14V LTS (PGTLS)	UNITED INSTRUMENTS
9502B-N.533	9502B-N.533	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS
9502B-N.536	9502B-N.536	INDICATOR, TURN & SLIP - 14V LTS (CONN)	UNITED INSTRUMENTS
9502-N.526	9502-N.526	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9543051		ASSEMBLY, WHEEL	GOODYEAR
9543051		ASSEMBLY, MAIN WHEEL	GOODYEAR
9550		TURN AND SLIP INDICATOR	UNITED INSTRUMENTS
9550377		ASSEMBLY, BREAK	GOODYEAR
9550A-N.503	9550A-N.503	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9550A-N.505	9550A-N.505	INDICATOR, TURN & SLIP - 28V LTS (PGTLS)	UNITED INSTRUMENTS
9550B-N.537	9550B-N.537	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS
9550B-N.540	9550B-N.540	INDICATOR, TURN & SLIP - 28V LTS (CONN)	UNITED INSTRUMENTS
9550-N.501	9550-N.501	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9551A-N.508	9551A-N.508	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9551A-N.510	9551A-N.510	INDICATOR, TURN & SLIP - 28V LTS (PGTLS)	UNITED INSTRUMENTS
9551B-N.538	9551B-N.538	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS
9551B-N.541	9551B-N.541	INDICATOR, TURN & SLIP - 28V LTS (CONN)	UNITED INSTRUMENTS
9551-N.506	9551-N.506	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9552A-N.513	9552A-N.513	INDICATOR, TURN & SLIP - 5V LTS (PGTLS)	UNITED INSTRUMENTS
9552A-N.515	9552A-N.515	INDICATOR, TURN & SLIP - 28V LTS (PGTLS)	UNITED INSTRUMENTS
9552B-N.539	9552B-N.539	INDICATOR, TURN & SLIP - 5V LTS (CONN)	UNITED INSTRUMENTS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
9552B-N.542	9552B-N.542	INDICATOR, TURN & SLIP - 28V LTS (CONN)	UNITED INSTRUMENTS
9552-N.511	9552-N.511	INDICATOR, TURN & SLIP - NO LITES	UNITED INSTRUMENTS
9599-607-121XX	IND-021	INDICATOR, ALTITUDE	TRT
9599-607-141XX	IND-821A	INDICATOR, HEIGHT	TRT
9599-607-145XX	ERT-011	UNIT, TRANSCEIVER	TRT
960-0329-XXX	MKV	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-0331-XXX	MKV	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-0335-XXX	MKV	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-0336-XXX	MKV	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-0337-XXX	MKV	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-2224-()	EGPWS MKVII	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-2225-()	EGPWS MKVII	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
960-2226-()	EGPWS MKVII	SYSTEM, GROUND PROXIMITY WARNING	HONEYWELL
966()-()-01	966()-()-01	REGULATOR, CABIN PRESSURE	KOLLSMAN
966-0013-003		TRANSMITTER, FLAP POSITION AND STALL	UNITED CONTROLS
966C-01	966C-01	REGULATOR, CABIN PRESSURE	KOLLSMAN
967()-()-01	967()-()-01	CONTROLS, CABIN RATE LIMIT	KOLLSMAN
967B-01	967B-01	CONTROL, RATE OF CLIMB	KOLLSMAN
968B-01	968B-01	CONTROL, CABIN PRESSURE LIMITS	KOLLSMAN
968B-01	968B-01	CONTROL, CABIN PRESSURE LIMITS	KOLLSMAN
971083-1	TFM-500	TRANSCEIVER, VHF/UHF FM AIRBORNE	TECHNISONIC IND. LIMITED
971083-3	TFM-500	TRANSCEIVER, VHF/UHF FM AIRBORNE	TECHNISONIC IND. LIMITED
971-4193-00X		ACCELEROMETER, THREE AXIS	HONEYWELL
975-0395		SWITCH, THERMAL	SUNDSTRAND
976J417-1/2		RECTIFIER, ALTERNATOR	WESTINGHOUSE
976J553-2		GENERATOR, AC-DC	WESTINGHOUSE
980-4100XXXX		RECORDER, UNIVERSAL FLIGHT DATA	HONEYWELL
980-4120XXXX		RECORDER, SOLID STATE UNIVERSAL FLIGHT	HONEYWELL
980-4700-XXX		RECORDER, FLIGHT DATA, SOLID STATE	HONEYWELL
980-4710-001	AR-64	RECORDER, SOLID STATE MEMORY FLIGHT DATA	HONEYWELL
980-4710-002	AR-128	RECORDER, SOLID STATE MEMORY FLIGHT DATA	HONEYWELL
980-4710-003	AR-256	RECORDER, SOLID STATE MEMORY FLIGHT DATA	HONEYWELL
980-6005-054	AV-577B	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-055	AV-577B	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-056	AV-577B	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-057	AV-577B	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-058	AV-577B	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-074	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-075	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-076	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-077	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-078	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6005-079	AV-557C	RECORDER, COCKPIT VOICE	HONEYWELL
980-6019-001	AV-557D	RECORDER, COCKPIT VOICE	HONEYWELL
980-6020-XXX		RECORDER, SOLID STATE COCKPIT VOICE,	HONEYWELL
980-6021-032	AR-602C	RECORDER, SOLID STATE MEMORY VOICE/DATA	HONEYWELL
980-6021-066	AR-204C	RECORDER, SOLID STATE MEMORY VOICE/DATA	HONEYWELL
980-6021-072	AR-204C	RECORDER, SOLID STATE MEMORY VOICE/DATA	HONEYWELL
980-6021-083	AR-302C	RECORDER, SOLID STATE MEMORY VOICE/DATA	HONEYWELL
980-6022-XXX		RECORDER, SOLID STATE COCKPIT VOICE,	HONEYWELL
980-6023-001	AR-30	RECORDER, SOLID STATE MEMORY COCKPIT	HONEYWELL
980-6023-002	AR-120	RECORDER, SOLID STATE MEMORY COCKPIT	HONEYWELL
980-6025-001	DVDR-120-4X	RECORDER, DIGITAL VOICE-DATA, DVDR	HONEYWELL
980-6109-()		MONITOR, MICROPHONE	HONEYWELL
980-8015-001	AV-557A	TEST SET, COCKPIT VOICE RECORDER	HONEYWELL
9813-25		INDICATOR, DUAL TORQUE	EDISON
9813-25-()	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-05	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-05		INDICATOR, DUAL TORQUE	EDISON
9813-25-07	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
9813-25-12	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-13	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-15	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-16	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-17	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-17(MOD)		INDICATOR, DUAL TORQUE	CLIFTON PRECISION
9813-25-18	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-19	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-21	9813-25	INDICATOR, TORQUE - DUAL	CLIFTON PRECISION
9813-25-5		INDICATOR, DUAL TORQUE	CLIFTON PRECISION
9813-25-7		INDICATOR, DUAL TORQUE	CLIFTON PRECISION
983-()-01	983-()-01	ALTIMETER, DENSITY	KOLLSMAN
98-39117		BOARD, PRINTED CIRCUIT	BEECHCRAFT
98AM		INDICATOR, SENSITIVE ALTIMETER	SMITHS
990-3333-185	B1045-J521-RBH3	PANEL, AUDIO CONTROL	BAKER ELECTRONICS INC.
99-364136		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-364158-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-364205-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-364210-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-364230-1		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-364246-()		BOARD, PRINTED CIRCUIT	BEECHCRAFT
99-384039		ALTIMETER, PRESSURE	INSTRUMENTS INC.
995-1		DIMMER, D.C LAMP	AVTECH
996()		VALVES, DRAIN	AUTO-VALVE
9-9827-C1		TRANSMITTER, FUEL FLOW	BENDIX
9-9827-C1		TRANSMITTER, FUEL FLOW	BENDIX
A 80-AAU-8/A		INDICATOR, ALTIMETER	AEROSONIC
A 80-AAU-8A/A		INDICATOR, ALTIMETER	AEROSONIC
A-()	A-()	INDICATOR, RATIO RESISTANCE TYPE	AMETEK
A-()		INDICATOR, BANK AND TURN	BENDIX
A-1		INDICATOR, TEMPERATURE - OAT	ELECTRONICS
A-12	A-12	PILOT, AUTOMATIC	HONEYWELL
A151()	93A151-()	UNITS, CONTROL - SOLID-STATE	LORAL
A152()	93A152-()	UNITS, CONTROL - SOLID-STATE	LORAL
A1918()		BOX, JUNCTION	AMETEK
A-2	A-2	AMPLIFIER, COMPASS AMPLIFIER AND SINGLE	HONEYWELL
A200S	A200S	SYSTEM, SOLID-STATE COCKPIT VOICE	L3 COMMUNICATION
A2562-01	A2550-1	INDICATOR, TURN & SLIP	KELLY
A26877-10-001	A26877-10-001	INDICATOR, RATE OF CLIMB	KOLLSMAN
A27745-10-()	A27745-10-()	INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	KOLLSMAN
A27745-10-011	A27745-10-011	INDICATOR, AIRSPEED	KOLLSMAN
A27817-10-()	A27817-10-()	INDICATOR, ELECTRIC TACHOMETER	KOLLSMAN
A-3	A-3	GYROPILOT	HONEYWELL
A-30	A-30	ENCODER, ALTITUDE	ACK
A301-61(A)	A301-61(A)	CONTROL, COMMUNICATION	ANDREA
A301-61B-1	A301-61B-1	CONTROL, COMMUNICATION	ANDREA
A301-6R	A301-6R	CONTROL, AUDIO	ANDREA
A301-6W	A301-6W	CONTROL, AUDIO	ANDREA
A32069-10-006		INDICATOR, RATE OF CLIMB	KOLLSMAN
A35-MA-10L-X		INDICATOR, ALTIMETER	AEROSONIC
A36157-10-160	A36157-10-160	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A36157-10-160	A36157-10-167	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A36157-10-260	A36157-10-260	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A38119-10-001	A38119-10-001	ALTIMETER, INTEGRALLY LIGHTED PRESSURE	KOLLSMAN
A38119-10-004	A38119-10-004	ALTIMETER, INTEGRALLY LIGHTED PRESSURE	KOLLSMAN
A38119-10-006	A38119-10-006	ALTIMETER, PRESSURE	KOLLSMAN
A38119-10-008	A38119-10-008	ALTIMETER, PRESSURE	KOLLSMAN
A38119-10-016	A38119-10-016	ALTIMETER, PRESSURE	KOLLSMAN
A38729-10-004	A38729-10-004	ALTIMETER, DRUM POINTER	KOLLSMAN
A40179-10-()	A40179-10-()	ALTIMETER, PRESSURE	KOLLSMAN

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
A41019-10-004	A41019-10-004	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A41019-10-004	A41019-10-004	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A41449-10-()	A41449-10-()	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
A41449-10-()	A41449-10-()	INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	KOLLSMAN
A41869-10-015	A41869-10-015	ALTIMETER, SERVOED	KOLLSMAN
A41869-10-128	A41869-10-128	ALTIMETER, SERVOED	KOLLSMAN
A41869-10-128	A41869-10-128	ALTIMETER, SERVOED	KOLLSMAN
A41869-10-21	A41869-10-21	ALTIMETER, SERVOED	KOLLSMAN
A42899-10-016	A42899-10-016	ALTIMETER, SERVOED - AUTOMATIC PRESSURE	KOLLSMAN
A42899-10-115	A42899-10-115	ALTIMETER, SERVOED - AUTOMATIC PRESSURE	KOLLSMAN
A42899-10-215	A42899-10-215	INDICATOR, ALTIMETER - SERVOED	KOLLSMAN
A42899-10-216	A42899-10-216	ALTIMETER, SERVOED - AUTOMATIC PRESSURE	KOLLSMAN
A42899-10-217	A42899-10-217	ALTIMETER, SERVOED - AUTOMATIC PRESSURE	KOLLSMAN
A43049-10-004	A43049-10-004	INDICATOR, ALTIMETER SERVOED	KOLLSMAN
A43991-10-001	A43991-10-001	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
A44485-10-202	A44485-10-202	INDICATOR, ALTIMETER PRESSURE	KOLLSMAN
A44488-10-008	A44488-10-008	ALTIMETER, INTEGRALLY LIGHTED PRESSURE	KOLLSMAN
A44871-10-001		INDICATOR, ALTERTER - ALTITUDE	KOLLSMAN
A-457		TESTER, INDICATOR CALIBRATION	AMETEK
A50-MA-3		INDICATOR, ALTIMETER	AEROSONIC
A55()	93A055-()	MODUALS, MICROPHONE - SOLID STATE	LORAL
A-550	A-550	AMPLIFIER, AUDIO	SIGMA-TEK
A5920	A5920	INDICATOR, TURN & SLIP	KELLY
A5930	A5930	INDICATOR, TURN & SLIP	KELLY
A6912/1		AMPLIFIER, SUMMING	THALES
A-770	A-770	AMPLIFIER, AUDIO	SIGMA-TEK
A-8(), A-9()	A-8(), A-9()	REGULATOR, OXYGEN	BENDIX
A8/A-10-3		INDICATOR, ALTIMETER	AEROSONIC
A81-13-1	C-2106/AIC-18	INTERCOMMUNICATION SET CONTROL	ANDREA
A-905-G2		TESTER, TRANSMITTER - POSITION	AMETEK
AA20 / 22	AA20 / 22	LOUDHAILER	NAT
AA20/22	AA20/22	SYSTEMS, LOUDHAILER / PA	NAT
AA-200	AA-200	SYSTEM, RADIO ALTITUDE	HONEYWELL
AA22	AA22	PA/SIREN SYSTEM	NAT
AA30	AA30	ACCESSORIES, AUDIO	NAT
AA34	AA34	INTERFACE, RADIO - UNIVERSAL	NAT
AA38-3XX	AA38-3XX	LOOP, LOCAL ICS	NAT
AA3X	AA3X	ACCESSORIES, AUDIO	NAT
AA80-001	AA80-001	SYSTEM, INTERVOX INTERCOM	NAT
AA80-020	AA80-020	SYSTEM, INTERVOX INTERCOM	NAT
AA80-060	AA80-060	SYSTEM, INTERVOX INTERCOM	NAT
AA80-062	AA80-062	SYSTEM, INTERVOX INTERCOM	NAT
AA82	AA82	SYSTEMS, STEREO INTERCOM	NAT
AA83	AA83	SYSTEM, STEREO INTERCOM	NAT
AA85-001	AA85-001	INTERCOM, INTERVOX II	NAT
AA90	AA90	CONTROLLERS, AUDIO	NAT
AA90 / AMS40	AA90 / AMS40	CONTROLLERS, AUDIO	NAT
AA95	AA95	CONTROLLERS, AUDIO	NAT
AA96	AA96	CONTROLLERS, AUDIO	NAT
AA97	AA97	CONTROLLERS, AUDIO	NAT
AA9X	AA9X	CONTROLLER, SINGLE CHANNEL AUDIO	NAT
AB5773-2		UNITS, ENGINE GAGE	EDISON
AC-135	AC-135	INDICATOR, RATE OF CLIMB	KARNISH
AE342-1-A		INDICATOR, RATE OF CLIMB	BENDIX
AE-355-1-A	AE-355-1-A	INDICATOR, TURN & SLIP GYRO	BENDIX
AH01-0101-()		INDICATOR, ARTIFICIAL HORIZON GYRO	HUMPHREY
AH07-0201-1		INDICATOR, ATTITUDE GYRO	HUMPHREY
AH-1-366		INDICATOR, ARTIFICIAL HORIZON GYRO	HUMPHREY
AIR 5850	AIR 5850	HEADSETS, AIRLITE 70	AIRMED
AIRLITE 70	5850	HEADSET	AIRMED

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
AK058/079	AK058/079	AUTOPILOT	SIGMA-TEK
AK301	AK301	AUTOPILOT	SIGMA-TEK
AK594	AK594	AUTOPILOT	SIGMA-TEK
AL/0718 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
AL58D1113A3		SWITCH, PRESSURE	GENERAL CONTROLS
ALTIMATIC	ALTIMATIC	SYSTEM, AUTOPILOT	PIPER
ALTIMATIC III	ALTIMATIC III	SYSTEM, AUTOPILOT	PIPER
ALTIMATIC V	ALTIMATIC V	SYSTEM, AUTOPILOT	PIPER
ALTIPLUSD2		INDICATOR, ALTITUDE	PRETEL
AM 250	AM 250	ENCODER, REMOTE ALTITUDE	HORIZON
AM 275	AM 275	INDICATOR, ALTITUDE ALERTER	HORIZON
AM-550/660	AM-550/660	RECEIVER, AUDIO AMPLIFIER MARER BEACON	SIGMA-TEK
AMA-10A	AMA-10A	AMPLIFIER, PASSENGER ADDRESS	BENDIX
AMS40	AMS40	CONTROLLERS, AUDIO	NAT
AMS41	AMS41	CONTROLLERS, AUDIO	NAT
AMS42	AMS42	CONTROLLERS, AUDIO	NAT
AMS42/44	AMS42	CONTROLLERS, DUAL CHANNEL AUDIO	NAT
AMS43	AMS43	CONTROLLER, SINGLE CHANNEL AUDIO	NAT
AMS43	AMS43	CONTROLLERS, AUDIO	NAT
AMS43	AMS43	CONTROLLER, SINGLE CHANNEL AUDIO	NAT
AMS44	AMS44	CONTROLLERS, AUDIO	NAT
AMS45	AMS45	CONTROLLERS, AUDIO	NAT
AMT-9 / AMR-4	AMT-9 / AMR-4	TRANSMITTER/RECEIVER, SUPERPHONE COMM.	DYNAIR
AN2572	AN2572	THERMOMETER, PRECISION DIGITAL	ANALOGIC
AN3201A1200		AMMETER	HICKOCK
AN3201A150		AMMETER	HICKOCK
AN3201A300	CON724D39112	AMMETER	HICKOCK
AN3201A450		AMMETER	HICKOCK
AN3201A600		AMMETER	HICKOCK
AN5530-1	AN5530-1	GENERATORS, ELECTRIC TACHOMETER	KOLLSMAN
AN5531-1	AN5531-1	GENERATORS, ELECTRIC TACHOMETER	KOLLSMAN
AN5531-2	AN5531-2	GENERATORS, ELECTRIC TACHOMETER	KOLLSMAN
AN5736-(A)	AN5736-(A)	INDICATOR, GYRO-HORIZON	TERNSTEDT
AN5760-()	AN5760-()	ALTIMETER, SENSITIVE	KOLLSMAN
AN5766T3	AN5766T3	STANDBY, COMPASS	KOLLSMAN
AN5771-5()	AN5771-5()	INDICATOR, SUCTION GAGE	AMETEK
AN5772-2	AN5772-2	GAUGE, OIL PRESSURE	RANCO
AN5773-1A		UNITS, ENGINE GAGE	EDISON
AN5790-()	AN5790-()	INDICATOR, THERMOMETER	AUTO-LITE
AN5795-()	AN5795-()	INDICATOR, THERMOMETER	AUTO-LITE
AN5839-1	AN5839-1	INDICATOR, POSITION LANDING GEAR	KOLLSMAN
AN-ASN-43	AN-ASN-43	SET, GYROMAGNETIC COMPASS	HONEYWELL
ANS-20()	ANS-20()	INDICATOR, DIRECTIONAL GYRO	AEROSONIC
ANS-30()	ANS-30()	INDICATOR, ARTIFICIAL HORIZON GYRO	AEROSONIC
ANS-50	ANS-50	INDICATOR, TURN & BANK GYRO	AEROSONIC
AP-4040A	AP-4040A	PANEL, AUDIO	DYNAIR
APT-311-1000-200G		TRANSMITTER, PRESSURE (200 PSI)	KULITE
APTE-139-1500SG		TRANSMITTER, PRESSURE	KULITE
APTE-25KBS-1000-100G		TRANSMITTER, PRESSURE	KULITE
APTE25SRT1-1000-100G		TRANSDUCER, TORQUE PRESSURE	KULITE
AR-204/207	SC-12 SERIES	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-204A	AR204 SERIES	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-204A	SC12 SERIES	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-204A-1D	AR-204A-1D	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-207	SC12 SERIES	INDICATOR, FUEL FLOW - LIGHTED	FOXBORO
AR-209	SC12 SERIES	INDICATOR, FUEL FLOW - LIGHTED	FOXBORO
AR-209	SC-12 SERIES	INDICATOR, FUEL FLOW - LIGHTED	FOXBORO
AR-209-11	AR-209-11	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-209-11	AR-209-11	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AR-209-8	AT-209-8	INDICATOR, FUEL FLOW - LIGHTED	FOXBORO

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
AR800()	AR800()	INDICATOR, 3" DRUM POINTER	HORIZON
ASA-31()	ASA-31()	AUDIO SELECTOR / AMPLIFIER	BENDIX
ASH450-1	ASH450-1	INVERTER, STATIC - 450 VA	SMITHS
ASH564B-()	ASH564B-()	SERVICE BULLETIN - STATIC INVERTER	SMITHS
ASH564B-6	ASH564B-6	INVERTER, STATIC - 1000 VA	SMITHS
ASH564B-6, -6A	ASH564B-6, -6A	INVERTER, STATIC	SMITHS
ASH674-()	ASH674-()	INVERTER, STATIC	SMITHS
ASH854-()	ASH854-()	INVERTER, STATIC	SMITHS
ASW20F		GLIDER	SA CENTRAIR
AT-204/208	SC-12 SERIES	INDICATOR, FUEL FLOW - UNLIT	FOXBORO
AT-205	SC-12 SERIES	INDICATOR, FUEL REMAINING TOTALIZING	FOXBORO
AT-205-2, 3, 5	AT-205-2, 3, 5	INDICATOR, FUEL REMAINING TOTALIZING	FOXBORO
AT-206	SC-12 SERIES	INDICATOR, FUEL REMAINING TOTALIZING	FOXBORO
AT-209	SC12 SERIES	INDICATOR, FUEL REMAINING TOTALIZING	FOXBORO
AT-210	SC12 SERIES	INDICATOR, FUEL REMAINING TOTALIZING	FOXBORO
AUTOCONTROL III	AUTOCONTROL III	SYSTEM, AUTOPILOT	PIPER
AUTOFLITE II	AUTOFLITE II	SYSTEM, AUTOPILOT	PIPER
AV16B1864B		VALVE, GATE	GENERAL CONTROLS
AW 1569 AB01		INDICATOR, OXYGEN PRESSURE	AMETEK
AW 1826 AD04		GAGE, EMERGENCY AIR BREAK PRESSURE	AMETEK
AW 1842 BA06		INDICATOR, TORQUE PRESSURE	AMETEK
AW 2825 AK()		INDICATOR, TRUE AIRSPEED	AMETEK
AW 2835 AE01		INDICATOR, DUAL CABIN ALT & DIFFERENTIAL	AMETEK
AW 2837 Series		INDICATOR, MACH AIRSPEED	AMETEK
AW-1 7/8-()-()		INDICATOR, PRESSURE GAGE	AMETEK
AW-2 3/4-14-()		INDICATOR, PRESSURE - MANIFOLD	AMETEK
AW-2 3/4-20-()		INDICATOR, AIRSPEED	AMETEK
AW-2 3/4-25-()		INDICATOR, PRESSURE - MANIFOLD	AMETEK
AW2835AG01		INDICATOR, DUAL CABIN ALT & DIFFERENTIAL	AMETEK
AY-110()-1()-A1		SYNCHRO, AUTOSYN	BENDIX
B-()	B-()	ACCELEROMETERS	KOLLSMAN
B-00()		REGULATOR, VOLTAGE	LAMAR
B0063-()	B0063	ALTIMETER, COUNTER POINTER DRUM	SMITHS
B0063-()	B0063	ALTIMETER, COUNTER POINTER DRUM	SMITHS
B0090-()		INDICATOR, ALTIMETER	SMITHS
B0090-()		INDICATOR, ALTIMETER	SMITHS
B0090-81101		INDICATOR, ALTIMETER - SERVO	SMITHS
B0090-81105	B0090	INDICATOR, ALTIMETER - SERVO	SMITHS
B0090-81105	B0090	INDICATOR, ALTIMETER - SERVO	SMITHS
B0240-23101		INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	SMITHS
B0247-()	B0247	INDICATOR, AIRSPEED - MACH	SMITHS
B0650-()-()	B0650	INDICATOR, ALTITUDE ALERTER	SMITHS
B0651-()-1		INDICATOR, ALTITUDE ALERTER	SMITHS
B0652-()-1	B0652	INDICATOR, ALTITUDE ALERTER	SMITHS
B0704-()		SENSORS, OVERSPEED LIMIT	SMITHS
B0704-()		SENSORS, OVERSPEED LIMIT	SMITHS
B0704-()		SENSORS, OVERSPEED LIMIT	SMITHS
B0705-10001		SWITCH, MACH AIRSPEED WARNING	ASTEK
B0705-10001		SENSOR, OVERSPEED LIMIT	SMITHS
B1035()	B1035()	PANEL, AUDIO CONTROL	BAKER ELECTRONICS INC.
B1045()	B1045()	PANEL, AUDIO CONTROL	BAKER ELECTRONICS INC.
B1045-J521-RBH3	B1045-J521-RBH3	PANEL, AUDIO CONTROL	BAKER ELECTRONICS INC.
B118-75		INDICATOR, POWER UNIT	SIMMONDS PRECISION
B118-TYPE		ASSEMBLY, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION
B-14325-4	X-10	SELECTOR, FREQUENCY	GABLES
B-14379-3	X-26	SELECTOR, FREQUENCY	GABLES
B1800-()	B1800	INDICATOR, ALTITUDE - SERVOED	SMITHS
B2888-01	A2850-1	ASSEMBLY, RATE GYROSCOPE TRANSMITTER	KELLY
B2888-02	A2850-5	ASSEMBLY, RATE GYROSCOPE TRANSMITTER	KELLY
B294C-()		ASSEMBLY, FUEL QUANTITY INDICATOR	SIMMONDS PRECISION

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
B31521-10-()	B31521-10-()	INDICATOR, ELECTRICAL TACHOMETER	KOLLSMAN
B365-()		INDICATOR, PROP RPM TACHOMETER	KELLY
B366-()	B366-()	INDICATOR, % TACHOMETER	KELLY
B367-()		INDICATOR, PROP RPM TACHOMETER	KELLY
B38079-10-051	B38079-10-051	INDICATOR, MAX ALLOWABLE AIRSPEED	KOLLSMAN
B39041-10-206	B39041-10-206	INDICATOR, ALTIMETER - NON SERVOED	KOLLSMAN
B4-()	B4-()	ASSEMBLIES, BANK AND TURN INDICATOR	SCHWEIN
B406-4	B406-4	TRANSMITTER, EMERGENCY LOCATOR	ARTEX
B44202-10-()	B44202-10-()	ALTIMETER, PRESSURE	KOLLSMAN
B45152-10-406	B45152-10-406	INDICATOR, ALTIMETER - ENCODING	KOLLSMAN
B45152-10-410	B45152-10-410	ALTIMETER, ENCODER - INTEGRALLY LIGHTED	KOLLSMAN
B45451-10-001	B45451-10-001	ALTIMETER, ALTITUDE REPORTING	KOLLSMAN
B4A-()	B4A-()	ASSEMBLIES, BANK AND TURN INDICATOR	SCHWEIN
B4A-()	B4A-()	ASSEMBLIES, BANK AND TURN INDICATOR	SCHWEIN
B4B-K	MS28024-1__	INDICATOR, TURN & BANK	SCHWEIN
B55529-41-121	895518-20-001	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
B7000/B7100	B7000/B7100 SERIES	VERTICAL SPEED INDICATOR	UNITED INSTRUMENTS
B711-()		INDICATOR, HYDRAULIC OIL QUANTITY	SIMMONDS PRECISION
B712-()		INDICATOR, HYDRAULIC OIL QUANTITY	SIMMONDS PRECISION
BC2206F-1-20		COOLING FAN	IMC
BC2206F-1-20		FAN, COOLING	IMC MAGNETICS
BG174B2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG174C1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG174C2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG174D1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG174D2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG274B2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG274C1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG274C2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG274D1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG274D2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374C1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374C2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374C3	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374C4	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374D1	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374D2	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374D3	BG174/374	COMPUTOR, AUTOPILOT	KING
BG374D4	BG174/374	COMPUTOR, AUTOPILOT	KING
BH104		COMPENSATOR, SYSTEM - EGT	HOWELL
BH10910		SCHEMATIC	HOWELL
BH112JA-55		ANALYZER, JET CAL	HOWELL
BH112JB-915		TESTER, JETCAL - ANALYZER/TRIMMER	HOWELL
BH112JD		TESTER, JETCAL - ANALYZER/TRIMMER	HOWELL
BH116B		TESTER, TEMPCAL	HOWELL
BH12099-1		ASSEMBLY, AMPLIFIER BOARD	HOWELL
BH14992-()		ASSEMBLIES, PC BOARD	HOWELL
BH153H-20		RECORDER CALIBRATOR, TEMPERATURE	HOWELL
BH17641-1		DIAGRAM, SCHEMATIC	HOWELL
BH17650		LIST, BASIC PARTS	HOWELL
BH18098-2		ASSEMBLY, BRIDGE BOARD	HOWELL
BH183M		INDICATOR, AUTOTEMP	HOWELL
BH183M-21		INDICATOR, TURBINE INLET TEMPERATURE	HOWELL
BH183R-16		INDICATOR, AUTOTEMP	HOWELL
BH183R-16A		INDICATOR, AUTOTEMP	HOWELL
BH185 SERIES		INDICATORS	HOWELL
BH185L-37		INDICATOR, FAN SPEED	HOWELL
BH185R-134		INDICATOR, AUTOTEMP	HOWELL
BH185R-134 POST 446D		INDICATOR, AUTOTEMP	HOWELL
BH185R-134 PRE SN 44		INDICATOR, AUTOTEMP	HOWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
BH185R-154		INDICATOR, AUTOTEMP	HOWELL
BH185R-154B		INDICATOR, AUTOTEMP	HOWELL
BH185R-154C		INDICATOR, AUTOTEMP	HOWELL
BH185R-154D		INDICATOR, AUTOTEMP	HOWELL
BH185R-213		INDICATOR, AUTOTEMP	HOWELL
BH185R-256A		INDICATOR, AUTOTEMP	HOWELL
BH185R-280A		INDICATOR, AUTOTEMP	HOWELL
BH185R-291		INDICATOR, AUTOTEMP	HOWELL
BH185R-4		INDICATOR, AUTOTEMP	HOWELL
BH185R-50		INDICATOR, AUTOTEMP	HOWELL
BH185R-71		INDICATOR, TEMPERATURE - AUTOTEMP	HOWELL
BH185R-73A-1		INDICATOR, AUTOTEMP	HOWELL
BH185R-77		INDICATOR, AUTOTEMP	HOWELL
BH187B-4A		INDICATOR, TOTAL AIR TEMPERATURE	HOWELL
BH2481		ASSEMBLY, AMPLIFIER BOARD	HOWELL
BH2484		CABLING, PCB MACHINED	HOWELL
BH2485		ASSEMBLY, BRIDGE BOARD	HOWELL
BH2868		SCHEMATIC	HOWELL
BH5157		ASSEMBLY, AMPLIFIER BOARD	HOWELL
BH5645D		ASSEMBLY, REAR COVER	HOWELL
BH5846		ASSEMBLY, AMPLIFIER BOARD	HOWELL
BH5868		SCHEMATIC	HOWELL
BH6795		CABLING, PCB ASSEMBLY	HOWELL
BH6850		ASSEMBLY, INDICATOR	HOWELL
BH6850B		ASSEMBLY, INDICATOR	HOWELL
BH6850D		ASSEMBLY, UNIT	HOWELL
BH6958		ASSEMBLY, AMPLIFIER BOARD	HOWELL
BH7560		ASSEMBLY, PCB	HOWELL
BH7567		ASSEMBLY, BRIDGE BOARD	HOWELL
BH7971		COMPENSATOR, EGT	HOWELL
BH7973		INTERCONNECTING, CABLING	HOWELL
BH809A		ASSEMBLY, POTENTIOMETER SLIDE WIRE	HOWELL
BH8924A		ASSEMBLY, MECHANICAL	HOWELL
BH9502-1		ASSEMBLY, CABLING BOARD	HOWELL
BH9756		ASSEMBLY, TAPOT GEAR	HOWELL
BH9910		SCHEMATIC	HOWELL
BH9979-2		SCHEMATIC	HOWELL
BJ112J()		ANALYZER, JETCAL	HOWELL
BT25-()		BOXES, FUEL CONTENTS GAUGE CABLE	SMITHS
BTI 600 Series		SYSTEMS, BATTERY TEMPERATURE INDICATOR	FOXTRONICS
BTM-()	BTM-()	MONITOR, BATTERY TEMP - OVERTEMP ALERT	K.S. AVIONICS
BTMK-501	BTMK-501	MONITOR, BATTERY TEMPERATURE	MARATHON
C-()	C-()	INDICATOR, RATIO RESISTANCE TYPE	AMETEK
C0001-81103		INDICATOR, ALTITUDE - L.N.D.	SMITHS
C0007-()		INDICATOR, ALTITUDE - L.N.D.	SMITHS
C0240-23101		INDICATOR, MAX ALLOWABLE AIRSPEED - MACH	SMITHS
C-14	C-14	INDICATOR, AIRPSEED	KOLLSMAN
C-2	C-2	INDICATOR, RATE OF CLIMB	KOLLSMAN
C-2 & C-3	C-2 & C-3	INDICATOR, RATE OF CLIMB	BENDIX
C-2()	C-2()	COMPASS, GYROSYN	HONEYWELL
C22061-10-012	C22061-10-012	ALTIMETER, PRESSURE	KOLLSMAN
C2300-DL4		INDICATOR, COMPASS - STANDBY	AIRPATH
C-3814/ARC-89(V)	C-3814/ARC-89(V)	INTERCOMMUNICATION SET CONTROL	ANDREA
C-3815/ARC-89(V)	C-3815/ARC-89(V)	INTERCOMMUNICATION SET CONTROL	ANDREA
C39049-10-296	C39049-10-296	ALTIMETER, PRESSURE	KOLLSMAN
C-4()	C-4()	SYSTEM, GYROSYN COMPASS	HONEYWELL
C-4000(AF)	C-4000(AF)	TRANSMITTER, EMERGENCY LOCATOR	POINTER SENTRY
C406-1	C406-1	TRANSMITTER, EMERGENCY LOCATOR	ARTEX
C406-1HM	C406-1HM	TRANSMITTER, EMERGENCY LOCATOR	ARTEX
C406-N	C406-N	TRANSMITTER, EMERGENCY LOCATOR	ARTEX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
C414-()	C414-()	GAGE, DUAL FUEL	KELLY
C41542-10-003	C41542-10-003	INDICATOR, ALTIMETER - ENCODING	KOLLSMAN
C420-()		GAGE, DUAL FUEL FLOW	KELLY
C450-1		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
C450-2		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
C450A-2		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
C450A-3		INDICATOR, ENGINE GAUGE UNIT - TRIPLE	KELLY
C-47	C-47	SYSTEM, ELECTRONIC WEIGHING	CHADWICK-HELMUTH
C-4E		INDICATOR, COMPASS - STANDBY	AMETEK
C-5()		INDICATOR, COMPASS - STANDBY	AMETEK
C55189-41-122	895518-20-005	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
C-6()	C-6()	INDICATOR, GYROSYN COMPASS	HONEYWELL
C824/AIC10	C824/AIC10	SYSTEM, INTERCOM	ANDREA
C-9,10,11	C-9,10,11	SYSTEMS, GYROSYN COMPASS	HONEYWELL
C90277	S-3B/C	SYSTEM, GYROSYN COMPASS	HONEYWELL
CA-DP-10-ILB		INDICATOR, DIFFERENTIAL PRESSURE	AEROSONIC
CAS-81	CAS-81	SYSTEM, COLLISION AVOIDANCE	HONEYWELL
CB-2100	AN-5766-1	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100	AN-5766-2	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100	AN-5766-4	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100-3	AN-5766-3	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100-3	AN-5766-T3	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100-M	AN-5766-3	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100-T4	AN-5766-T4	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2100-T4-A	AN-5766-T4	INDICATOR, COMPASS - STANDBY	AIRPATH
CB-2125-28A	MS17983-4	INDICATOR, COMPASS - STANDBY	AIRPATH
CB70	CB70	SYSTEM, COMPASS	BENDIX
CC-2024B/C/D	CC-2024B/C/D	UNIT, CHECKLIST CONTROL	BENDIX
CC250/450	CC250/450	CONTROLLERS, COMMUNICATION	NAT
CE100TR-(0XX)	CE100TR-(0XX)	PRE-AMP, MICROPHONE	CARTER ENGINEERING
CE12092B/U	CE12092B/U	MOUNT, JACK AND PANEL	CARTER ENGINEERING
CE500HT-3G	CE500HT-3G	AMPLIFIER, INTERCOM	CARTER ENGINEERING
CE504D	CE504D	SIREN / PA, ELECTRONIC	CARTER ENGINEERING
CE510D-1	CE510D-1	SYSTEM, AUDIO MIXER INTERCOM	CARTER ENGINEERING
CE520	CE520	SYSTEM, AUDIO MIXER INTERCOM	CARTER ENGINEERING
CE705J	CE705J	INTERCOM, DUAL AUDIO MIXER AND	CARTER ENGINEERING
CE706D-1	CE706D-1	DUAL, MIXER INTERCOM	CARTER ENGINEERING
CE706D-2	CE706D-2	DUAL, MIXER INTERCOM	CARTER ENGINEERING
CENTURY 2000	CENTURY 2000	SYSTEM & FLIGHT COMPUTER	CENTURY
CENTURY 21	CENTURY 21	SYSTEM, AUTOPILOT	SIGMA-TEK
CENTURY 31	CENTURY 31	TRANSPONDER	IFD
CENTURY 41	CENTURY 41	SYSTEM, AUTOPILOT	CENTURY
CENTURY I	CENTURY I	AUTOPILOT	SIGMA-TEK
CENTURY II	CENTURY II	AUTOPILOT	CENTURY
CENTURY II/III	CENTURY II/III	AUTOPILOT	SIGMA-TEK
CENTURY II/III	CENTURY II/III	SYSTEMS, AUTOMATIC FLIGHT	SIGMA-TEK
CENTURY IIB	CENTURY IIB	AUTOPILOT	CENTURY
CENTURY IIB/III	CENTURY IIB/III	AUTOPILOT	SIGMA-TEK
CENTURY III	CENTURY III	AUTOPILOT	CENTURY
CG117B1		CONTROLLER, FLIGHT	KING
CG117B2		CONTROLLER, FLIGHT	KING
CG117B3		CONTROLLER, FLIGHT	KING
CG1230AC11	LASERTRAC	UNIT, DISPLAY - NAVIGATION	HONEYWELL
CG136A1		SELECTOR, HEADING	KING
CG136B1		SELECTOR, HEADING	KING
CG2015AC10		SELECTOR, MODE	HONEYWELL
CG217B1		CONTROLLER, FLIGHT	KING
CG217B2		CONTROLLER, FLIGHT	KING
CG217B3		CONTROLLER, FLIGHT	KING
CG301A1		GYRO, AIR-DRIVEN VERTICAL	KING

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
CG301A2		GYRO, AIR-DRIVEN VERTICAL	KING
CG301B1		GYRO, AIR-DRIVEN VERTICAL	KING
CG301B2		GYRO, AIR-DRIVEN VERTICAL	KING
CG301C1		GYRO, AIR-DRIVEN VERTICAL	KING
CG301C2		GYRO, AIR-DRIVEN VERTICAL	KING
CG301P2		GYRO, AIR-DRIVEN VERTICAL	KING
CG317B1		CONTROLLER, FLIGHT	KING
CG317B2		CONTROLLER, FLIGHT	KING
CG317B4		CONTROLLER, FLIGHT	KING
CG317D1		CONTROLLER, FLIGHT	KING
CG317D2		CONTROLLER, FLIGHT	KING
CG417A1		CONTROLLER, FLIGHT	KING
CG417A2		CONTROLLER, FLIGHT	KING
CG417B1		CONTROLLER, FLIGHT	KING
CG417B2		CONTROLLER, FLIGHT	KING
CG417G1		CONTROLLER, FLIGHT	KING
CG417G2		CONTROLLER, FLIGHT	KING
CG515		CONTROLLER, FLIGHT	KING
CG517A1		CONTROLLER, FLIGHT	KING
CG517A2		CONTROLLER, FLIGHT	KING
CG517A3		CONTROLLER, FLIGHT	KING
CH200-XXX	CH200-XXX	HEADS, CONTROL	NAT
CH300-XXX	CH300-XXX	HEADS, CONTROL	NAT
CH400-XXX	CH400-XXX	HEADS, CONTROL	NAT
CIA 360		AMPLIFIER, COMPRESSION - ISOLATION	FOXTRONICS
CID-552A/554A	CID-552A/554A	INDICATOR, CONVERTER	SIGMA-TEK
CID662/664	CID662/664	INDICATOR, CONVERTER	SIGMA-TEK
CIR-11-()	CIR-11-()	BATTERY	COMMUNICATIONS
CITATION CJ1+/CJ2+/C	CITATION	SYSTEM, AVIONICS - CESSNA CITATION	COLLINS
CMF1167		MONITOR, CONTROL - FUEL QUANTITY	MEGGITT AVIONICS
CN 863A	CN 863A	PANEL, COLOR WEATHER RADAR CONTROL	BENDIX
CNA-2010	CNA-2010	SYSTEM, VHF COM/NAV	BENDIX
COC-B1-32-()	COC-B1-32-()	SYSTEM, STATIC PRESSURE	KAMOV
CP466A/B	CP466A/B	PANEL, RADAR CONTROL	BENDIX
CSV1105-20	CSV1105-20	REGULATOR, VOLTAGE	SMITHS
CT4086400()		GENERATORS, MOTOR	KEARFOTT
D11772()	PGS 1810	SENSOR, AIR DATA	SMITHS
D11842	TP 91D/200	TRANSDUCER, AIRSPEED	SMITHS
D11843	PP4	TRANSDUCER, ALTITUDE PRESSURE	SMITHS
D120-P2-T	D120-P2-T	DIGITIZER	TRANS-CAL IND. INC.
D22061 04 021		ALTIMETER, PRESSURE	KOLLSMAN
D22061 10 012		ALTIMETER, PRESSURE	KOLLSMAN
D22061-()-()	D22061-()-()	ALTIMETER, PRESSURE	KOLLSMAN
D3	D3	INDICATOR, ELECTRIC BANK AND TURN	SCHWEIN
D38410-00-201_	D38410-00-201_	MODULE, ALTICODER	KOLLSMAN
D55489-41-180		INDICATOR, ALTITUDE ALERTER	KOLLSMAN
D-7	D-7	INDICATOR, AIRSPEED	KOLLSMAN
DALT55	1811 SERIES	TEST SET- PITOT STATIC	BARFIELD
DAS650	1811 SERIES	TEST SET- PITOT STATIC	BARFIELD
DBTI-2000	DBTI-2000	SYSTEM, BATTERY TEMPERATURE	FOXTRONICS
DCE642	DCE642	EQUIPMENT, DISTANCE COMPUTING	AERODATA
DDL-OC119A		INDICATOR, DUAL REPEATER	AMETEK
DDL-OC119C		INDICATOR, FUEL TANK TEMPERATURE	AMETEK
DF105		CONTROLS, FRONT PANEL	NAT
DG04-0109-1		GYRO, DIRECTIONAL	HUMPHREY
DG1009		ADAPTER, AUTO-TRIM	KING
DG1010		ADAPTER, AUTO-TRIM	KING
DG104A1		ADAPTER, NAV RECEIVER	KING
DG104B1		ADAPTER, NAV RECEIVER	KING
DG114A1		COUPLER, ATTITUDE REFERENCE	KING

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
DG-360	DG-360	SYSTEM, COMPASS	SIGMA-TEK
DG-360	DG-360	SYSTEM, COMPASS	SIGMA-TEK
DGL-1	DGL-1	DONGLE FOR ELT	ARTEX
DG-OC110A		INDICATOR, TURBINE SPEED	AMETEK
DJ-150	DJ-150	INDICATOR, TACHOMETER	AMETEK
DJ-54	DJ-54	INDICATOR, DC SELSYN	AMETEK
DK100/120/130/140	DK100/120/130/140	BEACON, UNDERSWATER ACOUSTIC	DUKANE CORP.
DRA45C-46		SWITCH, AIRSPEED - MACH	PRECISION SENSORS
DSF1291-2		INDICATOR, FUEL FLOW	CONSOLIDATED AIRBORNE
DSF1291-6		INDICATOR, FUEL FLOW	MEGGITT AVIONICS
DSFG1579		INDICATOR, FUEL QUANTITY	CONSOLIDATED AIRBORNE
DSFS1580		INDICATOR, FUEL STATUS	CONSOLIDATED AIRBORNE
DSN1591-()		INDICATOR, TACHOMETER - N1,N2	CONSOLIDATED AIRBORNE
DSN1967-3		INDICATOR, ENGINE GAS GENERATOR RPM	MEGGITT AVIONICS
DST-29-6		INDICATOR, TEMPERATURE - THERMOCOUPLE	CONSOLIDATED AIRBORNE
DTE12/TE12/DP12	DTE12/TE12/DP12	DTMF TONE ENCODER/DATA ENTRY KEYPAD	NAT
DWY120	DWY120	NAV / COMM., DWY SWITCHES	GABLES
E-1	E-1	TRANSMITTER, FUEL PRESSURE	AMETEK
E-1	E-1	INDICATOR, PRESSURE - HYD. 0-4000 PSI.	BENDIX
E-13	E-13	GENERATORS, ELECTRIC TACHOMETER	KOLLSMAN
E2	E2	INDICATOR, COMPASS	SMITHS
E22061 04 018		ALTIMETER, PRESSURE	KOLLSMAN
E22061-04-018	E22061-04-018	ALTIMETER, PRESSURE	KOLLSMAN
E-23	E-23	GENERATORS, ELECTRIC TACHOMETER	KOLLSMAN
E42459-10-114	E42459-10-114	ALTIMETER, ALTI-CODER	KOLLSMAN
E55529-41-221	895518-20-013	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
E-7	E-7	TRANSMITTER, PRESSURE - FUEL	AMETEK
E-9	E-9	TACHOMETERS, SENSITIVE ELECTRIC	KOLLSMAN
EA100AN		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA100AN-133()		INDICATOR, LIQUID QUANTITY	SIMMONDS PRECISION
EA100ANH-139H		INDICATOR, LIQUID QUANTITY	SIMMONDS PRECISION
EA100ANH-98()		INDICATOR, LIQUID QUANTITY	SIMMONDS PRECISION
EA1015-3398		SYSTEM, FUEL QUANTITY	SIMMONDS PRECISION
EA101AN()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA102AN-()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA1091A-20XX		TRANSMITTER, OIL QUANTITY	SIMMONDS PRECISION
EA124AN		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA133AN		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA-1400 SERIES	EA-1400 SERIES	INDICATOR, VERTICAL SPEED	SIGMA-TEK
EA-1400 SERIES	EA-1400 SERIES	INDICATOR, VERTICAL SPEED	SIGMA-TEK
EA148AN()		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA148ANH-102H		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
EA148ANH-95H		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
EA148ANH-95H		INDICATOR, OIL QUANTITY	SIMMONDS PRECISION
EA150AN		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA-2324-()		TRANSMITTER, FUEL QUANTITY	SIGMA-TEK
EA-2521-()M		INDICATOR, DUAL FUEL QUANTITY	SIGMA-TEK
EA-2522-()		TRANSMITTER, FUEL QUANTITY	SIGMA-TEK
EA-2523-()		TRANSMITTER, FUEL QUANTITY	SIGMA-TEK
EA303AN		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA31		INDICATOR, FUEL QUANTITY	SIMMONDS PRECISION
EA315()		TESTER, FIELD	SIMMONDS PRECISION
EA-401/801A	400/800 SERIES	ALTIMETER, ENCODING	ARC
EA-401A	EA-401A	INDICATOR, ALTIMETER - ENCODING	ARC
EA470()-358X		SYSTEM, FUEL QUANTITY	SIMMONDS PRECISION
EA470A-1526		SYSTEM, FUEL	SIMMONDS PRECISION
EA5170	EA5170	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5170 SERIES	EA-5170 SERIES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171	EA5171	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5171	EA-5171	INDICATOR, AIRSPEED	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
EA5171-()	EA5171-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-()	EA5171-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-AC	EA5171-()-AC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-ACA	EA5171-()-ACA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-BEC	EA5171-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-BEC	EA5171-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-BEL	EA5171-()-BEL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-CES	EA5171-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-FRD	EA5171-()-FRD	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()L-()	EA5171-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()L-()	EA5171-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-MAL	EA5171-()-MAL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-MON	EA5171-()-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-ROB	EA5171-()-ROB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-TAC	EA5171-()-TAC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-()-VAR	EA5171-()-VAR	INDICATOR, AIRSPEED	SIGMA-TEK
EA5171-3-MON	EA5171-3-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172	EA5172	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5172	EA-5172	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()	EA5172-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-()	EA5172-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()AA	EA5172-()AA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-AC	EA5172-()-AC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-AER	EA5172-()-AER	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-BEC	EA5172-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-BEL	EA5172-()-BEL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-BN	EA5172-()-BN	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-CES	EA5172-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-FAC	EA5172-()-FAC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L	EA5172-()L	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-()	EA5172-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-AER	EA5172-()L-AER	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-BEC	EA5172-()L-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-BEL	EA5172-()L-BEL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-CES	EA5172-()L-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-MON	EA5172-()L-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()L-SAB	EA5172-()L-SAB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-MON	EA5172-()-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-PA	EA5172-()-PA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-PIT	EA5172-()-PIT	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-ROB	EA5172-()-ROB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-SAB	EA5172-()-SAB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-SOC	EA5172-()-SOC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-()-VA	EA5172-()-VA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5172-1-ALA	EA5172-1-ALA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173	EA5173	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5173	EA-5173	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()	EA5173-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-()	EA5173-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-ACM	EA5173-()-ACM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-BEC	EA5173-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-CES	EA5173-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-CES	EA5173-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-GAF	EA5173-()-GAF	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()L	EA5173-()L	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()L-()	EA5173-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-RAM	EA5173-()-RAM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-ROB	EA5173-()-ROB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-()-TS	EA5173-()-TS	INDICATOR, AIRSPEED	SIGMA-TEK
EA5173-1-BD	EA5173-1-BD	INDICATOR, AIRSPEED	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
EA5174	EA5174	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5174	EA-5174	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()	EA5174	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()-()	EA5174-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()-ACM	EA5174-()-ACM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()-BEC	EA5174-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()-CES	EA5174-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()-PT	EA5174-()-PT	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()PT-()	EA5174-()PT-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()PT-BEC	EA5174-()PT-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()PTL-()	EA5174-()PTL-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()PTL-MAL	EA5174-()PTL-MAL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()PT-MAL	EA5174-()PT-MAL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()T	EA5174-()T	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()T-()	EA5174-()T-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()T-ACM	EA5174-()T-ACM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5174-()T-BEC	EA5174-()T-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175	EA5175	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()	EA5175	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()-()	EA5175-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()-ACM	EA5175-()-ACM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()-AYR	EA5175-()-AYR	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()-BEC	EA5175-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()-CES	EA5175-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()L	EA5175-()L	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()L-()	EA5175-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()L-CES	EA5175-()L-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()L-CIR	EA5175-()L-CIR	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT	EA_5175-()PT	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT-()	EA5175-()PT-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT-BEC	EA5175-()PT-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-()	EA5175-()PTL-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-APS	EA5175-()PTL-APS	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-BEC	EA5175-()PTL-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-CES	EA5175-()PTL-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-CIR	EA5175-()PTL-CIR	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-MEY	EA5175-()PTL-MEY	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PTL-MON	EA5175-()PTL-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT-MON	EA5175-()PT-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT-ROB	EA5175-()PT-ROB	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()PT-SOC	EA5175-()PT-SOC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T	EA5175-()T	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-()	EA5175-()T-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-AA	EA5175-()T-AA	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-ACM	EA5175-()T-ACM	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-BEC	EA5175-()T-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-BEL	EA5175-()T-BEL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()TL-()	EA5175-()TL-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()TL-BEC	EA5175-()TL-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5175-()T-MON	EA5175-()T-MON	INDICATOR, AIRSPEED	SIGMA-TEK
EA-5176	EA-5176	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()	EA5176-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-()	EA5176-()-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-AYR	EA5176-()-AYR	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-BEC	EA5176-()-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-CES	EA5176-()-CES	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()L	EA5176-()L	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()L-()	EA5176-()L-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()L-BEC	EA5176-()L-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-PT	EA5176-()-PT	INDICATOR, AIRSPEED	SIGMA-TEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
EA5176-()PT-()	EA5176-()PT-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()PT-BEC	EA5176-()PT-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()PTL-()	EA5176-()PTL-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()PTL-BEC	EA5176-()PTL-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()PTL-BEL	EA5176-()PTL-BEL	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()PT-PIP	EA5176-()PT-PIP	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()-SAC	EA5176-()-SAC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()TL-()	EA5176-()TL-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-()TL-BEC	EA5176-()TL-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5176-PT-BEC	EA5176-PT-BEC	INDICATOR, AIRSPEED	SIGMA-TEK
EA5177-()	EA5177-()	INDICATOR, AIRSPEED	SIGMA-TEK
EA584BC-827()		TRANSMITTER, LIQUID QUANTITY	SIMMONDS PRECISION
EA-801A	EA-801A	INDICATOR, ALTIMETER - ENCODING	ARC
EAC-1		INDICATOR, TEMPERATURE - EGT/OAT/CHT	ELECTRONICS
EB-2BW	EB-2BW	BEACON, EMERGENCY POSITION INDICATING	MARTECH INC.
EBC-502	EBC-502	EMERGENCY BEACON	EMERGENCY BEACON CORP
EE0005-0111		BATTERY, STANDBY	SERMAT
EG5()	EG5()	UNIT, POWER - FUEL SYSTEM	HONEYWELL
EG70A-1	EG70A-1	AMPLIFIER, FUEL QUANTITY	HONEYWELL
ELP-362D	ELP-362D	BEACON, EMERGENCY LOCATOR	BENTHOS
EQ131-34	EQ131-34	INDICATOR, TURN & BANK GYRO	JAEGER
F-()	F-()	INDICATOR, RATIO RESISTANCE TYPE	AMETEK
F-1()	F-1()	INDICATOR, SENSITIVE AIRSPEED	KOLLSMAN
F-2	F-2	INDICATOR, AIRSPEED	KOLLSMAN
F-2/4	F-2/4	INDICATOR, SUCTION GAGE	AMETEK
F-4	F-4	FILTER, CENTRAL AIR	JET/AIM
F-40668B	F-40668B	INDICATORS & INDICATORS, DISCHARGE	KIDDE
F55179-41-122	895518-20-017	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
FCS-810	FCS-810	SYSTEM, FLIGHT CONTROL	BENDIX
FDS-840	FDS-840	SYSTEM, FLIGHT DIRECTOR	BENDIX
FG-101()	FG-101()	TRANSMITTER, QUANTITY - FUEL	HONEYWELL
FG120P()	FG120P()	UNIT, FUED QUANTITY TANK	HONEYWELL
FG8()	FG8()	TRANSMITTER, QUANTITY - FUEL	HONEYWELL
FGS-70	FGS-70	SYSTEM, FLIGHT GUIDANCE	BENDIX
G-112A	G-112A	INDICATOR, DIRECTIONAL GYRO	ARC
G-113A,B	G-113A,B	INDICATOR, ATTITUDE GYRO	ARC
G-1162B_	G-1162B	PANEL, VHF NAV/VHF COMM CONTROL	GABLES
G-1444	G-1444	CONTROL, AUDIO	GABLES
G-1584	G-1584	SELECTOR, AUDIO	GABLES
G-1728	G-1728	COMM.	GABLES
G-1956	G-1956	PANEL, AUDIO CONTROL	GABLES
G-1980B	G-1980B	LIGHTS, PANEL	GABLES
G-2092C	G-2092C	COMM., DUAL	GABLES
G-20A	G-20A	SWITCH, PRESSURE - DIFFERENTIAL	HONEYWELL
G-2118	G-2118	PANEL, NAV / COMM. CONTROL	GABLES
G-213A1/B1	G-213A1/B1	INDICATOR, ATTITUDE GYRO	ARC
G-2140	G-2140	PANEL, NAV / DME CONTROL	GABLES
G-2389	G-2389	PANEL, AUDIO CONTROL	GABLES
G-2532	G-2532	NAV / COMM., DUAL	GABLES
G-2573B	G-2573B	PANEL, NAV / COMM. CONTROL	GABLES
G-2587	G-2587	PANEL, AUDIO CONTROL	GABLES
G-2594D	G-2594D	PANEL, AUDIO CONTROL	GABLES
G-2800B	G-2800B	CONTROL, DUAL COMM / NAV.	GABLES
G-2887	G-2887	TRANSPONDER, DUAL ATC	GABLES
G-3()-AB	RCBB	RECEIVER	LEAR
G-3122C	G-3122C	AMPLIFIER, INTERPHONE	GABLES
G-3224	G-3224	CONTROL, DUAL ADF	GABLES
G-3245B	G-3245B	PANEL, AUDIO CONTROL	GABLES
G-3260B	G-3260B	CONTROL, DUAL DME	GABLES
G-3425A	G-3425A	AMPLIFIER, P.A.	GABLES

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
G-3427	G-3427	PANEL, NAV / COMM. CONTROL	GABLES
G-3437	G-3437	PANEL, DME CONTROL	GABLES
G-3441	G-3441	PANEL, ADF CONTROL	GABLES
G-3493	G-3493	HEAD, CONTROL	GABLES
G-3523	G-3523	PANEL, NAV / COMM CONTROL	GABLES
G-3524	G-3524	PANEL, COMM CONTROL	GABLES
G-3803	G-3803	AMPLIFIER, ISOLATION	GABLES
G-3805	G-3805	AMPLIFIER, AUDIO INTERPHONE	GABLES
G-3806	G-3806	AMPLIFIER, SPEAKER	GABLES
G406-4	G406-4	TRANSMITTER, EMERGENCY LOCATOR	ARTEX
G-4189	G-4189	PANEL, ADF CONTROL	GABLES
G-4287	G-4287	HEAD, CONTROL	GABLES
G4304		INDICATOR, PRESSURE	KRATOS
G-4345	G-4345	PANEL, AUDIO CONTROL	GABLES
G-4390	G-4390	CONTROL, NAV / COMM	GABLES
G-4410	G-4410	PANEL, VHF-NAV CONTROL	GABLES
G-4433A	G-4433A	PANEL, ADF CONTROL	GABLES
G-4434A/G-4434	G-4434A/G-4434	PANEL, COMM CONTROL	GABLES
G-4436A	G-4436A	PANEL, ATC CONTROL	GABLES
G-4452	G-4452	PANEL, VHF COMM CONTROL	GABLES
G-4457	G-4457	CONTROL, AUDIO	GABLES
G-4518	G-4518	PANEL, NAV / DME CONTROL	GABLES
G-4518/G-4435	G-4518/G-4435	PANEL, NAV / DME CONTROL	GABLES
G-4553	G-4553	HOLD, DME	GABLES
G-4606A	G-4606A	PANEL, AVIONICS CONTROL	GABLES
G-4606E	G-4606E	PANEL, AVIONICS CONTROL	GABLES
G-4793A	G-4793A	CONTROL, VHF-NAV	GABLES
G-4874-09	G-4874-09	CONTROL, NAV / DME	GABLES
G-4998	G-4998	PANEL, ATC CONTROL	GABLES
G-5178	G-5178	PANEL, ADF CONTROL	GABLES
G-5179	G-5179	PANEL, ADF CONTROL	GABLES
G52339-41-()	G52339-41-()	INDICATOR, TRUE AIRSPEED AND STATIC AIR	KOLLSMAN
G-5492	G-5492	HEAD, ADF CONTROL	GABLES
G55189-41-122	895518-20-015	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
G-5569	G-5569	PANEL, NAV / COMM CONTROL	GABLES
G-5570	G-5570	PANEL, ATC / MKR CONTROL	GABLES
G-5658	G-5658	PANEL, NAV / COMM CONTROL	GABLES
G-5682	G-5682	CONTROL, NAV / COMM	GABLES
G-5706	G-5706	CONTROL, AUDIO	GABLES
G-6101	G-6101	PANEL, AUDIO CONTROL	GABLES
G-610-11	G-610-11	AMPLIFIER, INTERCOM	GABLES
G-6436	G-6436	PANEL, ATC / MKR CONTROL	GABLES
G-6481	G-6481	PANEL, VHF NAV / DME CONTROL	GABLES
G-6770	G-6770	CONTROL, NAV / DME	GABLES
G-6950-02	G-6950-02	PANEL, AVIONICS CONTROL	GABLES
G-7009-02B	G-7009-02B	PANEL, ADF CONTROL	GABLES
G-7018-01A	G-7018-01A	PANEL, ADF CONTROL	GABLES
G-7404-()	G-7470-()	PANELS, RADIO TUNING	GABLES
GA100-0000	GA100	RECORDER, COCKPIT VOICE	L3 COMMUNICATIONS
GA-21080	CDP-10-CM-10	INDICATOR, CABIN DIFFERENTIAL PRESSURE	AEROSONIC
GC361A	GC361A	COMPUTER, RADAR GRAPHICS	BENDIX
GC362A	GC362A	COMPUTER, TCAS GRAPHICS	BENDIX
GE16720-010-()		LIGHT, AFT ANTI-COLLISION/POSITION	GOODRICH
GG205A1		GYRO, TURN AND BANK INDICATOR	KING
GG205A3		GYRO, TURN AND BANK INDICATOR	KING
GG205A4		GYRO, TURN AND BANK INDICATOR	KING
GG205A5		GYRO, TURN AND BANK INDICATOR	KING
GG205B4		GYRO, TURN AND BANK INDICATOR	KING
GG205C1		GYRO, TURN AND BANK INDICATOR	KING
GG205C2		GYRO, TURN AND BANK INDICATOR	KING

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
GG205C4		GYRO, TURN AND BANK INDICATOR	KING
GG2479AA01	TRU-2A/A	TRANSMITTER, GYRO - RATE OF TURN	HONEYWELL
GG2479AB03	GG2479AB03	TRANSMITTER, GYRO - RATE OF TURN	HONEYWELL
GG302A1		GYRO, AIR-DRIVEN DIRECTIONAL	KING
GG302B1		GYRO, AIR-DRIVEN DIRECTIONAL	KING
GG302C1		GYRO, AIR-DRIVEN DIRECTIONAL	KING
GG53A-1	332D-8	INDICATOR, CAGEABLE VERTICAL GYRO	COLLINS
GNC250/300	GNC250/300	RECEIVER, GNC	GARMIN
GNC250XL	GNC250XL	RECEIVER, GNC	GARMIN
GNS530	GNS530	RECEIVER, GNS	GARMIN
GNS530W SERIES	GNS530W SERIES	RECEIVER, GNS	GARMIN
GPD500	GPD500	RECEIVER, GPS	GARMIN
GPS155	GPS155	RECEIVER, GPS	GARMIN
GPS155XL	GPS155XL	RECEIVER, GPS	GARMIN
GPS165	GPS165	RECEIVER, GPS	GARMIN
GTX320A	GTX320A	TRANSPONDER, ATC	GARMIN
GTX327	GTX327	TRANSPONDER, ATC	GARMIN
GTX330, 330D	GTX330, 330D	TRANSPONDER	GARMIN
H140()		INDICATOR, GYROSCOPIC HORIZON	THALES
H153B		TESTER, TEMPERATURE INDICATOR	HOWELL
H1901-1		INDICATOR, TACHOMETER - NG%	HOWELL
H220ABM		INDICATOR, GYROSCOPIC HORIZON	THALES
H262		TESTER, TEMPCAL	HOWELL
H2900K-401()		INDICATOR, TEMPERATURE - DIGITAL	HOWELL
H2900K-401A		INDICATOR, AUTOTEMP	HOWELL
H2900K-401B		INDICATOR/MONITOR, AUTOTEMP	HOWELL
H2900K-416		INDICATOR, TEMPERATURE - DIGITAL (S-61L)	HOWELL
H2900K-416A		INDICATOR, TEMPERATURE - DIGITAL (S-61N)	HOWELL
H2900K-416B		INDICATOR, TEMPERATURE - DIGITAL (S-61N)	HOWELL
H2900K-418		INDICATOR, TEMPERATURE - DIGITAL (206B)	HOWELL
H2900K-436		INDICATOR, TEMPERATURE - DIG. (205A-1)	HOWELL
H2900K-450		INDICATOR, TEMPERATURE - DIG. (206 SER.)	HOWELL
H2949-501		INDICATOR, TEMPERATURE - DIGITAL	HOWELL
H296G-2	H296G-2	APU TESTER	HOWELL
H296G-2A	H296G-2A	APU TESTER	HOWELL
H301()		INDICATOR, GYROSCOPIC HORIZON	THALES
H321()		INDICATOR, GYROSCOPIC HORIZON	THALES
H330()		ASSEMBLY, DIAL	HOWELL
H331()		AMPLIFIER	HOWELL
H341()		INDICATOR, GYROSCOPIC HORIZON	THALES
H394		TESTER, TEMPCAL	HOWELL
H900K-2099		INDICATOR, TEMPERATURE - AUTOTEMP	HOWELL
H900K-238		INDICATOR, AUTOTEK	HOWELL
H900K-238A		INDICATOR, AUTOTEK	HOWELL
H900K-238B		INDICATOR, AUTOTEK	HOWELL
H900K-243		INDICATOR, AUTOTEK	HOWELL
H901-254		INDICATOR, AUTOTEK	HOWELL
H903K-14		INDICATOR, AUTOTEK	HOWELL
H903K-204		INDICATOR, AUTOTEK	HOWELL
H903K-204A		INDICATOR, AUTOTEK	HOWELL
H903K-214		INDICATOR, AUTOTEK	HOWELL
H903K-4		INDICATOR, AUTOTEK	HOWELL
H904-1		INDICATOR, TACHOMETER	HOWELL
H940-226		INDICATOR, TORQUE	HOWELL
HF-9000	HF-9000	RECEIVER-TRANSMITTERS	COLLINS
HG180U()	HG180U()	COMPUTER, AIR DATA	HONEYWELL
HG2001AC20	LASEREF III	REFERENCE UNIT, INERTIAL	HONEYWELL
HG2021GD01		SENSOR UNIT, GLOBAL NAVIGATION	HONEYWELL
HG2021GD02		SENSOR UNIT, GLOBAL NAVIGATION	HONEYWELL
HM510-3	6610-12-16A-0617	ALTIMETER	SMITHS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
HM525-1	6610-12-157-7219	ALTIMETER	SMITHS
HRA-100	HRA-100	ALTIMETER, RADAR	HOFFMAN
HSD-830	HSD-830	SYSTEM, HORIZONTAL SITUATION DISPLAY	BENDIX
HSD-880	HSD-880	SYSTEM, HORIZONTAL SITUATION	BENDIX
HSI-610	HSI-610	INDICATOR, HORIZONTAL SITUATION	JET/AIM
HT-108	HT-108	TESTER, TANK UNIT - FUEL	HONEYWELL
HT-110	HT-110	TESTER, LEAKAGE - TANK UNIT	HONEYWELL
HT-202	HT-202	ADAPTER, TANK UNIT LEAKAGE TESTER	HONEYWELL
I55529-41-121	895518-20-016	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
IA 160		AMPLIFIER, ISOLATION	FOXTRONICS
IC651	IC651	DAMPER, YAW	SIGMA-TEK
IC707	IC707	CONVERTER, VOR / LOC	SIGMA-TEK
IC709	IC709	AMPLIFIER, ELECTRONIC PITCH TRIM	SIGMA-TEK
IC752-100/200		DAMPER, SERIES YAW	CENTURY
ID-250()	ID-250()	INDICATOR, RADIO MAGNETIC	AERONETICS
IN 182A	IN 182A	INDICATOR, COLOR RADAR	BENDIX
IN 862A	IN 862A	SYSTEM, COLOR WEATHER RADAR	BENDIX
IN 862B	IN 862B	INDICATOR, COLOR RADAR	BENDIX
IN-1004A	IN-1004A	INDICATOR, RMI	ARC
IN-2021A	IN-2021A	MULTIFUNCTION COLOR INDICATOR	BENDIX
IN-2025A	IN-2025A	MULTIFUNCTION COLOR INDICATOR	BENDIX
IN-223A	IN-223A	CONVERTER, VOR / LOC	BENDIX
IN-224A	IN-224A	CONVERTER, AVOR / ILS	BENDIX
IN-225/226	IN-225/226	INDICATOR, CONVERTER	BENDIX
IN-403()A	IN-403()A	CONVERTER / INDICATORS	DYNAIR
IN-404A	IN-404A	INDICATOR, RMI	ARC
IN-502A	IN-502A	ANNUNCIATOR, SLAVING	ARC
IN-862A	IN-862A	INDICATOR, COLOR RADAR	BENDIX
ITU100	ITU100	UNIT, IRIDIUM TRANSCEIVER	HONEYWELL
J-2	J-2	SYSTEM, SLAVED GYRO MAGNETIC COMPASS	HONEYWELL
JG-1052()	JG-1052()	INDICATOR, ALTITUDE ALERT	HONEYWELL
JG-120A_	JG120A	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-130A-()	JG-130A-()	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-131A()	JG-131A()	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-132A-1	JG-132A-1	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-140A()	JG-140A()	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-298A()_	JG298A()	INDICATOR, PRESSURE RATIO	HONEYWELL
JG-413B()	JG-413B()	INDICATOR, FUEL QUANTITY	HONEYWELL
JG-7020()	JG-7020()	INDICATOR, FUEL / OIL QUANTITY	HONEYWELL
JG-7021()	JG-7021()	INDICATOR, FUEL / OIL QUANTITY	HONEYWELL
JG-7031A()	JG-7031A()	COMPENSATOR ASSY.	HONEYWELL
JG7044A-()	332D-6/64	INDICATOR, CAGEABLE VERTICAL GYRO	COLLINS
JG-865C()	JG-865C()	INDICATOR, ALTITUDE - ELECTRIC	HONEYWELL
JG-872A	JG-872A	INDICATOR, TEMPERATURE - STATIC AIR	HONEYWELL
JG872B	JG872B	INDICATOR, SERVO - S.A.T.	HONEYWELL
JG873A	JG873A	INDICATOR, MASTER TAS	HONEYWELL
JG873B	JG873B	INDICATOR, SERVO TAS	HONEYWELL
K55189-41-122	89551-20-018	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
KCA-010()	KCA-010()	INDICATOR, COMPASS - STANDBY	SMITHS
KCA0101()		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0102()		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0104()		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0105W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0106W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0107W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0109W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0110W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0112W		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0113()		INDICATOR, COMPASS - STANDBY	SMITHS
KCA0114W		INDICATOR, COMPASS - STANDBY	SMITHS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
KMA 1001		INDICATOR, MACHMETER	SMITHS
KSB-020X		DETECTOR, STALL	SMITHS
KSB-021X		DETECTOR, STALL	SMITHS
KT-A-0-20	FA160341	GAUGE, ABSOLUTE PRESSURE	WALLACE & TIERNAN
KTD 0701()		INDICATOR, PERCENT TACHOMETER	SMITHS
KTD 0704()		INDICATOR, PERCENT TACHOMETER	SMITHS
L2	L2	AUTOPILOT	SMITHS
L4	L4	SYSTEM, STABILITY AUGMENTATION	HAMILTON STANDARD
L-5	L-5	AUTOPILOT	SMITHS
L55189-41-222	895518-20-019	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
L-7()	L-7()	INDICATOR, SENSITIVE MAXIMUM ALLOWABLE	KOLLSMAN
LA26		AMPLIFIERS, FUEL CONTENTS GAUGE	SMITHS
LD08	LD08	DIMMER, LAMP	NAT
LD12	LD12	DIMMER, LAMP	NAT
LG-14C	LG-14C	TRANSDUCER, PRESSURE RATIO	HONEYWELL
LPE-22251-2()	F-2*	INDICATOR, AIRSPEED (50-700 MPH)	BENDIX
LR-6A-1	LR-6A-1	RECEIVER, VHF	LEAR
LRA-6A	LRA-6A	ADAPTER, LOW FREQUENCY	LEAR
LT-100	LT-100	CONVERTER, DC TO DC	KGS ELECTRONICS
LT-3100	LT-3100	CONVERTER, DC TO DC	KGS ELECTRONICS
LT-48()	LT-48()	SUPPLIES, LIGHT DIMMER POWER	KGS ELECTRONICS
LT-50	LT-50	SUPPLY, LIGHT DIMMER POWER SUPPLY	KGS ELECTRONICS
LT-52A	LT-52A	CONVERTER, DC TO DC	KGS ELECTRONICS
LT-55()	LT-55()	DC/DC CONVERTER REG. VAR. OUTPUT	KGS ELECTRONICS
LT-70	LT-70	CONVERTER, DC TO DC	KGS ELECTRONICS
LT-73	LT-73	CONVERTER, DC TO DC	KGS ELECTRONICS
LTD-331	LTD-331	VIBRATOR, STRAP-ON	SENSONICS
LTH-11-B-3		SYNCHRO, LINEAR GENERATOR	CLIFTON PRECISION
M1035	M1035	SYSTEM, AUDIO	BAKER ELECTRONICS
M1035 SERIES	M1035 SERIES	SYSTEM, AUDIO	BAKER ELECTRONICS
M1035()	M1035()	SYSTEM, AUDIO	BAKER ELECTRONICS
M1035-A167-EJF()	M1035-A167-EJF()	SYSTEM, AUDIO	BAKER ELECTRONICS
M1035-CHKF-JLJ2		SYSTEM, AUDIO	BAKER ELECTRONICS
M1035K-2	M1035K-2	SYSTEM, AUDIO	BAKER ELECTRONICS
M1045()	M1045()	SYSTEM, AUDIO	BAKER ELECTRONICS
M1049C	M1049C	AMPLIFIER PCB	BAKER ELECTRONICS
M1050	M1050	AMPLIFIER & CHIME, CABIN ADDRESS	BAKER ELECTRONICS
M1050()	M1050()	SYSTEM, AUDIO	BAKER ELECTRONICS
M1050-()-00	M1050-()-00	SYSTEM, AUDIO	BAKER ELECTRONICS
M1050S	M1050S	SYSTEM, AUDIO	BAKER ELECTRONICS
M1052A	M1052A	INTERPHONE AMPLIFIER	BAKER ELECTRONICS
M1080 A, B, C, D	M1080 A, B, C, D	M1080 A, B, C, D FINAL ASSY	BAKER ELECTRONICS
M1080()	M1080()	M1080() ADJUSTMENT LOCATIONS	BAKER ELECTRONICS
M1080A	M1080A	M1080A OUTLINE DRAWING	BAKER ELECTRONICS
M1080A/B	M1080A/B	M1080A OR B SCHEMATIC	BAKER ELECTRONICS
M1080C OR D	M1080 C OR D	M1080C OR D SCHEMATIC	BAKER ELECTRONICS
M1084()	M1084()	STEREO PRE-AMPLIFIER AND LINE DRIVER	BAKER ELECTRONICS
M1085()	M1085()____	SYSTEM INTERCONNECT - M1085()	BAKER ELECTRONICS
M1086()	M1086()	STEREO PRE-AMPLIFIER AND LINE DRIVER	BAKER ELECTRONICS
M108X A, B, C, D	M108X A, B, C, D	M108X A, B, C, D SCHEMATIC	BAKER ELECTRONICS
M108X()	M1108X()	STEREO PRE-AMPLIFIER	BAKER ELECTRONICS
M1090	M1090	ADAPTER, CVR	BAKER ELECTRONICS
M1285()	M1285()	CHIME/TONE WARNING SYSTEM	BAKER ELECTRONICS
M2153		SWITCH, ANEROID	NEGRETTI & ZAMBRA LTD
M3075-()	M3075-()	INDICATOR, TURN & SLIP	KELLY
M3520	M3520	INDICATOR, TURN & SLIP	KELLY
M3562-01	M3540-1	INDICATOR, TURN & SLIP	KELLY
M55189-41-122	895518-20-022	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
MARK 2 ASTRO	MARK 2 ASTRO	COMPASS	KOLLSMAN
MB-4050A	MB-4050A	RECEIVER, MARKER BEACON	DYNAIR

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
MC-1	MC-1	GYROSCOPE, RATE SWITCHING	KELLY
MD-4()	MD-4()	INDICATOR, TURN & SLIP	KELLY
MD-8()	MD-8()	INDICATOR, TURN & SLIP	KELLY
ME406	ME406	EMERGENCY LOCATOR TRANSMITTER	ARTEX
ME406HM	ME406HM	EMERGENCY LOCATOR TRANSMITTER	ARTEX
MG112A1		ACTUATOR, TRIM	KING
MG112B1		ACTUATOR, TRIM	KING
MG113A1		ACTUATOR, ROTARY ELECTROPNEUMATIC	KING
MG113A2		ACTUATOR, ROTARY ELECTROPNEUMATIC	KING
MG113A3		ACTUATOR, ROTARY ELECTROPNEUMATIC	KING
MG113E1		ACTUATOR, ROTARY ELECTROPNEUMATIC	KING
MG113E3		ACTUATOR, ROTARY ELECTROPNEUMATIC	KING
MGE130-200		ASSEMBLY, MOTOR-GENERATOR	SMITHS
MH-100	MH-100	TEST STAND, SYSTEM - FUEL INDICATOR	HONEYWELL
MI-585008		ANTENNA	HONEYWELL
MI-585009		RECEIVER-TRANSMITTER	HONEYWELL
MI-585011(-)		INDICATOR	HONEYWELL
MI-585015(-)		INTERROGATOR, DME	HONEYWELL
MI-585016(-)_		INDICATOR, DISTANCE	HONEYWELL
MI-585017(-)		INDICATOR, DISTANCE / GROUND-SPEED	HONEYWELL
MI-585022(-)		RECEIVER-TRANSMITTER	HONEYWELL
MI-585023(-)_		INDICATOR	HONEYWELL
MI-585024(-)_		ANTENNA	HONEYWELL
MI-585025		ANTENNA	HONEYWELL
MI-585026		ANTENNA	HONEYWELL
MI-585034(-)		ANTENNA	HONEYWELL
MI-585035_		RECEIVER-TRANSMITTER	HONEYWELL
MI-585036(-)		INDICATOR	HONEYWELL
MI-585072(-)		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MI-585077(-)		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MI-585134(-)		INDICATOR, DIGITAL	HONEYWELL
MI-585135(-)		RECEIVER-TRANSMITTER	HONEYWELL
MI-585136(-)		ANTENNA	HONEYWELL
MI-585147(-)_		INDICATOR, DIGITAL	HONEYWELL
MI-585148(-)_		ANTENNA	HONEYWELL
MI-585149(-)		RECEIVER-TRANSMITTER	HONEYWELL
MI-585150_		INDICATOR, DIGITAL	HONEYWELL
MI-585151(-)		ANTENNA	HONEYWELL
MI-585152(-)		RECEIVER-TRANSMITTER	HONEYWELL
MI-585153(-)		INDICATOR, CONSOLE	HONEYWELL
MI-585154_		ANTENNA	HONEYWELL
MI-585161	PRIMUS-90 WXD	RECEIVER/TRANSMITTER, RADAR	HONEYWELL
MI-585161-1	PRIMUS-90 WXD	INDICATOR, RADAR - DIGITAL	HONEYWELL
MI-585162	PRIMUS-90 WXD	INDICATOR, RADAR - DIGITAL	HONEYWELL
MI-585164	PRIMUS-90 WXD	ANTENNA, PEDESTAL - RADAR	HONEYWELL
MI-585164(-)	PRIMUS-90 WXD	ANTENNA, PEDESTAL - RADAR	HONEYWELL
MI-585164(-)		ANTENNA	HONEYWELL
MI-585200(-)	RT-4001	RECEIVER-TRANSMITTER	HONEYWELL
MI-585201	DI-4001	INDICATOR, DIGITAL	HONEYWELL
MI-585201(-)	DI-4001	INDICATOR, DIGITAL	HONEYWELL
MI-585201-1	DI-4001	INDICATOR, DIGITAL	HONEYWELL
MI-585201-2	DI-4001	INDICATOR, DIGITAL	HONEYWELL
MI-585201-3	DI-4001	INDICATOR, DIGITAL	HONEYWELL
MI-585202	AP-4001	PEDESTAL, ANTENNA	HONEYWELL
MI-585202(-)	AP-4001	ANTENNA	HONEYWELL
MI-585222-1	RT-2002	RECEIVER-TRANSMITTER	HONEYWELL
MI-585224(-)	AP-3001	ANTENNA	HONEYWELL
MI-585226	DI-9003	INDICATOR, DIGITAL	HONEYWELL
MI-585226-2	DI-900B	INDICATOR, DIGITAL	HONEYWELL
MI585245/1	KB-3001	KEYBOARD, PILOT ENTRY	HONEYWELL

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
MI-585272/-X	DATA NAV III	ASSEMBLY, CONTROL PANEL	HONEYWELL
MI-585277-()	DI-2007	INDICATOR, DIGITAL	HONEYWELL
MI-585280-()	RTA-1003	RECEIVER-TRANSMITTER-ANTENNA	HONEYWELL
MI-585291/-X	DATA NAV III	ASSEMBLY, CONTROL PANEL	HONEYWELL
MI-585298/-X	DATA NAV III	ASSEMBLY, CONTROL PANEL	HONEYWELL
MI5852XX-X	DNCP100X	UNITS, CONTROL	HONEYWELL
MI5852XX-XX	DNCP100X	PANEL, CONTROL	HONEYWELL
MI-585300-()	RT-5001	RECEIVER-TRANSMITTER	HONEYWELL
MI-585300-6	RT-900B	RECEIVER-TRANSMITTER	HONEYWELL
MI585316-X	DNC1002	COMPUTER, INTERFACE	HONEYWELL
MI585316-XX	DNC1002	COMPUTER, INTERFACE	HONEYWELL
MI-585343-()	DI-4002	INDICATOR, DIGITAL	HONEYWELL
MI-585350-34	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-35	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-36	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-37	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-4	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-5	WR-800	TRANSMITTER, WEATHER RADAR RECEIVER	HONEYWELL
MI-585350-6	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585350-7	WR-800	RECEIVER-TRANSMITTER	HONEYWELL
MI-585351-2	WI-800	INDICATOR, DIGITAL	HONEYWELL
MI-585353	WA-800	ANTENNA, WEATHER RADAR	HONEYWELL
MI-585398/-X	DATA NAV III	ASSEMBLY, CONTROL PANEL	HONEYWELL
MI-585399/-X	DATA NAV III	ASSEMBLY, CONTROL PANEL	HONEYWELL
MI58539X-XX	DNCP100X	PANEL, CONTROL	HONEYWELL
MI-585438-()	DI-1007	INDICATOR, DIGITAL COLOR WEATHER RADAR	HONEYWELL
MI-585439-()	DI-1008	INDICATOR, DIGITAL COLOR WEATHER RADAR	HONEYWELL
MI-591003-()		RECEIVER-TRANSMITTER	HONEYWELL
MI-591005-()		INDICATOR, CONSOLE	HONEYWELL
MI-591011-()		ANTENNA	HONEYWELL
MI-591016-()		RECEIVER-TRANSMITTER	HONEYWELL
MI-591018-()		INDICATOR, CONSOLE	HONEYWELL
MI-591020		ANTENNA	HONEYWELL
MI-591020-()	AVQ-20	INDICATOR, DISPLAY STORAGE TUBE	HONEYWELL
MI-591029-()		INDICATOR, CONSOLE	HONEYWELL
MI-591038-()	AVQ-55	INDICATOR, DISPLAY STORAGE TUBE	HONEYWELL
MI-591083-()		INTERROGATOR, DME	HONEYWELL
MI-591084-()		INDICATOR, DME DISTANCE	HONEYWELL
MI-591085-()		INDICATOR, DISTANCE / GROUND SPEED	HONEYWELL
MI-591089		UNIT, DME TRANSPONDER ANTENNA	HONEYWELL
MI-591089-1		UNIT, DME / TRANSPONDER ANTENNA	HONEYWELL
MI-592020		ANTENNA	HONEYWELL
MI-592021		RECEIVER-TRANSMITTER	HONEYWELL
MI-592022-()		INDICATOR	HONEYWELL
MI-592100-()		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MI-592127		ANTENNA, NAV / COMM	HONEYWELL
MI-592128		ANTENNA, VHF COMM	HONEYWELL
MI-592128-()		ANTENNA, VHF COMM	HONEYWELL
MI-592129		ANTENNA, VHF NAV	HONEYWELL
MI-592130		ANTENNA, MARKER BEACON	HONEYWELL
MI-592132		INDICATOR, MARKER BEACON	HONEYWELL
MI-592177-()		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MI-592178-()		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MI-592179-()		INDICATOR, VHF NAVIGATION RECEIVER	HONEYWELL
MM-OC19A/D		INDICATOR, TURBINE TEMPERATURE	AMETEK
MOD. ()100	MOD. ()100	ILLUSTRATED PARTS CATALOGUE	BEECHCRAFT
MODEL 100	MODEL 100	SYSTEM, PITOT-STATIC PRESSURE	BEECHCRAFT
MS18098-150		VOLT-AMMETER, DUAL POINTER, DIRECT	AMETEX
MS18098-300		VOLT-AMMETER, DUAL POINTER, DIRECT	AMETEX
MS18098-450		VOLT-AMMETER, DUAL POINTER, DIRECT	AMETEX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
MS28010-1		INDICATOR, MULTIPURPOSE PRESSURE	AMETEK
MS28043-1		UNITS, ENGINE GAGE	EDISON
MS28043-2		UNITS, ENGINE GAGE	EDISON
N15F210B	N15F210B	BEACON, UNDERWATER ACOUSTIC	DUKANE CORP.
N30A5B	N30A5B	SYSTEM, UNDERWATER ACOUSTIC LOCATOR	DUKANE CORP.
N55189-41-122	895518-20-023	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
NAVALERT2	NAVALERT2	INDICATOR, NAVIGATION	ICARUS
NPX138	NPX138	RADIO, PANEL MOUNT	NAT
NPX138-9	NPX138-9	BACKLIGHT SUB-ASSEMBLY	NAT
NPX138N-050	NPX138N-050	BACKLIGHT SUB-ASSEMBLY	NAT
NR-402()A	NR-402()A	RECEIVERS, NAVIGATION	DYNAIR
NSD-360	NSD-360	SYSTEM, COMPASS	SIGMA-TEK
NT136/150	NT136/150	TRANSCEIVERS, VHF	NAT
NT403/450/470	NT403/450/470	TRANSCEIVERS, UHF	NAT
NT403-NT806	NT403-NT806	TRANSCEIVER, UHF	NAT
O-1	O-1	CONVERTER, OMNI	PIPER
O-1 / OL-1	O-1 / OL-1	CONVERTER, OMNI	PIPER
Old Sperry Type	AN5735	INDICATOR, DIRECTIONAL GYRO	SIGMA-TEK
Old Sperry Type	AN5736	INDICATOR, ATTITUDE GYRO	SIGMA-TEK
P-()	P-()	SYSTEMS, AUTOPILOT	ASTRONAUTICS
P10/11	P10/11	INVERTER	JET/AIM
P-20	P-20	INVERTER	AIM
P-20	P-20	INVERTER	JET/AIM
P-21	P-21	INVERTER	JET/AIM
P-904-SG		SWITCH, DIFFERENTIAL PRESSURE	AEROTEC
PA040401		INDICATOR, MAXIMUM ALLOWABLE AIRSPEED	AEROSONIC
PA110/220	PA110/220	SYSTEMS, LOUDHAILER / PA	NAT
PA110/220	PA110/220	SYSTEMS, PA	NAT
PB08	PB08	SWITCH, PUSHBUTTON	NAT
PBS-250	PBS-250	SYSTEM, DIGITAL PASSENGER BRIEFING	HEADS UP
PBS400	PBS400	SYSTEM, DIGITAL PASSENGER BRIEFING	HEADS UP
PC-15H()	PC-15H()	INVERTER, STATIC	FLITE-TRONICS
PC-17	PC-17	INVERTER, STATIC	FLITE-TRONICS
PC-350	PC-350	INVERTER, 350 VA STATIC	HONEYWELL
PC-50	PC-50	INVERTER, STATIC	FLITE-TRONICS
PC-600	PC-600	SYSTEM, FUEL MANAGEMENT	FOXBORO
PC-800	PC-800	CONDITIONER, SIGNAL - FUEL	FOXBORO
PDCR 120/WL		TRANSDUCER, TORQUE PRESSURE	DRUCK
PG51A1		CONTROL, ALTITUDE	KING
PM-1	PM-1	BEACON, MARKER	PIPER
PRIMUS-50 WXD	PRIMUS-50 WXD	RADAR, AIRBORNE DIGITAL WEATHER	HONEYWELL
PRIMUS-50 WXD	PRIMUS-50 WXD	RADAR, AIRBORNE DIGITAL WEATHER	HONEYWELL
PRO-360	PRO-360	PROTRACTOR, DIGITAL	KELL-STROM
PS-240	PS-240	SUPPLY, POWER	E.M.P. ELECTRONICS
PW/0706 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0707 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0708 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0711 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0718 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0720 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0721 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0722 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0723 KTD/CP/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0725 KTD/CP/2		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0726 KTD/MS/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/0729 KTD/1		INDICATOR, PERCENT TACHOMETER	SMITHS
PW/727MV/BU/44/700		INDICATOR, TEMPERATURE - T5	SMITHS
PW/727MV/BU/44/700		INDICATOR, TEMPERATURE - T5	SMITHS
R 6885-20M		SWITCH, PRESSURE	EATON
R-2200	R-2200	SYSTEM, WARNING	SAFE FLIGHT INSTRUMENT

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
R-552/622	R-552/622	RECEIVER, NAVIGATION	SIGMA-TEK
R-552/662	R-552/662	RECEIVER, NAVIGATION	SIGMA-TEK
R-554/664	R-554/664	RECEIVER, NAVIGATION - W/ GLIDESLOPE	SIGMA-TEK
R-556	R-556	FINDER, AUTOMATIC DIRECTIONAL	SIGMA-TEK
R6607-1-41		SWITCH, PRESSURE	EATON
R6607A		SWITCH, PRESSURE	EATON
R88-1-2662-10	5815	INDICATOR, TEMPERATURE - THERMOCOUPLE	HICKOK
R88-1-2664-10	5816	INDICATOR, TEMPERATURE - THERMOCOUPLE	HICKOK
RA-21A	RA-21A	RECEIVER, VHF	BENDIX
RB-SERIES	RB-SERIES	CONVERTER, DC TO DC	KGS ELECTRONICS
RC-20-ILB		INDICATOR, RATE OF CLIMB	AEROSONIC
RC30V		INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC30V		INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC30V10		INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC-30-VIL		INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC-60-VIL-1		INDICATOR, VERTICAL VELOCITY	AEROSONIC
RC-75	RC-75	CONVERTER, RMI	JET/AIM
RCA10	RCA10	INDICATOR, DIRECTIONAL GYROSCOPE	KELLY
RCA11	RCA11	INDICATOR, DIRECTIONAL GYROSCOPE	KELLY
RCA11A	RCA11A	INDICATOR, DIRECTIONAL GYROSCOPE	KELLY
RCA11D	RCA11D	INDICATOR, DIRECTIONAL GYROSCOPE	KELLY
RCA12	RCA12	INDICATOR, TURN & BANK	KELLY
RCA15()	RCA15A/B/C	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15()	RCA15A/B/C	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15A-1	RCA15A-1	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15AK	RCA15AK	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15BK()	RCA15BK()	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15BK-4	RCA15BK-4	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15C()	RCA15C()	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA15CM()	RCA15CM()	INDICATOR, ELECTRIC DIRECTIONAL	KELLY
RCA20	RCA20	INDICATOR, HORIZON GYROSCOPE	KELLY
RCA21	RCA21	INDICATOR, HORIZON GYROSCOPE	KELLY
RCA22(-)	RCA22(-)	INDICATOR, HORIZON GYROSCOPE	KELLY
RCA25(-)(-)	RCA25(-)(-)	INDICATOR, ELECTRIC ATTITUDE GYROSCOPE	KELLY
RCA26(-)(-)	RCA26(-)(-)	INDICATOR, ELECTRIC ATTITUDE GYROSCOPE	KELLY
RCA28	RCA28	INDICATOR, TURN & BANK	KELLY
RCA30	RCA30	INDICATOR, TURN & BANK	KELLY
RCA35	RCA35	INDICATOR, TURN & BANK	KELLY
RCA56	RCA56	INDICATOR, TURN & BANK	KELLY
RCA60()	RCA60()	INDICATOR, TURN & SLIP	KELLY
RCA70-01	RCA70-01	INDICATOR, TORQUE	KELLY
RCA80	RCA80	INDICATOR, TURN COORDINATOR	KELLY
RCA82A	RCA82A	INDICATOR, TURN COORDINATOR	KELLY
RCA83A	RCA83A	INDICATOR, TURN COORDINATOR	KELLY
RCS-20-10		INDICATOR, RATE OF CLIMB	AEROSONIC
RDR-100	RDR-100	SYSTEM, WEATHER AVOIDANCE RADAR	BENDIX
RDR1100/IN2027A	RDR1100/IN2027A	SYSTEM, WEATHER RADAR	BENDIX
RDR-1150()	RDR-1150()	SYSTEMS, WEATHER RADAR	BENDIX
RDR-1200/140	RDR-1200/140	SYSTEMS, WEATHER RADAR	BENDIX
RDR1200/IN2021A	RDR1200/IN2021A	SYSTEM, WEATHER RADAR	BENDIX
RDR-1200/IN-2021A		WEATHER RADAR SYSTEM	BENDIX
RDR-130	RDR-130	SYSTEM, WEATHER RADAR	BENDIX
RDR1300/IN2022A	RDR1300/IN2022A	SYSTEM, WEATHER RADAR	BENDIX
RDR1300/IN2028A	RDR1300/IN2028A	SYSTEM, WEATHER RADAR	BENDIX
RDR1400B/IN2025	RDR1400B/IN2025	WEATHER RADAR SYSTEM	BENDIX
RDR-1400C	RDR-1400C	SYSTEM, WEATHER RADAR	BENDIX
RDR150/IN2026A	RDR150/IN2026A	SYSTEM, WEATHER RADAR	BENDIX
RDR-160XD	RDR-160XD	SYSTEM, WEATHER RADAR	BENDIX
RDR2000	RDR2000	SYSTEM, COLOR WEATHER RADAR	BENDIX
RDR-230HP	RDR-230HP	SYSTEM, WEATHER RADAR	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
RDS 82	RDS 82	SYSTEM, WEATHER RADAR	BENDIX
RESCU 77C	RESCU 77C	TRANSMITTER, EMERGENCY LOCATOR	GARRETT
RG-203	RG-203	GYRO, RATE	HONEYWELL
RL 1350AM/MS/3	1350AM	INDICATOR, COUNTER POINTER ALTIMETER	SMITHS
RL/1101AM/MS/10		INDICATOR, SERVO ALTIMETER	SMITHS
RL/801AM/MS/3,5,7	800AM	INDICATOR, ALTIMETER	SMITHS
RMI810	RMI-810	INDICATOR, RMI CONVERTER	JET/AIM
RN-222	RN-222	RECEIVER, NAV	BENDIX
RNS3400	RNS3400	SYSTEM, AREA NAVIGATION	KING
ROSE/RI	ROSE/RI	READ-OUT SUPPORT EQUIPMENT/RECORDER	LORAL
RS 861A	RS 861A	SENSOR, RADAR	BENDIX
RS12	RS12	SWITCH, REMOTE	NAT
RS12/RS24	RS12/RS24	SWITCH, REMOTE	NAT
RS16 SERIES	RS16 SERIES	SWITCH, REMOTE	NAT
RS24-020	RS24-020	SWITCH, REMOTE	NAT
RS-861A	RS-861A	SENSOR, RADAR	BENDIX
RT-1060A	RT-1060A	TRANSPONDER	HONEYWELL
RT-10E()	RT-10E()	TRANSMITTER, VHF	LEAR
RT-377A	RT-377A	EQUIPMENT, DISTANCE MEASURING	HONEYWELL
RT-377B	RT-377B	EQUIPMENT, DISTANCE MEASURING	HONEYWELL
RT-4010A	RT-4010A	TRANSCEIVER, COMMUNICATIONS	DYNAIR
RT-551	RT-551	TRANSCEIVER, COMMUNICATION	SIGMA-TEK
RT-551	RT-551	TRANSCEIVER, COMM	SIGMA-TEK
RT-553	RT-553	TRANSCEIVER, NAV / COMM	SIGMA-TEK
RT-553()	RT-553()	NAV / COMM	SIGMA-TEK
RT-563()	RT-563()	SYSTEM, NAV / COMM	SIGMA-TEK
RT-661	RT-661	TRANSCEIVER, COMM	SIGMA-TEK
RT-667/777	RT-667/777	TRANSPONDERS, ATC	SIGMA-TEK
RT-667/777	RT-667/777	TRANSPONDERS, ATC	SIGMA-TEK
S-()	S-()	CONTROLS, DIRECTIONAL GYRO	HONEYWELL
S()-()000-00-()	F1000	RECORDER, FLIGHT DATA - SOLID-STATE	LORAL
S100-0080-()	A100S	RECORDER, SOLID STATE COCKPIT VOICE	L3 COMMUNICATIONS
S100-0080-()	A100S	RECORDER, COCKPUT VOICE - SOLID-STATE	LORAL
S1032	S1032	AMPLIFIER, 15 WATT	BAKER ELECTRONICS
S1042	S1042	INTERCOM, 4/8 POSITION	BAKER ELECTRONICS
S1046	S1046	SYSTEM, AUDIO	BAKER ELECTRONICS
S1047()	S1047()	AMPLIFIER, PAGING	BAKER ELECTRONICS
S-15-KAW		INDICATOR, AIRSPEED	AEROSONIC
S-15-KILR-1	S-15-KIL SERIES	INDICATOR, AIRSPEED	AEROSONIC
S200-XXXX-XX	A200S	RECORDER, SOLID STATE COCKPIT	L3 COMMUNICATIONS
S-61		INDICATION, TORQUE	BENDIX
S6155-61198-102		SENSOR, FREQUENCY	SIKORSKY AIRCRAFT
S6190-60045-4		PANEL, CHANNEL MONITOR	SIKORSKY AIRCRAFT
S6190-60060		PANEL, AUTO FLIGHT CONTROLS	SIKORSKY AIRCRAFT
S6192-61090-1		AMPLIFIER, SINGLE CHANNEL LAG	SIKORSKY AIRCRAFT
S-61N	S-61N	AIRCRAFT	SIKORSKY AIRCRAFT
S76		COMPASS SWING PROCEDURE	SIKORSKY AIRCRAFT
SA110120W	SS50	INVERTER, STATIC	KGS ELECTRONICS
SA20-()		INDICATOR, TORQUE	SERV AERO
SA21-()		TRANSMITTER, TORQUE	SERV AERO
SA23-()		GAUGE, THREE-IN-ONE	SERV AERO
SA24-()		INDICATOR, PROP TACH	SERV AERO
SA26-()		TACH, GAS GENERATOR	SERV AERO
SA28-()		INDICATOR, INTER-TURBINE TEMPERATURE	SERV AERO
SA-30	SA-30	AMPLIFIER, RMI SERVO	JET/AIM
SA330/332		EQUIPMENT LIST	AEROSPATIALE
SA341	SA341	INSTURMENTS, ENGINE - GAZELLE	AEROSPATIALE
SA341	SA341	SERVICE BULLETIN	AEROSPATIALE
SC-12()	SC-12()	CONVERTER, RMI	JET/AIM
SCD130-1-2		SYSTEM, ADRESS/CABIN INTERPHONE	AVTECH

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
SD 48A-1		YAW CALIBRATOR	BENDIX
SEDL-OC2P		INDICATOR, ENGINE TORQUE	AMETEK
SEDL-OC2S		INDICATOR, ENGINE TORQUE	AMETEK
SEDL-OC329A		INDICATOR, DUAL TACHOMETER ENGINE ROTOR	AMETEK
SEL-019()		INDICATOR, TURBINE OUTLET TEMPERATURE	AMETEK
SEL-019A()		INDICATOR, TURBINE TEMPERATURE	AMETEK
SEL-019B()		INDICATOR, TURBINE OUTLET TEMPERATURE	AMETEK
SEL-019D()		INDICATOR, TURBINE OUTLET TEMPERATURE	AMETEK
SEL-019ED		INDICATOR, TURBINE OUTLET TEMPERATURE	AMETEK
SEL-OC19()		INDICATOR, EXHAUST GAS TEMPERATURE	AMETEK
SEL-OC19AB		INDICATOR, TURBINE TEMPERATURE	AMETEK
SEL-OC19AM		INDICATOR, TURBINE TEMPERATURE	AMETEK
SEL-OC19AP		INDICATOR, TURBINE TEMPERATURE	AMETEK
SEL-OC19DW		INDICATOR, INTERTURBINE TEMPERATURE	AMETEK
SEL-OC19EK		INDICATOR, INTERTURBINE TEMPERATURE	AMETEK
SEL-OC19EL, -1		INDICATOR, TEMPERATURE, TIT	AMETEK
SEL-OC19K		INDICATOR, TURBINE TEMPERATURE	AMETEK
SEL-OC29DA		INDICATOR, NH% RPM	AMETEK
SEL-OC29DF		INDICATOR, PROP RPM	AMETEK
SEL-OC29DJ		INDICATOR, NL% RPM	AMETEK
SEL-OC29DK		INDICATOR, NH% RPM	AMETEK
SEL-OC29F		INDICATOR, GAS GENERATOR TACHOMETER	AMETEK
SEL-OC2N		INDICATOR, TORQUE	AMETEK
SEL-OC8G		INDICATOR, FUEL FLOW	AMETEK
SEL-OC8J		INDICATOR, FUEL FLOW	AMETEK
SETL-OC329A		INDICATOR, TRIPLE TACHOMETER ENGINE	AMETEK
SETL-OC420F		INDICATOR, CABIN PRESSURIZATION	AMETEK
SG 832B	SG-832B	GYRO, REMOTE SLAVED	BENDIX
SG28A1		SWITCH, DIFFERENTIAL PRESSURE	KING
SG28A3		SWITCH, DIFFERENTIAL PRESSURE	KING
SHARC 7A / 7C / 7K	SHARC 7A / 7C / 7K	BATTERY	LEIGH
SHZ-212	SHZ-212	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
SHZ-212-3	SHZ-212-3	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
SHZ-222	SHZ-222	SYSTEM, INTEGRATED FLIGHT CONTROL	HONEYWELL
SI2002		SPECIFICATION, PROCUREMENT	JET ELECTRONICS
SIZE11	SIZE11	INDICATOR, SYNCHRO TORQUE TRANSMITTERS &	AMETEK
SK-30-MC-IL-3		INDICATOR, AIRSPEED	AEROSONIC
SKY497	SKY497	KIT, TRAFFIC ADVISORY SYSTEM INSTALLATION	L3 COMMUNICATIONS
SL1010-55023-13-N00		INDICATOR, TACHOMETER - MECHANICAL	SUPERIOR LABS
SLZ8126		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ8826_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ906X		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9155_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ91XX		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9200()-()_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9211_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ924X_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9464A-()_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9504A_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ9688A_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SLZ98XXA_		INDICATOR, INERTIAL-LEAD VERTICAL SPEED	TELEDYNE
SN3308		SN3308	SANDEL
SP-3	SP-3	SYSTEM, AUTOMATIC PILOT	HONEYWELL
SPC-10 (D TO U)	SPC-10 (D TO U)	INVERTER, STATIC	KGS ELECTRONICS
SPC-10()	SPC-10()	INVERTER, STATIC	KGS ELECTRONICS
SPC-10()	SPC-10()	INVERTER, STATIC	KGS ELECTRONICS
SPC-10(V)	SPC-10(V)	INVERTER, STATIC	KGS ELECTRONICS
SPC-1308-3	SPC-1308-3	CHANGER, FREQUENCY	KGS ELECTRONICS
SPC-1606()-3	SPC-1606()-3	CHANGER, FREQUENCY	KGS ELECTRONICS
SPC-38()	SPC-38()	INVERTER, STATIC	KGS ELECTRONICS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
SPC-6-1000-3PH	SPC-6-1000-3PH	CHANGER, FREQUENCY	KGS ELECTRONICS
SPC-6-750()	SPC-6-750()	CHANGER, FREQUENCY	KGS ELECTRONICS
SPC-75(A)	SPC-75(A)	INVERTER, STATIC	KGS ELECTRONICS
SPC-75(B)	SPC-75(B)	INVERTER, STATIC	KGS ELECTRONICS
SPDD2100		SWITCH, PRESSURE	CLIFTON PRECISION
SPDD-2100		SWITCH, PRESSURE	BENDIX
SPH-1606()-3	SPH-1606()-3	FREQUENCY CHANGER, STATIC	KGS ELECTRONICS
SPI-401/402	SPI-401/402	SYSTEM, FLIGHT DIRECTOR INSTRUMENT	HONEYWELL
SPI-80/81	SPI-80/81	SYSTEM, FLIGHT DIRECTOR INSTRUMENT	HONEYWELL
SPS-1307()	SPS-1307()	INVERTER, STATIC	KGS ELECTRONICS
SPS-1607()	SPS-1607()	INVERTER, STATIC	KGS ELECTRONICS
SPS-306	SPS-306	INVERTER, STATIC	KGS ELECTRONICS
SPS-5()	SPS-5()	INVERTER, STATIC	KGS ELECTRONICS
SPS-5()	SPS-5()	INVERTER, STATIC	KGS ELECTRONICS
SPS-60()	SPS-60()	INVERTER, STATIC	KGS ELECTRONICS
SPS-750()	SPS-750()	INVERTER, STATIC	KGS ELECTRONICS
SPS-750()	SPS-750()	INVERTER, STATIC	KGS ELECTRONICS
SR-15()A		INDICATOR, PRESSURE	AMETEK
SR-153C		INDICATOR, SYNCHRO	AMETEK
SR-154C		INDICATOR, PRESSURE	AMETEK
SR-2()		INDICATOR, TORQUE	AMETEK
SR-2A()		INDICATOR, SYNCHRO	AMETEK
SR-2A()		INDICATOR, TORQUE	AMETEK
SR-2A()		INDICATOR, TORQUE	AMETEK
SR-2AE		INDICATOR, TORQUE	AMETEK
SR-2AM		INDICATOR, TORQUE	AMETEK
SR-2AP		INDICATOR, TORQUE	AMETEK
SR-3()		INDICATOR, PRESSURE	AMETEK
SR-4()		INDICATOR, SYNCHRO	AMETEK
SR-4AJ		INDICATOR, TORQUE PRESSURE	AMETEK
SR-5()		INDICATOR, SYNCHRO	AMETEK
SR-6A	MS28010-1	INDICATOR, SYNCHRO - MULTI-PURPOSE	AMETEK
SR-7A		INDICATOR, PRESSURE	AMETEK
SR-8B		INDICATOR, PRESSURE	AMETEK
SR-94()		INDICATOR, PRESSURE	AMETEK
SR-9A		INDICATOR, PRESSURE	AMETEK
SRDL-0C12F		INDICATOR, PRESSURE - DUAL HYDRAULIC	AMETEK
SRDL-6D		INDICATOR, DUAL PRESSURE	AMETEK
SRDL-7G		INDICATOR, DUAL HYDRAULIC BREAK PRESSURE	AMETEK
SRDL-7H		INDICATOR, DUAL HYDRAULIC SYSTEM	AMETEK
SRL-0		INDICATOR, 2INCH SYNCHRO	AMETEK
SRL-7F	SRL-7F	INDICATOR, PRESSURE - HYDRAULIC	AMETEK
SRL-C2K		INDICATOR, PRESSURE - TORQUE	AMETEK
SRL-O4L		INDICATOR, OIL PRESSURE	AMETEK
SRL-O4L		INDICATOR, OIL PRESSURE	AMETEK
SRL-OC4N		INDICATOR, OIL	AMETEK
SRSW-94()		INDICATOR, PRESSURE	AMETEK
SRSW-94A		INDICATOR, OIL PRESSURE	AMETEK
SRT-314A		INDICATOR, SENSITIVE TORQUEMETER	AMETEK
SRZ-850	SRZ-850	SYSTEM, INTEGRATED RADIO	HONEYWELL
ST SERIES		BOURDON TUBE ACTUATED, SYNCHRO	AMETEK
ST-103K		TRANSMITTER, PRESSURE - FUEL	AMETEK
ST-104A		TRANSMITTER, PRESSURE	AMETEK
ST-104A		TRANSMITTER, PRESSURE (0-500 PSI)	AMETEK
ST-104A		TRANSMITTER, PRESSURE (0-500 PSI)	AMETEK
ST-104D		TRANSMITTER, PRESSURE	AMETEK
ST-104E		TRANSMITTER, PRESSURE	AMETEK
ST-104P		TRANSMITTER, OIL PRESSURE	AMETEK
ST-104Z		TRANSMITTER, PRESSURE - OIL	AMETEK
ST-106()		TRANSMITTER, PRESSURE	AMETEK

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
ST-107R		TRANSMITTER, PRESSURE - HYDRAULIC	AMETEK
ST-12S		TRANSMITTER, POSITION	AMETEK
ST-12S-1		TRANSMITTER, POSITION	AMETEK
ST-3A	MS28005-4	TRANSMITTER, PRESSURE (0-1000 PSI)	AMETEK
ST-3A	MS28005-4	TRANSMITTER, PRESSURE (0-1000 PSI)	AMETEK
ST-3D		TRANSMITTER, PRESSURE (0-100 PSI)	AMETEK
ST-3E		TRANSMITTER, PRESSURE (0-350 PSI)	AMETEK
ST-3E,4D,9A		TRANSMITTER, PRESSURE	AMETEK
ST-3G		TRANSMITTER, PRESSURE	AMETEK
ST-3H		TRANSMITTER, FUEL PRESSURE	AMETEK
ST-4B	MS28005-2	TRANSMITTER, PRESSURE (0-100 PSI)	AMETEK
ST-4C	F-3	TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
ST-4D	F-3A	TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
ST-4E	MS28005-3	TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
ST-4H	MS28005-3	TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
ST-4J	MS28005-2	TRANSMITTER, PRESSURE (0-100 PSI)	AMETEK
ST-502H		TRANSMITTER, TORQUE PRESSURE	AMETEK
ST-502K		TRANSMITTER, TORQUE PRESSURE	AMETEK
ST-504P		TRANSMITTER, PRESSURE - OIL	AMETEK
ST-504P		TRANSMITTER, OIL PRESSURE	AMETEK
ST-53A/54A		TRANSMITTER, PRESSURE	AMETEK
ST-57A		TRANSMITTER, MULTI-PURPOSE	AMETEK
ST-5A	MS28005-6	TRANSMITTER, MANIFOLD PRESSURE	AMETEK
ST-5E		TRANSMITTER, MANIFOLD PRESSURE	AMETEK
ST60-1	ST60-1	AUTOPILOT	S-TEC
ST60-2	ST60-2	AUTOPILOT	S-TEC
ST-62A	MIL-T-7748, TYPE I	TRANSMITTER, PRESSURE (0-250 PSI)	AMETEK
ST-6S		TRANSMITTER, PRESSURE	AMETEK
ST-7D		TRANSMITTER, HYDRAULIC PRESSURE	AMETEK
ST-7R		TRANSMITTER, HYDRAULIC PRESSURE	AMETEK
ST-9A		TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
ST-9A		TRANSMITTER, PRESSURE (0-200 PSI)	AMETEK
SXXX-X000-()	F1000	RECORDER, SOLID STATE FLIGHT DATA	L3 COMMUNICATIONS
T3837-02	T4040-2	GYROSCOPE, RATE SWITCHING	KELLY
T5-2000		TENSIOMETER, CABLE	PACIFIC SCIENTIFIC
T55529-41-121	895518-20-020	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
T5-8000		TENSIOMETER, CABLE	PACIFIC SCIENTIFIC
T60-1001-C8-1A	C8	TENSIOMETER, CABLE	PACIFIC SCIENTIFIC
T60-1001-C9-1A	C9	TENSIOMETER, CABLE	PACIFIC SCIENTIFIC
TARSYN(X)	TARSYN(X)	FIXTURES, SPECIAL TOOLS AND	HONEYWELL
TC-100	TC-100	INDICATOR, TURN COORDINATOR	JET/AIM
TC-100/TS-200	TC-100/TS-200	INVERTER	JET/AIM
TC-120	TC-120	INDICATOR, TURN COORDINATOR	JET/AIM
TF-20-()	TF-20-()	TEST SET, LIQUID QUANTITY SYSTEM -	CONSOLIDATED AIRBORNE
TFF 1573__	TFF 1573	TRANSMITTER, FUEL MANAGEMENT	CONSOLIDATED AIRBORNE
TFM-138A	TFM-138A	TRANSCEIVER, VHF/FM AIRBORNE	TECHNISONIC IND. LTD.
TFM-138B	TFM-138B	TRANSCEIVER, VHF/FM AIRBORNE	TECHNISONIC IND. LTD.
TFM-138C SERIES	TFM-138C SERIES	TRANSCEIVER, VHF / FM	TECHNISONIC IND. LTD.
TFM-403	TFM-403	TRANSCEIVER, UHF / FM	TECHNISONIC IND. LTD.
TID66A	TID66A	DISPLAY, TRAFFIC INDICATOR	HONEYWELL
TNL1000	TNL1000	RECEIVER, GPS	TRIMBLE
TNL2000	TNL2000	RECEIVER, GPS/LORAN RECEIVERS	TRIMBLE
TNL2000A	TNL2000A	RECEIVER, GPS/LORAN RECEIVERS	TRIMBLE
TNL2000T	TNL2000T	RECEIVER, GPS/LORAN RECEIVERS	TRIMBLE
TNL3000	TNL3000	RECEIVER, GPS/LORAN RECEIVERS	TRIMBLE
TNL3000T	TNL3000T	RECEIVER, GPS/LORAN RECEIVERS	TRIMBLE
TPR-2060	TPR-2060	SYSTEM, ATC TRANSPONDER	BENDIX
TPR-600	TPR-600	SYSTEM, ATC TRANSPONDER	BENDIX
TPR-610	TPR-610	SYSTEM, ATC TRANSPONDER	BENDIX
TPR-660	TPR-660	SYSTEM, ATC TRANSPONDER	BENDIX

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
TRA-61A/C	TRA-61A/C	SYSTEM, ATC TRANSPONDER	BENDIX
TRA-63	TRA-63	SSYSTEM, ATC TRANSPONDER	BENDIX
TRP-640	TRP-640	SYSTEM, ATC TRANSPONDER	BENDIX
TS-200-2()	TS-200-2()	INDICATOR, TURN & SLIP	JET/AIM
TS-200-3()	TS-200-3()	INDICATOR, TURN & SLIP	JET/AIM
TS-200-4()	TS-200-4()	INDICATOR, TURN & SLIP	JET/AIM
TS350B	TS350B	ANALYSER, AIRFRAME - TOT	NAT
TS350B	TS350B	ANALYZER, AIRFRAME	NAT
TS400 SERIES	TS400 SERIES	SERVICE BULLETIN	JET/AIM
TT-1000	TT-1000	TEST SET, DIGITAL TURBINE TEMPERATURE	BARFIELD
TYPE 4	TYPE 4	SYSTEM, ALTITUDE REPORTING	SMITHS
TYPE 802	TYPE 802	CONTROLS, MECHANICAL	GABLES
TYPE 999-3	TYPE 999-3	PANEL, FAILURE WARNING	ECE
TYPE Y	TYPE Y	SELECTOR, COMM FREQUENCY	GABLES
U-1102B/D	U-1102B/D	RECEIVER, AM / FM / FSK	COLLINS
U55529-41-121	895518-20-026	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
UNS-1	UNS-1	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1/1JR	UNS-1JR	SYSTEM, NAVIGATION MANAGEMENT	UNIVERSAL AVIONICS
UNS-1A	UNS-1A	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1A	UNS-1A	SYSTEM, MULTI-MISSION MANAGEMENT	UNIVERSAL AVIONICS
UNS-1A	UNS-1A	SYSTEM, COMPACT FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1B	UNS-1B	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1C+	UNS-1C+	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1CSP	UNS-1CSP	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1E	UNS-1E	SYSTEM, SUPER FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1K	UNS-1K	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1K+	UNS-1K+	SYSTEM, FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1L	UNS-1L	SYSTEM, SUPER FLIGHT MANAGEMENT	UNIVERSAL AVIONICS
UNS-1M	UNS-1M	SYSTEM, NAVIGATION MANAGEMENT	UNIVERSAL AVIONICS
UNS-1M	UNS-1M	SYSTEM, NAVIGATION MANAGEMENT	UNIVERSAL AVIONICS
V55529-41-121	895518-20-024	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
VA-100	VA-100	SYSTEM, VOICE ADVISORY	HONEYWELL
VARIES	VARIES	NICKEL-CADMIUM AIRCRAFT BATTERIES	SAFT
VC SERIES	VC SERIES	COMM / NAV SWITCHES	GABLES
VG-865A	VG-865A	GYRO, VERTICAL DISPLACEMENT - REMOTE	BENDIX
VHF-250X	VHF-250X	TRANSCIEVER, COMMUNICATIONS	COLLINS
VIL-0C7B		INDICATOR, HYDRAULIC PRESSURE	AMETEK
VIL-OC3B		INDICATOR, FUEL PRESSURE	AMETEK
VIL-OC4A		INDICATOR, OIL PRESSURE	AMETEK
VIL-OC7D		INDICATOR, HYDRAULIC PRESSURE	AMETEK
VIR-30A	VIR-30A	RECEIVER, NAVIGATION	HONEYWELL
VR204	VR204	REGULATOR, VOLTAGE	SMITHS
VR206	VR206	REGULATOR, VOLTAGE	SMITHS
VSDL-OC208()		INDICATOR, FUEL FLOW	AMETEK
VSDL-OC410()		INDICATOR, DIGITAL FAN SPEED	AMETEK
VSDL-OC419()		INDICATOR, INTERTURBINE TEMPERATURE	AMETEK
VSTL-OC403B		INDICATOR, FUEL QUANTITY	AMETEK
VT-0107B		TRANSMITTER, HYDRAULIC PRESSURE	AMETEK
VT-0107H		TRANSMITTER, HYDRAULIC PRESSURE	AMETEK
VT-0306D		TRANSMITTER, MULTI-PURPOSE FUEL/OIL	AMETEK
VT3F29057-1		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-11		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-15		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-21		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-25		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-31		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-35		AIR SPEED INDICATORS	UNITED/VARIOUS
VT3F29057-5		AIR SPEED INDICATORS	UNITED/VARIOUS
W55529-41-121	895518-20-025	INDICATOR, ALTITUDE ALERTING	KOLLSMAN
WL/0201KID/()		INDICATOR, FUEL QUANTITY	SMITHS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
WL/0801 KID/2		INDICATOR, FUEL QUANTITY	SMITHS
WL/105AMA/JA()		INDICATOR, MACH AIRSPEED	SMITHS
WL/106RNA/EA/1		INDICATOR, RADIO MAGNETIC	SMITHS
WL/1101AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1103AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1103AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1103AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1103AM/MS/10		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1105AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1105AM/MS/2		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1106AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1107AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1107AM/MS/4		ALTIMETER, SERVO	SMITHS
WL/1108AM/MS/1		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1109AM/MS/3		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1110AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1112 AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/113AMA/JA/()		INDICATOR, MACH AIRSPEED	SMITHS
WL/113AMA/JA/1		INDICATOR, MACH AIRSPEED	SMITHS
WL/113AMA/JA/2		INDICATOR, MACH AIRSPEED	SMITHS
WL/113AMA/JA/4		INDICATOR, MACH AIRSPEED	SMITHS
WL/113AMA/JA/5		INDICATOR, MACH AIRSPEED	SMITHS
WL/1150AM/MS/()		INDICATOR, SERVO ALTIMETER	SMITHS
WL/1150AM/MS/5		INDICATOR, SERVO ALTIMETER	SMITHS
WL/116RNA()/A/()		INDICATOR, RADIO MAGNETIC	SMITHS
WL/118AMA/JA/()		INDICATOR, MACH AIRSPEED	SMITHS
WL/118AMA/JA/1		INDICATOR, MACH AIRSPEED	SMITHS
WL/118AMA/JA/4		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/()		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/1		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/3		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/4		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/5		INDICATOR, MACH AIRSPEED	SMITHS
WL/120AMA/JA/6		INDICATOR, MACH AIRSPEED	SMITHS
WL/126RNA/EA/1		INDICATOR, RADIO MAGNETIC	SMITHS
WL/1350AM/MS/()	1350AM	INDICATOR, COUNTER POINTER ALTIMETER	SMITHS
WL/136RNA/EA/()		INDICATOR, RADIO MAGNETIC	SMITHS
WL/1381AM-MS/()	1350AM	INDICATOR, COUNTER POINTER ALTIMETER	SMITHS
WL/1401AM/MS/()	1400AM	INDICATOR, SERVO ALTIMETER	SMITHS
WL/1403AM/MS/()	1400AM	INDICATOR, SERVO ALTIMETER	SMITHS
WL/1404AM/MS/()	1400AM	INDICATOR, SERVO ALTIMETER	SMITHS
WL/1407AM/MS/()	1400AM	INDICATOR, SERVO ALTIMETER	SMITHS
WL/301RC/JA/1		INDICATOR, VERTICAL SPEED	SMITHS
WL/301RC/MS/()		INDICATOR, VERTICAL SPEED	SMITHS
WL/504CUF/EA/()		UNIT, ALTITUDE ALERTING	SMITHS
WL/506CUF/MS/()		UNIT, ALTITUDE ALERTING	SMITHS
WL/508CUF/EA/()		UNIT, ALTITUDE ALERTING	SMITHS
WL/509CUF/EA/1		UNIT, ALTITUDE ALERTING	SMITHS
WL/510CUF/EA/()		UNIT, ALTITUDE ALERTING	SMITHS
WL/511CUF/EA/3		UNIT, ALTITUDE ALERTING	SMITHS
WL/512CUF/EA/1		UNIT, ALTITUDE ALERTING	SMITHS
WL/801AM/CP/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/801AM/MS/3,6	800AM	INDICATOR, ALTIMETER	SMITHS
WL/802AM/CP/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/804AM/CP/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/806AM/CP/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/807AM/CP/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/808AM/EA/1,2	800AM	INDICATOR, ALTIMETER	SMITHS
WL/809AM/MS/2	800AM	INDICATOR, ALTIMETER	SMITHS
WL/810AM/MS/1	800AM	INDICATOR, ALTIMETER	SMITHS

PART NUMBER	MODEL	DESCRIPTION	MANUFACTURER
WL/820AM/MS/1,2,3,4	800AM	INDICATOR, ALTIMETER	SMITHS
WL/820AM/MS/5,6,7,8	800AM	INDICATOR, ALTIMETER	SMITHS
WL/841AM/MS/1,2,3,4	800AM	INDICATOR, ALTIMETER	SMITHS
WL/842AM/MS/1,2	800AM	INDICATOR, ALTIMETER	SMITHS
WL/852AM/MS/1,2	800AM	INDICATOR, ALTIMETER	SMITHS
WL/855AM/MS/1,2	800AM	INDICATOR, ALTIMETER	SMITHS
WL/856AM/MS/1	800AM	INDICATOR, ALTIMETER	SMITHS
WL/862AM/MS/1,2,3,4	800AM	INDICATOR, ALTIMETER	SMITHS
WL/862AM/MS/5,7	800AM	INDICATOR, ALTIMETER	SMITHS
WL1001KCA1		INDICATOR, COMPASS - STANDBY	SMITHS
WL102AMS()		INDICATOR, ALTIMETER/AIRSPEED	SMITHS
WL106 AMA ()		INDICATOR, MACH AIRSPEED	SMITHS
WL106 AMA 20		INDICATOR, MACH AIRSPEED	SMITHS
WL106 AMA 7		INDICATOR, MACH AIRSPEED	SMITHS
WL107 AMA ()		INDICATOR, MACH AIRSPEED	SMITHS
WL1107AM-MS5		ALTIMETER, SERVO	SMITHS
WL1605()	1605 SERIES	INDICATOR, ALTIMETER - 2" STANDBY	SMITHS
WL1704AM()		ALTIMETERS, COUNTER/POINTER	SMITHS
WL1802AM		INDICATOR, ALTIMETER	SMITHS
WL506AMAJA10	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL506AMAJA11	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL506AMAJA4	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL506AMAJA5	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL506AMAJA6	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL506AMAJA9	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL508AMA1	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL508AMA2	506AMA	INDICATOR, MACH AIRSPEED	SMITHS
WL604AMA()		INDICATOR, MACH AIRSPEED	SMITHS
WL606 AMA-2		DISPLAY, SPEED COMPUTING	SMITHS
WL651RSA()		INDICATOR, N2% RPM	SMITHS
WL656RSA()		INDICATOR, N2% RPM	SMITHS
WL702 RSA 1		INDICATOR, N1% RPM	SMITHS
WL706 RSA ()		INDICATOR, TURBINE GAS TEMPERATURE	SMITHS
WL719 RSA 1		INDICATOR, N1% RPM	SMITHS
WXR-150	WXR-150	SYSTEM, WEATHER RADAR	COLLINS
WXR-80	WXR-80	SYSTEM, WEATHER RADAR	COLLINS
YG-552A-()	YG-552A-()	INDICATOR, FUEL QUANTITY	HONEYWELL